



This intelligent weighing controller accepts input directly from a 4-wire or a 6-wire strain gauge.

The PRO-WEI100 has a number of advanced functions designed specifically for the weighing industry, and is simple to set up and operate. It also features output and input isolation, eliminating the need for any special consideration when interfacing to analog/serial inputs, or PCs/PLCs/HMIs.

### Order Codes

<b>PRO-WEI100</b>	Strain gauge input
-HV	85–265V AC / 95–370V DC
-LV	15–48V AC / 10–72V DC

#### Options

-R2	2 x relay outputs
-R4	4 x relay outputs
-A	1 x mA/V analog output
-S2R	1 x RS232 (RJ11 terminal)
-S4S	1 x RS485 (screw terminal)

### Contents

<b>1</b>	<b>Specifications</b> .....	<b>2</b>
<b>2</b>	<b>Features</b> .....	<b>3</b>
<b>3</b>	<b>Front Panel &amp; Display</b> .....	<b>6</b>
<b>4</b>	<b>Wiring</b> .....	<b>8</b>
<b>5</b>	<b>Dimensions &amp; Installation</b> .....	<b>11</b>
<b>6</b>	<b>Input Setup &amp; Calibration</b> .....	<b>13</b>
<b>7</b>	<b>Setpoint Setup</b> .....	<b>24</b>
<b>8</b>	<b>Setpoint Direct Access</b> .....	<b>27</b>
<b>9</b>	<b>Reset PIN Numbers</b> .....	<b>27</b>
<b>10</b>	<b>Factory Analog Output Calibration</b> .....	<b>28</b>
<b>A</b>	<b>Appendix A - Input Functions</b> ...	<b>29</b>
<b>B</b>	<b>Appendix B - Serial Modes</b> .....	<b>31</b>

## 1

## SPECIFICATIONS

## Input

**Input** 4/6-wire strain gauge, 1–5mV/V

**Power** HV= 85–265V AC / 95–370V DC,  
or LV= 15–48V AC / 10–72V DC

**Max power** 5W, fully optioned,  
8 loadcells

**Excitation** 5V DC excitation supplied  
(powers up to 8 x 350Ω loadcells)

**Sampling rate** Up to 60Hz

**Resolution** 18 bit

**Accuracy** 0.005% of reading

**Temperature drift** Typically 3ppm/°C

## Relay Output

OPTIONAL

**Number of relay outputs** None, 2, or 4

**Relay output type** 5A form A (3A 240V  
AC max or 3A 30V DC max)

## Analog Output

OPTIONAL

**Number of analog outputs** None or 1

**Analog output type** Isolated 16 bit  
4–20mA/0–10V

## Comm Port

OPTIONAL

**Number of comm ports** None or 1

## Comm port options

S2R= Isolated RS232, RJ terminal, or  
S4S= Isolated RS485, screw terminal

**Serial output** Custom ASCII, Modbus  
RTU slave, Gedge, Ranger A, or Print

## Programming

**Front panel buttons** Up, Down, Prog,  
plus 2 Function Buttons for menu access

**Factory calibrated** for 0–10,000 counts  
(2mV/V sensor gain at full scale). 2 cal  
sets for saving/restoring calibrations

**Security** Input and setpoint setups are  
independently PIN protected

## Display

**Display type** LED display, 5 buttons

**LED indicators** 6 setpoint indicator LED's

**Digits** 1 row of 6 digits, 13mm (0.5"),  
14 segment alphanumeric LED

## Construction

**IP65** dust/splash proof (face only)

## Dimensions (H x W x D)

96 x 48 x 120mm (3.78 x 1.89 x 4.72")

**Panel cutout** 92 x 45mm (3.62 x 1.77")

## 2

## FEATURES

## 2.1 - Batching

To access batching features, the controller's **Mode** must be set to **Batch** (see 6.2F). It is then possible to perform the following functions from the **P** button or rear input pins:

<b>Batch</b>	This function is used to display the live weight of the system but take regular 'batches' of product without continually changing the setpoint. When the <i>Batch</i> function is activated the display will tare and SP 1 and SP 2 will turn on.
<b>Batch Reset</b>	Resets the batch value to zero and halts any current batching operations.
<b>Batch Pause</b>	Pauses the batching process and holds the current batched weight on the display.
<b>Batch Resume</b>	Resumes the batching process after it has been paused, or if power was lost during a previous batch.

See 6.2H–K and Appendix A for instructions on setting up and operating these features.

### 2.1A - Gain in Weight (GIW) Batching Direction

The **Batching Direction** parameter is set in 6.2G, and should be set to **GIW** (Gain in Weight) for applications where the weight increases as product is added to the weighing system.

*E.g. Setting a setpoint value of 50Kg for SP 1 and 45Kg for SP 2 and enabling **GIW** batching will allow the user to fill a container to 50Kg, with a potential speed change at 45Kg. (See 2.1C for an alternative method of setting up SP 2.)*

*The cycle is initiated when the **Batch** function is triggered. The display will tare, and when 45Kg net weight is shown, SP 2 will drop out. As product continues to feed, at 50Kg SP 1 will drop out, halting the fill.*

*If **Flash Gross** is enabled (see 6.2L) the gross weight will be displayed (E.g. Now 1050Kg, if the starting gross weight was 1000Kg). The user can then trigger the **Batch** function again to call another 50Kg batch.*

### 2.1B - Loss in Weight (LIW) Batching Direction

The **Batching Direction** parameter is set in 6.2G, and should be set to **LIW** (Loss in Weight) for applications where the weight decreases as product is removed from the weighing system.

*E.g. Setting a setpoint value of 50Kg for SP 1 and 45Kg for SP 2 and enabling **LIW** batching will allow the user to fill a container to 50Kg, with a potential speed change at 45Kg. (See 2.1C for an alternative method of setting up SP 2.)*

*The cycle is initiated when the **Batch** function is triggered. The display will tare, and when 45Kg net weight is discharged, SP 2 will drop out. As product continues to be discharged, at 50Kg SP 1 will drop out, halting the product flow.*

*If **Flash Gross** is enabled (see 6.2L) the gross weight will be displayed (E.g. Now 950Kg, if the starting gross weight was 1000Kg). The user can then trigger the **Batch** function again to call another 50Kg batch.*

*In this mode if there is not enough product to drop a batch, then the instrument will advise the operator by showing the message **Low Product**. If gross > SP 1, the **Batch Value** is reset to zero and the display flashes **Batch**. SP 1 is turned on (and SP 2 if set up). If gross < SP 1, batching is not started.*

## 2.1C - Setpoint Tracking

In applications where the batch weight is continuously being changed, it is possible to configure SP 2 so that it tracks SP 1, and always turns off at a fixed amount below the required batch weight.

*E.g. If your initial batch weight was 100Kgs and you wanted SP 2 to turn off 5Kgs before it reached the batch weight, you would set up the SP 1 value for 100Kgs and the SP 2 value for -5Kgs, and set the **Trail SP 1** option to on (see 6.2D).*

*This would cause SP 2 to turn off at 95Kgs (i.e. 100Kgs - 5Kgs). Then if you wanted the next batch weight to be 200Kgs, you only need to change SP 1 to 200Kgs, and without altering SP 2 it will now turn off at 195Kgs (200Kgs - 5Kgs).*

---


## 2.2 - Input signal averaging

This controller has input signal averaging (see 6.5), to reduce noise and optimise stable measurement. If your input signal contains large noise spikes, you can increase the size of the **Averaging Window** to ensure that these are still averaged. If the change in input exceeds the **Averaging Window** value it will not average, ensuring fast response when there are large differences between readings.

*Note that increasing the window size too far will reduce the ability of the controller to respond quickly to real changes in input signal.*

---

## 2.3 - Tare

To access tare features, the controller's **Mode** must be set to **Normal** (see 6.2F). It is then possible to **Tare/Reset Tare** from the  button or rear input pins:

<b>Tare</b>	This feature 'zeroes' the display, and is usually used to deduct the weight of the container from the total weight, leaving only the weight of the product.
<b>Tare Reset</b>	This feature clears the current tare value and shows the gross weight on the display.

See 6.2H–K and Appendix A for instructions on setting up and operating these features.

## 2.4 - Zero maintenance

The **Zero Maintenance** feature is used to automatically compensate for slow drift in loadcell output due to factors such as temperature change, rain and dust accumulation over time.

When **Auto Zero** is enabled (see 6.4B), the controller display will zero automatically if changes to the loadcell are within the user specified **Capture Band**, **Motion Band** and **Zero Band** parameters (see 6.4C–E):

<b>Capture Band (6.4C)</b>	<p>This is the maximum number of display counts that the controller will automatically zero within. The <b>Capture Band</b> is referenced to the current zero value. If the input value on the load cell is not within the <b>Capture Band</b> setting then the controller displays the current loadcell value and does not zero.</p> <p><i>Capture Band can be set from 1 to 254 counts, and should always be set to less than the smallest weight to be measured. Setting the Capture Band to 0 will turn the auto zero feature off.</i></p>
<b>Motion Band (6.4D)</b>	<p>This provides a rate of change limit setting, to determine the number of counts/second allowed within the <b>Capture Band</b>. If the count change is within the <b>Capture Band</b>, but the speed of the count change is more than the selected <b>Motion Band</b>, then the controller displays the current loadcell value and does not zero.</p> <p><i>The Motion Band can be set from 0 to 255 counts. Typical value is 1 or 2 counts/sec.</i></p>
<b>Zero Band (6.4E)</b>	<p>This provides a limit for the number of counts of zero offset allowed to accumulate, relative to the calibrated zero setting. If the accumulated zero offset becomes greater than this window, then the controller displays the current loadcell value and does not zero.</p> <p><i>The suggested limit for the Zero Band is 2% of the calibrated span. If the controller fails to zero, check for mechanical or electrical faults.</i></p>


## 3

## FRONT PANEL &amp; DISPLAY

## 3.1 - Front panel

**SPX** The SP LED's are used to indicate active setpoints.

**NET** The net LED indicates when the net value is being displayed, and is also used for the *Flash Gross* function (see 6.2L).



**F1** This button is used to access the **Input Setup & Calibration** menu (Section 6) and the **Factory Analog Output Calibration** menu (Section 10).

**P** This button is used to save your settings and advance to the next step in the setup process. A custom function can also be programmed (see 6.2H).

**↑** This button is typically used to scroll through options or increase values in the setup menu. Pressing this button from the main display will allow you to view/reset the *Peak* value, and view the raw input value (see 3.3).






**↓** This button is typically used to scroll through options or decrease values in the setup menu. Pressing this button from the main display will allow you to view/reset the *Valley* value (see 3.3).



**F2** This button is used to access the **Setpoint Setup** menu (Section 7) and the **Setpoint Direct Access** menu (Section 8).

## 3.2 - Display brightness



To adjust the display brightness, press the **P** and **↑** buttons together from the main display. **BRI** appears and toggles with the current setting. Use the **↑** and **↓** buttons to adjust the LED backlight, and then press **P** to finish.

### 3.3 - Up and down button shortcuts

Pressing the  and  buttons from the main operational display allows instant access to a number of values held in the controller's memory. These variables will appear in the order shown in the table below, and will cycle continuously at each press of the  or  button. Press  at any time to return to normal operating mode.

**PEAK** and **VALLEY** may be reset to zero by pressing the  and  buttons **at the same time** while the variable is being displayed.

#### Up and down button shortcuts


	<b>PEAK</b>	The maximum measured weight since the instrument was turned on or reset
	<b>RAW IP</b>	The current raw value of the input signal in mV
	<b>VALLEY</b>	The minimum measured weight since the instrument was turned on or reset

## 4

## WIRING

BEFORE YOU BEGIN WIRING, ensure that the unit is switched off and the power supply is disconnected.

## 4.1 - Pinouts




## Key

- 4.1A Relay Output (See 4.3)
- 4.1B Serial Port (See 4.5)
- 4.1C Analog Output (See 4.4)
- 4.1D Analog Input (See 4.2)
- 4.1E Function Pins (See 4.6)
- 4.1F Power Supply HV/LV (See 4.7)

## 4.2 - Wire the strain gauge input module

Wire your loadcell input module as shown in the diagram. This input module is pre-calibrated for 0–10,000 counts full scale with a 2.000mV/V load cell sensor.

See 4.1D






### 4.3 - Wire the relay outputs (if installed)

If your controller has relay outputs fitted, wire them as shown below. Relays can be programmed to operate within the total span range of the controller.


See 4.1A



### 4.4 - Wire the analog output (if installed)

If your controller has analog output fitted, wire it as shown for either voltage (0–10V) or current (4–20mA).


See 4.1C



### 4.5 - Wire the serial port (if installed)

If your controller has serial port fitted, wire it as shown in the applicable diagram. (S2R: RS232, RJ11 terminal, S4S: RS485, screw terminal).

See 4.1B




## 4.6 - Wire the function pins

Connect external switches to enable a function to be executed when its switch is activated.

Pin functions are user configurable, and can be set up in 6.2I–K.

See 4.1E and Appendix A




## 4.7 - Wire the power supply

DO NOT attempt to wire your controller while the power is on. NEVER connect your low voltage controller to mains power.

Wire your controller for low or high voltage power supply, as show in the diagrams below. Check the label on the unit against the colour of the connector:

- › **Orange =**  
High voltage (85–265V AC,  
95–370V DC)
- › **Black =**  
Low voltage (15–48V AC,  
10–72V DC)

See 4.1F





Once you have completed the wiring process it is safe to switch on your power supply. Ensure that your display is functioning before you proceed.

## 5


## DIMENSIONS &amp; INSTALLATION

## 5.1 - Case dimensions




## 5.2 - Installation instructions

- A** Prepare the **Panel Cutout** to  $92 \times 45\text{mm} \pm 0.5$  ( $3.62 \times 1.77'' \pm 0.02$ ), as shown below. **Allow at least 155mm (6.10'')** depth behind the panel to accommodate the meter body and protruding cabling.
- B** Remove the **Mounting Clips** from the meter back.
- C** Slide the **Panel Gasket** over the rear of the unit to the back of the **Meter Faceplate**.
- D** From the front of the panel, insert the meter into the **Panel Cutout**. Holding the unit in place, engage the **Mounting Clips** so that the tabs snap into place over the notches on the case.
- E** To achieve a proper seal, tighten the **Screws** evenly until the unit sits firmly against the panel. Do not over-tighten the screws.



Panel Cutout



## 6

## INPUT SETUP &amp; CALIBRATION

## 6.1 - Enter F1 PIN number

A Enter the calibration mode by pressing the **F1** button.

**\_\_\_ ENTER F1 PIN** scrolls across the display and toggles with **0**. Use the **↑** and **↓** buttons to enter your security code (factory default 1). Then press **P**. If the correct PIN is entered, setup is started at 6.2.

If an incorrect PIN number is entered, **\_\_\_ ACCESS DENIED** scrolls across the display and it returns to normal operating mode.

You will have the opportunity to change your PIN number at the end of this section (6.9). If you have forgotten your PIN number, see Section 9.

## 6.2 - Input setup

A **\_\_\_ INPUT SETUP** scrolls across the display and toggles with **SKIP**. Press **P** to skip to 6.3, or the **↑** button and then **P** to **ENTER** input setup.




B **\_\_\_ SUPPLY REJECTION FREQUENCY** scrolls across the display. Use the **↑** and **↓** buttons to select **50HZ** or **60HZ**, and then press **P**.

C **\_\_\_ SAMPLING RATE** scrolls across the display and toggles with the current selection. Use the **↑** and **↓** buttons to select an option from the following list: **1HZ**, **2HZ**, **5HZ**, **10HZ**, or **50HZ/60HZ** (50 or 60Hz will depend on your selection in 6.2B above). Then press **P**.

D **\_\_\_ DECIMAL POINT POSITION** scrolls across the display and toggles with the current selection. Use the **↑** and **↓** buttons to select **NO DP** (default), **0.0**, **0.00**, **0.000** or **0.0000**, and then press **P** to accept and continue.

E **\_\_\_ ROUNDING** scrolls across the display and toggles with the current display rounding. Using the **↑** and **↓** buttons, select: **NONE** (default), **2**, **5**, **10**, **20**, **50**, **100**, **200**, **500**, or **1000**. Then press **P**.




*Rounding is quoted in display counts and is not influenced by decimal point position. For example, if your input signal is 5.3, the display will show: 5.3 (for rounding=NONE), 5.4 (for rounding=2), 5.5 (for rounding=5), 5.0 (for rounding=10), etc.*

**F** **\_\_\_ MODE** scrolls across the display and toggles with the current weighing mode. Use the  and  buttons to select **NORMAL** (default) or **BATCH**, and then press .

➔ If you selected **NORMAL**, skip to 6.2H now.

➔ If you selected **BATCH**, continue to 6.2G now.

*In **NORMAL** (default) mode the controller displays the gross or net weight on the display, and does not perform any batch calculations. In **BATCH** mode the controller displays batch or gross weight, and SP 1 and SP 2 function as dedicated batch control setpoints (see 2.1).*





**G** **\_\_\_ BATCHING DIRECTION** scrolls across the display and toggles with current selection. Use the  and  buttons to select either: **LIW** (loss in weight, for emptying operations) or **GIW** (gain in weight, for filling operations). Press .




*See Section 2.1 for additional information.*




---




For 6.2H–K, please refer to the list of input functions in Appendix A.




---

**H** **\_\_\_ PROG BUTTON** scrolls across the display and toggles with the current selection. Referring to the table in Appendix A, use the  and  buttons to select a function to be performed when the  button is pressed: **HOLD**, **TARE<sup>1</sup>**, **BATCH<sup>2</sup>**, **ZERO**, **PEAK**, **PK RST** or **PRINT**. Then press .

**I** **\_\_\_ USER INPUT1** scrolls across the display and toggles with the current selection. This controls the function that will be performed when the User 1 input pin at the rear of the meter (see 4.6) is activated. Referring to the table in Appendix A, use the  and  buttons to select: **LOCK**, **TARE<sup>1</sup>**, **BATCH<sup>2</sup>**, **ZERO**, **PEAK**, **PK RST**, **PRINT**, **GROSS**, **START<sup>2</sup>** or **STOP<sup>2</sup>**. Then press .

**J** **\_\_\_ USER INPUT2** scrolls across the display and toggles with the current selection. This controls the function that will be performed when the User 2 input pin at the rear of the meter (see 4.6) is activated. Referring to the table in Appendix A, use the  and  buttons to select: **HOLD**, **TARE<sup>1</sup>**, **BATCH<sup>2</sup>**, **ZERO**, **PEAK**, **PK RST**, **PRINT**, **GROSS**, **START<sup>2</sup>** or **STOP<sup>2</sup>**. Then press .

**K** **\_\_\_ USER INPUT3** scrolls across the display and toggles with the current selection. This controls the function that will be performed when the User 3 input pin at the rear of the meter (see 4.6) is activated. Referring to the table in Appendix A, use the  and  buttons to select: **TARE**<sup>1</sup>, **BATCH**<sup>2</sup>, **ZERO**, **PEAK**, **PK RST**, **PRINT**, **GROSS**, **START**<sup>2</sup> or **STOP**<sup>2</sup>. Then press .

**L** **\_\_\_ FLASH GROSS** scrolls across the display and toggles with the currently selected setting. Using the  and  buttons, select **NO** or **YES**, and press .





*This will cause the display to toggle between the Net/Gross values for 3 seconds each. Toggling will only occur if the controller has been tared and the Net/Gross values are different. The NET LED indicates which value is being displayed (On: Net, Off: Gross). This option will be disabled if a batch is currently in progress.*

<sup>1</sup> **TARE** feature is only available when the Mode is set to **NORMAL** (see 6.2F).

<sup>2</sup> **BATCH**, **START** and **STOP** features are only available when the Mode is set to **BATCH** (see 6.2F).

## 6.3 - Calibration

This unit has been calibrated for 0–10,000 counts (2mV/V sensor gain at full scale).

**A** **\_\_\_ CALIBRATION TECHNIQUE** scrolls across the display and toggles with **SKIP**. Press  to skip to 6.4, or use the  and  buttons to select a calibration method: **AUTO**, **MV/V**, **ZERO**, **E\_CAL**, or **CALSET**, and press  to continue.

- ➔ If you selected **AUTO**, complete steps 6.3B–F now.
- ➔ If you selected **MV/V**, complete steps 6.3G–I now.
- ➔ If you selected **ZERO**, complete step 6.3J now.
- ➔ If you selected **E\_CAL**, complete steps 6.3K–L now.
- ➔ If you selected **CALSET**, complete steps 6.3M–N now.
- ➔ If you selected **SKIP**, skip to 6.4 now.

**AUTO** calibration uses zero and span values to calculate the scale and offset. This is the most accurate calibration method, but requires known low and high input signals, usually supplied by test weights. Zero and span calibration procedures are performed separately.

**MV/V** uses values from the load cell manufacturer's test certificate.

**ZERO** allows manual adjustment of the calibrated zero offset.

**E\_CAL** allows the user to view and edit the electronic calibration values (zero offset and scale factor). These two values are updated when any calibration is performed. Noting these values and entering them into another instrument will copy the calibration. You may also 'trim' these




values to alter the current calibration.

**CALSET** allows the user to select and switch between calibration sets, giving them the option of saving and restoring a previous calibration.

---




## Auto calibration




---

**B** **\_\_\_ CAL SET X – CALIBRATE ZERO** scrolls across the display, where **X** is the Cal Set where the current calibration will be stored (see 6.3M). – **CALIBRATE ZERO** toggles with the currently selected option. Use the  and  buttons to select **YES** or **NO**, and then press .

➔ If you selected **YES**, continue to 6.3C now.




➔ If you selected **NO**, skip to 6.3D now.

**C** **\_\_\_ REMOVE WEIGHT – PRESS P TO ACCEPT** scrolls across the display and toggles with the current no-load value. Remove the weight. Use the  and  buttons to adjust the no-load value if required, and then press .

**D** **\_\_\_ CALIBRATE SPAN** scrolls across the display and toggles with the current selection. Use the  and  buttons to select **YES** or **NO**, and then press .

➔ If you selected **YES**, continue to 6.3E now.

➔ If you selected **NO**, skip to 6.3F now.

**E** **\_\_\_ ADD CAL WEIGHT – ENTER DESIRED SPAN – PRESS P TO ACCEPT** scrolls across the display and toggles with the current span value. Apply a calibration weight to the weigh platform. Then use the  and  buttons to adjust the value, and press  to accept.

**F** If Auto calibration was successful, you will be directed out of the calibration menu to the operational display without viewing any further scrolling messages. (To enter step 6.4, you must select **SKIP** at 6.3A.)










If calibration fails, **\_\_\_ CALIBRATION FAILED** will scroll across the display and you will be directed back to the operational display. Check your signal and connections, and then repeat the calibration procedure.



---




 mV/V calibration
 

---

- G** **\_\_\_ ENTER TOTAL FULL SCALE WEIGHT OF LOAD CELLS IN COUNTS** scrolls across the display and toggles with the current selection. Using the  and  buttons, enter the total full scale weight of the connected load cell(s) in counts, referring to the load cell manufacturer's test certificate. Then press .
- H** **\_\_\_ ENTER MV/V FROM LOAD CELL** scrolls across the display and toggles with the current selection. Using the  and  buttons, enter the mV/V (or average mV/V) of the connected load cell(s), and then press .
- I** **\_\_\_ SET ZERO NOW?** scrolls across the display and toggles with the current selection. Use the  and  buttons to select **YES** or **NO**, and then press .
- Selecting YES sets your zero position when the load cells are powered up and in position.*
- mV/V calibration is now complete. You will be directed back to the operational display. (To enter step 6.4, you must select **SKIP** at 6.3A.)
- 







 Zero (offset) calibration
 

---

- J** **\_\_\_ ADJUST OFFSET** scrolls across the display and toggles with the currently selected zero value. Place a known weight on the weigh platform if required, and use the  and  buttons to enter the desired value. Press  to accept.
- The offset will be automatically calculated to match the desired weight, and the scale factor will not be altered. (Normally the weight would be removed and the value would be zero.)*
- Zero calibration is now complete. You will be directed back to the operational display. (To enter step 6.4, you must select **SKIP** at 6.3A.)
- 

 E\_Cal calibration
 

---

- K** **\_\_\_ E\_CAL ZERO OFFSET** scrolls across and toggles with the current selection. Use the  and  buttons to adjust the zero offset value, and then press .
- This is updated after each calibration to show the internal ZERO OFFSET E Cal value.*
- L** **\_\_\_ E\_CAL SCALE FACTOR** scrolls across and toggles with the current selection. Use the  and  buttons to adjust the scale factor value, and press .
-




*This is updated after each calibration to show the internal **SCALE FACTOR E Cal** value.*

E\_Cal calibration is now complete. You will be directed back to the operational display. (To enter step 6.4, you must select **SKIP** at 6.3A.)





---

## Cal set selection

---

**M** \_\_\_ **SELECT CAL SET** scrolls across and toggles with the current selection. Use the  and  buttons to choose either **SET 1** or **SET 2**, and then press .

*This feature allows you to save two sets of calibration values on the controller, and to roll back to a previous calibration, if necessary. The set that you select will be the active calibration set.*




**N** \_\_\_ **CALIBRATION TECHNIQUE** scrolls across the display and toggles with **SKIP**. You are now back at 6.3A. Press  to skip to 6.4, or use the  and  buttons to select a new calibration method, and then press .




---

## 6.4 - Zero maintenance

---

See Section 2.4 for more information on zero maintenance parameters.




**A** \_\_\_ **ZERO MAINTENANCE** scrolls across the display and toggles with **SKIP**. Press  to skip to 6.5, or the  button and then  to **ENTER** zero maintenance.

**B** \_\_\_ **AUTO ZERO** scrolls across the display and toggles with the current auto zero selection. Use the  and  buttons to select **ON** or **OFF**, and press .

➔ If you selected **ON**, continue to 6.4C now.

➔ If you selected **OFF**, skip to 6.4E now.

*If **AUTO ZERO** mode is **ON**, the controller's offset will be automatically adjusted so that the instrument reads zero when it senses that the scale is not loaded (see 2.4).*

**C** \_\_\_ **CAPTURE BAND** scrolls across the display and toggles with the selected capture band. Adjust this value using the  and  buttons, and then press .

*This is referenced to the current zero value, and is the maximum number of display counts that the controller will zero within. **CAPTURE BAND** can be set from **1** to **254** counts, and should always be set to less than the smallest weight to be measured.*

- D** **\_\_\_ MOTION BAND** scrolls across the display and toggles with the selected motion band. Adjust this value using the **↑** and **↓** buttons, and then press **P**.

*This provides a rate of change limit setting, to determine the number of counts/second allowed within the **CAPTURE BAND**. **MOTION BAND** can be set from 0 to 255 counts. Typical value is 1 or 2 counts/sec.*


- E** **\_\_\_ ZERO BAND** scrolls across the display and toggles with the selected zero band. Adjust this value using the **↑** and **↓** buttons, and then press **P**.

*This provides a limit for the number of counts of zero offset allowed to accumulate, relative to the calibrated zero setting. If the accumulated zero offset becomes greater than this window, then the controller displays the current loadcell value and does not zero. The suggested limit for the **ZERO BAND** is 2% of the calibrated span.*

## 6.5 - Averaging

Your controller has input signal averaging, optimising stable measurement.

If the change in input exceeds the averaging window value it will not average, ensuring fast response when there are large differences between readings. (E.g. When product is being dropped into a bag.)



- A** **\_\_\_ AVERAGING PARAMETERS** scrolls across and toggles with **SKIP**. Press **P** to skip to 6.6, or the **↑** button and then **P** to **ENTER** averaging setup.

- B** **\_\_\_ AVE SAMPLES** scrolls across the display and toggles with the currently selected averaging. Using the **↑** and **↓** buttons, alter the number of input samples that the controller will average, and then press **P**.

*Increasing the number of samples will stabilise measurement, but it will also slow down response rates. A typical value is 4.*

- C** **\_\_\_ AVE WINDOW** scrolls across the display and toggles with the currently selected averaging window value. Using the **↑** and **↓** buttons, alter the signal averaging window. Then press **P**.

*If your input signal contains large noise spikes, you can increase the size of the averaging window to ensure that these are still averaged. However, increasing the window size too far will*

reduce the ability of the controller to respond quickly to real changes in input signal. Setting **AVE WINDOW** to **0** will give continuous averaging as per the selected averaging samples. A typical value is 10% of your system capacity.

---

## 6.6 - Analog output setup

*N.B. All new units are calibrated before shipping. Recalibration is **only** necessary if settings are wiped or the unit's accuracy requires verification after a long period of use. e.g. 1 year.*

**A** **\_\_\_ ANALOG OUTPUT SETUP** scrolls across the display and toggles with **SKIP**. If your controller does not have analog output installed, (or you do not wish to configure your analog output now), press **[P]** to skip to 6.7.

Otherwise, press the **[↑]** button and then **[P]** to **ENTER** analog output setup.

**B** **\_\_\_ DATA SOURCE FOR ANALOG O/P** scrolls across the display and toggles with the current analog output data source. Use the **[↑]** and **[↓]** buttons to select an option from: **NET/BATCH**, or **LIVE**, and then press **[P]**.

*Note that where **NET/BATCH** is indicated, the option that will be displayed is controlled by the weighing mode selected in 6.2F. **NORMAL** mode = **NET**, **BATCH** mode = **BATCH**.*

**C** **\_\_\_ LOW SCALE VALUE FOR ANALOG O/P** scrolls across the display and toggles with the currently selected low scale display value. Use the **[↑]** and **[↓]** buttons to enter your cal low position, and then press **[P]**.

**D** **\_\_\_ HIGH SCALE VALUE FOR ANALOG O/P** scrolls across the display and toggles with the currently selected high scale display value. Use the **[↑]** and **[↓]** buttons to enter your cal high position, and then press **[P]**.

---



To calibrate your analog output, see Section 10.




**Factory analog output calibration is precisely set before shipping this instrument, and should not be adjusted unless advised by the manufacturer.**

---

## 6.7 - Serial setup




**A** **\_\_\_ SERIAL SETUP** scrolls across the display and toggles with **SKIP**. If your controller does not have a serial port installed, (or you do not wish to configure your serial options now), please press **[P]** to skip to 6.8.

Otherwise, press the  button and then  to **ENTER** serial setup.

**B** **\_\_\_ SERIAL MODE** scrolls across the display and toggles with the current serial mode. Use the  and  buttons to choose between: **ASCII** (custom), **MODBUS** (RTU), **GEDGE**, **RNGR A** (Ranger A), or **PRINT**. Then press .




- ➔ If you selected **GEDGE**, continue to 6.7C now.
- ➔ If you selected **RNGR A** or **PRINT**, skip to 6.7D now.
- ➔ If you selected **ASCII** or **MODBUS**, skip to 6.7H now.

*See Appendix B for more information about the available serial modes.*

**C** **\_\_\_ OUTPUT FORMAT** scrolls across the display and toggles with the currently selected Gedge output format. Use the  and  buttons to choose between **C1**, **C2**, or **C3**, and then press .

- ➔ Please skip to 6.7G now.




*See Appendix B.3 for more information on Gedge output formats.*

**D** **\_\_\_ DATA SOURCE** scrolls across the display and toggles with the currently selected serial data source. Use the  and  buttons to select an option from: **NET/BATCH**, **LIVE**, or **PEAK**, and then press .

*Note that where **NET/BATCH** is indicated, the option that will be displayed is controlled by the weighing mode selected in 6.2F. **NORMAL** mode = **NET**, **BATCH** mode = **BATCH**.*




**E** The step that you proceed to now will depend on the Serial Mode that you selected in 6.7B:

- ➔ If your Serial Mode = **PRINT**, continue to 6.7F now.
- ➔ If your Serial Mode = **RNGR A**, skip to 6.7G now.




**F** **\_\_\_ PRINT UNITS** scrolls across the display and toggles with the current units that will be printed on the *Weigh Ticket* (see B.5) when the print function is triggered. Use the  and  buttons to choose between **NONE**, **GRAMS**, **KGS**, **TONNES**, **LBS** or **KN**, and then press .




- ➔ Please skip to 6.7H now.

*This option controls the units that are printed on the Weigh Ticket (see B.5). It does not perform any conversion calculations. Please scale the instrument to match the printed units.*

- G** **\_\_\_ OUTPUT MODE** scrolls across the display and toggles with the current output mode. Use the  and  buttons to select either **CONT** (continuous) or **PULSED**, and then press .




*In **CONT** (continuous) mode, the controller outputs a continuous stream of data. In **PULSED** mode, the controller outputs a single string when the print function is triggered from a user input button or pin (see 6.2H–K and Appendix A).*

- H** **\_\_\_ BAUD RATE** scrolls across the display and toggles with the current selection. Use the  and  buttons to select one of: **300**, **600**, **1200**, **2400**, **4800**, **9600**, **19200** or **38400**. Then press .




- I** **\_\_\_ PARITY** scrolls across the display and toggles with the currently selected parity. Using the  and  buttons, select: **NONE**, **ODD** or **EVEN**, and then press .

- J** The step that you proceed to now will depend on the Serial Mode that you selected in 6.7B:

- ➔ If your Serial Mode = **GEDGE**, **RNGR A**, or **PRINT**, continue to 6.7K now.
- ➔ If your Serial Mode = **ASCII** or **MODBUS**, skip to 6.7L now.

- K** **\_\_\_ DATA BITS** scrolls across the display and toggles with the currently selected data bits. Using the  and  buttons, select: **7** or **8**, and then press .

- ➔ The last step only applies to **ASCII** or **MODBUS** mode. Proceed to 6.8 now.

- L** **\_\_\_ SERIAL ADDRESS** scrolls across the display and toggles with the currently selected serial address. Use the  and  buttons to alter the serial address, and then press .

*The serial address parameter is used to identify a particular device when it is used with other devices in a system. (It applies particularly to **MODBUS** mode when used on an RS485 serial network.) The serial address of the controller must be set to match the serial address defined in the master device.*

---

Refer to Appendix B for more information on serial modes and registers.

---

## 6.8 - Clock setup

- A** \_\_\_ **CLOCK SETUP** scrolls across the display and toggles with **SKIP**. Press **P** to skip to 6.9, or the **↑** button and then **P** to **ENTER** and set the date and time.
- B** \_\_\_ **HOURS** scrolls across the display and toggles with the current selection. Use the **↑** and **↓** buttons to adjust the hour (from **0** to **23**), and press **P**.  
*The controller's internal clock uses 24 hour time; you cannot select a.m. or p.m.*
- C** \_\_\_ **MINUTES** scrolls across the display and toggles with the current selection. Use the **↑** and **↓** buttons to adjust the minutes (from **0** to **59**), and press **P**.  
*After pressing **P** the seconds timer will be reset to zero, and will immediately begin counting.*
- D** \_\_\_ **DATE** scrolls across the display and toggles with the current selection. Use the **↑** and **↓** buttons to adjust the date (from **1** to **31**), and press **P**.
- E** \_\_\_ **MONTH** scrolls across the display and toggles with the current selection. Use the **↑** and **↓** buttons to select a month (from **JAN** to **DEC**), and press **P**.
- F** \_\_\_ **YEAR** scrolls across the display and toggles with the current selection. Use the **↑** and **↓** buttons to adjust the display to the current year, and press **P**.

---

## 6.9 - Edit F1 PIN number

- A** \_\_\_ **EDIT F1 PIN** scrolls across the display and toggles with **SKIP**. Press **P** to skip and return to the operational display, or the **↑** button and then **P** to **ENTER** and change your PIN number.
- B** \_\_\_ **ENTER NEW F1 PIN** scrolls across the display and toggles with the current PIN (default 1). Using the **↑** and **↓** buttons, enter your new F1 PIN number. Then press **P** to exit to the operational display.

## 7

## SETPOINT SETUP

The software in your controller will allow you to configure up to 4 setpoints, however full functionality is only supported when relay output hardware installed.

(Setpoints with no corresponding relay output hardware may be used as simple LED indicators, if desired. In this case, features requiring relay output functionality will continue to appear in the setup menu, but will be ignored by the controller.)

## 7.1 - Enter F2 PIN number

- A Enter setpoint setup mode by pressing and holding the **F2** button for 3 seconds. **\_\_ \_ ENTER F2 PIN** scrolls across the display and toggles with **0**. Use the **↑** and **↓** buttons to enter your security code (factory default 1). Then press **P**. If the correct PIN is entered, setup is started at 7.2.

If an incorrect PIN number is entered, **\_\_ \_ ACCESS DENIED** scrolls across the display and it returns to normal operating mode.




You will have the opportunity to change your PIN number at the end of this section (7.3). If you have forgotten your PIN number, see Section 9.

## 7.2 - Setpoint setup

- A **\_\_ \_ EDIT SETPOINT** scrolls across the display and toggles with **SKIP**. Press **P** now to skip to 7.3, or use the **↑** and **↓** buttons to select a setpoint to edit, and then press **P**.
- B **\_\_ \_ SP VALUE** scrolls across the display and toggles with the current value for the selected setpoint. Using the **↑** and **↓** buttons, adjust the display value at which the selected setpoint will activate, and then press **P**.
- C The step that you proceed to now will depend on which setpoint you are editing (selected in 7.2A):






- ➔ If you are currently editing **SP 1**, skip to 7.2E now.
- ➔ If you are currently editing **SP 2–4**, continue to 7.2D now.

**D** **\_\_\_ TRAIL SP1** scrolls across the display and toggles with the tracking setting for the selected setpoint. Using the  and  buttons, select **OFF** or **ON**, and then press .




*A setpoint with **TRAIL SP1** enabled will track the setpoint value of **SP 1**, with the setpoint value of the tracking setpoint becoming an offset value.*

**E** The step that you proceed to now will depend on which setpoint you are editing (selected in 7.2A):




- ➔ If you are currently editing **SP1–2**, then the step that you proceed to now will depend on your controller's weighing mode (selected in 6.2F):
  - ▶ If your controller is in **NORMAL** mode, continue to 7.2F now.
  - ▶ If your controller is in **BATCH** mode, skip to 7.2J now.
- ➔ If you are currently editing **SP 3–4**, continue to 7.2F now.

**F** **\_\_\_ SP SOURCE** scrolls across the display and toggles with the activation source for the selected setpoint. Use the  and  buttons to choose **NET/BATCH** or **LIVE**, and then press .

*Note that where **NET/BATCH** is indicated, the option that will be displayed is controlled by the weighing mode selected in 6.2F. **NORMAL** mode = **NET**, **BATCH** mode = **BATCH**.*




**G** **\_\_\_ SP ACTIVATION** scrolls across the display and toggles with the current activation for the selected setpoint. Using the  and  buttons, select the relay activation to operate **ABOVE** or **BELOW** the setpoint value, and then press .

***ABOVE**: Relay turns on above the setpoint value and off below it. **BELOW**: Relay turns on below the setpoint value and off above it.*


**H** **\_\_\_ HYSTERESIS VALUE** scrolls across the display and toggles with the hysteresis value for the selected setpoint. Use the  and  buttons to adjust this value if required, and then press .

- ➔ If you set the Hysteresis Value to **0**, skip to 7.2J now.
- ➔ If you set the Hysteresis Value to anything else, continue to 7.2I now.


*The **HYSTERESIS VALUE** defines the separation band between setpoint activation and deactivation, and will operate as per the **HYSTERESIS TYPE** setting selected in 7.2I.*




- I **\_\_\_ HYSTERESIS TYPE** scrolls across the display and toggles with the hysteresis type for the selected setpoint. Using the  and  buttons, select either **ALARM** or **CNTRL** (control), and then press .




**ALARM - SETPOINT VALUE** controls setpoint activation point. **HYSTERESIS VALUE** controls setpoint deactivation point.





**CNTRL - SETPOINT VALUE** controls setpoint deactivation point. **HYSTERESIS VALUE** controls setpoint reactivation point.









- J **\_\_\_ MAKE DELAY** scrolls across the display and toggles with the current make delay time for the selected setpoint. This is the time delay between setpoint activation, and when the relay turns on. Adjust this value in 0.1 second increments using the  and  buttons, and then press .

- K **\_\_\_ USER ACCESS?** scrolls across the display and toggles with the direct access permission setting for the selected setpoint. Use the  and  to select either **OFF** or **ON**, and then press .

*When enabled, this option allows the selected setpoint's value to be edited directly after pressing the  button, without needing to enter a PIN number or go through all of the other options. Each setpoint can individually have this option enabled or disabled. See Section 8.*

- L **\_\_\_ EDIT SETPOINT** scrolls across the display and toggles with **SKIP**. You are now back at 7.2A. To edit another setpoint, follow the instructions from 7.2A–L again. If you do not wish to edit another setpoint, press  now to skip to 7.3.

## 7.3 - Edit F2 PIN number

- A **\_\_\_ EDIT F2 PIN** scrolls across the display and toggles with **SKIP**. Press  to skip and return to the operational display, or the  button and then  to **ENTER** and change your PIN number.
- B **\_\_\_ ENTER NEW F2 PIN** scrolls across the display and toggles with the current PIN (default 1). Using the  and  buttons, enter your new F2 PIN number. Then press  to exit to the operational display.

## 8

## SETPOINT DIRECT ACCESS

If none of the setpoints have their direct access option enabled then this feature will be disabled and the **F2** button will not respond to a short button press. (See 7.2K.)

- A Begin by pressing the **F2** button for less than 3 seconds.
- B The name of the first access-enabled setpoint will appear on the display and toggle with the current value for that setpoint. Using the **↑** and **↓** buttons, adjust the selected value. Then press **P** to accept and continue.
- C The name of the next access-enabled setpoint will appear on the display, along with its setpoint value. Repeat step 8B. The direct access menu will proceed through all access-enabled setpoints in this fashion. Pressing **P** for the last enabled setpoint will exit and return to the operational display.

## 9

## RESET PIN NUMBERS / VIEW FIRMWARE VERSION

If you have forgotten your PIN number(s), follow the procedure below to reset both the F1 and F2 PINs to their factory default of 1.

This procedure will also allow you to view the current software installed on your controller, which may be required for support purposes.

- A Press **↑**, **↓** and **P** at the same time. (This key combination can be difficult to execute and you may need several tries to get it right.)
- B A message will appear on the display, with details of the unit's current software configuration (Product Name, Firmware Version, and Macro Version). At the end, you will see **PIN RESET TO 1**.
- C Both the F1 PIN number and the F2 PIN number have now been reset to '1'. You can change this, if required, by following the instructions in 6.9 (for the F1 menu) and 7.3 (for the F2 menu), using '1' to enter each menu initially.

## 10

## FACTORY ANALOG OUTPUT CALIBRATION

**Do not access this feature unless instructed by the manufacturer.**

Factory analog output calibration is precisely set before shipping this instrument. For analog output scaling, see 6.6.

- A** Start with the controller powered off. Power up while holding the **F1** button.
- B** **\_\_\_ ENTER F1 PIN** scrolls across the display and toggles with **0**. Use the **↑** and **↓** buttons to enter your security code (factory default 1). Then press **P**. If the correct PIN is entered, continue to 10C.

If an incorrect PIN number is entered, **\_\_\_ ACCESS DENIED** scrolls across the display and it returns to normal operating mode.

If you have forgotten your PIN number, see Section 9.

- C** **\_\_\_ CALIBRATE ANALOG O/P?** scrolls across and toggles with the current selection. Use the **↑** and **↓** buttons to select **YES** or **NO**, and then press **P**.

➔ If you selected **YES**, connect a mA or volt meter across the analog output connector (see 4.4), and then continue to 10D.

➔ If you selected **NO**, the display will return to normal operating mode.

*N.B. All new units are calibrated before shipping. Recalibration is **only** necessary if settings are wiped or the unit's accuracy requires verification after a long period of use. e.g. 1 year.*

- D** **\_\_\_ CAL LOW ANALOG O/P** scrolls across the display and toggles with a calibration number shown in internal units (around -16000). Press the **↑** or **↓** buttons until the multimeter displays your target low output, then press **P**.
- E** **\_\_\_ CAL HIGH ANALOG OUTPUT** scrolls across the display and toggles with a calibration number shown in internal units (around 30000). Press the **↑** and **↓** buttons until the multimeter displays your target high output, then press **P**.
- F** Factory analog output calibration is now complete. The display will return to normal operating mode.

## A

## APPENDIX A - INPUT FUNCTIONS

A number of user programmable functions are accessible from the **P** button and rear pins (see 6.2H–K). Note that availability of the **TARE/BATCH** and **START/STOP** features are subject to your weighing mode, as selected in 6.2F.

## User programmable input functions

Function	Btn/Pin & Activation Time	Description
<b>HOLD</b>	<b>P</b> ↔ Continuous	Freezes the display value.
<b>LOCK</b>	↔ Continuous	Locks the control panel.
<b>TARE</b> (see 2.3)	<b>P</b> ↔ ½ sec	Tares display value (flashes <b>TARE</b> ).
	<b>P</b> ↔ 2+ sec	Resets tare to zero (flashes <b>TR RST</b> and then shows gross).
<b>BATCH</b> (see 2.1)	<b>P</b> ↔ ½ sec	If no batch operation is active: Performs a batch operation; display shows <b>BATCH</b> If a batch operation is in progress: Current batch is paused; display shows <b>PAUSE</b> If a batch operation has been paused, or you have just powered up following a power loss during batching: Controller will resume without resetting the batch value; display shows <b>RESUME</b>
	<b>P</b> ↔ 2+ sec	Resets the batch value to zero and flashes <b>BT RST</b> . Any current batching operations will be halted.
<b>ZERO</b> (see 2.4)	<b>P</b> ↔ ½ sec	Zeroes the weight if the zero offset (i.e. the difference between the current no load weight and the calibration no load value) is within the <b>ZERO BAND</b> (see 2.4). <i>If the offset is less than the limit set in <b>ZERO BAND</b> (see 6.4E), the zero value is updated and the display flashes <b>ZERO</b>. If the offset is greater than the limit set in <b>ZERO BAND</b>, the zero value is not updated and the display scrolls <b>OUTSIDE OF ZERO BAND!</b></i>
	<b>P</b> ↔ 2+ sec	Resets the zero offset value to the original calibration offset value. Display flashes <b>RS ZER</b> and then shows gross.

## User programmable input functions

Function	Btn/Pin & Activation Time	Description
<b>PEAK</b>	<b>P</b> ½ sec	Displays the peak value for 2 seconds.
	<b>P</b> 2+ sec	Sets the peak value to the current input value (flashes <b>PK RST</b> ).
	↔↔ Continuous	Displays the peak value continuously.
<b>PK RST</b>	<b>P</b> ↔↔ Continuous	Sets the peak value to the current input value (flashes <b>PK RST</b> ).
<b>PRINT</b> (see B.5)	<b>P</b> ↔↔ Continuous	Sends a single Ranger A output string. <i>SERIAL MODE (6.7B) must be set to RNGR A, and OUTPUT MODE (6.7G) must be set to PULSED.</i>
<b>GROSS</b>	↔↔ Continuous	Displays the gross value continuously.
<b>START</b>	↔↔ ½ sec	Starts a new batch, or resumes the batching process after it has been paused.
<b>STOP</b>	↔↔ ½ sec	Pauses the batching process and holds the current batched weight on the display.
	↔↔ 2+ sec	Resets the batch value to zero and halts any current batching operations.

**B****APPENDIX B - SERIAL MODES**

## B.1 - Custom ASCII mode

Custom ASCII is a simple, custom protocol that allows connection to various PC configuration tools. ('Custom ASCII' differs from the 'Modbus (ASCII)' protocol used by some devices.) Custom ASCII command strings must be constructed in this order:

**<Start> <Controller Address> <Read/Write Command> <Register Address>  
<Separator Character> <Data Value> <Message Terminator>**

**Start** - Use 'S' for the start character of a command string (not case sensitive). This must be the first character in the string.

**Controller Address** - Use an ASCII number from '1' to '255' for the controller address. If the character following the start character is not an ASCII number, then address '0' is assumed. All controllers respond to address '0'.

**Read/Write Command** - Use ASCII 'R' for read, 'U' for unformatted read, or 'W' for write (not case sensitive). Any other character aborts the operation.

*In Custom ASCII mode, data is normally read as formatted data (which includes decimals and any text characters that may be selected to show units). However it is also possible to read unformatted data by using a 'U' in the read command. There is no unformatted write command, as when writing to fixed point registers, any decimal point and text characters are ignored.*

**Register Address** - The register address for the read/write operation will be an ASCII number from '1' to '65535'. This character must be specified for a write command, but may be omitted for a read command, (in which case the controller will respond with the data value currently on the display).

**Separator Character** - The separator character can be either a space or a comma, and is used to separate the register address from the data value.

**Data Value** - Must be an ASCII number. The absolute limits for this number are -1000000 to +1000000, but note that not all registers will accept this range.

**Message Terminator** - This is the last character, and must be either a '\$' (dollar) or an '\*' (asterisk). Neither of these characters should be used elsewhere in the

message string. If '\$' is used, a 50ms minimum delay is inserted before a reply is sent. If '\*' is used, a 2ms minimum delay is inserted before a reply is sent.

#### Custom ASCII Read/Write Examples

Example	Description
SR\$	Read display value from all controllers, 50ms delay.
S15R\$	Read display value from controller address 15, 50ms delay.
S3U40*	Read unformatted data in channel 4 from controller address 3, 2ms delay.
S2W2 -10000\$	Write -10000 to the display register of controller address 2, 50ms delay.
SWT CHAN_1\$	Write ASCII text string Chan_1 to channel 1 text register, 50ms delay.

**Controller Response** - After the controller has completed a read or write instruction, it responds by sending a carriage return/line feed (CR/LF) back to the host. If the instruction was a read command, the CR/LF follows the last character in the ASCII string. If it was a write command, CR/LF is the only response sent back. The host must wait for this before sending further commands to the controller. If the controller encounters an error, it will respond with a null (0x00) CR/LF.

#### Custom ASCII Registers

##### 16 Bit Unsigned

Address	Function
1	Alarm status (SP1=Bit 0, SP2=Bit 1, SP3=Bit 2, SP4=Bit 3)
65-68	Hysteresis (SP1=65, SP2=66, SP3=67, SP4=68)
71-74	Make delay (SP1=71, SP2=72, SP3=73, SP4=74)

##### 32 Bit Signed

Address	Function
3	Tared/Batch weight (net)
4	mV
39	Live weight (gross)
16	Tare value
12	Peak
13	Valley
6-9	Setpoint 1-4 (SP1=6, SP2=7, SP3=8, SP4=9)
34	D/A scale low value
36	D/A scale high value



## B.2 - Modbus (RTU) mode

Modbus (RTU) is an industry standard RTU slave mode that allows connection to a wide range of devices. Modbus registers are all holding registers, and should be accessed via function codes 3 and 6.

Register addresses are displayed in the Modicon™ 5-digit addressing format. I.e. Register 65=40065 (subtract 1 for direct addressing).

### Modbus (RTU) Registers

#### 16 Bit Unsigned

Address	Function
40001	Alarm status (SP1=Bit 0, SP2=Bit 1, SP3=Bit 2, SP4=Bit 3)
40065– 40068	Hysteresis (SP1=40065, SP2=40066, SP3=40067, SP4=40068)
40071– 40074	Make delay (SP1=40071, SP2=40072, SP3=40073, SP4=40074)

#### 32 Bit Signed (2 x 16 Bit)

LSW	MSW	Function
40515	40516	Tared/Batch weight (net)
40517	40518	mV
40521	40522	Live weight (gross)
40529	40530	Tare value
40525	40526	Peak
40527	40528	Valley
40535 –541	40536 –542	Setpoint 1–4 (SP1=40535, SP2=40537, SP3=40539, SP4=40541)
40587	40588	D/A scale low value
40591	40592	D/A scale high value

## B.3 - Gedge mode

This serial mode is used to drive Gedge displays. Depending on your output format selected in 6.7C, the Gedge output string will be constructed as shown:

- › **C1= <STX> <Displayed Weight> <ETX>**
- › **C2= <STX> <Displayed Weight> <D2> <D3> <D4> <D5> <D6> <D7> <ETX>**
- › **C3= <STX> <Gross Weight> <Tare Weight> <Net Weight> <D2> <D3> <D4> <D5> <D6> <D7> <ETX>**

---

## Gedge Command Strings

<b>STX</b>	Start of transmission ( \$02 )
<b>ETX</b>	End of transmission ( \$03 )
<b>CR/LF</b>	Carriage return and Line feed ( \$0D \$0A )
<b>Weight</b>	8 ASCII alpha/numerics: <Space or minus sign> <Space> <6 digits> (E.g. "- 002387") or <Space or minus sign> <6 digits and decimal> (E.g. "-002.387")
<b>D2</b>	Displayed weight identity. <b>G</b> : Gross. <b>N</b> : Net. <b>T</b> : Tare.
<b>D3</b>	<b>M</b> : Scale is in motion. <b>S</b> : Scale is still.
<b>D4</b>	<b>I</b> : In scale. <b>O</b> : Over scale. <b>U</b> : Under scale.
<b>D5</b>	<b>Z</b> : Gross is zero. <b>ASCII Space</b> : Gross is not zero.
<b>D6</b>	<b>E</b> : Stored tare is not zero. <b>ASCII Space</b> : Stored tare is zero.
<b>D7</b>	<b>P</b> : Print key operation. <b>ASCII Space</b> : No print key operation.

---

## B.4 - Ranger A mode

Ranger A is a continuous output, used to drive remote displays and other instruments in the Rinstrum™ range. (Ranger is a trade name belonging to Rinstrum Pty Ltd.) Ranger A output strings are constructed as shown:

**<Start> <Sign> <Output Value> <Status> <End>**

**Start** - STX character (ASCII 02)

**Sign** - Output value sign (space for + and dash for -)

**Output Value** - Seven character ASCII string containing the current output value and decimal point. (If there is no decimal point, then the first character is a space. Leading zero blanking applies.)

**Status** - Single character output value status. 'U'=Under, 'O'=Over, 'E'=Error.


**End** - ETX character (ASCII 03)

---

## B.5 - Print mode

This mode outputs a *Weigh Ticket* (as shown) to the serial port when the *Print* function is triggered from the **P** button or rear input pins (see 6.2H–K).

The weigh ticket shows the current value of the selected *Serial Data Source* (as set in 6.7D), and the units selected in 6.7F.



```
WEIGH TICKET  
DATE: 13/2/12  
TIME: 12:50  
  
PEAK WEIGHT: 8.4 KGS
```

---

Note that changing the display units in 6.7F **does not perform any conversion calculations**. You will need to scale the instrument to match the printed units.

---


A date and time will also be printed on the Weigh Ticket. **In order to print the current date and time, *Real-Time Clock* hardware must be installed.** If the required hardware is not installed, the controller time stamp will revert back to the firmware revision date and time whenever the unit is restarted.



---

## Define Instruments

### New Zealand (Head Office)

 10B Vega Place, Rosedale,  
Auckland 0632, New Zealand  
PO Box 245 Westpark Village,  
Auckland 0661, New Zealand

Ph: +64 (9) 835 1550

Fax: +64 (9) 835 1250

 [sales@defineinstruments.co.nz](mailto:sales@defineinstruments.co.nz)

[www.defineinstruments.com](http://www.defineinstruments.com)

### United States (Dallas, TX)

Ph: (214) 926 4950

 [sales@defineinstruments.com](mailto:sales@defineinstruments.com)

[www.defineinstruments.com](http://www.defineinstruments.com)

---