

# Instruction Manual

## Micro Control X (Socket terminal type)

### Model : PXF4

INP-TN2PXF4UF-E

**Fuji Electric Co., Ltd.**  
 Gate City Ohsaki, East Tower, 11-2, Osaki 1-chome, Shinagawa-ku,  
 Tokyo 141-0032, Japan  
 Phone: +81-3-5435-7111  
 www.fujielectric.com  
 www.fujielectric.com/products/instruments/

Thank you for purchasing the Fuji digital temperature controller.  
 Once you have confirmed that this is the product you ordered, please use  
 it in accordance with the following instructions.  
 For detailed information on operating this equipment, please refer to the  
 separate user's manual.  
 In addition, please keep this instruction manual within easy reach of the  
 actual person using this equipment.

## Confirming Specifications and Accessories

- Before using the product, confirm that it matches the type ordered.  
 (For model code, please refer to "12. Model Specifications".)
- Confirm that all of the following accessories are included.
  - Temperature Controller 1 unit
  - Mounting bracket 1 pc
  - Instruction Manual 1 copy
  - Waterproof packing 1 pc

Name	Quantity	Order No.
PC loader communication cable	1 cable	ZZP* TQ501923C3
Without alarm functions 8-pin socket TP48X type (for rail mounting)	1 pc	*ZZPPXF2-C100
Without alarm functions 8-pin socket TP48SB type (for panel mounting)	1 pc	*ZZPPXF2-C101
With alarm functions 11-pin socket TP411X type (for rail mounting)	1 pc	*ZZPPXF2-C102
With alarm functions 11-pin socket TP411SBA type (for panel mounting)	1 pc	*ZZPPXF2-C103

## Related Information

Refer to the following reference materials for details about the items described in this manual.

Document	Reference No.
Micro Controller (Model: PXF) Operation Manual	INP-TN5A2400-E

The latest manuals can also be downloaded at the following URL:  
 www.fujielectric.com/products/instruments/

## Safety Information (Please Read First)

Please read this section thoroughly before using and observe the mentioned safety warnings fully.

Safety warnings are categorized as "Warning" or "Caution". Failure to follow the instructions may result in a safety hazard.

<b>Warning</b>	Mishandling may lead to minor or serious personal injury, fire, and/or property damage.
<b>Caution</b>	Mishandling may cause injury to the user or property damage.

If the equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.

### CAUTION

The contents of this manual are subject to change without notice. This manual is compiled with possible care for the purpose of accuracy, however, Fuji Electric shall not be held liable for any damages, including indirect damage, caused by typographical errors, absence of information or use of information in this manual.

## 1. Warning

### 1-1. Limitations in Use

This product is a temperature controller which was developed, designed and manufactured on the premise that it would be used for general machinery. In particular, if this product is to be used for applications that require the utmost safety as described below, please take into consideration of the safety of the entire system and the machine by adopting such means as a fail-safe design, a redundancy design as well as he conducting of periodical inspections.

- Safety devices for the purpose of protecting the human body
- Direct control of transportation equipment
- Airplanes
- Space equipment
- Atomic equipment, etc.

Please do not use this product for applications which directly involve human lives.

### 1-2. Installation and Wiring

- This equipment is intended to be used under the following conditions.

Ambient temperature	-10 °C to 50 °C
Ambient humidity	90% RH or below (with no condensation)
Overvoltage category	II by IEC 61010-1
Pollution degree	2
Recommended fuse	250 V AC, 0.1 A, T(Time-Lag) (100 to 240 V AC), 400 V DC/AC, 1 A, T(Time-Lag) (24 V DC/AC)
Usage environment	Indoor use

- For 24 V DC/AC power supply model, if the equipment is connected to the Safety Extra Low Voltage (SELV) circuit, a basic insulation\* must be provided between the SELV circuit and the power input terminals. Otherwise, the power input terminals must be connect to Extra Low Voltage (ELV) circuit so as to prevent the electric shock.

#### About safety standard

Please observe the following instructions to meet the requirements of safety standard. Failure to observe these instructions violates safety standards. (This product is not a safety equipment.)

- Install a recommended fuse, which is specified in the instruction manual, between the external main power (mains circuit) and this equipment.
- If accessible Safety Extra Low Voltage (SELV) circuits are to be connected to Signal input terminal, SSR Drive output terminal or Current output terminal, ensure to provide a basic insulation\* between the SELV circuits and these terminals (For example, use transformer which has a basic insulation\* or higher degree of insulation).
- Whole this equipment must be mounted in an enclosure in order to prevent the electric shock and spread of fire.
- Be sure to install an appropriate external protective circuit to prevent excessive temperature rise etc.
- When performing wiring work, be sure to turn the power off and to wear protection gloves or safety glasses, to prevent an electric shock.
- Set proper parameter input signals which correspond to each input to be connected. Be careful not to confuse voltage input with current input, or vice versa.
- Do not use this equipment for the measurement of circuits which falls under measurement categories II, III, or IV.
- Do not use this equipment for measurement of signals to which a voltage over 30 VRMS or over 60 V DC is applied.

\* The basic insulation requires a clearance at least 1.5 mm and a creepage of at least 3.0 mm. If such insulation is not provided, the UL61010 and EN61010 safety compliance may become invalid.

- If the voltage exceeds 50 V DC (which is called as hazardous voltage), install a basic insulation between all terminals and the ground, and supplementary insulation on the digital outputs. Note that the insulation class for this equipment is as follows. Before installing, please confirm that the insulation class for equipment meets usage requirements.

— Basic insulation (1500 V AC)    — Functional insulation (500 V AC)    .... No insulation

Power supply (100 to 240 V AC)	Internal circuit
Power supply (24 V DC/AC)	
Control output 1 (relay contact)	Process value input
Alarm output 1 to 2 (relay contact)	Control output 1 (SSR drive, current)

- In case where damage or problems with this equipment may lead to serious accidents, install appropriate external protective circuits.
- As this equipment has no power switch or fuse, install them separately as needed. If you install a fuse, be sure to place it between the main power switch and this equipment. (Main power switch: double-pole breaker, fuse rating: 250V, 1A)
- A power switch or a circuit breaker should be installed within the power supply facility.
- A power switch or a circuit breaker should be properly installed within easy reach of an operator.
- A power switch or a circuit breaker should be identified as the one for this product.
- Electrical wiring must be made by the qualified personnel only and in accordance with your local and national standards.
- For power supply wiring, use wire equal to 600 V vinyl insulated wire or above.
- To prevent damage and failure of the equipment, provide the rated power voltage.
- To prevent shock and equipment failure, do not turn the power ON until all wiring is complete.
- Before turning on power, confirm that clearance space has been secured to prevent shock or fire.
- Do not touch the terminal while the machine is on. Doing so risks shock or equipment errors.
- Never disassemble, convert, modify or repair this equipment. Doing so risks abnormal operation, shock or fire.
- If any failure occurs, please contact the manufacturer and return the product.
- Output relay is the part has a limited life. When output relay contact comes to the end of its life, it might remain on-state, or off-state. For safety, use a protective circuit outside.
- The factory default setting of this equipment is as follows. Change the setting as necessary so as the equipment to meet your application. Please note that the improper settings may result in overheat or unexpected damage. For the details of operation, refer to the separate volume, "Operation Manual (INP-TN5A2400-E)".
  - Control output 1: heating control
  - Alarm output 1 to 2 (optional): No function
- Symbols on the instrument
  - △: Read this instruction manual thoroughly before using the product, and use the product safely.

### 1-3. Maintenance

- When installing or removing the equipment, turn the power OFF. Otherwise, shock, operational errors or failures may be caused.
- Periodic maintenance is recommended for continuous and safe use of this equipment.
- Some parts installed on this equipment have a limited life and/or may deteriorate with age.
- The warranty period for this unit (including accessories) is three years after the date of manufacture, if the product is used properly.

## 3. Limited warranty

### 3-1. Scope of warranty

If malfunction occurs in the period of warranty due to Fuji Electric, the malfunctioning parts are exchanged or repaired for free. However, in the case where an engineer needs to visit your place for replacement or repair, you will be charged our call out fee. Please note that we cannot provide commissioning and/or readjustment for whole system including our product at repair or replacement of failed parts. The warranty does not apply to the following cases.

- The malfunction occurs due to inappropriate conditions, environment, handling or usage that is not instructed in a catalog, instruction book or user's manual.
- The malfunction is caused by the factors that do not originate in the purchased or delivered product.
- The malfunction is caused by other devices or software design that does not originate in Fuji Electric products.
- The malfunction occurs due to an alteration or repair that is not performed by Fuji Electric.
- The malfunction occurs because the expendable parts listed in an instruction book or connectable were not maintained nor exchanged in an appropriate manner.
- The malfunction occurs due to factors that were not foreseeable by the practical application of science and technology at the time of purchase or delivery.
- The malfunction occurs because the product is used for an unintended purpose.
- The malfunction occurs due to a disaster or natural disaster that Fuji Electric is not responsible for.

### 3-2. Exclusion of liability for loss of opportunity

Regardless of the time period of the occurrence, the amount of compensation assumed by Fuji Electric for damage, excluding which is caused by intentional acts or acts of gross negligence or illegal act by Fuji Electric, shall not exceed the amount stipulated

## 2. Caution

### 2-1. Cautions when Installing

- Please avoid installing in the following locations.
  - Locations in which the ambient temperature falls outside the range of -10 to 50 °C when equipment is in use.
  - Locations with rapid temperature changes, leading to dew condensation
  - Locations with corrosive gases (especially sulfide gas, ammonia, etc.) or flammable gases.
  - Locations with vibration or shock directly. (Vibration and shock may cause output relay malfunction.)
  - Locations in contact with water, oil, chemicals, steam or hot water. (If the equipment gets wet, there is a risk of electric shock or fire, so have it inspected by Fuji distributor.)
  - Locations with high concentrations of atmospheric dust, salt or iron particles.
  - Locations with large inductive interference, resulting in static electricity, magnetic fields or noise
  - Locations in direct sunlight.
  - Locations that build up heat from radiant heat sources, etc.
- Recommended site conditions
  - A place where the ambient humidity during operation is between 45 to 85% RH.


#### About EMC standard

- This equipment is a class A, for industrial locations, equipment. Do not use this equipment in domestic establishment, such as residential areas, or it may cause radio interference. If you use this equipment in domestic locations, take adequate measures on the outside of the equipment to reduce radio interference.
- Under the requirement of EMC standard, the maximum length of external cable including a sensor to be connected to this equipment is 30 m. Do not connect the sensor longer than 30 m.

### 2-2. Cautions when Attaching to the Panels

- Insert the controller unit into the panel cutout from the front, and then put the mounting bracket from the rear. The mounting bracket should be pushed in until the controller is securely fixed to the panel. If there is a slight gap remaining, gently tighten the two screws until the gap disappears. (Make sure not to over tighten the screws, as doing so may result in the mounting bracket separating from the stopper.)
- The front of this equipment is waterproof in compliance with NEMA-4X standards (IP66- equivalent). To effect waterproof, the included packing is shall be attached between the controller and the panel according to the guidelines below. (Incorrect attachment may cause the equipment to lose its waterproof capabilities.)
  - As shown in Fig. 1, insert the panel after attaching the packing to the equipment case.
  - As shown in Fig. 2, tighten the screws of the mounting bracket so that no gaps can remain between the equipment face, the packing and the panels. Once finished, confirm that there are no changes in shape such as displaced or improperly-fitted packing, etc. as shown in Fig. 3

< Attachment on vertical surface (Horizontal attachment) >



- Note that NEMA-4X and IP66 are not subject to UL/cUL certificate.
- If the panel does not have enough strength, gaps may develop between the packing and the panel to lose waterproofing capabilities.
- In order to aid heat dissipation, do not block the sides of the equipment.
- Do not block the air vents on the top and bottom of the case.


### 2-3. Cautions for Wiring

- For thermocouple input, use the designated compensation lead; for resistance bulb input, use wires with small lead wire resistance and without any resistance difference among the three wires.
- To avoid noise conductor effects, input signal wires should be separated from electric power lines or load lines.
- Input signal wire and output signal wire should be separated each other. And both should be shield wire.
- If there is a lot of noise from the power source, adding an insulation transducer and using a noise filter is recommended. Always attach a noise filter to a panel that is grounded securely, and keep the wiring between the noise filter output side and the measuring equipment power terminal wiring to a minimum length. Please do not attach fuses and switches, etc. to the noise filter output wiring; otherwise the filter's effectiveness will be decreased.
- Twisting the power wires is effective when connecting the wires. (The shorter the pitch of the twist, the more effective the connection is against noise.)
- Operation preparation time is required for the contact output when power is turned on. If using it as a signal to an external interlock circuit, please couple it with a delayed relay.
- Concerning the output relay, connecting the maximum rated load will shorten the product's life; so please attach an auxiliary relay. If the output operation frequency is high, selecting a SSR drive output type is recommended. [Proportionate cycles] Relay output: 30 seconds or more, SSR drive output: 1 second or more
- When inductive loads such as magnetic opening/closing equipment, etc. as relay output equipment are connected, use of a surge absorber is recommended in order to protect the contacts against opening/closing surges and to ensure long-term use. Recommended specification for the surge absorber

Voltage	Nominal varistor voltage
100 V	240 V
200 V	470 V

Attachment position: between the relay control output contacts.

Example



### 2-4. Key Operation Cautions/Error Operations

- The alarm function does not work properly when an error takes place unless the settings are made correctly. Always verify its setting before operation.
- If the input wiring breaks, the display will read "UUUU" or "LLLL". When replacing the sensor, always turn the power OFF.

### 2-5. Others

- Please do not wipe the equipment with organic solvents such as alcohol or benzene, etc. If wiping is necessary, use a neutral cleaning agent.
- Do not use mobile phones near this equipment (within 50 cm). Otherwise a malfunction may result.
- Trouble may occur if the equipment is used near a radio, TV, or wireless device.
- This equipment should be treated as an industrial waste when it is disposed of.

in the contract with the customer.

Fuji Electric is not liable for the damage to products that were not manufactured by Fuji Electric, incidental damages or consequential damages, or damage caused due to special situations regardless of whether it was foreseeable or not, or passive damages such as opportunity loss or lost profits of the purchaser.

### 3-3. Scope of application

- This equipment must be used under the following conditions:
    - The use of the equipment incurs no risk of a serious accident even if a failure or malfunction occurs on the equipment, and in case of product failure or malfunction, safety measures such as redundant design, prevention of malfunction, fail safe setting, foolproof mechanism are provided outside of the equipment by the user.
  - The product described in this document is designed and manufactured as a general-purpose products for general industrial applications.
  - The warranty does not apply to the following cases:
    - For the use not described in or beyond the conditions or environment specified in the instruction manual or the user manual,
    - For the use which has large influence on publicity including nuclear power and other power generation, gas, and/or water,
    - For the use in which safety is especially required, because it may seriously affect railroads, vehicles, combustion equipment, medical equipment, entertainment devices, safety equipment, defense equipment, and/or human lives and property.
- However, we will study the possibility of application of the equipment for the above use, if the user limits the usage of it and agrees to require no special quality. Please consult us.

## 4. Specifications

Power supply voltage	<ul style="list-style-type: none"> <li>100 (-15%) to 240 (+10%) V AC, 50/60 Hz</li> <li>24 (±10%) V DC/AC, 50/60 Hz</li> </ul>
Power consumption	10 VA MAX. (100 to 240 V AC), 5 VA MAX. (24 V DC/AC)
Control output	Relay contact output <ul style="list-style-type: none"> <li>1 SPDT contact, 250 V AC/ 30 V DC, 5 A (resistive load)</li> </ul> SSR drive output (voltage pulse output)* <ul style="list-style-type: none"> <li>ON voltage: 12 V DC (10.7 to 13.2 V DC)</li> <li>OFF voltage: 0.5 V DC or lower</li> <li>Maximum current: 20 mA DC</li> <li>Load resistance: 600 Ω MAX.</li> </ul> Current output <ul style="list-style-type: none"> <li>0 to 20 mA DC/4 to 20 mA DC</li> <li>Accuracy ±5%FS</li> <li>Load resistance: 500 Ω MAX.</li> </ul>
Process value input	Accuracy <ul style="list-style-type: none"> <li>Thermocouple input: 0.5%FS±1digit±1°C</li> <li>*except: Thermocouple B: 0 to 400°C: no accuracy assurance</li> <li>Thermocouple R: 0 to 500°C: 1%FS±1digit±1°C</li> <li>Other thermocouples: -200 to -100°C: ±2°C ±1 digit</li> <li>RTD: either ±0.8°C ±1 digit or ±0.2% ±1 digit, whichever is larger</li> <li>mV input, voltage input, current input: ±0.3%FS ±1 digitmV</li> </ul> *Note that the sensor should be sufficiently warmed up to secure the accuracy.
Alarm output	Relay contact output (AL1 to AL2) <ul style="list-style-type: none"> <li>1 SPST contact, 250 V AC/30 V DC, 1 A (resistive load)</li> </ul>


Loader interface	TTL Level <ul style="list-style-type: none"> <li>Connection method: dedicated cable</li> <li>Communication method: Half-duplex bit serial, asynchronous communication</li> <li>Transmission rate: 38400 bps, no parity</li> <li>Protocol: Modbus RTU compatible</li> </ul>
Storage temperature and humidity	-20 to 60°C, 90%RH or less (no condensation)
Operating temperature and humidity	-10 to 50°C, 90%RH or less (no condensation)
Altitude	up to 2000 m
Recommended fuse	250 V AC, 0.1A T(Time-Lag) for 100 to 240 V AC Power supply, 400 V DC/AC, 1 A T(Time-Lag) for 24 V DC/AC Power supply
Service life	Service life: 10 years (at an average temperature of 25°C) The life is shortened by half when the temperature rises by 10°C (Arrhenius' law). If you use the controller inside a cabinet or the like, please note that the ambient temperature can rise.

\*The following table shows the difference of outputs among other micro-controller X series models.

	SSR driving output		Allowable load resistance for 4 to 20mA DC output
	Voltage	Maximum current	
PXR3	15 V DC	20 mA	100 to 500 Ω
PXR4/5/7/9	24 V DC	20 mA	600 Ω or less
PXV3	5.5 V DC	20 mA	600 Ω or less
PXV/W/Z	24 V DC	20 mA	600 Ω or less
PXF	12 V DC	20 mA	500 Ω or less


## 5. Installation and Mounting

### 5-1. External Dimensions (unit: mm)



\* When using the parameter loader with PXF being mounted on a panel: t (panel thickness) 1 ≤ t ≤ 4


### 5-2. Panel Cut Dimensions (unit: mm)



- Panel cut dimensions should also meet the above dimensions after the panel is coated.
- Cautions when Side stick mounting:
  - In this installing, the waterproof of PXF is lost.
  - When the power supply is 200 V AC, keep the maximum ambient temperature at 45°C. (We recommend use of a fan, as a heat radiating measure.)
  - If any equipment or walls which have a depth of 70 mm exist around this instrument, keep a clearance of at least: 30 mm on the both sides, 50 mm below, 30 mm above.


## 6. Wiring

### 6-1. Terminal Connection Diagram (Without alarm functions 8-pin socket)



\*1: The terminal layout differs from that of PXW4/PXZ4/PXV4.


### 6-2. Terminal Connection Diagram (With alarm functions 11-pin socket)



\*2: Check the power supply voltage before installation.


## 7. Part names and functions

### 7-1. Operation keys



Key	Name	Allows you to...
	USER	<ul style="list-style-type: none"> <li>switch between SV and MV, in the operation mode or during standby.</li> <li>return to the operation mode from the parameter setup mode.</li> </ul>
	SEL	<ul style="list-style-type: none"> <li>enter the parameter setup mode from the operation mode or standby.</li> <li>finish selecting and save change.</li> </ul>
	LEFT	<ul style="list-style-type: none"> <li>move the digit when you editing the numerals.</li> </ul>
	UP	<ul style="list-style-type: none"> <li>change the set value when PXF is in the operation mode or standby.</li> <li>select a parameter in the parameter selection mode.</li> </ul>
	DOWN	<ul style="list-style-type: none"> <li>change a parameter setpoint in the parameter editing mode.</li> </ul>

### 7-2. Display



- Process variable (PV)**
  - Indicates the measured value.
  - In the Operation control mode and the Setup mode, the parameter name is displayed.
  - In the Channel selection mode, the channel number is displayed.
- OUT1 indicator**
  - Lights during control output is ON.
- EV1, EV2 indicators**
  - Lights during digital output 1 to 2 are ON.
- STBY indicator**
  - Lights during standby.
- MANU indicator**
  - Lights during manual mode.
- °C/°F indicator**
  - Shows the temperature unit under use.
- A, % indicator**
  - Shows the unit being applied to values on SV screen during the operation mode.
- Set Value (SV)/Manipulated variable (MV)**
  - Indicates the set value or the manipulated variable. The MV indicator lights during MV display.
- Screen No.**
  - Shows screen No. when in parameter setting.
- AT indicator**
  - Lights during auto tuning.
- RUN/HOLD/END indicators**
  - Lights during ramp/soak operation.
- Lock indicator**
  - Lights during key lock.

## 8. Basic Operations

**< Operation mode >**

**To switch between SV, MV and power**

Each time you press , the displayed value switches in the following order:

SV → MV → Power

**To change the setpoint**

- 1 Press to display the SV.
- 2 Press or to change the value. Press to move to the next digit.
- 3 Press to save the change.

**< Channel selection mode >**

**To change the channel**

1 Press or .

CH1	CH2	CH3	CH4	CH5	CH6
Pid	Plt	PRG	MoN	ALM	SET
CH7	CH8	CH11	CH12	CH13	
SYS	MAth	dSP	CFG	PASS	

→ See the "Parameter list" on the right page.

**< Setup mode >**

**To change a parameter setpoint**

- 1 Press or to select the parameter you want to edit.
- 2 Press .
- 3 Press or to change the value. To change the digit, use .
- 4 Press .

→ For details of the parameters, See the "Parameter list" on the right page.

**< Operation control mode >**

**To change the setpoint**

- 1 Press or to change the parameter.
- 2 Press select the parameter you want to edit. → The parameter setpoint starts blinking.
- 3 Press or to change the setpoint.
- 4 Press to save the change.

→ See the "Parameter list" on the right page.

### ●Operation mode

In this mode the normal operation is performed. The process value (PV) and the set value (SV) are displayed. The device starts in this mode when you turn on the power. You can change the set value (SV) in this mode. You can check the output value (MV) and the amount of electric power by switching in the screen.

### ●Operation control mode

In this mode you can put the device to standby or change the alarm set value.

### ●Channel selection mode

In this mode you can select the parameter channel to be displayed.

### ●Setup mode

In this mode you can setup each parameter. This mode includes the parameter selection submode and the parameter editing submode, which can be switched by key. In the parameter selection submode, you can switch between parameters by using keys. In the parameter editing submode, you can change parameter values by using keys.

### Changing MV (control output values)

- 1 Press to switch to the Operation control mode.
- 2 Press to change the value of the parameter "MAN".
- 3 Press to change "oFF" to "oN", and then press to save the change. (MANU indicator appears.)
- 4 Press to display the MV. (MANU indicator appears.)
- 5 Press or to change the MV. (Changes are reflected to the MV as it is changed.)

## 9. Setting the Temperature Controller

### 9-1. Input Setting

Set the type and the range for input sensor. Input can be set in the setup menu ("Ch5 Sel"). For more on input types, input scaling, decimal point location, and input codes, see "10. Input Range and Codes (standard range)".

#### Choose an input type ("Pvt")

- 1 Check the type of the thermocouple or resistance bulb which is used.

#### Set the PV scaling (input range) ("Pvb" / "Pvf")

- 1 Set Pvb to the lower limit of the temperature range and Pvf to the upper limit.
- 2 It is recommended to set the values at the standard range, even though they can be set at values beyond of it. There is no standard range for DC voltage or DC current input. (-1999 to 9999, lower limit < upper limit)

#### Set the decimal point location ("Pvd")

- 3 Sets whether or not to display digits after the decimal point. Two digits can also be displayed after the decimal point when using 1 to 5V DC, and 4 to 20mA DC.

**Point** PV scaling and decimal point location can be used with the factory settings.

### 9-2. Output Setting

Sets the control output. (Only when the output is current or voltage.)

#### Sets the range of the control output (OUT1) ("IR")

- 1 Choose any of 0 to 5V, 1 to 5V, 0 to 10V, 2 to 10V, 0 to 20mA or 4 to 20mA DC.

### 9-3. Control Setting

Sets controls to normal operation or reverse operation.

#### ●Reverse operation:

As the process value (PV) rises, the control output (MV) becomes smaller. Used to heat the control object.

#### ●Normal operation:

As the process value (PV) rises, the control output (MV) becomes larger. Used to cool the control object.

#### Set the normal or reverse operation ("REV")

Choose any of the following combinations of heat and cool to suit your system.

1	REV	Control output 1
	RV--	Reverse
	No--	Normal

### 9-4. Alarm Output Setting

Changing the DO type setting, set as below.

- Set the "do2t" to the value output from AL1.
- Set the "do3t" to the value output from AL2.

## 10. Input Range and Codes (standard range)

Input type	Input code	Measurement range (°C)	Minimum input increment (°C)	Measurement range (°F)	Minimum input increment (°F)	
		(PVT)	(PVB, PVF)	(PVB, PVF)	(PVB, PVF)	
RTD JIS (IEC)	JPt 100	JPT1	0.0 to 150.0	0.1	32.0 to 302.0	0.1
		JPT2	0.0 to 300.0	0.1	32.0 to 572.0	0.1
		JPT3	0.0 to 500.0	0.1	32.0 to 932.0	0.1
		JPT4	0.0 to 600.0	0.1	32 to 1112	1
		JPT5	-50.0 to 100.0	0.1	-58.0 to 212.0	0.1
		JPT6	-100.0 to 200.0	0.1	-148.0 to 392.0	0.1
		JPT7	-199.9 to 600.0	0.1	-328 to 1112	1
	Pt 100	PT1	0.0 to 150.0	0.1	32.0 to 302.0	0.1
		PT2	0.0 to 300.0	0.1	32.0 to 572.0	0.1
		PT3	0.0 to 500.0	0.1	32.0 to 932.0	0.1
		PT4	0.0 to 600.0	0.1	32 to 1112	1
		PT5	-50.0 to 100.0	0.1	-58.0 to 212.0	0.1
		PT6	-100.0 to 200.0	0.1	-148.0 to 392.0	0.1
		PT7	-199.9 to 600.0	0.1	-328 to 1112	1
		PT8	-200 to 850	1	-328 to 1562	1
	Thermocouple	J	J1	0.0 to 400.0	0.1	32.0 to 752.0
J2			-20.0 to 400.0	0.1	-4.0 to 752.0	0.1
J3			0.0 to 800.0	0.1	32 to 1472	1
J4			-100 to 1000	1	-148 to 1832	1
K		K1	0 to 400	0.1	32 to 752	0.1
		K2	-20.0 to 500.0	0.1	-4.0 to 932.0	0.1
		K3	0.0 to 800.0	0.1	32 to 1472	1
		K4	-200 to 1300	1	-328 to 2372	1
R		R	0 to 1700	1	32 to 3092	1
B		B	0 to 1800	1	32 to 3272	1
		S	S	0 to 1700	1	32 to 3092
T		T1	-199.9 to 200.0	0.1	-199.9 to 392.0	0.1
		T2	-199.9 to 400.0	0.1	-199.9 to 752.0	0.1
E		E1	0.0 to 800.0	0.1	32 to 1472	1
		E2	-150.0 to 800.0	0.1	-238 to 1472	1
		E3	-200 to 800	1	-328 to 1472	1
L	L	-100 to 850	1	-148 to 1562	1	
	U	U1	-199.9 to 400.0	0.1	-199.9 to 752.0	0.1
U2		-200 to 400	1	-328 to 752	1	
N	N	-200 to 1300	1	-328 to 2372	1	
	W	W	0 to 2300	1	32 to 4172	1
PL-II	PL-1	0 to 1300	1	32 to 2372	1	
	PL-2	0 to 1300	1	32 to 2372	1	
DC voltage	0 to 5 V DC	0-5V	-1999 to 9999 (Range where scaling is allowed)	-1999 to 9999 (Range where scaling is allowed)	—	
	1 to 5 V DC	1-5V				
	0 to 10V DC	0-10				
	2 to 10V DC	2-10				
DC current	0 to 100mV DC	MV	-1999 to 9999 (Range where scaling is allowed)	-1999 to 9999 (Range where scaling is allowed)	—	
	0 to 20 mA DC	0-20				
	4 to 20 mA DC	4-20				

## 11. Error Indications

This controller has a display function to indicate several types of error code shown below. If any of the error code is displayed, please eliminate the cause of error immediately. After the cause is eliminated, turn off the power once, and then re-start the controller.

Display	Possible cause	Control output
"UUUU"	(1) Thermocouple burnout. (2) Resistance bulb sensor (A) burnout. (3) PV exceeds upper limit of the range by 5%FS.	The controller outputs the specified value for an error.
"LLLL"	(1) Resistance bulb sensor B or C wire burnout. (2) Resistance bulb sensor (between A & B or A & C) short. (3) PV is below lower limit of the range by 5%FS. (4) Burnout or short in the voltage input.	The controller outputs the specified value for an error. (The value can be set in parameter Flo1)
"ERR"	Incorrect setting (Pvb/Pvf)	Normal control * The controller does not have to be restarted
PV is not displayed	Check the set value of DSPT.	Normal control * The controller does not have to be restarted
SV is not displayed	Check the set value of DSPT.	Normal control * The controller does not have to be restarted
Parameters may not be displayed	Check the settings of Ch11 DSP.	Normal control * The controller does not have to be restarted
"ALM1" / "ALM2"	Alarm 1 or alarm 2 is occurred under the condition that ALMF is set to 1 or 3.	Normal control
"ALMR"	The number that relay has operated reached the RYCN (relay contact life limit) under the condition that ALMF is set to 1 or 3.	
"ALMo"	The number of days that the device has operated reached the oPtM (upper limit of operating days) under the condition that ALMF is set to 1 or 3.	

## 12. Model Specifications

Digit	Specifications	Note
4	<Front panel size W × H> 48×48mm	4
5	<Input signal> Universal input Universal input (PXWIZ/V)	A N
6	<Control output> Relay contact (SPDT) SSR drive output Current output	B C E
7	<Terminal form> Socket type	U
8	<Revision code>	2
9	<Alarm output> None 2 points	4 G
10	<Power supply voltage> 100 to 240V AC 24 V AC/DC	V B
11		Y
12		0
13		0

Parameter List

The following explains each channel parameter.

- The list also shows the operational range of set values for parameters that are limited.
● When the PV input lower limit (Pvb), PV input upper limit (Pvf), or decimal place position (Pvd) is changed, reconfigure all the initial parameter setting values.
● When the parameter that has [RESET] on its Remarks column is changed, turn off the power once, and then re-start the controller.

Operation control parameter table with columns: No, Display, Name, Function, Factory default setting, Remarks. Includes parameters like Switchover between auto and manual mode, Ramp soak control command, Auto-tuning run command, etc.

CH1 PID (control parameters) table with columns: No, Display, Name, Function, Factory default setting, Remarks. Includes parameters like Proportional band, Integration time, Differential time, etc.

CH2 PLT (PID palette parameters) table with columns: No, Display, Name, Function, Factory default setting, Remarks. Includes parameters like SV1, Proportional band 1, Integration time 1, etc.

CH 3 PRG (ramp soak parameters) table with columns: No, Display, Name, Function, Factory default setting, Remarks. Includes parameters like Ramp soak operation pattern, Ramp soak time units, etc.

CH 4 MON (monitor parameters) table with columns: No, Display, Name, Function, Factory default setting, Remarks. Includes parameters like Ramp soak progress, MV1(%), Remote SV, etc.

CH5 ALM (monitor parameters) table with columns: No, Display, Name, Function, Factory default setting, Remarks. Includes parameters like ALM1 alarm type, ALM1 hysteresis, ALM1 delay, etc.

CH 6 SET (setup parameters) table with columns: No, Display, Name, Function, Factory default setting, Remarks. Includes parameters like PV input type, PV input lower limit, PV input upper limit, etc.

CH 7 SYS (system parameters) table with columns: No, Display, Name, Function, Factory default setting, Remarks. Includes parameters like USER key, USER + UP key, USER + DOWN key, etc.

CH 8 MATH (calculation parameters) table with columns: No, Display, Name, Function, Factory default setting, Remarks. Includes Simple calculation ON/OFF.

CH 11 DSP (parameter mask) table with columns: No, Display, Name, Function, Factory default setting, Remarks. Includes Parameter mask.

CH 12 CFG (configuration parameters) table with columns: No, Display, Name, Function, Factory default setting, Remarks. Includes Operation timeout, Blinking SV during Soft Start, etc.

CH 13 PASS (password parameters) table with columns: No, Display, Name, Function, Factory default setting, Remarks. Includes Password1 setup, Password2 setup, Password3 setup.

For details, refer to the operation manual (INP-TN5A2400-E) available from our website:

www.fujielectric.com/products/instruments/