

Cast Iron Fountains Assembly Instructions

(Lisbon 2-3 Tier Fountains)

- Our Cast Iron Fountains have been levelled in our warehouse prior to shipping.
- We ship these fountains disassembled to avoid freight damage on transit.
- Individual components have been marked with chalk marks, these marks MUST line up with each other.

POST ASSEMBLY

- Silicone sealant must be applied to ALL joints and around ALL bolts. This will prevent the water from seeping into the centre shafts.
- Penetrol in liquid form should be applied liberally with a paint brush to the whole fountain to protect it against rust. This process should be repeated whenever rust starts to appear or every 6 months.

