

ASSEMBLY MANUAL AND PART REFERENCE



WWW.SYNERGYRCHELICOPTERS.COM







INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD

TAIL AND HUB

BATTERY TRAY

MAIN AND TAIL BLADES

PANEL SYSTEM

OPTIONS AND CONFIGURATIONS



Congratulations on your purchase of the Synergy 766 model helicopter kit!

For further information, you can contact the AMA at:

The Synergy 766 was designed and developed by Matt Botos, a world class competition model helicopter pilot, and is the result of thousands of hours of research and experience.

Before you proceed please verify you have the latest version of this manual by visiting our website at http://synergyrchelicopters.com/manuals. If you have any questions during the assembly process or need clarification on anything in this manual please visit our forums at http://synergyrchelicopters.com/forum where you will find great tips and expert advice.

THIS RADIO CONTROLLED HELICOPTER IS NOT A TOY. IT IS A SOPHISTICATED PIECE OF EQUIPMENT DESIGNED AND INTENDED FOR RECREATIONAL USE ONLY. IF NOT PROPERLY ASSEMBLED, MAINTAINED, AND OPERATED, IT IS CAPABLE OF CAUSING PROPERTY DAMAGE AND BODILY HARM TO BOTH THE OPERATOR AND SPECTATORS. BOTOS DESIGN & DISTRIBUTION, ITS AFFILIATES, AND ITS AUTHORIZED DISTRIBUTORS ASSUME NO LIABILITY FOR DAMAGE THAT COULD OCCUR FROM THE ASSEMBLY OR USE OR MISUSE OF THIS PRODUCT. USE THIS PRODUCT AT YOUR OWN RISK.

Operating a model helicopter requires a high degree of aptitude and meticulousness. If you are new to model helicopters, it is your responsibility to seek help and guidance from experienced modelers. Having an experienced modeler inspect your model and provide instruction will both greatly speed up the learning process and make it much safer for you. For those pilots who will be operating their Synergy 766 in the United States, we strongly recommend joining the AMA. The AMA is a non-profit organization that provides services to the model aircraft pilots. As an AMA member, you will receive a liability insurance plan to cover against a possible accident or injury. All AMA charter clubs require individuals to hold a current AMA membership prior to operation of their models at their facility.

Academy of Model Aeronautics 5151 East Memorial Drive Muncie, IN 47302 (800) 435-9262 https://www.modelaircraft.org

WWW.SYNERGYRCHELICOPTERS.COM





INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD

TAIL AND HUB

BATTERY TRAY

MAIN AND TAIL BLADES

PANEL SYSTEM

OPTIONS AND CONFIGURATIONS



SPECIFICATIONS AND FEATURES

SPECIFICATIONS:

• Main Blades: 716-806mm

Available Main Gear Ratio: 9.27-11.58*

Available Tail Gear Ratios: 4.5 / 4.7 / 5.1*

Available Boom Sizes: 716 / 766 / 806*

• Tail blades: 106-116mm

Battery Configuration: 12s-14s

• 64mm frame width

*This kit includes the following:

- 13T main pinion
- 4.7 tail ratio (27T Pinion). See page 8.
- Boom, torque tube, and tail control rod lengths optimized for 766mm main blades. See pages 64-67 for specific sizes.

Optional parts are available from the Synergy RC Helicopters website at http://www.mattbotos.com/store.

Main and tail blades are not included.

MAIN FEATURES:

- CNC Machined Helical mod 1 main and auto gears
- Monster-mod 1.25 24T front and rear tail drive bevel gears
- Torque tube tail drive for high efficiency
- Ultra-wide head for rigid, precise control
- Tunable blade grip pitch arm geometry
- 12mm Main Shaft / 10mm Spindle & rocker support
- Dual main shaft thrust bearings
- Serviceable dual-bearing swash plate system
- Quad progressive & adjustable head dampening
- Turnbuckle linkage adjustments
- Low disk loading
- Multiple tail drive ratios
- Locking battery tray with CG adjustment
- Optimized tail arm geometry
- Optimum boom options for each blade size
- 3 panel canopy system with high-visibility paint
- Grease ports for all 6 thrust bearings
- CNC Machined Delrin gears
- Designed and supported in the U.S.A

www.synergyrchelicopters.com





INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD

TAIL AND HUB

BATTERY TRAY

MAIN AND TAIL BLADES

PANEL SYSTEM

OPTIONS AND CONFIGURATIONS






Frame alignment should be verified once both sides are completely assembled and the main shaft inserted. Unless noted otherwise, do not fully tighten these bolts yet.















INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD


TAIL AND HUB

BATTERY TRAY

MAIN AND TAIL BLADES

PANEL SYSTEM







<u>(1)</u>

Components that are factory assembled provide a reference for model assembly. Disassembly and application of thread lock is required where indicated.

INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD

TAIL AND HUB

BATTERY TRAY

MAIN AND TAIL BLADES

PANEL SYSTEM


OPTIONS AND CONFIGURATIONS





DO NOT TIGHTEN BOLTS YET

Frame alignment should be verified once both sides are completely assembled and the main shaft inserted. Unless noted otherwise, do not fully tighten these bolts yet.



SIDE 1





INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD


TAIL AND HUB

BATTERY TRAY

MAIN AND TAIL BLADES

PANEL SYSTEM







INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD

TAIL AND HUB

BATTERY TRAY

MAIN AND TAIL BLADES


PANEL SYSTEM

OPTIONS AND CONFIGURATIONS





TRANSFER SHAFT



STOP! **IMPORTANT**

Prior to assembly, thread set screw the entire length of the hole to check for burrs or other obstacles.

Tighten and secure set screw with blue thread lock. This set screw secures the bevel gear pin!



retainer. Wipe away excess. Removal may require heat.

**Allow Thread lock to dry prior to installation on the following page. Failure to do so may allow thread lock to wick into the bearings.



<u>(i)</u>

Components that are factory assembled provide a reference for model assembly. Disassembly and application of thread lock is required where indicated.

INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD

TAIL AND HUB

BATTERY TRAY

MAIN AND TAIL BLADES

PANEL SYSTEM

OPTIONS AND CONFIGURATIONS




TRANSMISSION

BEVEL GEAR BLOCKS

FRONT MUSHROOM BEARING BLOCK ASSEMBLY

766-507 Front Mushroom Gear Bearing Block




(i)

PREASSEMBLED COMPONENTS

The 766-301 24T Front Trans Mushroom Gear Block contains radial bearings and mushroom bevel gear which does not require disassembly.

Tip: If repair or disassembly are required, freeze components to easily remove mushroom gear.







INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD

TAIL AND HUB

BATTERY TRAY

MAIN AND TAIL BLADES


PANEL SYSTEM

OPTIONS AND CONFIGURATIONS



TRANSMISSION

SIDE PLATES







INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD


TAIL AND HUB

BATTERY TRAY

MAIN AND TAIL BLADES

PANEL SYSTEM









INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD

TAIL AND HUB

BATTERY TRAY


MAIN AND TAIL BLADES

PANEL SYSTEM

OPTIONS AND CONFIGURATIONS



TOP BEARING BLOCK





<u>(i)</u>

Components that are factory assembled provide a reference for model assembly. Disassembly and application of thread lock is required where indicated.

INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD

TAIL AND HUB

BATTERY TRAY

MAIN AND TAIL BLADES


PANEL SYSTEM

OPTIONS AND CONFIGURATIONS





MIDDLE BEARING BLOCK







INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD

TAIL AND HUB

BATTERY TRAY

MAIN AND TAIL BLADES

PANEL SYSTEM

OPTIONS AND CONFIGURATIONS





LOWER BEARING BLOCK


APPLY BLUE THREAD LOCK TO INDICATED BOLTS

109-122 12x16x2mm Thrust Bearing Spacer

108-912 12x21 Thrust Bearing


766-113 Thrust Bearing Housing

100-212 M2x12 Socket Head (4)



OUTSIDE

INSIDE





<u>.</u>

Components that are factory assembled provide a reference for model assembly. Disassembly and application of thread lock is required where indicated.

INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD

TAIL AND HUB

BATTERY TRAY

MAIN AND TAIL BLADES

PANEL SYSTEM

OPTIONS AND CONFIGURATIONS






Frame alignment should be verified once both sides are completely assembled and the main shaft inserted. Unless noted otherwise, do not fully tighten these bolts yet.



SIDE 1







INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD

TAIL AND HUB

BATTERY TRAY

MAIN AND TAIL BLADES

PANEL SYSTEM

OPTIONS AND CONFIGURATIONS




OO NOT TIGHTEN BOLTS YET

Frame alignment should be verified once both sides are completely assembled and the main shaft inserted. Unless noted otherwise, do not fully tighten these bolts yet.



SIDE 1







INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD

TAIL AND HUB

BATTERY TRAY

MAIN AND TAIL BLADES


PANEL SYSTEM

OPTIONS AND CONFIGURATIONS





SIDE 1 COMPLETED





<u>(1)</u>

Components that are factory assembled provide a reference for model assembly. Disassembly and application of thread lock is required where indicated.

INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD


TAIL AND HUB

BATTERY TRAY

MAIN AND TAIL BLADES

PANEL SYSTEM









INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD


TAIL AND HUB

BATTERY TRAY

MAIN AND TAIL BLADES

PANEL SYSTEM









INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD


TAIL AND HUB

BATTERY TRAY

MAIN AND TAIL BLADES

PANEL SYSTEM









INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD

TAIL AND HUB

BATTERY TRAY

MAIN AND TAIL BLADES

PANEL SYSTEM

OPTIONS AND CONFIGURATIONS




DO NOT TIGHTEN BOLTS YET

Frame alignment should be verified once both sides are completely assembled and the main shaft inserted. Unless noted otherwise, do not fully tighten these bolts yet.



SIDE 2







INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD

TAIL AND HUB

BATTERY TRAY

MAIN AND TAIL BLADES


PANEL SYSTEM


OPTIONS AND CONFIGURATIONS





SIDE 2







<u>(1)</u>

Components that are factory assembled provide a reference for model assembly. Disassembly and application of thread lock is required where indicated.

INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD

TAIL AND HUB

BATTERY TRAY

MAIN AND TAIL BLADES


PANEL SYSTEM

OPTIONS AND CONFIGURATIONS





ANTI-ROTATION BRACKET









INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD

TAIL AND HUB


BATTERY TRAY

MAIN AND TAIL BLADES

PANEL SYSTEM

OPTIONS AND CONFIGURATIONS





WWW.SYNERGYRCHELICOPTERS.COM





INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD


TAIL AND HUB

BATTERY TRAY

MAIN AND TAIL BLADES

PANEL SYSTEM









INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD

TAIL AND HUB

BATTERY TRAY

MAIN AND TAIL BLADES


PANEL SYSTEM

OPTIONS AND CONFIGURATIONS



MAIN FRAME

LANDING GEAR







INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD


TAIL AND HUB

BATTERY TRAY

MAIN AND TAIL BLADES

PANEL SYSTEM









INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD

TAIL AND HUB

BATTERY TRAY

MAIN AND TAIL BLADES


PANEL SYSTEM


OPTIONS AND CONFIGURATIONS



MAIN FRAME COMPLETED











INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD

TAIL AND HUB

BATTERY TRAY

MAIN AND TAIL BLADES

PANEL SYSTEM

OPTIONS AND CONFIGURATIONS






SLEEVE AND BUSHINGS



) VERIFY SMOOTH OPERATION

Temporarily install each bronze bushing onto the sleeve to verify smooth rotation.

IF REQUIRED: Using oil as a lubricant and 1000grit wet/dry sandpaper, lightly sand the INSIDE of the bronze bushing.







INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD

TAIL AND HUB

BATTERY TRAY

MAIN AND TAIL BLADES

PANEL SYSTEM

OPTIONS AND CONFIGURATIONS




MAIN DRIVE

AUTO HUB



Apply a thin coating of RED thread lock to the outside of the bronze bushing. Use only a thin layer to prevent contamination of the one-way bearing inside the hub.





<u>(1)</u>

Components that are factory assembled provide a reference for model assembly. Disassembly and application of thread lock is required where indicated.

INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD

TAIL AND HUB

BATTERY TRAY

MAIN AND TAIL BLADES

PANEL SYSTEM

OPTIONS AND CONFIGURATIONS




MAIN DRIVE

MAIN GEAR AND AUTO HUB



DO NOT OVER TIGHTEN!

Apply BLUE thread lock to six(6) 101-308 M3x8 Button Head bolts and tighten lightly. Over tightening these bolts may crack the main gear.





APPLY BLUE THREAD LOCK TO INDICATED BOLTS





INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD

TAIL AND HUB

BATTERY TRAY

MAIN AND TAIL BLADES


PANEL SYSTEM

OPTIONS AND CONFIGURATIONS





AUTO GEAR HUB







766-608 127T Helical Auto Gear



IMPORTANT!

Auto gear has a top and bottom side. Note direction during installation.



766-501 Auto Gear Hub

101-308 M3x8 Button Head (4)

32





INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD

TAIL AND HUB

BATTERY TRAY

MAIN AND TAIL BLADES


PANEL SYSTEM

OPTIONS AND CONFIGURATIONS




MAIN DRIVE

AUTO GEAR HUB



Apply oil only to the auto sleeve and one-way bearing. Use a lightweight oil such as Tri-flo or other bearing oil.

DO NOT USE GREASE!



766-503 Auto Hub Sleeve



Apply grease to both sides of the Delrin shims. For optimum performance, use extreme pressure synthetic grease, Boto-Lube Part BD-001.



Note orientation of the main auto hub. Bolt heads should always be on the underside facing the auto gear hub.



317-505 Auto Hub Delrin Shim •••••••







INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD

TAIL AND HUB

BATTERY TRAY

MAIN AND TAIL BLADES

PANEL SYSTEM

OPTIONS AND CONFIGURATIONS








IMPORTANT!

The 12mm Main Shaft Shim is located below the main drive assembly.

109-112 12mm Main Shaft Shim







INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD


TAIL AND HUB

BATTERY TRAY

MAIN AND TAIL BLADES

PANEL SYSTEM









INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD

TAIL AND HUB


BATTERY TRAY

MAIN AND TAIL BLADES

PANEL SYSTEM


OPTIONS AND CONFIGURATIONS







- 1. Loosen 8 bolts that secure the transmission
- 2. Slide transmission forward to mesh tight with the main drive gear.
- 3. Move the transmission back slightly to obtain 0.1-0.2mm gear backlash.







INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD


TAIL AND HUB

BATTERY TRAY

MAIN AND TAIL BLADES

PANEL SYSTEM







INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD

TAIL AND HUB

BATTERY TRAY

MAIN AND TAIL BLADES


PANEL SYSTEM

OPTIONS AND CONFIGURATIONS





FRAME SUB



125

Scorpion 4525-520Kv

Scorpion 4530-540Kv

Scorpion 4530-500Kv

145

Scorpion 4530-450Kv

Scorpion 4535-450Kv



INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD

TAIL AND HUB

BATTERY TRAY

MAIN AND TAIL BLADES

PANEL SYSTEM

OPTIONS AND CONFIGURATIONS




RECOMMENDED PROCEDURE

- 1. Loosely install the pinion onto the motor shaft without set screw.
- 2. Install the motor mount.

- 3. Do not fully tighten bolts yet.
- 4. Adjust pinion height on the following page.









INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD

TAIL AND HUB

BATTERY TRAY

MAIN AND TAIL BLADES

PANEL SYSTEM

OPTIONS AND CONFIGURATIONS


WWW.SYNERGYRCHELICOPTERS.COM

MOTOR MOUNTING




RECOMMENDED PROCEDURE

- 1. Verify the pinion is resting on lower support bearing
- 2. Secure the pinion with M4x6 set screw using RED thread lock against the flat spot on the motor shaft.
- 3. Adjust pinion mesh on the following page.











INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD

TAIL AND HUB

BATTERY TRAY

MAIN AND TAIL BLADES

PANEL SYSTEM


OPTIONS AND CONFIGURATIONS



MAIN GEAR MESH ADJUSTMENT



- 1. Loosen bolts that secure the motor mount and lower motor shaft support block.
- 2. Slide the assembly to fully mesh with main gear.
- 3. Adjust the assembly to obtain 0.1-0.2mm gear backlash
- 4. Fully tighten all motor mount bolts.









INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD

TAIL AND HUB


BATTERY TRAY

MAIN AND TAIL BLADES

PANEL SYSTEM















INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD


TAIL AND HUB

BATTERY TRAY

MAIN AND TAIL BLADES

PANEL SYSTEM









INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD

TAIL AND HUB

BATTERY TRAY

MAIN AND TAIL BLADES


PANEL SYSTEM

OPTIONS AND CONFIGURATIONS



CYCLIC SERVO ARMS & ELEVATOR SERVO

CARBON FIBER SERVO ARMS (3)





PIVOT BALL LOCATION

If you choose not to use the provided servo arms, the pivot ball should be positioned as close to 20mm as possible. Use appropriate arm for your servo manufacturer.



<u>.</u>

Components that are factory assembled provide a reference for model assembly. Disassembly and application of thread lock is required where indicated.

INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD


TAIL AND HUB

BATTERY TRAY

MAIN AND TAIL BLADES

PANEL SYSTEM









INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD

TAIL AND HUB

BATTERY TRAY


MAIN AND TAIL BLADES


PANEL SYSTEM

OPTIONS AND CONFIGURATIONS



ELEVATOR SERVO ARM INSTALLATION





[']••••••••••••••••

INSTALL SERVO ARM AT 90 DEGREES

USING THE SETUP PROCEDURE FOR

YOUR SPECIFIC FBL UNIT.

ELEVATOR CYCLIC ARM





INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD


TAIL AND HUB

BATTERY TRAY

MAIN AND TAIL BLADES

PANEL SYSTEM









INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD

TAIL AND HUB

BATTERY TRAY


MAIN AND TAIL BLADES


PANEL SYSTEM

OPTIONS AND CONFIGURATIONS



FRONT CYCLIC SERVO ARMS





SERVO ARM SCREW

INSTALL SERVO ARM AT 90 DEGREES USING THE SETUP PROCEDURE FOR YOUR SPECIFIC FBL UNIT.





INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD


TAIL AND HUB

BATTERY TRAY

MAIN AND TAIL BLADES

PANEL SYSTEM











INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD

TAIL AND HUB

16.0mm


BATTERY TRAY


MAIN AND TAIL BLADES


PANEL SYSTEM

OPTIONS AND CONFIGURATIONS











PIVOT BALL LOCATION

Pivot ball should be positioned as close to 16mm as possible. Use appropriate arm for your servo manufacturer.





<u>(!)</u>

Components that are factory assembled provide a reference for model assembly. Disassembly and application of thread lock is required where indicated.

INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD

TAIL AND HUB

BATTERY TRAY

MAIN AND TAIL BLADES

PANEL SYSTEM

OPTIONS AND CONFIGURATIONS






200-402 Swash Plate Assembly 12mm



Secure swash pinch bolt to remove inner swash play!

100-310 M3x10 Socket Head









INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD

TAIL AND HUB

BATTERY TRAY


MAIN AND TAIL BLADES

PANEL SYSTEM

OPTIONS AND CONFIGURATIONS



SWASH PLATE PIVOT BALLS






SWASH PIVOT BALLS

Inner swash ring contains four (4) SHORT pivot balls. Apply RED thread lock to secure.

DO NOT OVER TIGHTEN!

Outer swash ring contains three (3) LONG pivot balls. Apply RED thread lock to secure.







INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD

TAIL AND HUB

BATTERY TRAY

MAIN AND TAIL BLADES


PANEL SYSTEM

OPTIONS AND CONFIGURATIONS




CYCLIC TURNBUCKLE LINKAGES

IMPORTANT!! TURNBUCKLES AND PLASTIC LINKS MUST BE CHANGED AFTER A CRASH. STRESS FRACTURE TO LINKAGE IS NOT ALWAYS VISIBLE.



THREAD INDICATORS AND LINKAGE ORIENTATION

Notice thread indicator mark - this groove indicates left hand threaded side while the opposite side of the link is right hand threaded. Orient all linkages the same for adjustment symmetry.







INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD

TAIL AND HUB

BATTERY TRAY


MAIN AND TAIL BLADES

PANEL SYSTEM

OPTIONS AND CONFIGURATIONS



SWASH INSTALLATION & LINKAGE ARMS









INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD

TAIL AND HUB

BATTERY TRAY

MAIN AND TAIL BLADES


PANEL SYSTEM


OPTIONS AND CONFIGURATIONS





LEVEL SWASH PLATE USING THE SETUP PROCEDURE FOR YOUR SPECIFIC FBL UNIT.







INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD

TAIL AND HUB

BATTERY TRAY


MAIN AND TAIL BLADES

PANEL SYSTEM

OPTIONS AND CONFIGURATIONS










106-103 10x1.0mm Washer is located between









INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD

TAIL AND HUB

BATTERY TRAY

MAIN AND TAIL BLADES

PANEL SYSTEM

OPTIONS AND CONFIGURATIONS






HEAD PART 1 OF 3



The Synergy 766 allows for various flight styles, head speeds, and rotor sizes by utilizing an adjustable head damping system.

The standard configuration consists of (2) 90 durometer and (2) 80 durometer dampers suitable for 766mm blades running at an optimum head speed of 1950rpm.

Note: Lower RPM may require softer damping and higher RPM may require stiffer damping.





✓ GREASE COMPONENTS

Apply grease to the dampers and Axle Pivot prior to installation.

57





INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD

TAIL AND HUB

BATTERY TRAY

MAIN AND TAIL BLADES


PANEL SYSTEM

OPTIONS AND CONFIGURATIONS



HEAD ASSEMBLY

HEAD PART 2 OF 3



Apply grease to the head axle prior to inserting.





INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD

TAIL AND HUB

BATTERY TRAY

MAIN AND TAIL BLADES


PANEL SYSTEM

OPTIONS AND CONFIGURATIONS





HEAD PART 3 OF 3







INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD

TAIL AND HUB

BATTERY TRAY


MAIN AND TAIL BLADES

PANEL SYSTEM

OPTIONS AND CONFIGURATIONS



SWASH FOLLOWER ARMS







INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD

TAIL AND HUB

BATTERY TRAY

MAIN AND TAIL BLADES


PANEL SYSTEM

OPTIONS AND CONFIGURATIONS



HEAD & SWASH FOLLOWERS INSTALLATION









INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD

TAIL AND HUB

BATTERY TRAY

MAIN AND TAIL BLADES

PANEL SYSTEM


OPTIONS AND CONFIGURATIONS



PITCH TURNBUCKLE LINKAGES


IMPORTANT!! TURNBUCKLES AND PLASTIC LINKS MUST BE CHANGED AFTER A CRASH. STRESS FRACTURE TO LINKAGE IS NOT ALWAYS VISIBLE.

107-100 Ball Link (4)





Notice thread indicator mark - Orient all linkages the same for adjustment symmetry.







INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD

TAIL AND HUB

BATTERY TRAY


MAIN AND TAIL BLADES

PANEL SYSTEM

OPTIONS AND CONFIGURATIONS



PITCH LINK INSTALLATION





<u>(1)</u>

Components that are factory assembled provide a reference for model assembly. Disassembly and application of thread lock is required where indicated.

INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD

TAIL AND HUB

BATTERY TRAY


MAIN AND TAIL BLADES

PANEL SYSTEM

OPTIONS AND CONFIGURATIONS



TORQUE TUBE BEARING SUPPORTS



Optional 160.0mm 230.0mm 200.0mm





INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD


TAIL AND HUB

BATTERY TRAY

MAIN AND TAIL BLADES

PANEL SYSTEM







<u>(1)</u>

Components that are factory assembled provide a reference for model assembly. Disassembly and application of thread lock is required where indicated.

INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD

TAIL AND HUB


BATTERY TRAY

MAIN AND TAIL BLADES

PANEL SYSTEM

OPTIONS AND CONFIGURATIONS





66





INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD

TAIL AND HUB

BATTERY TRAY

MAIN AND TAIL BLADES


PANEL SYSTEM

Optional

for 716

OPTIONS AND CONFIGURATIONS





766-305 Carbon Tail Control Rod 720mm

Optional 716 Length 720.0mm





INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD

TAIL AND HUB

BATTERY TRAY

MAIN AND TAIL BLADES


PANEL SYSTEM

OPTIONS AND CONFIGURATIONS



TAIL BOOM GUIDES

INSTALL BOOM CLAMP AND TAIL CONTROL GUIDES



INSERT TAIL ROD GUIDE AND THREAD ON BALL LINK







INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD

TAIL AND HUB

BATTERY TRAY

MAIN AND TAIL BLADES

PANEL SYSTEM


OPTIONS AND CONFIGURATIONS








•••••••




CORRECT INSTALLATION



INCORRECT INSTALLATION











INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD


TAIL AND HUB

BATTERY TRAY

MAIN AND TAIL BLADES

PANEL SYSTEM









INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD


TAIL AND HUB

BATTERY TRAY

MAIN AND TAIL BLADES

PANEL SYSTEM









INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD

TAIL AND HUB

BATTERY TRAY

MAIN AND TAIL BLADES

PANEL SYSTEM

OPTIONS AND CONFIGURATIONS






carbon support rod. Allow to cure then proceed to pin the support rods with M3x12 set screws. Sand carbon before applying glue.

Both ends should be exactly parallel with each other.



BOOM SUPPORT RODS







INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD

TAIL AND HUB

BATTERY TRAY

MAIN AND TAIL BLADES

PANEL SYSTEM


OPTIONS AND CONFIGURATIONS




BOOM SUPPORT RODS INSTALLATION



Apply BLUE thread lock and secure all bolts.







INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD

TAIL AND HUB

BATTERY TRAY

MAIN AND TAIL BLADES


PANEL SYSTEM

OPTIONS AND CONFIGURATIONS



TAIL ASSEMBLY

TAIL BOX RIGHT SIDE





PREASSEMBLED COMPONENTS

The 766-400 Tail Box contains radial bearings and mushroom bevel gear preassembled from the factory that does not require disassembly.

Tip: If repair and disassembly is required, freeze components to easily remove mushroom gear.

Head until fitting the tail box to the boom on

This bolt will pin the tail box into the boom to provide additional support and prevent twisting.



<u>(1)</u>

Components that are factory assembled provide a reference for model assembly. Disassembly and application of thread lock is required where indicated.

INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD

TAIL AND HUB

BATTERY TRAY

MAIN AND TAIL BLADES

PANEL SYSTEM

burrs or other obstacles.

Tighten and secure 100-366 M3x6 Set Screw with blue thread lock. This set screw secures the bevel gear pin.


OPTIONS AND CONFIGURATIONS





TAIL BOX LEFT SIDE





75



<u>(!)</u>

Components that are factory assembled provide a reference for model assembly. Disassembly and application of thread lock is required where indicated.

INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD

TAIL AND HUB

BATTERY TRAY

MAIN AND TAIL BLADES


PANEL SYSTEM

OPTIONS AND CONFIGURATIONS



TAIL ASSEMBLY

TAIL PITCH SLIDER



322 Tail Pitch Link



LINKAGE SIZING


Delrin is strong, flexible yet expands and contracts with changing temperature. For best results use Boto-Sizer tool part #700-001 to properly size all linkages for your specific climate.



PITCH LINKS AND PINS

Pitch links are directional and should only be installed on the ball in the proper direction. Take care to observe large and small opening of the link.

Link Pins can be installed from either side.







INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD

TAIL AND HUB

BATTERY TRAY

MAIN AND TAIL BLADES


PANEL SYSTEM


OPTIONS AND CONFIGURATIONS





TAIL HUB AND TAIL GRIPS







Use the tail hub to help determine which sides are the inside and outside halves:

Loose Fit
(Large Inside Diameter)

(Small Inside Diameter)



INSIDE

OUTSIDE

IMPORTANT!

106-501 5mm Shim is located between Outside Thrust and Radial Bearing.



Apply Grease to each thrust bearing component! For optimum performance, use extreme pressure synthetic grease, Boto-Lube Part BD-001.

106-501 5mm Shim

108-503 5x10x3 Radial Bearing

100-354 M3 Washer

100-308 M3x8 Socket Head



RED THREAD LOCK





INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD

TAIL AND HUB

BATTERY TRAY

MAIN AND TAIL BLADES


PANEL SYSTEM

OPTIONS AND CONFIGURATIONS



TAIL ASSEMBLY

TAIL PITCH ARM ASSEMBLY







INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD

TAIL AND HUB

BATTERY TRAY

MAIN AND TAIL BLADES


PANEL SYSTEM

OPTIONS AND CONFIGURATIONS



TAIL ASSEMBLY

TAIL HUB AND PITCH SLIDER MOUNTING







INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD

TAIL AND HUB

BATTERY TRAY

MAIN AND TAIL BLADES


PANEL SYSTEM

OPTIONS AND CONFIGURATIONS



TAIL ASSEMBLY

TAIL HUB SET SCREW







INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD

TAIL AND HUB

BATTERY TRAY


MAIN AND TAIL BLADES


PANEL SYSTEM

OPTIONS AND CONFIGURATIONS



TAIL MOUNTING







4-5 DEGREES AGAINST TORQUE

Tail blades should be 4-5 degrees against torque at center tail servo position. Following the setup procedure for your specific FBL unit to position the tail servo at center.

APPLY BLUE THREAD LOCK TO ALL BOLTS

81







INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD

TAIL AND HUB


BATTERY TRAY

MAIN AND TAIL BLADES

PANEL SYSTEM

OPTIONS AND CONFIGURATIONS





WWW.SYNERGYRCHELICOPTERS.COM





INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD


TAIL AND HUB

BATTERY TRAY

MAIN AND TAIL BLADES

PANEL SYSTEM









INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD

TAIL AND HUB


BATTERY TRAY

MAIN AND TAIL BLADES

PANEL SYSTEM











INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD

TAIL AND HUB

BATTERY TRAY


MAIN AND TAIL BLADES

PANEL SYSTEM

OPTIONS AND CONFIGURATIONS




TAIL BLADE INSTALLATION



The key point here is to have both bolts tightened equally so the tail blades can lead\lag equally. Both tail blades should be able to move with the same amount of force.









INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD


TAIL AND HUB

BATTERY TRAY

MAIN AND TAIL BLADES

PANEL SYSTEM









INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD

TAIL AND HUB

BATTERY TRAY


MAIN AND TAIL BLADES

PANEL SYSTEM

OPTIONS AND CONFIGURATIONS



NOSE PANEL ASSEMBLY







INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD

TAIL AND HUB

BATTERY TRAY

MAIN AND TAIL BLADES

PANEL SYSTEM









INTRODUCTION

SPECIFICATIONS

FRAME SIDE 1

TRANSMISSION

MAIN BEARING BLOCKS

FRAME SIDE 2

LANDING GEAR

MAIN DRIVE

MOTOR

SERVO INSTALLATION

SWASH PLATE

SWASH PLATE LINKAGES

HEAD ASSEMBLY

PITCH LINKAGES

TORQUE TUBE / BOOM / CONTROL ROD

TAIL AND HUB

BATTERY TRAY

MAIN AND TAIL BLADES

PANEL SYSTEM

OPTIONS AND CONFIGURATIONS



CONFIGURATIONS

MAXIMUM SUPPORTED HEAD SPEEDS: To maximize efficiency of the power system, increase longevity of all rotating parts and bearings, and minimize mechanical stresses, each blade configuration has a maximum supported head speed. The recommended governor settings are also provided as a general starting point.

Choose a tail configuration based on your highest head speed condition, typically IDLE UP 2. Theses calculations are based on thrust provided near or at maximum allowed tail RPM. Maximum tail RPM for 106mm blades: 10,500 rpm. Maximum tail RPM for 116mm blades: 9,500 rpm.

716 716mm Main Blades

MAX SUPPORTED HEAD SPEED: 2250 RPM

Boom: 766-301

Tail Control Rod: 766-305 Torque Tube: 320-509

Boom Supports: 315-117 or 766-304

Motor and Battery Configurations

12S LIPO	560Kv	520Kv	500Kv	450Kv	400Kv
12T (11.6:1)* 13T (10.7:1) 14T (9.9:1)* 15T (9.3:1)*	1950 2100 2250	1800 1950 2100 2250	1750 1850 2000 2150	1550 1700 1800 1950	1400 1500 1600 1750
14S LIPO **** 12T (11.6:1)* 13T (10.7:1) 14T (9.9:1)* 15T (9.3:1)*	••••••	2100 2250	2000 2200	1800 1950 2100 2250	1600 1750 1875 2000

Tail Blade and Tail Drive Ratio Configurations

HEAD SPEED	DRIVE RATIO	BLADES
UP TO 1850	5.1:1 (Optional 25T*)	116mm+
1900-2150	4.7:1 (Standard 27T)	116mm
2200-2250	4.5:1 (Optional 28T*)	106mm

766 766mm Main Blades

MAX SUPPORTED HEAD SPEED: 2050 RPM

Boom: 766-302

Tail Control Rod: 766-306 Torque Tube: 320-510 Boom Supports: 766-304

Motor and Battery Configurations

12S LIPO	520Kv	500Kv	450Kv	400Kv
12T (11.6:1)* 13T (10.7:1) 14T (9.9:1)*	1800 1950	1750 1850 2000	1550 1700 1800 1950	1400 1500 1600 1750
15T (9.3:1)* 14S LIPO 12T (11.6:1)* 13T (10.7:1) 14T (9.9:1)* 15T (9.3:1)*	2050	2000	1800 1950 2050	1600 1750 1875 2000

Tail Blade and Tail Drive Ratio Configurations

HEAD SPEED	DRIVE RATIO	BLADES
UP TO 1850	5.1:1 (Optional 25T*)	116mm+
1900-2050	4.7:1 (Standard 27T)	116mm

806mm Main Blades

MAX SUPPORTED HEAD SPEED: 1900 RPM

Boom: 766-303

Tail Control Rod: 766-307 Torque Tube: 320-511 Boom Supports: 766-304

Motor and Battery Configurations

12S LIPO	520Kv	500Kv	450Kv	400Kv	••
12T (11.6:1)* 13T (10.7:1) 14T (9.9:1)* 15T (9.3:1)*	1800 1900	1750 1850	1550 1700 1800 1900	1400 1500 1600 1750	
145 LIPO	••••••	1900	1800 1900	1600 1750 1900	••

Tail Blade and Tail Drive Ratio Configurations

HEAD SPEED	DRIVE RATIO	BLADES
UP TO 1850	5.1:1 (Optional 25T*)	116mm+
1900	4.7:1 (Standard 27T)	116mm

OPTIONAL PARTS: 12T Pinion: 305-012H 14T Pinion: 305-014H

15T Pinion: 305-015H

25T Tail Pinion: 766-625H 28T Tail Pinion: 766-628H

8MM SHAFT PINIONS 13T PINION: 766-505H

14T PINION: 766-506H