

Introduction & Features

The VS41 is an intelligent 4 camera switcher for controlling front, rear, and blind spot cameras. Manually connect cameras and trigger wires, or connect to a BCI-, RP4.2-, or RP5.2-module's Expansion Port for full digital control, and fast easy connectivity. VS41 accepts pulsed or constant inputs.

Important Notes

1. If you are using the VS41 with another PAC interface, such as a BCI-, RP4.2-, or RP5.2-, with an Expansion Port, simply connect the 10-pin connector into the module. Do not manually wire the positive or negative trigger wires. The BCI-, RP4.2-, or RP5.2- module will digitally control the VS41 switching operation when connected to the Expansion Port.
2. The VS41 video output will always default to the signal from Input 1 when none of the input triggers are activated. This Input is ideal for connecting the rear (reverse) camera.
3. The VS41 inputs have priority in descending numerical order. For example: If you have Input 3 or 4 triggered, then you trigger a lower number input (for example Input 2), Input 2 will take priority over the higher numbered Input.
4. The input triggers can accept either a pulsed or constant input, making them ideal for connecting to a turn signal as a trigger.
5. The reverse trigger output will provide a 150 mA 12v (+) trigger while any of the input triggers are activated.
6. Upon deactivation of the last positive or negative trigger, the last video input source and the reverse trigger output will remain active for an additional 3 seconds. (Not applicable when used with a BCI-, RP4.2-, or RP5.2- interface).
7. If there is poor video quality after installation of this module, please ensure quality connections on any RCA connections.
8. Positive Input triggers accept input voltages in the range of 2v to 12v.

Wiring Connection Chart

