



Function Key Programming

NEO HS2016 / HS2083 / HS2064 / HS2128 v1.3

All NEO keypads have five Function Keys that can provide the quick activation of a preprogrammed function. Each keypad can be programmed with different functions.

Function Keys are defaulted as:

- Function Key 1: Stay Arm (03)
- Function Key 2: Away Arm (04)
- Function Key 3: Chime On/Off (06)
- Function Key 4: Command Output 2 (22)
- Function Key 5: Quick Exit (16)

Function Keys can be reprogrammed to provide any of the operations listed below:

| Function Key Programming Options: | | |
|-----------------------------------|--------------------------|----------------------------|
| 00 - Null Key | 17 - Arm Interior | 37 - Time/Date Programming |
| 02 - Instant Stay Arm | 21 - Command Output 1 | 39 - Trouble Display |
| 03 - Stay Arm | 22 - Command Output 2 | 40 - Alarm Memory |
| 04 - Away Arm | 23 - Command Output 3 | 61 - Partition Select 1 |
| 05 - [*][9]No Entry Arm | 24 - Command Output 4 | 62 - Partition Select 2 |
| 06 - Chime On/Off | 29 - Bypass Group Recall | 63 - Partition Select 3 |
| 07 - System Test | 31 - Local PGM Active | 64 - Partition Select 4 |
| 09 - Night Arm | 32 - Bypass Mode | 65 - Partition Select 5 |
| 12 - Global Stay Arm ** | 33 - Bypass Recall | 66 - Partition Select 6 |
| 13 - Global Away Arm ** | 34 - User Programming | 67 - Partition Select 7 |
| 14 - Global Disarming | 35 - User Functions | 68 - Partition Select 8 |
| 16 - Quick Exit | | |

➤ **Tech Tip:** ** Be cautious when using the Global Stay Arm (12) or Global Away Arm (13). If a partition is 'Not Ready' the system will not arm it.

| [860] Display Keypad Slot Number | | |
|---|--|---|
| [861] [876] Keypad Programming | | |
| Refer to the installation instructions provided with the keypads for details. | | |
| 000 – Keypad Partition Mask | 00 – Global | |
| | 01 – <input checked="" type="checkbox"/> Partition 1 | 05 – <input type="checkbox"/> Partition 5 |
| | 02 – <input type="checkbox"/> Partition 2 | 06 – <input type="checkbox"/> Partition 6 |
| | 03 – <input type="checkbox"/> Partition 3 | 07 – <input type="checkbox"/> Partition 7 |
| | 04 – <input type="checkbox"/> Partition 4 | 08 – <input type="checkbox"/> Partition 8 |
| 001 – Function Key 1 (Default: 03): | | |
| 002 – Function Key 2 (Default: 04): | | |
| 003 – Function Key 3 (Default: 06): | | |
| 004 – Function Key 4 (Default: 22): | | |
| 005 – Function Key 5 (Default: 16): | | |

Function Key Programming

Panel Programming:

[] = NEO Panel Section / Solid ~ Red Lock light in programming /
 { } = NEO Subsection / Single Flashing ~ Red Lock light in programming /
 () = Data / Solid ~ Green Check light in programming /

Section [860] Verify the keypad's supervisory slot number.

- **Tech Tip:** The keypad slot number can be viewed in Section [860] at the desired keypad. [*] [8] [Installer Code] [860]

Section [861 - 876] Specific keypad programming options for Keypad 1 – 16.

{001} Function Key 1
 {002} Function Key 2
 {003} Function Key 3
 {004} Function Key 4
 {005} Function Key 5

- **Tech Tip:** Each keypad in the NEO has its own programming section which can be accessed in programming from any keypad.

Section [861] = Keypad #1

Section [862] = Keypad #2

•
•
•

Section [876] = Keypad #16

Favorites:

- For customers that do not want an exit delay when arming in the Stay Arm, use the **Instant Stay Arm (02)**. This feature will provide an instant Stay Arm condition with zero exit delay.
- For CP-01 compliant panels (USA market), to arm in the Away Arm a zone assigned to zone type Delay1 or Delay2 needs to open or* close within the exit delay. By using the **Night Arm (09)** you can force the panel into the "Away Arm" without having to open and close a delay door. Great for the Master bedroom keypad.
 - **Special Note:** The Night Arm feature will bypass any zone assigned to zone type Night Zone (012). Therefore, this feature does not arm the panel into the Away Arm completely if you are using the Night Zone feature.

Function Key Programming



● = Function Key location

- **Tech Tip:** On the HS2LCD, HS2ICN, HS2LED style keypads, Press and Hold the function key for at least 2 seconds. Shorter hold times will not activate the function. Tell your customers 5 seconds!



- **Tech Tip:** Function Key 2 on the HS2TCHP touchscreen should not be changed. This key must stay as Away Arm (04) to be operational.