


home®



Microwave Oven
1.3 Cubic Feet

Before using your Microwave Oven, please read this manual.
This manual is to be used with hOme's Microwave Oven, SKU: HMW010002N (Model: EM036AT3).

USER MANUAL TABLE OF CONTENTS

Precautions to Avoid Possible Exposure to Excessive Microwave Energy	5
Specifications	5
Important Safety Instructions	6
Grounding Instructions	7
Radio Interference	7
Safety	8
Utensils	8
Material you can use in Microwave Oven	9
Materials to be avoided in Microwave Oven	10
Setting Up Your Oven	10
Countertop Installation	11
Installation	11
Operation	12-15
Maintenance	16
Warranty	17
Warning	17



CONGRATULATIONS

...on purchasing your new hOme® appliance!

Don't forget to register your product at www.home.family/reg for updates, coupons, and other relevant information.

Although greatly appreciated, product registration is not required to activate any warranty.



PRECAUTIONS TO AVOID POSSIBLE EXPOSURE TO EXCESSIVE MICROWAVE ENERGY

When using electrical appliances, basic safety precautions should always be followed, including the following:

- A. Do not attempt to operate this oven with the door open since open-door operation can result in harmful exposure to microwave energy.
- B. It is important not to defeat or tamper with the safety interlocks.
- C. Do not place any object between the oven front face and the door or allows soil or cleaner residue to accumulate on sealing surfaces.
- D. Do not operate the oven if it is damaged. It is particularly important that the oven door close properly and that there is no damage to the:
 - (1) DOOR (bent)
 - (2) HINGES AND LATCHES (broken or loosened)
 - (3) DOOR SEALS AND SEALING SURFACES
- E. The oven should not be adjusted or repaired by anyone except properly qualified service personnel.

SPECIFICATIONS

SKU:	HME010002N
Model:	EM036AT3
Rated Voltage:	120V ~ 60Hz
Rated Input Power (Microwave):	1500W
Rated Output Power (Microwave):	1000W
Oven Capacity:	36L
Turntable Diameter:	12.4 inches
External Dimensions:	20.4 x 16.8 x 12.4 inches
Net Weight:	33.5 pounds

SAVE THESE INSTRUCTIONS / HOUSEHOLD USE ONLY

When using electrical appliances basic safety precautions should be followed, including the following:

WARNING - To reduce the risk of burns, electric shock, fire, injury to persons or exposure to excessive microwave energy:

1. Read all instructions before using the appliance.
2. Install or locate this appliance only in accordance with the provided installation instructions.
3. Read and follow the specific: "PRECAUTIONS TO AVOID POSSIBLE EXPOSURE TO EXCESSIVE MICROWAVE ENERGY" found on page 4.
4. Some products such as whole eggs and sealed containers - for example, closed glass jars - are able to explode and should not be heated in this oven.
5. Use this appliance only for its intended use as described in the manual. Do not use corrosive chemicals or vapors in this appliance. This type of oven is specifically designed to heat, cook or dry food. It is not designed for industrial or laboratory use.
6. This appliance must be grounded. Connect only to properly grounded outlet. See "GROUNDING INSTRUCTIONS" found on page 6.
7. As with any appliance, close supervision is necessary when used by children.
8. Do not operate this appliance if it has a damaged cord or plug, if it is not working properly, or if it has been damaged or dropped.
9. This appliance should be serviced only by qualified service personnel. Contact hOme® Customer Service at 1-800-898-3002 for examination, etc.
10. Do not cover or block any openings on the appliance.
11. Do not store this appliance outdoors. Do not use this product near water - for example, near a kitchen sink, in a wet basement, near a swimming pool, or similar location.
12. Do not immerse cord or plug in water.
13. Keep cord away from heated surface.
14. Do not let cord hang over edge of table or counter.
15. When cleaning surfaces of door and oven that comes together on closing the door, use only mild, nonabrasive soaps, or detergent applied with a sponge or soft cloth.
16. To reduce the risk of fire in the oven cavity:
 - 1). Do not overcook food. Carefully attend appliance when paper, plastic, or other combustible materials are placed inside the oven to facilitate cooking.
 - 2). Remove wire twist-ties from paper or plastic bag before placing bag in oven.
 - 3). If material inside of the oven ignite, keep oven door closed, turn oven off, and disconnect the power cord, or shut off power at the fuse or circuit breaker panel.
 - 4). Do not use the cavity for storage purposes. Do not leave paper products, cooking utensils, or food in the cavity when not in use.
17. Liquids, such as water, coffee, or tea are able to be overheated beyond the boiling point without appearing to be boiling. Visible bubbling or boiling when the container is removed from the microwave oven is not always present.

THIS COULD RESULT IN VERY HOT LIQUID SUDDENLY BOILING OVER WHEN THE CONTAINER IS DISTURBED OR A UTENSIL IS INSERTED INTO THE LIQUID.

 **WARNING**

To reduce the risk of injury to persons:

1. Do not overheat the liquid.
2. Stir the liquid both before and halfway through heating it.
3. Do not use straight-sided containers with narrow necks.
4. After heating, allow the container to stand in the microwave oven for a short time before removing the container.
5. Use extreme care when inserting a spoon or other utensil into the container.

GROUNDING INSTRUCTIONS

This appliance must be grounded. In the event of an electrical short circuit, grounding reduces the risk of electric shock by providing an escape wire for the electric current. This appliance is equipped with a cord having a grounding wire with a grounding plug. The plug must be plugged into an outlet that is properly installed and grounded.

WARNING

Improper use of the grounding can result in a risk of electric shock.

Consult a qualified electrician or serviceman if the grounding instructions are not completely understood, or if doubt exists as to whether the appliance is properly grounded. If it is necessary to use an extension cord, use only a 3-wire extension cord that has a 3-blade grounded plug, and 3-slot receptacle that will accept the plug on the appliance. The marked rating of the extension cord shall be equal to or greater than the electrical rating of the appliance.

DANGER

Electric Shock Hazard

Touching some of the internal components can cause serious personal injury or death. Do not disassemble this appliance.

WARNING

Electric Shock Hazard

Improper use of the grounding can result in electric shock. Do not plug into an outlet until appliance is properly installed and grounded.

1. A short power-supply cord is provided to reduce the risks resulting from becoming entangled in or tripping over a longer cord.
2. Longer cord sets or extension cords are available and may be used if care is exercised in their use.
3. If a long cord or extension cord is used:
 - 1) The marked electrical rating of the cord set or extension cord should be at least as great as the electrical rating of the appliance.
 - 2) The extension cord must be a grounding-type 3-wire cord.
 - 3) The longer cord should be arranged so that it will not drape over the counter top or tabletop where it can be pulled on by children or tripped over unintentionally.

RADIO INTERFERENCE

1. Operation of the microwave oven may cause interference to your radio, TV or similar equipment.
2. When there is interference, it may be reduced or eliminated by taking the following measures:
 - 1) Clean door and sealing surface of the oven
 - 2) Reorient the receiving antenna of radio or television.
 - 3) Relocate the microwave oven with respect to the receiver.
 - 4) Move the microwave oven away from the receiver.
 - 5) Plug the microwave oven into a different outlet so that microwave oven and receiver are on different branch circuits.

SAFETY

1. The oven must be on a leveled surface.
2. The turntable and turntable roller rest must be in the oven during cooking. Place the cookware gently on the turntable and handle it carefully to avoid possible breakage.
3. Incorrect use of browning dish may cause the turntable to break.
4. Use only the specified bag size when using Direct Access Popcorn.
5. The oven has several built-in safety switches to ensure that the power remains off when the door is open. Do not tamper with these switches.
6. Do not operate the microwave oven empty. Operating the oven with no food or food that is extremely low in moisture can cause fire, charring or sparking.
7. Do not cook bacon directly on the turntable. Excessive local heating of the turntable may cause the turntable to break.
8. Do not heat baby bottles or baby food in the microwave oven. Uneven heating may occur and could cause physical injury.
9. Do not heat narrow-necked containers, such as syrup bottles.
10. Do not attempt to deep-fry in your microwave oven.
11. Do not attempt home canning in this microwave oven, as it is impossible to be sure all contents of the jar have reached boiling temperature.
12. Do not use this microwave oven for commercial purpose. This microwave oven is made for household use only.
13. To prevent delayed eruptive boiling of hot liquids and beverages or scalding yourself, stir liquid before placing the container in the oven and again halfway through cooking time. Let stand in the oven for a short time and stir again before removing the container.
14. Use carefully when cooking food in the microwave oven to avoid burning due to excessive cooking.
15. When the appliance is operated in the combination mode, children should only use the oven under adult supervision due to the temperatures generated.
16. Failure to maintain the oven in a clean condition could lead to deterioration that could adversely affect the life of the appliance and possibly result in a hazardous situation.

UTENSILS



CAUTION

Personal Injury Hazard

Tightly-closed utensils could explode. Closed containers should be opened and plastic pouches should be pierced before cooking.

See the instructions on “Materials you can use in microwave oven or to be avoided in microwave oven.”

There may be certain non-metallic utensils that are not safe to use for microwaving. If in doubt, you can test the utensil in question following the procedure below.

Utensil Test:

1. Fill a microwave-safe container with 1 cup of cold water (250ml) along with the utensil in question.
2. Cook on maximum power for 1 minute.
3. Carefully feel the utensil. If the empty utensil is warm, do not use it for microwave cooking.
4. Do not exceed 1 minute cooking time.

MATERIAL YOU CAN USE IN MICROWAVE OVEN

Before calling for hOme® customer service, review this list. It may save your time and expense. This list includes common occurrences that are not the result of defective workman-ship or materials in this appliance.

UTENSILS	REMARKS
Aluminum foil	Shielding only. Small smooth pieces can be used to cover thin parts of meat or poultry to prevent overcooking. Arcing can occur if foil is too close to oven walls. The foil should be at least 1 inch (2.5cm) away from oven walls.
Browning dish	Follow manufacturer instructions. The bottom of browning dish must be at least 3/16 inch (5mm) above the turntable. Incorrect usage may cause the turntable to break.
Dinnerware	Microwave-safe only. Follow manufacturer's instructions. Do not use cracked or chipped dishes.
Glass jars	Always remove lid. Use only to heat food until just warm. Most glass jars are not heat resistant and may break.
Glassware	Heat-resistant oven glassware only. Make sure there is no metallic trim. Do not use cracked or chipped dishes.
Oven cooking bags	Follow manufacturer* instructions. Do not close with metal tie. Make slits to allow steam to escape.
Paper plates and cups	Use for short term cooking/warming only. Do not leave oven unattended while cooking.
Paper towels	Use to cover food for reheating and absorbing fat. Use with supervision for short-term cooking only.
Parchment paper	Use as a cover to prevent splattering or a wrap for steaming.
Plastic	Microwave-safe only. Follow the manufacturer instructions. Should be labeled "Microwave Safe". Some plastic containers soften, as the food inside gets hot. "Boiling bags" and tightly closed plastic bags should be slit, pierced or vented as directed by package.
Plastic wrap	Microwave-safe only. Use to cover food during cooking to retain moisture. Do not allow plastic wrap to touch food. Microwave-safe only (meat and candy thermometers).
Thermometers Wax paper	Use as a cover to prevent splattering and retain moisture.

MATERIALS TO BE AVOIDED IN MICROWAVE OVEN


UTENSILS	REMARKS
Aluminum tray	May cause arcing. Transfer food into microwave-safe dish.
Food carton with metal handle	May cause arcing. Transfer food into microwave-safe dish.
Metal or metal- trimmed utensils	Metal shields the food from microwave energy. Metal trim may cause arcing.
Metal twist ties	May cause arcing and could cause a fire in the oven.
Paper bags	May cause a fire in the oven.
Plastic foam	Plastic foam may melt or contaminate the liquid inside when exposed to high temperature.
Wood	Wood will dry out when used in the microwave oven and may split or crack.

SETTING UP YOUR OVEN

Names of Oven Parts and Accessories


Remove the oven and all materials from the carton and oven cavity. Your oven comes with the following accessories:

- x1 - Glass Tray
- x1 - Turntable Ring Assembly
- x1 - Instruction Manual



Turntable Installation

- a. Never place the glass tray upside down. The glass tray should never be restricted.
- b. Both glass tray and turntable ring assembly must always be used during cooking.
- c. All food and containers of food are always placed on the glass tray for cooking.
- d. If glass tray or turntable ring assembly cracks or breaks, contact your nearest authorized service center.




COUNTERTOP INSTALLATION

Remove all packing material and accessories. Examine the oven for any damage such as dents or broken door. Do not install if oven is damaged.

Cabinet: Remove any protective film found on the microwave oven cabinet surface. Do not remove the light brown Mica cover that is attached to the oven cavity to protect the magnetron.

INSTALLATION

1. Select a level surface that provide enough open space for the intake and/or outlet vents.



A minimum clearance of 3.0 inches (7.5cm) is required between the oven and any adjacent walls. One side must be open.

1. Leave a minimum clearance of 12 inches (30cm) above the oven.
2. Do not remove the legs from the bottom of the oven.
3. Blocking the intake and/or outlet openings can damage the oven.
4. Place the oven as far away from radios and TV as possible. Operation of microwave oven may cause interference to your radio or TV reception.

2. Plug your oven into a standard household outlet. Be sure the voltage and the frequency is the same as the voltage and the frequency on the rating label.

WARNING

Do not install oven over a range cooktop or other heat-producing appliance. If installed near or over a heat source, the oven could be damaged and the warranty would be void.

OPERATION

1. Power Level

10 power levels are available.

LEVEL	10	9	8	7	6	5	4	3	2	1	0
POWER	100%	90%	80%	70%	60%	50%	40%	30%	20%	10%	0%
DISPLAY	PL10	PL9	PL8	PL7	PL6	PL5	PL4	PL3	PL2	PL1	PL0

2. Clock Setting

- (1) Press **"CLOCK"** once, "00:00" will display.
- (2) Press the number keys and enter the current time. For example, time is 12:10 now, please press "1, 2, 1, 0" in turn.
- (3) Press **"CLOCK"** to finish clock setting. ":" will flash and the clock will be lighted.
- (4) If the numbers input are not within the range of 1:00--12:59, the setting will be invalid until valid numbers are input.

NOTE:

- 1) In the process of clock setting, if the **"STOP/CANCEL"** button is pressed or if there is no operation within 1 minute, the oven will go back to the former setting automatically.
- 2) If the clock need to be reset, please repeat step 1 to step 3.

3. Kitchen Timer

- (1) Press **"TIMER"** once, the screen will display 00:00, the first hour figure flash.
- (2) Press the number keys and enter the timer time. (The maximum cooking time is 99 minutes and 99 seconds.)
- (3) Press **"START/+30SEC."** to confirm setting.
- (4) When the timer time arrives, the buzzer will ring 5 times.
If the clock has been set (12-hour system), the screen will display the current time.

NOTE:

- 1) The kitchen time is different from 12-hour system. Kitchen Timer is a timer.
- 2) During kitchen timer, any program cannot be set.

4. Microwave Cook

- (1) Press **"COOK TIME"** once, the screen will display 00:00.
- (2) Press number keys to input the cooking time; the maximum cooking time is 99 minutes and 99 seconds.
- (3) Press **"POWER LEVEL"** once, the screen will display "PL10". The default power is 100% power. Now you can press number keys to adjust the power level.
- (4) Press **"START/+30SEC."** to start cooking.

Example: to cook the food with 50% microwave power for 15 minutes:

- a. Press **"COOK TIME"** once. "00:00" displays.
- b. Press "1", "5", "0", "0" in order.
- c. Press **"POWER LEVEL"** once, then press "5" to select 50% microwave power.
- d. Press **"START/+30SEC."** to start cooking.

NOTE:

- 1) In the process of setting, if the **"STOP/CANCEL"** button is pressed or if there is no operation within five (5) minute, the oven will go back to the former setting automatically.
- 2) If "PL 0" selected, the oven will work with fan for no power. You can use this level to remove the odour of the oven.
- 3) During microwave cooking, **"POWER"** can be pressed to change the power you need. After pressing **"POWER"**, the current power flash for 3 seconds, now you can press number button to change the power. The oven will work with the selected power for the rest time.

5. Speedy Cooking

- (1) In waiting state, instant cooking at 100% power level can be started by select a cooking time from 1 to 3 minutes by pressing number pads 1 to 3. Press **"START/+30SEC."** to increase the cooking time; the maximum cooking time is 99 minutes and 99 seconds.
- (2) In waiting state, instant cooking at 100% power level with 30 seconds' cooking time can be started by pressing **"START/+30SEC"**. Each press on the same button will increase cooking time by 30 seconds. the maximum cooking time is 99 minutes and 99 seconds.
- (3) Press **"COOK TIME"** and then input the time. Press **"START/+30SEC."** button to start 100% power level cooking.

NOTE:

- (1) During microwave cooking and time defrost, time can be added by pressing **"START/+30SEC."** button.
- (2) Under sensor reheat and weight defrost, time cannot be added by **"START/+30SEC."** button.

6. Weight Defrost Function

- (1) Press **"WEIGHT DEFROST"** once, the screen will display "0.0".
- (2) Press numerical buttons to input weight to be defrosted.
Input the weight ranged between 0.3~6.3 lbs.
- (3) Press **"START/+30SEC."** to start defrosting and the cooking time remained will be displayed.

7. Time Defrost Function

- (1) Press **"TIME DEFROST"** once, the screen will display "00:00".
- (2) Press number pads to input defrosting time. The effective time range is 0:01~99:99.
- (3) The default microwave power is power level 3 and it cannot be changed.
- (4) Press **"START/+30SEC."** to start defrosting. The remained cooking time will be displayed.

8. Popcorn

- a) Press **"POPCORN"** repeatedly until the number you wish appears in the display, "3.0", "3.5", "1.75"Oz will display in order. For example, press **"POPCORN"** once, "3.0" appears.
- b) Press **"START/+30 SEC."** to cook, buzzer sounds once. When cooking finishes, buzzer will sound five times and then the screen will display the current time.

9. Sensor Reheat

- (1) In waiting state, put food in the microwave oven, then press **"SENSOR REHEAT"** button.
- (2) Press **"START/+30SEC."** to start sensor reheat function. There is no need to set time for this function.
- (3) The sensor will sound twice when the steaming is emanated. The surplus time will then display. The buzzer will sound 5 beeps when finishing. The oven will then return to standby state.

NOTE:

- 1) When cooking or reheating food, the below parameters should be followed for best results:
 - a. The room temperature cannot be over 95°F (35°C).
 - b. The weight of food must be more than 4oz (110g).
 - c. The cavity, glass tray, and utensils must be dry before putting the food in.
 - d. The food being reheated can be covered with a lid, but the lid must have ventholes in order to emanate the steam. Do not use sealed containers with Sensor Reheat. Damage can be caused to the microwave oven.
- 2) During the cooking process, the following must be done to insure best results and avoid any damage.
 - a. Keep the door closed until display shows cooking complete and/or the buzzer sounds twice.
 - b. When the buzzer sounds twice, the time will count down and display the surplus time. You can open the door to mix the food up, turn over and/or replace the food.
- 3) Please let food sit in microwave oven until cooled to avoid personal injury.
- 4) During Sensor Reheat, the time is not counting down, please do not open the oven door or press **"STOP/CANCEL"** key. This could cause the sensor to malfunction.

Sensor Cook Chart

MENU	WEIGHT	INITIAL TEMP.	ADDITIONAL INSTRUCTIONS
Sensor Reheat	8~12 Oz (225~340g)	41°F (5°C)	Reheat food on a plate or vented container. When sensor time finishes, cooking time counts down. You can mix food once cooking time is counting down then continue reheating.
Frozen Pizza	6~12 Oz (170~340g)	0°F (-18°C)	If the weight is over 12oz (340g), please set the additional cooking time manually.
Fish	4~16 g (110~450g)	41°F (5°)	Arrange in a single layer. Cover with lid or vented plastic wrap. Cover the film before cooking and leave a space near the edge of the container in order to let the steam out. When cooking time counts down, press STOP/CANCEL to pause and open the oven door to turn over and then continue to cook.
Meat	8~24 Oz (225~680g)	41°F (5°)	Break apart meat in a glass bowl or colander. Cover with lid or vented plastic wrap. Juices should be clear when done. When cooking time counts down, press STOP/CANCEL to pause and open the oven door to mix and then continue to cook.
Fresh Vegetable	4~16 Oz (110~450g)	Room Temp.	All pieces should be the same size. Wash thoroughly, add 1tbsp. (15ml) water per 0.25lb (125g) vegetables, and cover with a lid or vented plastic wrap. When cooking time counts down, press STOP/CANCEL to pause and open the oven door to mix and then continue to cook.
Frozen Vegetable	6~16 Oz (170~450g)	0°F (-18°C)	Wash thoroughly, add 1 tbsp. (15ml) water per 0.25lb (125g) vegetables, and cover with a lid or vented plastic wrap. Do not salt/butter vegetables until after cooking.
Potato	1~4 Units (6~8Oz each one)	Room Temp	Pierce each potato with a fork 6 times around it's surface. Place potatoes around the edge of a paper-towel-lined turntable. Do not cover. If additional time is needed, continue to cook manually. Please let potatoes sit for 5 minutes in the oven after finishing to avoid personal injury.
Frozen Entree	8~32 Oz (225~900g)	0°F (-18°C)	Cover the film before cooking and leave a space near the edge of the container in order to let the steam out. When buzzer sounds twice, cooking time counts down. Press STOP/CANCEL to pause and open the oven door mix. Be careful when removing the film cover after cooking. Remove facing away from you to avoid personal injury from steam being released. If additional time is needed, continue to cook manually.

Note:

1) Avoid the following foods when using the Sensor Reheat function:

- a. Bread and other dry food, such as a biscuit or cake.
- b. Raw or uncooked foods.
- c. Beverages and frozen foods.

2) The oven cannot cook automatically when the temperature of the oven cavity is high.

3) The Sensor Reheat function has different requests for different food.

Casseroles - Add 3 to 4 tablespoons of water, cover with lid or vented plastic wrap. Stir when time appears in the display window.

Canned foods - Empty contents into casserole dish or serving bowl, cover dish with lid or vented plastic wrap. After reheating, let stand for a few minutes.

Plate of food - Arrange food on plate; top with butter, gravy, etc. Cover with lid or vented plastic wrap. After reheating, let stand for a few minutes.

10. Memory Function

(1) Press "**FAVORITE**" to choose memory 1-3 procedure. The screen will display 1, 2, 3.

(2) If the procedure has been set, press "**START/+30SEC.**" to use it. If not, continue to set the procedure. Only one or two stages can be set.

(3) After finishing the setting, press "**FAVORITE**" once to save the procedure.

If press "**START/+30 SEC.**" again, it will start cooking.

Example: To set the following procedure as the second memory, that is memory 2. To cook the food with 80% microwave power for 3 minutes and 20 seconds.

The steps to follow:

- a. In waiting states, press "**FAVORITE**" twice, stop pressing until the screen displays "2".
- b. Press "**COOK TIME**" once, the press "3", "2", "0" in order.
- c. Press "**POWER LEVEL**" once, "PL10" displays, then press "8" and "PL8" displays.
- d. Press "**FAVORITE**" to save the setting. Buzzer sounds once and the screen will display "2". If you press "**START/+30SEC.**" again, the procedure will be saved as memory 2 and operated.
- e. If you want to run the saved procedure, in waiting state, press "**FAVORITE**" twice, screen displays "2", then press "**START/+30SEC.**" to run.

11. Multi-stage Cooking

At most 2 stages can be set for cooking. In multi-stage cooking, if one stage is defrosting, then defrosting shall be placed at the first stage automatically.

Note:

Auto cooking cannot work in the multi-stage cooking.

Example: if want to cook with 80% microwave power for 5 minutes + 60% microwave power for 10 minutes. The cooking steps are as following:

- (1) Press "**COOK TIME**" once, then press "5", "0", "0" to set the cooking time.
- (2) Press "**POWER LEVEL**" once, then press "8" to select 80% microwave power.
- (3) Press "**COOK TIME**" once, then press "1", "0", "0", "0" to set the cooking time;
- (4) Press "**POWER LEVEL**" once, then press "6" to select 60% microwave power.
- (5) Press "**START/+30 SEC.**" to start cooking.

MAINTENANCE

Troubleshooting

Check your problem by using the chart below and try the solutions for each problem. If the microwave oven still does not work properly, contact the hOme® Customer Service at 1-800-898-3002.

TROUBLE	POSSIBLE CAUSE	POSSIBLE REMEDY
Oven will not start	<ul style="list-style-type: none">a. Electrical cord for oven is not plugged in.b. Door is open.c. Wrong operation is set.	<ul style="list-style-type: none">a. Plug into the outlet.b. Close the door and try again.c. Check instructions.
Arcing or sparking	<ul style="list-style-type: none">a. Materials to be avoided in microwave oven were used.b. The oven is operated when empty.c. Spilled food remains in the cavity.	<ul style="list-style-type: none">a. Use microwave-safe cookware only.b. Do not operate with oven empty.c. Clean cavity with wet towel.
Unevenly cooked foods	<ul style="list-style-type: none">a. Materials to be avoided in microwave oven were used.b. Food is not defrosted completely.c. Cooking time, power level is not suitable.d. Food is not turned or stirred.	<ul style="list-style-type: none">a. Use microwave-safe cookware only.b. Completely defrost food.c. Use correct cooking time, power level.d. Turn or stir food.
Overcooked foods	Cooking time, power level is not suitable.	Use correct cooking time, power level.
Undercooked foods	<ul style="list-style-type: none">a. Materials to be avoided in microwave oven were used.b. Food is not defrosted completely.c. Oven ventilation ports are restricted.d. Cooking time, power level is not suitable.	<ul style="list-style-type: none">a. Use microwave-safe cookware only.b. Completely defrost food.c. Check to see that oven ventilation ports are not restricted.d. Use correct cooking time, power level.
Improper defrosting	<ul style="list-style-type: none">a. Materials to be avoided in microwave oven were used.b. Cooking time, power level is not suitable.c. Food is not turned or stirred.	<ul style="list-style-type: none">a. Use microwave-safe cookware only.b. Use correct cooking time, power level.c. Turn or stir food.

WARRANTY

hOme® offers a limited two-year warranty (“warranty period”) on all of our products purchased new and unused from hOme Technologies, LLC or an authorized reseller, with an original proof of purchase and where a defect has arisen, wholly or substantially, as a result of faulty manufacture, parts or workmanship during the warranty period. The warranty does not apply where damage is caused by other factors, including without limitation: (a) normal wear and tear; (b) abuse, mishandling, accident, or failure to follow operating instructions; (c) exposure to liquid or infiltration of foreign particles; (d) servicing or modifications of the product other than by hOme®; (e) commercial or non-household use.

The hOme® warranty covers all costs related to restoring the proven defective product through repair or replacement of any defective part and necessary labor so that it conforms to its original specifications. A replacement product may be provided instead of repairing a defective product. hOme’s exclusive obligation under this warranty is limited to such repair or replacement.

A receipt indicating the purchase date is required for any claim, so please keep all receipts in a safe place. We recommend that you register your product on our website, www.home.family/reg. Although greatly appreciated, the product registration is not required to activate any warranty and product registration does not eliminate the need for the original proof of purchase.

The warranty becomes void if attempts at repair are made by non-authorized third parties and/or if spare parts, other than those provided by hOme®, are used.

You may also arrange for service after the warranty expires at an additional cost.

These are our general terms for warranty service, but we always urge our customers to reach out to us with any issue, regardless of warranty terms. If you have an issue with a hOme® product, please contact us at 1-800-898-3002, and we will do our best to resolve it for you.

This warranty gives you specific legal rights, and you may have other legal rights which vary from state to state, country to country or province to province. The customer may assert any such rights at their sole discretion.

WARNING

This manual is to be used with all items with the SKU/model numbers:

SKU: HMW010002N Model: EM036AT3

WARNING: Keep all plastic bags away from children.

State of California Proposition 65 Warnings:

WARNING: THIS PRODUCT COULD CONTAINS ONE OR MORE CHEMICALS WHICH ARE KNOWN TO THE STATE OF CALIFORNIA TO CAUSE CANCER, BIRTH DEFECTS OR OTHER REPRODUCTIVE HARM.

Manufacturer, distributor, importer and seller are not liable for ANY damage caused by improper use, storage, care or failure to follow warnings associated with this product.

CONTACT US

hOme®

Customer Service

Phone: 1-800-898-3002

Email: help@home.family

Website: www.home.family/help



HOUSEHOLD USE ONLY

SKU# : HMW010002N
PART#: HMW010002MNL
Model: EM036AT3

RATING: 120 V, 60 Hz, 240 WATTS, AC ONLY

© 2016 hOme Technologies, LLC
37 East 18 Street, 7th Floor. | New York, NY 10003
All rights reserved, hOme®.
Printed in China.