

FLUKE®

6500
Appliance Tester

Users Manual

PN 2141150
April 2005, Rev.1, 6/05
© 2005 Fluke Corporation, All rights reserved. Printed in UK
All product names are trademarks of their respective companies.

LIMITED WARRANTY AND LIMITATION OF LIABILITY

Each Fluke product is warranted to be free from defects in material and workmanship under normal use and service. The warranty period is two years and begins on the date of shipment. Parts, product repairs, and services are warranted for 90 days. This warranty extends only to the original buyer or end-user customer of a Fluke authorized reseller, and does not apply to fuses, disposable batteries, or to any product which, in Fluke's opinion, has been misused, altered, neglected, contaminated, or damaged by accident or abnormal conditions of operation or handling. Fluke warrants that software will operate substantially in accordance with its functional specifications for 90 days and that it has been properly recorded on non-defective media. Fluke does not warrant that software will be error free or operate without interruption.

Fluke authorized resellers shall extend this warranty on new and unused products to end-user customers only but have no authority to extend a greater or different warranty on behalf of Fluke. Warranty support is available only if product is purchased through a Fluke authorized sales outlet or Buyer has paid the applicable international price. Fluke reserves the right to invoice Buyer for importation costs of repair/replacement parts when product purchased in one country is submitted for repair in another country.

Fluke's warranty obligation is limited, at Fluke's option, to refund of the purchase price, free of charge repair, or replacement of a defective product which is returned to a Fluke authorized service center within the warranty period.

To obtain warranty service, contact your nearest Fluke authorized service center to obtain return authorization information, then send the product to that service center, with a description of the difficulty, postage and insurance prepaid (FOB Destination). Fluke assumes no risk for damage in transit. Following warranty repair, the product will be returned to Buyer, transportation prepaid (FOB Destination). If Fluke determines that failure was caused by neglect, misuse, contamination, alteration, accident, or abnormal condition of operation or handling, including overvoltage failures caused by use outside the product's specified rating, or normal wear and tear of mechanical components, Fluke will provide an estimate of repair costs and obtain authorization before commencing the work. Following repair, the product will be returned to the Buyer transportation prepaid and the Buyer will be billed for the repair and return transportation charges (FOB Shipping Point).

THIS WARRANTY IS BUYER'S SOLE AND EXCLUSIVE REMEDY AND IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. FLUKE SHALL NOT BE LIABLE FOR ANY SPECIAL, INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES OR LOSSES, INCLUDING LOSS OF DATA, ARISING FROM ANY CAUSE OR THEORY.

Since some countries or states do not allow limitation of the term of an implied warranty, or exclusion or limitation of incidental or consequential damages, the limitations and exclusions of this warranty may not apply to every buyer. If any provision of this Warranty is held invalid or unenforceable by a court or other decision-maker of competent jurisdiction, such holding will not affect the validity or enforceability of any other provision.

Fluke Corporation, P.O. Box 9090, Everett, WA 98206-9090, U.S.A.
Fluke Europe B.V., P.O. Box 1186, 5602 BD Eindhoven, The Netherlands.

Table of Contents

Title	Page
Introduction	1
Contacting Fluke	1
Unpacking the Tester	2
Safety Information	2
Operating Features	4
Front panel description	4
Understanding the Pushbuttons	5
Understanding the Beeper Sounds.....	6
Understanding Displayed Symbols.....	6
Powering the Tester	7
Understanding the Power-up Screen.....	7
Setting Up the Tester: Basic Functions	7
Adjusting the Display Contrast.....	7
Zeroing the Earth Bond Test.....	7
Setting Date and Time.....	8
Setting the Site Text	8
Setting Up the Tester: Advanced Functions	9

Changing the Access Code.....	9
Selecting Fast or Standard Test Mode.....	9
Creating/Editing an Auto-Test Sequence.....	9
Setting Manual Test Limits.....	11
Locking and Unlocking Manual Tests.....	12
Setting the Serial Port Communications Speed.....	12
Installing - Formatting a Compact Flash Card.....	13
Testing Appliances.....	14
Aborting a Test.....	14
Test Modes: Single - Continuous Test.....	15
Test Modes: Standard or Fast.....	15
Using the Auto-Test Mode.....	16
Performing Auto-Tests.....	16
Using the Manual Test Mode.....	18
Performing Manual Tests.....	18
Description of the Tests.....	19
Visual Inspection Test.....	19
Bond Test 25A/200 mA (R _{PE}).....	19
Insulation Test (R _{ISO}).....	20
Substitute Leakage Current Test (I _{SL}).....	22
Touch Current Test (I _{TC}).....	23
Load/ Leakage Current (I _{PE}) Test.....	24
IEC Lead Test.....	26
PELV Test.....	27
Using the Memory.....	28
Saving Test Results.....	28
Viewing Test Result Records.....	29
Viewing Auto-Test Sequences.....	29

Deleting Test Result Records	30
Clearing the Memory	30
Printing - Downloading Data.....	31
Connecting the Printer or the PC.....	31
Printing test results	32
Printing Auto-tests	32
Downloading Test Results to a PC	32
Transferring Results to Compact Flash Card.....	32
Maintaining the Tester.....	33
Cleaning	33
Calibration	33
Accessories	33
Specifications	34
General Specifications.....	34
Test Specifications	35
Power-on Test	35
Earth Bond Test.....	35
Insulation Test	35
Touch Current Test.....	36
Substitute Leakage Current Test	36
Load/Leakage Test: Load Current	36
Load/Leakage Test: Load Power	37
Load/Leakage Test: Leakage Current	37
PELV Test.....	37
Influence Factor Errors	37

6500 Appliance Tester Users Manual

Introduction

The Fluke model 6500 Appliance Tester (hereafter referred to as 'the tester') is designed to carry out the following tests to ensure the integrity of electrical equipment / portable appliances:

- L-N Mains Volts and Mains Wiring test.
- Insulation test (500 V dc).
- Earth Bond test 200 mA and 25A with test lead zero facility.
- Substitute Leakage Current test.
- Touch Current test .
- IEC Lead test.
- Leakage test.
- Appliance Power and Load current test.
- PELV test

Contacting Fluke

To contact Fluke for product information, operating assistance, service, or to get the location of the nearest Fluke distributor or Service Centre, call:

- +31-402-678-200 in Europe

Visit Fluke's web site at: www.fluke.com

Register your Tester at: register.fluke.com

Unpacking the Tester

The tester comes with the items listed in Table 1. If the tester is damaged or an item is missing, contact the place of purchase immediately.






Table 1. Shipment Box Contents

6500 Appliance Tester
Crocodile Clip
Test Lead
Touch Current Probe
Hard Case
Users Manual (this manual)

Safety Information

The tester must only be used by a suitably trained and competent person.

Carefully read the following safety information before using the tester.

Definitions of symbols used	
	Caution! Risk of Danger. Refer to Manual
	Caution! Risk of Electric Shock
	Conforms to Relevant European Standard
	Double Insulated (Class II) Equipment
	Earth Ground



Warnings: Read Before Using

To avoid possible electric shock or personal injury, follow these guidelines:

- If the tester does not power up immediately after connecting it to the mains outlet disconnect and verify that the mains outlet is correctly wired.
- Use the tester only as specified in this manual, or the protection provided by the tester might be impaired.
- The tester shall not be used for measurements in electrical installations.
- When conducting tests do not touch the appliance as some tests involve high voltages and high currents.
- Do not use the tester around explosive gas, vapour or dust, or in wet environments.
- Inspect the tester before using it. Do not use the tester if abnormal conditions of any sort are noted (such as a faulty display, broken case, etc.).
- Use only test leads and probes supplied with the tester, or indicated by Fluke as suitable for the tester.
- Inspect the test leads for damaged insulation or exposed metal. Check test lead continuity. Replace damaged leads before using the tester.
- When testing, always be sure to keep your fingers behind the safety barriers on the test leads.
- Never open the tester's case because dangerous voltages are present. There are no user replaceable parts in the tester.
- Have the tester serviced only by qualified personnel.
- The tester must be properly earthed. Only use a supply socket that has a protective earth contact. If there is any doubt as to the effectiveness of the supply socket earth, do not connect the tester. Do not use a two-conductor adapter or extension cord; this will break the protective ground connection.
- The tester has been set for a nominal 230 V ac – 50 Hz operation, it must never be connected to a higher voltage.
- The tester may only be connected to a correctly wired mains socket protected for a maximum current rating of 13 A.
- The mains supply is never to be connected to the IEC lead test connector or to the appliance test connector.
- When carrying out Earth Bond tests, regularly zero the Earth Bond test lead.
- Under certain test conditions the test socket may have mains potential with a maximum current of 13 A.
- If the tester continuously emits a two tone sound, you should unplug it immediately as this indicates a dangerous condition.

Operating Features

Front panel description

The connectors, controls and indicators of the tester are shown and listed below.




























Figure 1. Fluke 6500

No.	Description
1	Liquid Crystal Display (LCD).
2	Earth bar to zero the Earth Bond test lead.
3	Socket to connect IEC lead for IEC Lead test .
4	Serial RS-232 Port to connect the Fluke printer, Fluke bar code scanner, or a computer.
5	Socket to connect test lead and crocodile clip for Earth Bond test.
6	Socket to connect test probe for Insulation test, Touch Current test, Substitute Leakage test and PELV test.
7	Socket to connect the appliance to be tested.
8	Slot to insert a Type I Compact Flash Memory Card.

Understanding the Pushbuttons

The table below shows the pushbuttons to control operation of the tester.

Button	Function
	Select the Insulation test.
	Select the 25 A Earth Bond test.
	Select the 200 mA Earth Bond test.
	Select the Visual Inspection test.
	Select the Touch Current test.
	Select the combined Load/Earth Leakage Current test.
	Select the Substitute Leakage Current test.
	Start /Enter selection.
	Provide help on the current function.
	Select the auto-test mode.
	Select the IEC Lead test.
	Abort the current action and return to idle screen.

	Scroll up/down to highlight options in screen instructions (↑↓).
	Move left/right to change options in screen instructions (←→).
	Select the setup menu.
	Store test results or viewing auto-test sequences.
	Confirm a proposed action.
	Reject a proposed action.
	Download/Print test results and auto-tests.
	Use capital characters.
	Type the space character.
	Assign special characters to keys.
	Enter typed data.
	Backspace.









Understanding the Beeper Sounds

The tester can make several types of beeper sounds.

Sound	Meaning
Click	A key is pressed.
1 beep	A test passed.
2 beeps	- A test failed. - Warning, see display. - The STOP key is pressed, the current action is aborted.
Long beep	Test will start in continuous mode.
Continuous two tone sound	Dangerous condition! Unplug the unit immediately!

Understanding Displayed Symbols

The following symbols can be displayed:

	Caution! Risk of Electric Shock.
	Caution! Risk of Danger. Refer to Manual.
	Bond test lead has been zeroed.
	Auto-test failed. At IEC lead test: L-N/fuse test failed.
	Auto-test passed. At IEC lead test: L-N/fuse test passed.
LMT	Applicable limit is exceeded.
	The printer/PC is connected.
I II	Class I, Class II.
	Use buttons  .
Lockout on	Manual tests are locked out.

Powering the Tester

The tester will power up when you connect it to the mains supply. Disconnect the mains plug to power the tester down.



Warning

Read the safety information on page 2 before powering the tester.

Understanding the Power-up Screen

On power up the display will perform a self-test. During this test it shows the Fluke model 6500 and the software version, for example V1.32.

After performing the self test, if all is well, the tester shows the idle screen:

23/06/04 10:12	← date and time
Site: Fluke	← most recent entered site name
V_{TN} 231.2 V	← live-neutral voltage
V_{NE} 0.0 V	← neutral-earth voltage
50.2 Hz	← line frequency
∅	← bond test has been zeroed




If there is an error a self explanatory message will appear. Follow the screen instructions if an error message is displayed!

Setting Up the Tester: Basic Functions

This section describes how to set the parameters of the basic functions.

Adjusting the Display Contrast

To adjust the display contrast, do the following:


-  Power the tester up OR
 press STOP to see the idle screen.
-  Adjust the contrast.


Zeroing the Earth Bond Test


For correct Earth Bond test results you must zero the earth bond lead to eliminate its resistance:

- when setting up your new tester. Earth Bond tests are locked out unless the bond zero icon (∅) is on.
- occasionally, dependent on the condition of the bond socket and the test lead plug a dirty plug/socket can result in a significant contact resistance. .

To zero the test lead, do the following:

-  Open the setup menu.

2  Highlight **BOND ZERO set**.

3  Open the setup menu and follow the screen instructions:

- Attach the crocodile clip to the test lead and insert the test lead plug into the BOND 25A/200mA socket, see fig. 2.
- Firmly attach the crocodile clip to the BOND ZERO \emptyset bar on the tester.




Figure 2. Bond Zero Connections

When finished the tester shows the bond zero symbol \emptyset , and the resistance value of the test lead, for example $R_{PE} 0.09 \Omega$. It will subtract this value from bond test results. As it saves this zero value you will not need to repeat the operation every time you use the tester.




If the display shows the message $R_{PE} > 1.99 \Omega$ the lead resistance is more than 1.99Ω and cannot be zeroed. Earth bond tests will now be locked out.

If the Earth Bond test lead has been zeroed, the idle screen and the earth bond test results screen will show the zero symbol \emptyset , for example:

\emptyset Bond test 25A




Setting Date and Time

The tester has a date and time clock. To set the date and the time, do the following:

- 1  Open the set-up menu.
- 2  Highlight **DATE/TIME set**.
- 3  Open the next menu and follow the screen instructions.

Setting the Site Text

To set the site text, do the following:

- 1  Open the set-up menu.
- 2  Highlight **SITE text set**.
- 3  Open the next menu and follow the screen instructions.




Setting Up the Tester: Advanced Functions

This section describes how to set the parameters of the advanced functions.

Changing the Access Code

The factory set access code is 9999. You need the access code to enter or edit auto-tests, to lock or unlock manual tests, and to edit the access code. If you forget your access code contact Fluke.




To change the access code, do the following:

- 1  Open the set-up menu.
- 2  Highlight **ACCESS CODE set**.
- 3  Open the next menu and follow the screen instructions.

Selecting Fast or Standard Test Mode

In the standard test mode the tester provides help information during the tests. In the fast mode this information is bypassed where possible to save test time. See also 'Test Modes: Standard or Fast' on page 15.






To select the fast or standard mode, do the following:

- 1  Open the set-up menu.
- 2  Highlight **FAST MODE set**.
- 3  Open the next menu and follow the screen instructions.

Creating/Editing an Auto-Test Sequence

The tester is provided with factory programmed automatic test sequences, see page 17. You can create new auto-test sequences, and edit tests you created.

To create or edit auto-tests, proceed as follows:

- 1  Open the set-up menu.
- 2  Highlight **AUTO-TEST setup**.
- 3  Open the User auto-test setup menu.
- 4  Enter the access code, for example 9999.
- 5  Accept the access code.

In the next step you must enter a 3-digit test number:

- Enter a new auto-test number to start creating a user programmed auto-test from scratch.
- Enter the number of a factory programmed auto-test to make a copy of it, edit the copy, and store it as a new user programmed auto-test. See page 17 for the factory programmed tests.
- Enter the number of an existing user-programmed auto-test to edit the test.

Continue as follows:

6		Enter the test number, for example 123.
7		Accept the number. If you entered a factory programmed number do step 8 and 9 to make a copy. If you entered a new auto-test number or an existing user programmed auto-test number go to step 10.
8		Enter the number to be assigned to the copy of the factory programmed auto-test, for example 456.

9		Accept the new auto-test number and enter the set-up/instruction screen.
10		Start setting up the test.
11	 	Use the up/down keys to select the test parameter(s) to be changed. Use the left/right arrow key to change the test parameter For the test parameters see Table 2.
12		When finished exit the set up screen.
13	 	To review/edit. To save the auto-test.

Notes

Test numbers 137 to 142 and 235 to 240 are reserved for future factory programmed tests.

User programmed tests are stored in chronological order and not in numeric order.

To view saved auto-tests see 'Viewing Auto-Test Sequences' on page 29.

Table 2. Test parameters

Test	Parameter
Visual check	(Skipped) - SELECTED
Bond	
Current	200mA – 25A
Repeat ¹⁾	R0 – R1 – R2 - R3
Limit	0.1Ω ... 19.9Ω
Duration	(Skipped) - 5s....60s
Insulation	
Repeat	R0 – R1 – R2 - R3
Safety Class ²⁾	I – II
Limit	0.1 MΩ...290MΩ
Duration	(Skipped) - 5s....60s
Substitute Leakage	
Limit	0.5mA ... 19.5mA
Safety Class ²⁾	I – II
Duration	(Skipped) - 5s....60s
Load/leakage	
Limit Load	0VA...3200VA
Limit Leakage	0.5mA ... 19.5mA
Duration	(Skipped) - 5s....60s
Touch Current	
Repeat	R0 – R1 – R2 - R3
Limit	0.25mA, 0.5mA – 1.9mA
Duration	(Skipped) - 5s....60s
IEC Lead	
Limit Rpe ³⁾	0.1Ω... 19.9Ω
Duration ³⁾	(Skipped) - 5s....60s
Limit Riso	fixed at 2 MΩ





Notes

- 1) *The repeat test parameters R0, R1, R2, and R3 define how many times a test will be repeated. When you select for example R1, the test will be repeated once (two tests).*
- 2) *The selected class for the isolation test also applies to the substitute leakage test.*
- 3) *The IEC lead test can only be selected if all other tests, except for the visual check, are skipped.*

Setting Manual Test Limits

To set the manual test limits you need your access code (factory default 9999).




Do the following:

1		Open the set-up menu.
2		Highlight MANUAL LIMITS
3		Open the next menu and follow the screen instructions.
		To restore the factory set limits press  .
		For the test parameters see Table 2.

Locking and Unlocking Manual Tests

To unlock/lock manual tests you need your access code (factory default 9999).




Do the following:

- 1  Open the set-up menu.
- 2  Highlight **MANUAL TEST lock**.
- 3  Open the next menu and follow the screen instructions.

Setting the Serial Port Communications Speed

The tester communications speed (baud rate) must correspond to the communications speed of the connected printer, bar code scanner, or computer.

To set the communications speed, do the following:

- 1  Open the set-up menu.
- 2  Highlight **COMMS RATE set**.
- 3  Open the Serial port baud rate menu and follow the screen instructions.

The default communications speed setting for the SP1000 printer and the SP15 scanner is 9600 baud.

Installing - Formatting a Compact Flash Card

You can copy saved test results and user defined auto-tests to a Type I Compact Flash Memory Card (FAT12/FAT16 formatted) for backup purposes.

Caution

- **Do not remove the card or do not press the STOP key during a format or a write operation. This will damage your card!**
- **Formatting a card will erase all data on that card.**
- **Do not force the CF card into the 6500 card socket. If you encounter resistance, stop and check that you have plugged in the card in the correct orientation. If you use force you may damage the card and the card reader.**

To install a card gently insert it into the slot, see figure 3. To remove the card press the card eject button next to the slot.







Figure 3. Inserting the CF card

If the card has an invalid file format a screen message will prompt you to format the card.

To format the card, do the following:

- | | | |
|---|--|--|
| 1 |  | Open the set-up menu. |
| 2 |  | Highlight FORMAT a Compact Flash card |
| 3 |  | Open the Format menu and follow the screen instructions. |

Note

If you are formatting a CF card on a PC, please ensure you format it to FAT 12 or FAT 16 formats.

Testing Appliances

For the vast majority of testing you can use the auto-test mode. This is advantageous because you can just follow the on screen instructions.

The manual test mode is designed for applications where one particular test must be repeated several times in a row and to quickly carry out a test.




Warnings

- **Before commencing any testing you are strongly advised to make reference to the Electricity at Work Regulations 1989 and any relevant publications from the Health and Safety Executive.**
- **The appliance must be switched on for all tests.**
- **When conducting tests do not touch the appliance as some tests involve high voltages and high currents.**
- **The tests should only be performed by competent persons who are familiar with the requirements of the type of tests suitable for portable appliances.**
- **It is potentially hazardous for both user and appliance should the wrong type of tests be**

undertaken or if testing is carried out in an incorrect sequence.

- **It is important that you fully understand the various tests required and how they should be performed.**
- **The appliance must have passed the visual inspection, the earth bond test (Class I), and the insulation test (in this sequence) prior to any other test. If any of these fail further testing must be stopped and any faults must be rectified.**
- **During the load/leakage test and the touch current test, the appliance will be energized at mains voltage. For this purpose, switch on the appliance. Appliances driven by motors or equipped with heating units may present a danger for the person testing (comply with the appliance instruction manual!). Ensure that the appliance is in a safe condition to run. Please secure it prior to the test.**

Aborting a Test

Pressing  immediately aborts whatever test is in progress, makes the tester safe and then shows the idle screen.

Test Modes: Single - Continuous Test

You can run manual tests in a single test mode or in a continuous test mode. A test in the auto-test mode will always be a single test.

Single Test

To run a single manual test press a test button to select a test and then press and release to start the test.

The tester connects the test supply, performs one test, disconnects the test supply and holds the result on the display. In the auto-test mode the tester will proceed with the next test.

Note

To start the Visual Inspection test just press the key.

Continuous Test

To start a continuous manual test press a test button to select a test and then press and hold it down for at least 2 seconds. A long beep will indicate the continuous test has started.

The tester connects the test supply, makes the first test and displays the first result. Then the tester continues measuring and displaying results without disconnecting

the test supply. The maximum run time is 8 minutes. After this time the test stops.

To stop a continuous test, press the selected test button or press again. The tester disconnects the test supply and holds the last test result on the display.

Note

The IEC-Lead test cannot be run in the continuous test mode.

Test Modes: Standard or Fast

In the standard test mode the tester displays instructions on how to perform a test. The factory-set mode is the standard mode.

In the fast test mode screen instructions will be bypassed where possible. During auto-tests in the fast mode the Visual test is assigned a pass and the test screen is not shown.

To select the fast mode or standard mode see 'Selecting Fast or Standard Test Mode' on page 9.

Using the Auto-Test Mode

The tester provides a number of factory programmed auto-tests, see Table 3 (Class I appliances) and Table 4 (Class II appliances). An auto-test consists of a number of single tests that will be carried out in the programmed order. The test limits are pre-set, and the test result will give a pass/fail indication.

See page 9 on how to create new auto-tests.


Auto-tests are locked out unless the Earth Bond test lead resistance has been zeroed out, see page 7.

When any test fails during an auto-test, further tests can not be carried out .

Performing Auto-Tests

You can run an auto-test in the standard mode or in the fast mode. See 'Test Modes: Standard or Fast' on page 15 and 'Selecting Fast or Standard Test Mode' on page 9 for more information.

To start an auto-test, do the following:

- 1  Select the auto-test mode and follow the screen instructions.

The chapter 'Description of the Tests' on page 19 provides detailed information on the individual tests.



When the auto-test is finished a pass () or a fail () indication is displayed. Now you can review the results before saving them, and save the results.

Table 3. Factory Programmed Auto-Tests for Class I Appliances

Tests	131	132	133	134	135	136
Visual Inspection	Yes	Yes	Yes	Yes	Yes	Yes
Earth Bond 25A (Ω)	0.10	0.10	No	No	0.10	No
Earth Bond 200mA	No	No	0.10	0.10	No	0.10
Insulation ($M\Omega$)	1.00	1.00	1.00	1.00	1.00	1.00
Touch Current (mA)	No	No	No	No	No	No
Substitute Leakage (mA)	No	No	No	No	No	No
Load/Leakage (VA/mA)	3000/3.5	3000/0.75	3000/3.5	3000/0.75	No	No

Table 4. Factory Programmed Auto-Tests for Class II Appliances

Tests	231	232	233	234
Visual Inspection	Yes	Yes	Yes	Yes
Earth Bond 25A (Ω)	No	No	No	No
Earth Bond 200mA	No	No	No	No
Insulation ($M\Omega$)	2.00	2.00	2.00	2.00
Touch Current (mA)	0.25	0.25	No	No
Substitute Leakage (mA)	No	No	No	No
Load/Leakage (VA/mA)	3000/0.25	No	No	3000/0.25

Note: Test numbers 137 to 142 and 235 to 240 are reserved for future factory programmed tests.

Using the Manual Test Mode

To lock/unlock manual tests see page 12 .



Warning

NEVER carry out the TOUCH CURRENT and LOAD/LEAKAGE test unless you have first carried out a thorough visual inspection, followed by a test of the earthing (Class I appliances), and then a test of the insulation. You must verify that these tests are passed before engaging this test.

Table 5 shows the factory-set manual test limits.

Table 5. Factory-set manual test limits

Earth Bond	0.10 Ω
Insulation class I/class II	1 M Ω / 2 M Ω
Substitute Leakage class I/class II	3.5 mA / 0.5 mA
Touch Current	0.25 mA
Load	3200 VA
Leakage current	0.75 mA
IEC lead bond/insulation	0.10 Ω / 2 M Ω




To change the test limits refer to page 11.

Earth Bond tests are locked out if you did not zero the earth bond test lead resistance, see page 7.

Performing Manual Tests

You can run manual tests in the standard mode or in the fast mode. See 'Test Modes: Standard or Fast' on page 15 and 'Selecting Fast or Standard Test Mode' on page 9 for more information.

To perform a manual test do the following:

-  Select the required test key.
Follow the screen instructions.
-  Press and release for a short single test.
Press for longer than 2 seconds for a continuous test (not applicable for a visual inspection and IEC lead test).
To stop a continuous test, press the selected test key or press  again.

For more information on the individual test refer to 'Description of the Tests' on page 19.

After performing a test you can save the result, see 'Saving Test Results' on page 28.

Description of the Tests

Visual Inspection Test

Visually inspect the appliance before you start electrical testing.

Check the appliance for the following:

- condition of the appliance cables, i.e. no cuts, cracks or any physical damage to the outer insulation layer.
- condition of the plug, cable securely attached, no signs of overheating and that the correct value of fuse is fitted.
- any signs of damage, and that any mains or control switches will physically switch on and off.
- any sockets for signs of overheating or physical damage.

Bond Test 25A/200 mA (R_{PE})

The test checks the resistance between the earth pin of the appliance cable plug and the exposed metalwork on the appliance. The test applies to Class I appliances.

Remarks:

- To enable the bond test and to obtain correct bond test results you must have zeroed the test lead, see page 7.
- You should use the lower current 200 mA for certain appliances. Please refer to appliance test standards and guidance material.
- Connect the appliance and the earth bond test lead as indicated on the display. Clip the crocodile clip to an exposed conductive part on the appliance that requires testing, see fig. 4.
Do not use the probe for the 25 A bond test. The probe is only rated for 10 A!
- During the measurement flex the flexible cord along its length to help find any broken conductors or poor quality joints.
- Continuous 25 A bond test will periodically drop back to 200 mA test to prevent the tester from being overheated.




Figure 4. Bond Test Connections

The display can show the following specific information:

LMT >0.1Ω+LEAD	R _{PE} may have exceeded the recommended limit, possibly because of the length of the lead.
> 19.99 Ω	R _{PE} overrange.
∅	Bond test lead has been zeroed.

Insulation Test (R_{ISO})

Warning

- The test voltage is 500V dc. Do not touch the appliance during the insulation test! If the test fails any metal parts of the appliance could become live!
- Always make sure that the test has completed before disconnecting the appliance leads to ensure that all capacitances have discharged.

Caution

Do not perform the Insulation test on appliances that failed the bond test or the visual inspection test.

The test checks the resistance of the insulation between

- the earth pin of the appliance cable plug (Class I) or
 - the test probe to be applied to the appliance (Class II)
- and the Live and Neutral pins of the appliance (pins are connected together within the tester for this test).

The insulation test will be inhibited if the tester detects a terminal voltage >30 Vrms prior to initiation of the test.

Note

The insulation test may be not suitable for some types of appliances. For these appliances an alternative test may be conducted such as a touch current, leakage current, or substitute leakage current test. It is essential to refer to standards and/or reference material for the safe applicability of these alternative tests.

Remarks:

- Connect the appliance and the test probe as indicated on the display, see fig. 5 and fig. 6.
- For Class I appliances no probe is required.
- For Class II appliances apply the test probe to any exposed metalwork on the appliance. Do the test for all exposed metal parts on the appliance.




Figure 5. Insulation Test Connections Class I




Figure 6. Insulation Test Connections Class II

The display can show the following specific information:

LMT <1.0MΩ	The test result is below the recommended class I limit.
LMT <2.0MΩ	The test result is below the recommended class II limit.
> 299 MΩ	R _{ISO} overrange.

Substitute Leakage Current Test (I_{SL})

The test measures the leakage current between

- the earth pin of the appliance cable plug (Class I) or
- the test probe attached to the appliance under test (Class II)

and the Live and Neutral pins of the appliance (pins are connected together within the tester for this test).

It is essential to refer to standards and/or guidance material for the safe applicability of this test.

Remarks:

- Connect the appliance and the test probe as indicated on the display, see fig. 7 and fig. 8.
- For Class I appliances no test probe is required.
- For Class II appliances apply the test probe to any exposed metalwork on the appliance. Do the test for all exposed metal parts on the appliance.




Figure 7. Substitute Leakage Test Connections Cl. I




Figure 8. Substitute Leakage Test Connections Cl. II

The display can show the following specific information:

LMT > 3.5 mA	The acceptable test limit may have been exceeded. Refer to standards and/or guidance material.
> 19.99 mA	I_{SL} overrange.

Touch Current Test (I_{TC})

 **Warning**

NEVER carry out this test unless you have first carried out a thorough visual inspection, followed by a test of the earthing (Class I appliances), and then a test of the insulation. You must verify that these tests have passed before engaging this test.

 **Caution**

Live test! The appliance will be energized at mains voltage. For this purpose, switch on the appliance. Appliances driven by motors or equipped with heating units may present a danger for the person testing (comply with the appliance instruction manual!). Ensure that the appliance is in a safe condition to run. Please secure it prior to the test.

The Touch Current test consists of:

- a fuse and L-N loop pre-test
- a leakage current measurement with approx. 2 k Ω resistance connected between earth and exposed conductive parts on the appliance via the test probe. The measurement is performed by the direct method.

Connect the appliance and the test probe as indicated on the display (see fig. 9) and apply the test probe to:

- any exposed conductive part on Class II appliances
- any exposed conductive parts that are not connected to earth on Class I appliances.





Figure 9. Touch Current Test Connections

The display can show the following specific information:

	Live test going on!
LMT	The acceptable test limit may have been exceeded. Refer to standards and/or guidance material.
> 1.99 mA	Touch current overrange.

Fuse/L-N Pre-test

The pre-test verifies the fuse and lead continuity by applying a low voltage signal across the appliance phase and neutral pins.

If the pre-test fails the display will show a self-explanatory message.

A fail may indicate that the fuse is blown or that there is an open circuit in the L-N conductors. In this case press the **MEM** key to store the fail result.

The test could also fail because you forgot to switch the appliance on. In this case switch the appliance on and repeat the test.

Very low power appliances, or appliances with electronically controlled on/off switches or with an inductance may fail this test. To enable you to test these appliances you can assign a pass to the Fuse/L-N loop Pre-test by pressing **GO** to continue with the test.

Note

Accidental measurement of a defective unit may trip a RCCB (residual current circuit breaker).

Load/ Leakage Current (I_{PE}) Test



NEVER carry out this test unless you have first carried out a thorough visual inspection, followed by a test of the earthing (Class I appliances), and then a test of the insulation. You must verify that these tests are passed before engaging this test.



Live test! The appliance will be energized at mains voltage. For this purpose, switch on the appliance. Appliances driven by motors or equipped with heating units may present a danger for the person testing (comply with the appliance instruction manual!). Ensure that the appliance is in a safe condition to run. Please secure it prior to the test.

The Load/PE Leakage test consists of:

- a fuse and L-N loop pre-test.
- measurements of the appliance power consumption and load current at full mains voltage.
- measurement of the earth leakage current (differential measurement) at full mains voltage.

The measurements will be done in one test sequence.

Connect the appliance as indicated on the display (see also figure 10) .




Figure 10. Load / Leakage Test Connections

The display can show the following specific information:

	Live test going on.
I_{LN} 1.2 A	Load current.
P_{LN} 250 VA	Reactive power.
I_{PE} 0.3 mA	Leakage current.
LMT	The acceptable test limit may have been exceeded. Refer to standards and/or guidance material.
$I_{LN} > 13$ A	Load current overrange.
$P_{LN} > 3.2$ kVA	Power overrange.
$I_{PE} > 19.99$ mA	Leakage current overrange

Fuse/L-N Pre-test

The pre-test verifies the fuse and lead continuity by applying a low voltage signal across the appliance phase and neutral pins.

If the pre-test fails the display will show a self-explanatory message.

A fail may indicate that the fuse is blown or that there is an open circuit in the L-N conductors. In this case press **MEM** to store the fail result.

The test could also fail because you forgot to switch the appliance on. In this case switch the appliance on and repeat the test.

Very low power appliances, or appliances with electronically controlled on/off switches or with an inductance may fail this test. To enable you to test these appliances you can assign a pass to the Fuse/L-N loop Pre-test by pressing **GO** to continue with the test.

Note

Accidental measurement of a defective unit may trip a RCCB (residual current circuit breaker).

IEC Lead Test

The IEC lead test tests the IEC lead for:

- Earth bond resistance and insulation.
- Live-neutral lead/fuse continuity and polarity.

If there is a swapped polarity condition and a continuity failure in the same test, a failed polarity message will be displayed.

The IEC lead test runs only in single test mode.

Connect the IEC lead as indicated on the display (see also figure 11).




Figure 11. IEC Lead Test Connection





The display can show the following specific information:

R_{PE} 0.13 Ω	Protective earth conductor resistance.
R_{ISO} 55.6 $M\Omega$	Insulation resistance.
Fuse <input checked="" type="checkbox"/>	The fuse/continuity is ok
LMT	One of the test limits has been exceeded.
Fuse <input checked="" type="checkbox"/>	Fuse/continuity not ok
Polarity <input checked="" type="checkbox"/>	L-N are swapped
$R_{PE} > 19.99 \Omega$	Result overrange.
$R_{ISO} > 299 M\Omega$	
LMT $> 0.1\Omega + LEAD$	R_{PE} has exceeded the recommended limit, possibly because of the length of the lead.
LMT $< 2.0M\Omega$ CII	The test result is below the recommended class II limit.

PELV Test

The PELV (Protective Extra Low Voltage) test measures the voltage on the **PROBE PELV** input when the idle screen is being displayed.



To perform the PELV test, do the following:


- 1  Revert to the idle screen if it is not already being displayed.
- 2  Connect the test probe to the tester **PROBE PELV** terminal and connect the appliance to a mains supply socket.
- 3  Apply the test probe to the test point.
- 4  Store the test result, if required.

The display can show the following specific information:

PELV 30.0 V	PELV FAIL result, the threshold (25V) is exceeded.
PELV > 39.9 V	PELV overrange.
230 V 50 Hz	If the PELV threshold is not exceeded the display shows the mains voltage and frequency (PASS result)

Tip:

To store a PELV FAIL result press  and .

To store a PELV PASS result press  and select menu item "SAVE PELV pass result".

Using the Memory

The tester has a non-volatile memory to save test results and auto-test sequences.

Saved test results or auto-tests will not automatically be saved on the compact flash card. The compact flash card is intended to be used as a backup for the non-volatile memory. Refer to page 32 for information on how to download the memory contents to compact flash card.

Beside saving test results and auto-tests you can also view saved results, delete individual result records, clear the entire memory and review auto-tests.

Saving Test Results

In the auto-test mode and in the manual single test mode you can save test results when a test has finished.



In the manual continuous test mode you can save the displayed test result. The display reverts to the testing screen after the results have been saved.



Warning

In continuous test mode the test continues whilst you are saving the result!

Proceed as follows to save the results:

-  Open the Save result screen and enter appliance information.
-  Save test results and information.

The Save result screen will present you four fields that you can enter data into. The data can be inserted via the keyboard or the Fluke barcode scanner.


Appliance ID	← Mandatory field
Location	← Optional field
Description	← Optional field
Note	← Optional field

Appliance ID

On pressing  the Appliance ID field will :

- automatically be incremented by 1 from the last stored value if you are using numeric only appliance ID references.
- show the last appliance ID if you are using alphanumeric ID references.



Location

On pressing  the display shows the last stored location as long as the tester has not been powered down.

Note

You can use the 4-digit Fluke coding system for the description, location, and notes field. This speeds up data entry. Please refer to the Fluke Power PAT Plus software.




Remarks:

- After saving the results the display shows the record number in the top right.
- If the display shows the warning  **The store is full** you must save the data on PC or memory card and clear the store (see page 30).
- If you press  when the idle screen is displayed a PELV test pass result can be saved. See also 'PELV Test' on page 27.

Viewing Test Result Records

You can select the result records you want to view by record number, by date, by site, and by keyword search.




To view result records proceed as follows:

- 1  From the idle screen open the memory menu and follow the screen instructions.
To see the idle screen press the STOP key.
- 2  Highlight **VIEW RESULT records**.
- 3  Enter the view function and follow the screen instructions.

Viewing Auto-Test Sequences

You can view factory set and user defined auto-test sequences by simply scrolling through the store.




Proceed as follows:

- 1  From the idle screen open the memory menu and follow the screen instructions.
To see the idle screen press the STOP key.
- 2  Highlight **VIEW AUTO-TESTS**.
- 3  Enter the view function and follow the screen instructions.

Deleting Test Result Records

You can select the result records you want to delete by record number, by date, by site, and by keyword search.

To delete test result records proceed as follows:

- 1  From the idle screen open the memory menu.
To see the idle screen press the STOP key.
- 2  Highlight **DELETE a record**.
- 3  Enter the delete function and follow the screen instructions.

Result records are not renumbered when a record in the middle of the store is deleted.

Deleting records does not free memory space! To free memory space see 'Clearing the Memory' on page 30.




Clearing the Memory

To free memory you must clear the store. This will delete all result records. Automatic test procedures will not be cleared.



Before clearing the store you need to be sure that the contents has been downloaded to PC and/or backed-up on Compact Flash Memory card.

To clear the memory proceed as follows:

- 1  From the idle screen open the memory menu.
To see the idle screen press the STOP key.
- 2  Highlight **CLEAR**.
- 3  Enter the Clear menu and follow the screen instructions.

Printing - Downloading Data

The PRINT/DOWNLOAD functions enable you to :

- print some or all test results.
- print all auto-tests.
- download some or all test results to a PC for processing with Fluke Power PAT Plus software.
- download some or all test results to a Compact Flash memory card.


Only results or auto-tests that have been stored can be printed or downloaded.

You can download results in one of the following formats:

- .flk for Fluke PowerPAT Plus software.
- .csv (comma separated values), for example for Windows Excel.
- .prn SP1000 printer format (to compact flash card only).




Connecting the Printer or the PC

To establish a correct communication do the following:

- 1** Connect the SP1000 printer to the RS232 port using the cable supplied with the printer. In idle mode and in the print function the display shows the printer icon  when the printer is connected and is turned on.
- 2** Connect the PC to the RS232 port using the cable that is supplied with the Fluke Power PAT Plus software. Refer to this software for more specific information.
- 3** Ensure that the baud rate of the tester matches the printer baud rate (9600) or the PC com port baud rate. To set the tester baud rate see page 10.




Printing test results

To print one test result record or a range of test result records do the following:

- 1  Open the print/download menu.
- 2  Highlight **Print results** (not possible if no results are available).
- 3  Open the print results menu and follow the screen instructions.




Printing Auto-tests

To print all user programmed auto-tests do the following:

- 1  Open the print/download menu.
- 2  Highlight **Auto-Tests printout**.
- 3  Start printing.




Downloading Test Results to a PC

To download a range of test results to a PC using the Fluke Power PAT Plus software do the following:

- 1  Open the print/download menu.
- 2  Highlight **Download to PC** (not possible if no results are available).
- 3  Open the Download to PC menu and follow the screen instructions.

Transferring Results to Compact Flash Card

To transfer a range of test results to a compact flash card do the following:

- 1  Open the print/download menu.
- 2  Highlight **Transfer data to CF card** (not possible if no results are available).
- 3  Open the Transfer menu and follow the screen instructions.

The download format to be selected depends on the software you use to process the results, for example print format, Fluke Power PAT Plus format or CSV format (for Excel).

Maintaining the Tester

Cleaning

Periodically wipe the case with a damp cloth and mild detergent. Do not use abrasives or solvents.

Dirt or moisture on the earth bond test lead plug can result in a contact resistance that affects the readings. Therefore periodically zero the earth bond test (see page 7).

Calibration

To ensure the accuracy of the tester is maintained at high level it is recommended that the tester is calibrated at least once every 12 months. Calibration must be carried out by qualified personnel. Contact your local Fluke representative for calibration (see 'Contacting Fluke' on page 1).

Accessories

Table 6 and Table 7 list the part numbers of the accessories.

To obtain the accessories contact your local Fluke representative, see 'Contacting Fluke' on page 1.

Table 6. Standard Accessories

Item	Part Number
Crocodile Clip	532269474055
Test Lead	532269474056
Touch Current Probe	1276841
Users Manual (this manual)	¹⁾

¹⁾ Can be downloaded from your regional Fluke website, start at www.fluke.com .

Table 7. Optional Accessories

Item	Part Number
SPSCAN15 Barcode Scanner	1995050
SP1000 Mini Printer	1597281
EXTL100 Extension Lead Test Adapter	2414348
TA700 Appliance Adapter for 110V Tools	2389678
Fluke PowerPAT Plus Appliance Testing Software	2143155

Specifications

General Specifications

Size.....	200 mm (L) x 275 mm (W) x 100 mm (H)
Weight.....	3.0 kg
Power Supply.....	230 V + 10 % - 15 %, 50 Hz ± 2 %
Power Consumption (Tester).....	13 W typical (idle)
.....	60 W max. during 25A Bond Test
Operating temperature.....	0 to +40 °C
Storage temperature.....	-10 to +60 °C
Relative Humidity	
.....	non condensing < +10 °C
.....	95% from +10 to +30 °C
.....	75% from +30 to +40 °C

Operating Altitude.....	0 up to 2000 m
Sealing.....	IP-40 (enclosure), IP-20 (connectors)
EMC.....	complies with EN61326-1, criteria B
EMI Immunity.....	3 V/m
Safety.....	Complies with EN61010-1 2 nd edition DIN VDE0404-1 and DIN VDE0404-2 CAT II, 300 V, pol 2

Printer – PC RS232 Interface

Baud rate.....	factory default 9600, selectable 1200, 2400, 9600, 19200, 38400
Data bits.....	8
Stop bits.....	1
Parity.....	no

Resolution.....0.01 M Ω (0 to 19.99 M Ω)
0.1 M Ω (20 to 199.9 M Ω)
1 M Ω (200 to 299 M Ω)
Test Voltage.....500 V dc -0 % +25 % at 500 k Ω load
Test Current..... >1 mA at 500 k Ω load, < 15 mA at 0 Ω
Auto discharge time < 0.5 s for 1 μ F
Max. Capacitive Load operational up to 1 μ F

Touch Current Test

Operational error Measurement Range .. 0.1 to 1.99 mA ac
Operational error..... 6.0%
Accuracy \pm (4% + 2 counts)
Display Range 0 to 1.99 mA ac
Resolution..... 0.01 mA
Internal Resistance (via probe)..... 2 k Ω
Measuring method Probe
The appliance under test is energized at mains potential.

Substitute Leakage Current Test

Operational Error Measurement Range ... 0.25 to 19.00 mA
Operational Error 10%
Accuracy \pm (5% + 5 counts)
Display Range 0 to 19.99 mA ac
Resolution..... 0.01 mA
Test Voltage..... 35 V ac \pm 20%

Load/Leakage Test: Load Current

Display Range 0 to 13 A
Accuracy \pm (4% + 2 counts)
Resolution..... 0.1 A
The appliance under test is energized at mains potential.

