


Landice PWM Motor Control Board Instructions

TOOLS NEEDED: • Needle Nose Pliers • #2 Phillips Head Screwdriver



Removing the MCB

PLEASE NOTE: If the treadmill currently has a Horizontal or Double Stack Relay Board, the replacement will be a Vertical MCB (Landice part #70455).

- 1. Disconnect AC Power from treadmill.
- 2. Carefully remove each wire connection and harness from the MCB.
- 3. Using your # 2 Phillips Head screwdriver, remove MCB mounting screws.

If replacing a Horizontal MCB, new mounting holes need to be drilled into the motor pan for the new board!

Using a #25 Drill Bit, and a #10-32 Tap Bit, do the following:

Align one mounting hole on the Vertical MCB to one of the mounting holes in the motor pan. Using a marker or pen, mark where the 2nd mounting hole will need to be drilled. Drill and tap out the secondary mounting hole.

Page 1 of 2 Revised 03/09/2023








LANDICE, INC. 111 CANFIELD AVE., SUITE A-1 RANDOLPH, NJ 07869


Connecting the Motor Control Board

1. BROWN wire from Line Cord Connector (LCC) to the P-1 LINE terminal.

- 2. BLUE wire from LCC to the P-3

 Neutral terminal
- **3. GREEN** wire from **LCC** to the **P-5 GND** terminal, and ground to motor pan.
- 4. BLACK wire from the drive motor to the P-4 Black (MTR +) terminal
- **5. WHITE** wire from the drive motor to the **P-6 White (MTR -)** terminal.
- **6. SPEED SENSOR Harness** to the 3-pin Molex Connector.
- **7. UPPER WIRE Harness** to the 9-pin Molex Connector.
- **8. ELEVATION Harness** to the 6-pin Molex Connector.





PLEASE NOTE: NO SPEED CALIBRATION NECESSARY. POTS ARE PRESET AT THE FACTORY, CONTACT LANDICE BEFORE ADJUSTING!

Page 2 of 2 Revised 03/09/2023



