



CYCLONE CLASSIC PRO 2200W 16 GALLON GUTTER VACUUM

INSTRUCTIONAL MANUAL



Read instruction manual before use!

WWW.GUTTERPROVAC.COM

CONTENTS

1. Safety Instructions	2-3
2. Specifications	4
3. Parts Diagram	5-6
4. Parts List	7
5. Starting And Operating The Machine	8
6. Emptying After Dry Pick Up	8
7. Emptying After Wet Pick Up	9
9. After Use	9
10. Troubleshooting	10-11
11. Maintenance	11
12. Warranty & Customer Service	12

Thank you for purchasing from Gutter Pro Vac. Please read and follow this user manual carefully and keep it in a safe place for future reference. At Gutter Pro Vac, we stand behind our product with knowledgeable and dedicated customer service, so if you ever have any questions or concerns, please contact us for assistance.

We look forward to hearing about your experience with our product and if at any time you require immediate assistance, please call us at 1-800-617-9522 or send us an email to service@gutterprovac.com.

Bryan Watson
President

SAFETY INSTRUCTIONS

WARNING

To reduce risk of fire, electric shock, or injury, please read and follow all safety instructions and caution markings before use. Should damage occur to electrical or mechanical parts, please contact us at 1-800-617-9522 or send us an email at service@gutterprovac.com.



POWER CONNECTION

This gutter vacuum is designed for domestic use and operates using a standard 120V outlet, allowing it to be plugged into any typical household power source.



ELECTRICAL SAFETY FIRST

Do NOT use with a damaged electrical cord or plug. To unplug, grasp the plug, not the cord. Do not handle the plug or power cord with wet hands. Turn off all motors before unplugging.



SAFE VACUUM USAGE

The vacuum is not intended for use by young children. Young children should be supervised to ensure that they do not play with the machine.



HANDLING & MAINTENANCE

Do NOT leave the vacuum unattended when it is plugged in. Always unplug from the power source when not in use and before using the machine.



PROTECT THE POWER CORD

Do NOT pull or carry the vacuum by the cord, use the cord as a handle, close a door on the cord or pull the cord around sharp edges or corners. Keep cord away from heated surfaces.



VACUUMING SAFETY TIPS

Always ensure the vacuum is placed on stable, level ground. Do not place the unit on steps, sloped driveways, or other unstable surfaces. Avoid overstretching the hose or power cord, this can create tripping hazards or cause the unit to tip.

SAFETY INSTRUCTIONS (CONT'D)



AVOID HAZARDOUS DUST

Do NOT use this vacuum for picking up dust which may be considered hazardous.



NO FLAMMABLE LIQUIDS

Do NOT use to pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.



AVOID MOVING PARTS

Keep hair, loose clothing, fingers and all parts of the body away from openings and moving parts. Do not put any objects into openings or use with the inlet blocked. Keep openings free of dust, lint, hair and any debris that could reduce the flow of air.



DRY USE ONLY

Do NOT use a wet dust filter. Wash the dust filter with warm water and cleanser and then dry before reusing.



AVOID HOT MATERIALS

Do NOT use to pick up anything that is burning or smoking, such as cigarettes, matches or hot ashes.



FOLLOW GUIDELINES


Use only as described in this manual and only with the manufacturer's recommended attachments.



SAFETY PROTOCOL

If the vacuum is not working properly or has been dropped, damaged, or submerged into water, contact our customer support at service@gutterprovac.com or call us at (800) 617-9522.


SPECIFICATIONS




FEATURE	SPECIFICATION
Model	Cyclone Classic Pro
Starting Wattage	2400W
Running Wattage	2200W
Voltage	120 Volts
Cooling System	Recycle
Tank Material	Stainless Steel
Capacity	16 Gallon / 60L
Function	Wet/Dry
Weight	52 Lbs (23.6 Kg)

ACCESSORIES INCLUDED*	
1	Suction Hose
2	Inlet Connector
3	Outlet Connector

PARTS DIAGRAM



PARTS DIAGRAM (CONT'D)



PARTS LIST

1	Motor Head Handle	25	Vacuum Hose Connector
2	Switch	26	Handle Connector
3	Power Cable	27	Vacuum Hose
4	Top Cover	28	Drain Outlet Plug
5	Capacitor	29	Drain Hose Clip
6	Wire Fixing Plate	30	Tank Tipping Handle
7	Terminal	31	Drain Connection Plug
8	Middle Cover	32	Drain Hose
9	Motor Seal	33	Rubber Gasket
10	Middle Cover Gasket	34	Drain Hose Nut
11	Air Outlet Sponge	35	Drain Hose Rubber Gasket
12	Upper Gasket	36	Drain Connection Plug
13	Motor	37	Tipping Clip
14	Lower Gasket	38	Tipping Mount
15	Air Inlet Blocking Board	39	Tipping Shelf
16	Motor Base	40	Cart Handle
17	Barrel Cover	41	Tipping Mount Bar
18	Rubber Seal	42	Nut
19	Float	43	Washer
20	Float Basket	44	Foot Tipping Bearing
21	Filter	45	Cart Base
22	Support Basket	46	Locking Caster Wheel
23	Tank Lock	47	All Terrain Tires
24	Inlet Connector		

STARTING & OPERATING THE MACHINE

Check that all power switches are in the off position. Connect the suction hose into the suction inlet of the machine by pushing the hose forward until it clicks into place (to release the hose, press the release button downward and then pull out the hose). Connect the two stainless steel tubes using the hose connector, twisting the tubes to ensure a secure fit. Then connect the hose to your gutter poles. Plug the power cord into a standard household outlet. Once connected, switch the power to the "on" position to start the motor. Each motor is controlled by its own power switch.

NOTE: FOR WET PICK UP (GUTTER CLEANING)

The machine is equipped with a float valve that shuts off the airflow through the machine when the maximum liquid level is reached. You will hear a noticeable change of sound from the motor and the suction power of the vacuum will decrease. When this occurs switch off all motors, unplug the vacuum from the power outlet and either empty the tank or check for blockages.

EMPTYING AFTER DRY PICK UP

WARNING

Before checking the dust filter, turn off and unplug the vacuum cleaner.

Release the two latches holding the head unit in place and lift off the motor head. Check the dust filter and clean/replace if necessary. Replace the head unit onto the tank and secure with the latches. Never pick up dry material without the dust filter fitted in the machine. For replacement parts, simply scan the QR code or please visit:

<https://www.gutterprovac.com/collections/parts-accessories>.



EMPTYING AFTER WET PICK UP

WARNING

Before emptying the tank, unplug the vacuum cleaner. Always fully empty and clean the tank, filter and float valve and the float valve after picking up liquids. Never pick up liquid without the dust filter and float valve installed on the machine.

EMPTYING VIA TANK:

Release the two side latches that hold the head unit in place, lift off the head and set it aside in a safe place. The suction hose should be detached from the machine while emptying the tank. To avoid movement of the cart, lock the front casters and place one foot on the cart frame. Grasp the handle at the bottom of the tank, then tilt the container backwards on the frame to pour out the contents. You can attach a garbage bag to the top of the tank to collect the debris.

EMPTYING VIA DRAIN HOSE:

Detach the drain hose from the bracket by pulling the drain hose away from the machine. Place the end of the drain hose over a drain and remove the plug from drain hose. Gravity will then drain the liquids from the tank.

AFTER USE

Unplug the vacuum from the power outlet when the machine is not in use. Wind up the electrical cord starting from the machine end to avoid kinks. The power cord can be hooked on the side of the tank for easy storage.

TROUBLESHOOTING

PROBLEM	CAUSE	SOLUTION
The vacuum cleaner fails to start	Power cord is disconnected	Check the electric power supply line is connected to your standard household outlet correctly.
	Vacuum is not switched ON	Check that the vacuum is turned on. To turn on the vacuum press any of the on/off switches to the on position
	Electrical fault	Contact a technician for support
The vacuum cleaner does not vacuum efficiently	Vacuum tank is full	Empty the vacuum tank
	Dirty / Clogged / Full filter	Clean the filter as described in the maintenance section. (Empty or replace filters if necessary)
	Check that the vacuum hose, floor tools and/or extension poles are not blocked	Ensure that the hose is not blocked by removing the hose assembly and inserting a long object through the hose to clear any obstructions. Do not use excessive force to clear obstructions
The vacuum cleaner does not vacuum efficiently	The vacuum safety float valve has intervened due to the tank being full of liquid	Empty the vacuum tank
	Vacuum motor head unit is not fitted correctly	Refit the vacuum motor head unit checking that it sits well onto the vacuum tank. Secure it in place with the tank locks

TROUBLESHOOTING (CONT'D)

PROBLEM	CAUSE	SOLUTION
Substantial increase in motor revolutions and decrease in suction	Vacuum hose blocked	Ensure that the hose is not blocked by removing the hose assembly and inserting a long object through the hose to clear any obstructions. Do not use excessive force to clear obstructions
	The vacuum safety float valve blocks the vacuum caused by: A. Tank is full of liquid B. Vacuum has overturned	A. Turn of the vacuum and empty the tank B. Upright the vacuum and turn it off for approx. 3-5 seconds

MAINTENANCE

WARNING

Ensure the machine is turned off and disconnected from the power supply before carrying out any maintenance and/or cleaning of the machine.

- Clean any dust/debris from around the vacuum filter basket and on the underside of the motor head unit on a regular basis to prevent any dust/debris getting sucked into the vacuum motors.
- Immediately replace any worn out / damaged vacuum filters.
- Never attempt to lubricate any motor components.
- Regularly clean the vacuum filters to prolong the life of the vacuum. Cleaning the vacuum filters can be achieved by tapping or knocking the filter inside a garbage can to release dust and debris. You can also use compressed air or a brush to remove the dust and debris. Always ensure you are wearing the correct personal protection equipment (PPE) when cleaning vacuum filters. Always consider your surroundings and other persons within your working area when cleaning vacuum filters.

WARRANTY & CUSTOMER SERVICE

The Cyclone Classic Pro 16 Gallon 2200W Stainless Steel Vacuum, accessories and housing are warranted to be free from defects in material and workmanship for a period of One (1) year from the date of purchase when utilized for normal use by the original purchaser only. This does not include the replacement of items due to normal wear or mishandling. To initiate a warranty claim, the original purchaser must email service@gutterprovac.com with the following information: order number, original purchase date, and description of the issue or defect. Please attach clear images or videos illustrating the issue or defect.

If you have any questions or concerns, feel free to call us directly at 1-800-617-9522 or send us an email at service@gutterprovac.com.

