

Owner's Manual

HTP Air Plasma Cutting Systems

Micro Cut 125RF

HTP America, Inc.

180 Joey Dr., Elk Grove Village, IL 60007-1304
847-357-0700 800-USA-WELD (800-872-9353)
Fax: 847-357-0744 Email: sales@htpweld.com
www.usaweld.com

Table of Contents

Introduction	1
Limited Warranty	1
Safety Precautions	2
Inspection	4
Plasma/Cooling Gas Connection	4
Electrical Connection	5
Torch Connection	5
Ground Cable Connection	5
Operating Controls	6
Operation - Microcut 125RF	6
Maintenance and Service	8
Cutting Tips	8
Wiring Diagram - Microcut 125RF	9
Plasma Torch - Microcut 125RF	10

Introduction

Congratulations on your purchase of an HTP America Air Plasma Cutting System. Your purchase of an HTP Air Plasma Cutting System means that you have purchased one of the most technologically advanced, safest and economical plasma cutters available today.

The owner's manual has been designed to instruct you on the safe operation of your HTP Plasma Cutting System. If you read and follow the instructions in this manual, your plasma cutter will provide you with years of trouble free operation. If you fail to read and understand this manual, and correctly follow the operating instructions, you will significantly shorten the operating life of your plasma cutter.

Operation of your plasma cutting system without proper understanding of the facts contained within this manual or under unsafe or hazardous conditions may lead to **SERIOUS INJURY OR DEATH!**

Limited Warranty

Subject to the terms and conditions hereof, HTP warrants to its Distributor/Dealer that all new and unused Equipment furnished by HTP is free from defect in workmanship and material as of the time and place of delivery by HTP. No warranty is made by HTP with respect to trade accessories or other items manufactured by others. Such trade accessories and other items are sold subject to the warranties of their respective manufacturers, if any.

Except as specified below, HTP's warranty does not apply to components having normal useful life of less than one (1) year, such as relay and contactor points.

HTP shall be required to honor warranty claims on warranted Equipment in the event of failure resulting from a defect within the following periods from the date of delivery of Equipment to the original user:

1. Plasma cutters, power sources and components: 1 year.
2. All plasma torches: 90 days.
3. The electrode, cutting nozzle, insulator, spring, and gas diffuser are consumable items, **WHICH CARRY NO WARRANTY.**

provided that HTP is notified in writing within thirty (30) days of the date of such failure.

As a matter of general policy only, HTP may honor claims submitted by the original user within the foregoing periods.

In the case of HTP's breach of warranty or any other duty with respect to the quality of any goods, the exclusive remedies therefore shall be, at HTP's option (1) repair or (2) replacement or, where authorized in writing by HTP in appropriate cases, (3) the reasonable cost of repair or replacement at an authorized HTP service station upon return of the goods at Customer's risk and expense. HTP's option of repair or replacement will be F.O.B., Factory at Palatine, Illinois, therefore, no compensation for transportation costs of any kind will be allowed. Upon receipt of notice of apparent defect or failure, HTP shall instruct the claimant on the warranty claim procedures to be followed.

HTP America, Inc. has reserved the right to make changes in design or add any improvements to its products at any time without incurring any obligation to install same on equipment.

This warranty is null and void unless warranty card is sent to HTP America, Inc. within 15 days from date of purchase.

ANY EXPRESS WARRANTY NOT PROVIDED HEREIN AND ANY IMPLIED WARRANTY, GUARANTY OR REPRESENTATION AS TO PERFORMANCE, AND ANY REMEDY FOR BREACH OF CONTRACT WHICH, BUT FOR THIS PROVISION, MIGHT ARISE BY IMPLICATION, OPERATION OF LAW, CUSTOM OF TRADE OR COURSE OF DEALING, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR OF FITNESS FOR PARTICULAR PURPOSE, WITH RESPECT TO ANY AND ALL EQUIPMENT FURNISHED BY HTP IS EXCLUDED AND DISCLAIMED BY HTP.

Safety Precautions

WARNING: Before performing any installation or operating procedures read and follow the safety precautions listed below. Failure to observe these safety precautions can result in personal injury or death.

Personal Protection: Skin and eye burns resulting from body exposure to the electric-arc welding rays or hot metal can be more severe than sunburn:

- a. Use a proper face shield fitted with correct filter and cover plates to protect your eyes, face, neck and ears from sparks and rays of the cutting arc when cutting or observing cutting. **WARN** bystanders not to watch the arc or expose themselves to the welding-arc rays or hot metal.
- b. Wear flameproof gauntlet-type gloves, heavy long-sleeve shirt, cuffless trousers, high topped shoes and a welding helmet or cap for hair protection to protect the skin from arc rays and hot sparks or metal. A flameproof apron may also be desirable as protection against radiated heat and sparks.
- c. Hot sparks or metal can lodge in rolled up sleeves, trouser cuffs or pockets. Sleeves and collars should be buttoned, and pockets eliminated from the front of the clothing. Protect other nearby personnel from arc rays and sparks with a suitable non-flammable partition.
- d. Always wear safety glasses or goggles within the cutting area. Use safety glasses with side shields or goggles when chipping slag or grinding. Chipped slag is hot and can travel considerable distances. Bystanders should also wear safety glasses or goggles.

Fire Protection: Hot slag, or sparks, can cause serious fires when in contact with combustible solids, liquids or gases:

- a. Remove all combustible materials well away from the welding area or completely cover the materials with a non-flammable covering. Such combustible materials include wood, clothing, sawdust, gasoline, kerosene, paints, solvents, natural gas, acetylene, propane and similar combustible articles.
- b. Hot sparks or hot metals can fall into cracks in floors or wall openings and cause a hidden smouldering fire. Make certain that such openings are protected from hot sparks and metal. Do not weld, cut or perform other work on used barrels, drums, tanks or other containers until they have been completely cleaned.
- c. For fire protection, have fire extinguishing equipment handy for instant use. After completion of cutting, inspect the work area for hazardous hot sparks or metal.

Electrical Shock: Voltages in excess of 110V can cause severe burns or fatal shock. Severity of electrical shock is determined by the path and amount of current through the body:

- a. Never allow live metal parts to touch bare skin or wet clothing. When standing on metal or welding in a damp area you must be well-insulated. Wear dry gloves and rubber-soled shoes. Stand on a dry board or platform.
- b. Always ground the plasma cutter by connecting a ground wire between the machine and electrical ground. Do not use worn, damaged or overloaded welding cables. Use well maintained equipment.
- c. When not cutting, turn off the equipment. Accidental grounding can cause overheating and create a fire hazard. Do not coil or loop the welding cable around parts of your body. Be sure the ground cable is connected to the workpiece as close to the cutting area as possible. Grounds connected to the building framework or remote locations increase the possibility of stray cutting currents.
- d. Keep everything dry; clothing, work area, welding cables, electrode holder, and cutting machine. Fix water leaks immediately.

Ventilation: Cutting fumes, particularly in confined places, can cause discomfort and physical harm if breathed over an extended period of time:

- a. Provide adequate ventilation by natural or mechanical means. Do not cut on galvanized zinc, lead, beryllium, or cadmium materials unless positive mechanical ventilation is provided!
- b. Do not cut in locations close to chlorinated hydrocarbon vapors from degreasing or spraying operations. Heat or arc rays react with solvent vapors forming phosgene, a highly toxic gas.
- c. If you develop momentary eye, nose or throat irritation during cutting, ventilation is not adequate. Stop work and take necessary steps to improve ventilation. Discontinue cutting if physical discomfort persists.
- d. Refer to AWS Standard Z49.1 in Item 6 for specific ventilation recommendations.

Equipment Maintenance: Faulty or improperly maintained plasma cutting equipment results in poor cut-quality. It can cause physical injury or death through fires or electrical shock.

- a. Whenever possible, have a qualified person perform the installation, troubleshooting and maintenance work on the plasma cutter. Do not perform any electrical work on the plasma cutter unless qualified to perform such work. Before performing any maintenance work inside the plasma cutter, disconnect the machine from the main electrical power source.
- b. Maintain plasma cutting cables, grounding wire and connections, power cord and plasma cutter in safe working order. Do not operate the plasma cutter or accessory equipment in faulty condition. Keep the equipment away from heat sources such as furnaces, wet conditions such as water puddles, oil or grease, corrosive atmospheres and inclement weather.
- c. Keep all safety devices and cabinet covers in position and in good repair. Use the plasma cutter for its intended purpose and do not modify it in any manner. Unauthorized maintenance repair will result in loss of warranty coverage.

Additional Safety Information:

- a. "Safety in Welding and Cutting" - AWS Z49.1
- b. "Recommended Safe Practices for Gas-Shielded Arc Welding" - AWS A6.1
- c. "Safe Practices for Welding and Cutting Containers that Have Held Combustibles" - AWS A6.0
- d. "Recommended Safe Practices for Plasma Arc Cutting" - AWS A6.3
- e. "Recommended Safe Practices for Plasma Arc Welding" - AWS C5.1

Inspection

After removing your plasma cutter from its shipping carton, inspect the plasma cutter for any concealed damage not seen upon receiving the unit. Any claims for loss or damage occurring during shipping must be filed by the purchaser with the freight company.

Check the inlet air supply at the rear of the cabinet to be sure no packing materials have gotten inside to obstruct the air flow to the plasma torch.

Plasma/Cooling Gas Connection

Your plasma cutter has been designed to use clean, dry compressed air as both the plasma and cooling gas. Water and/or Oil in the air will significantly reduce the life of the electrode and the cutting nozzle, at the same time reducing the quality of the cut.

Safety sensing circuitry has been installed to eliminate arc-initiation if the pressure and volume are inadequate.

Damage to your plasma cutter due to excessive water and/or oil in the air supply line is not carried under warranty. HTP America, Inc. has 2 filters available for removing any impurities from the air. If you already have a drier on your compressor, we recommend the HTP Super Dry (Part #25300) which is a disposable in-line filter. This filter uses a desiccant to completely remove all moisture from the air. The desiccant is blue when new and turns clear when the filter needs to be discarded.

<u>Machine Model</u>	<u>Plasma/Cooling Gas Pressure and Volume</u>	
Microcut 125RF	80 to 100 psi	2 1/2 cfm

If you do not have a drier on your compressor, we strongly recommend the HTP Max Dry (Part #25310). This is a 3 stage filter which completely removes all oil and water from the air. The first stage of the Max Dry removes the water which is present in the air. The second stage of the filter removes any oil which may be in the air along with particulate down to .03 microns. The final stage is the desiccant drier, which removes the humidity from the air. The desiccant in the final stage is reusable. It is blue when it is fresh, and changes to pink when it has absorbed moisture. Just put the pink desiccant in the oven to bake the moisture out and reuse. This filter extends the life of your air tools and is great for painting also.

WARNING: Check the air regulator set every day for proper pressure, volume and water/oil levels.

Electrical Connection

All electrical connections should be performed by a qualified electrician in accordance with the National Electrical Code and local codes and ordinances. When connecting your plasma cutter, the yellow-green wire MUST BE CONNECTED TO GROUND, OR SERIOUS INJURY OR DEATH MAY RESULT!

ELECTRICAL SHOCK CAN KILL! Do not connect an input wire to the ground terminal. Do not connect the ground (yellow-green) wire to an input (hot) line terminal. It is also strongly recommended that a fusible line disconnect switch be installed in the input power circuit to the plasma machine. This would provide a safe and easy method to remove all electrical power from your plasma system whenever it is necessary to perform internal inspection or servicing.

BEFORE ATTEMPTING TO MAKE ANY PRIMARY POWER CONNECTIONS TO YOUR PLASMA CUTTER, BE SURE THAT ALL POWER IS OFF BY OPENING THE LINE DISCONNECT SWITCH.

MICROCUT 125RF

Your Microcut 125RF has been designed to operate from 110 volt single phase power wired for a minimum of 20 amps. The green or yellow-green wire must be connected to ground.

Torch Connection

MICROCUT 125RF

This cutter comes with the plasma torch installed on the machine and ready for use. The machine uses the NPT3-RF plasma torch. See page 10 for the parts breakdown.

Ground Cable Connection

Connect the ground clamp as close to the workpiece as possible. This will reduce the possibility of current loss through stray paths. Always connect the clamp to clean, bare metal.

OPERATING CONTROLS

- 1) On - Off Switch
- 2) Cutting Torch



Operation

MICROCUT 125RF

1. Be sure your Micro Cut **125RF** is connected to a clean, dry source of compressed air with a line pressure between 80 and 100 psi.
2. Connect your Micro Cut **125RF** to a 110 volt power supply (see electrical connection). Turn the On-Off switch on. The indicator lamp will light and the fan will begin to turn.
3. Refer to the safety suggestions to be sure the operator has the correct eye protection, gloves, clothing, and that all of the safety precautions have been followed.
4. Connect the ground clamp to a clean surface on the vehicle or the work piece that is as close as possible to the area to be cut. Make sure the ground clamp comes in contact with clean, bare metal. If you are working on an automobile, make sure the ignition is off, and disconnect the battery. Many auto manufacturers recommend the removal of on-board computers — if you have any questions, check with the vehicle manufacturer.

5. Your Microcut 125RF has a brass safety ring on the gas diffuser which prevents the trigger from being operational if the plasma torch is disassembled. Make sure that your gas diffuser is correctly installed on the cutting torch. If the brass ring on the gas diffuser is not making contact with the two brass pins on the gas diffuser is not making contact with the two brass pins on the torch head, the machine will not operate.
6. Depress the trigger on the cutting torch. The air will start to flow, overcoming the spring pressure, which will force the cutting tip against the gas diffuser and away from the electrode. Do not press down at this point. Pressing down will create a direct short. This will result in burning up tip and relay. When the cutting tip moves away from the electrode it will create a spark. This spark can momentarily create a plasma arc for about one tenth of a second, or the plasma arc may be maintained for as long as the trigger is depressed, it varies from plasma cutter to plasma cutter. When you release the trigger, the air will stop and the arc will extinguish.

Familiarize yourself with the consumable parts and their correct assembly onto the torch head (see page 10). Note, when the machine is not cutting, the spring in the torch head is pushing the cutting tip against the electrode. When the trigger is depressed, air will start flowing, overcoming the spring, and forcing the cutting tip against the gas diffuser. Therefore, when you are cutting, it is important to remember not to push down on the cutting tip, or you will ground it against the electrode.

WARNING: Never depress the cutting torch unless the machine has been disconnected from its power supply.

Keep in mind the cutting tip must be able to move freely in the gas diffuser. If this does not happen, the air pressure will not move the cutting tip off the electrode and a direct short will occur. Also, as the cutting tip and electrode wear, it may be possible the cutting tip is not making electrical contact with the electrode. If this happens, depressing the trigger will only start air flowing but will not start the plasma arc. Turn the cutter off and push the cutting tip against the electrode while rotating the cutting tip. This should remove any corrosion that has occurred and will allow the torch to fire up.

Bring the cutting tip in contact with the work. Hold the plasma torch lightly so when you depress the trigger, the cutting tip will be able to move away from the electrode. Do not push the cutting tip against the work, or the air pressure will not be able to push the cutting tip away from the electrode, and the arc will not start. Depress the trigger and the plasma arc will start.

The highest cutting efficiency is achieved by keeping the plasma cutting tip perpendicular and in contact with the work surface putting very little downforce on the plasma torch. Begin to move the plasma torch where you want the metal to be cut. If you move too fast, sparks will shoot up and you will not cut all the way through the work. If you are cutting correctly all the plasma sparks will go beneath the panel you are cutting.

To stop cutting, simply release the trigger on the plasma torch, and the arc will extinguish.

WARNING: Never depress the cutting nozzle with your finger when power is supplied to the machine.

Maintenance and Service

Always disconnect the machine from the main power source before performing any maintenance or service work.


1. Remove machine housing frequently and blow residual material from inside of machine.
2. Check Nozzle and Electrode often for excessive wear due to cutting.
3. Clean exposed torch consumables often. This will maintain their life.
4. Check Nozzle and Electrode often for proper installation.
5. Frequently check the Air Supply quality. This is the single most important factor in the maintenance of the plasma system.
6. If any damage to the machine or torch is noticed, contact your local distributor or HTP America, Inc. directly at 1-800-USA-WELD.

IF ANY SERVICE OTHER THAN THE AFOREMENTIONED IS NECESSARY, IT SHOULD BE PERFORMED BY AUTHORIZED PERSONNEL ONLY.

Cutting Tips


1. When making long, straight cuts, it may be easier to use a metal straight edge as a guide. Simply clamp it to the workpiece to be cut. HTP America, Inc. also manufactures a complete Circle-Cutting and Straight-Line Traversing Assembly for frequent cutting of circles and lines.
2. When cutting heavier gauge material (up to the machine capability) it is recommended to initiate the pilot arc off the edge of the material and dragging the pilot arc to the workpiece.
3. When making rust repairs, it is possible to place the new metal over the rusted area and then cut your patch panel at the same time you cut the rust. This process works similarly when splicing a quarter panel.
4. Please note that sparks from cutting arcs can damage painted surfaces. The sparks will also pit glass. We recommend the use of a welding blanket to protect these surfaces.
5. The best cutting speed is achieved when the plasma arc penetrates the workpiece at an angle of 5-10 degrees. The cutting speed is dependent on material thickness and composition as well as operator proficiency.
6. Never turn the machine off immediately after cutting. Always allow the post air flow circuitry to run its complete cycle to ensure proper cooling of the torch head.
7. It is highly recommended that piercing requirements be kept to a maximum of 75% of rated cutting thickness. This will greatly enhance the plasma torch's consumable life. When piercing thick pieces of metal, it is best to hold the cutting torch at a 45 degree angle to the work until the plasma arc has pierced the material. Holding the torch perpendicular to the work will result in sparks and slag firing back up into the plasma torch, greatly reducing consumable life.

- BT = Torch Trigger
- F₁ = Pressure Switch
- F₂ = Thermo Switch
- K₁ = Contactor
- M = Pan Motor
- MV₁ = Solenoid
- PIP = Parts in Place Circuit
- PGS = Rectifier
- S₁ = On-Off Switch
- T₁ = Control Transformer
- T₂ = Main Transformer
- R₁ = Resistor
- C₁ = Capacitor 50mF (1x)
- C₂ = Capacitor 100 mF (3x)



PLASMA TORCH - NTP3-RF

MICROCUT 125RF



Illust. #	Part #	Description
A	25102-RF	TORCH HEAD (Pkg. of 1)
B	25003B	ELECTRODES TIPS (Pkg. of 3)
C	23058	INSULATOR (Pkg. of 1)
D	23130	CUTTING TIP (Pkg. of 1)
E	23062	SPRING (Pkg. of 1)
F	23005	GAS DIFFUSER (Pkg. of 1)

CONSUMABLE KIT - 23011 RF
 12' PLASMA TORCH - 25912RF