



LPT FIRE PIT SERIES



⚠ WARNING: FOR OUTDOOR USE ONLY

For Use with Propane Tank Only

CODE AND SUPPLY REQUIREMENTS: When an appliance is for connection to a fixed piping system, the installation must conform with local codes, or in the absence of local codes with the National Fuel Gas Code ANSI Z223.1/NFPA 54, OR International Fuel Gas Code.

⚠ WARNING

Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.

An LP-cylinder not connected for use shall not be stored in the vicinity of this or any other appliance.

⚠ WARNING

Improper installation, adjustment, alteration, service or maintenance can cause injury or property damage. Read the installation, operating and maintenance instructions thoroughly before installing or servicing this equipment.

⚠ DANGER

If you smell gas:

1. Shut off gas to the appliance.
2. Extinguish any open flame.
3. If odor continues, keep away from the appliance and immediately call your gas supplier or fire department.

This appliance is designed as an “attended appliance”. Adults must be present when the unit is operating. DO NOT leave this unit burning when unattended. If this product is left burning unattended it may cause damage or serious injury.

⚠ DANGER

CARBON MONOXIDE HAZARD

This appliance can produce carbon monoxide which has no odor.

Using it in an enclosed space can kill you.

Never use this appliance in an enclosed space such as a camper, tent, car, or home.



INSTALLER - Owner's Manual must be left with the consumer for future reference.

CONSUMER - Owner's Manual must be saved for future reference.

STARFIRE DIRECT LPT FIRE PIT SERIES – TABLE OF CONTENTS

Cover – Important Safety Information.....	1
Table of Contents.....	2
Important Safety Information	
Minimum Clearances to Combustibles.....	2
Pre-Installation & Preparation Guidelines.....	3
Installation Information	
Connecting the Gas to the Fire Pit.....	5
Operating Instructions.....	6
Lighting Instructions.....	6
Operating Information.....	4
Maintenance and Care.....	7
Warranty.....	7

IMPORTANT SAFETY INFORMATION

READ THESE INSTRUCTIONS FULLY BEFORE INSTALLING THIS OUTDOOR FIRE PIT.


If not installed and used correctly per these instructions, this product can cause serious injury.

CAUTION: INSTALLATION, MODIFICATION AND REPAIR MUST BE DONE BY A QUALIFIED, PROFESSIONAL INSTALLER.

Be sure you understand all safety precautions and warnings contained in this manual.

- A. CHECK STATE AND LOCAL CODES TO DETERMINE IF THE OUTDOOR FIRE PIT IS PERMITTED IN YOUR LOCALITY BEFORE INSTALLATION.
- B. FOR OUTDOOR USE ONLY. THIS UNIT MUST BE INSTALLED AT LEAST 60" FROM CENTER OF BURNER TO ANY COMBUSTIBLE WALLS, CEILINGS, OR MATERIAL.
- C. When shutting the unit down—be sure to TURN THE CONTROL VALVE FULLY OFF.
- D. **WARNING: CARBON MONOXIDE POISONING MAY LEAD TO DEATH. DO NOT MODIFY THIS OUTDOOR FIRE PIT OR ITS CONTROLS, EXCEPT AS PROVIDED FOR IN THIS MANUAL.**
Any other change may be dangerous. Improper installation or use of your Outdoor Fire Pit can cause serious injury or death from fire, burns, explosions or carbon monoxide poisoning.

MINIMUM CLEARANCE TO COMBUSTIBLES



Clearances to Combustible Construction:

- Sidewalls: 60" (1.5 m) from center of unit (Figure 1)
- Ceiling: 60" (1.5 m) from top of unit to ceiling or overhang
- Flooring: 0" – Can be installed on deck, slab, floor, etc.

The dimensions shown in Figure 1 are **MINIMUM CLEARANCES** to maintain when you install this Outdoor Fire Pit. **THERE MUST BE AT LEAST 60" of clearance from the center of the unit** to any combustible sidewalls, ceilings, or materials.

IMPORTANT SAFETY INFORMATION

OPERATING INSTRUCTIONS

- A. **YOUNG CHILDREN SHOULD BE CAREFULLY SUPERVISED WHEN THEY ARE IN THE AREA OF THIS APPLIANCE.**
- B. **DO NOT sit or place any part of the body or combustible materials on the Fire Pit surround. Children and adults should be alerted to the hazard of high surface temperatures and should stay away to avoid burns or clothing ignition.**
- C. Every time you use your Fire Pit make sure that the area around the Fire Pit is clear of flammable items such as gasoline, yard debris, wood, etc.
- D. **WARNING: HOT WHILE IN OPERATION AND FOLLOWING OPERATION.** Children must be carefully supervised when in the vicinity of this appliance. Serious injury may occur. **DO NOT** throw trash, paper, or other flammable materials onto your Fire Pit. **DO NOT** leave in operation when unattended. **WARNING: DO NOT operate this Fire Pit in the rain.**
- E. SOLID FUEL MUST NOT BE BURNED in the Fire Pit.
- F. **DO NOT** continue using if you smell unusual odors or have headaches, nausea or are dizzy.
- G. **DO NOT** store any combustible materials, gasoline, or any other flammable vapors/liquids around the area of your Fire Pit. Provide adequate clearance for servicing and operation.
- H. **DO NOT hang or place clothing or any flammable material on or near your Fire Pit.** Matches, paper, garbage, or any other material must not be thrown on top of the lava rock, logs, or burner, or into the flame.
- I. **DO NOT use this appliance if any part of it has been under water.** Immediately call a qualified service technician to inspect the appliance and to replace any part of the control system and any gas control which has been under water.
- J. **Installation and repair should be done by a qualified service person.** Open the door on the unit to gain access for inspection.
- K. **The appliance should be inspected before use and at least annually by a qualified service person.** More frequent cleaning may be required as necessary. It is imperative that control compartment, burners and circulating air passageways of the appliance be kept clean.
- L. The burner must be replaced prior to the appliance being put into operation if it is evident that the burner is damaged. Contact Starfire Direct at 866-578-8538 for a replacement burner.

IMPORTANT SAFETY INFORMATION

PRE-INSTALLATION AND PREPARATION SAFETY GUIDELINES

- A. Before installing this Outdoor Fire Pit, check “Minimum Clearance to Combustibles” on page 2. **MINIMUM CLEARANCES** must be maintained when you install this Outdoor Fire Pit. **THERE MUST BE AT LEAST 60” (1.5 m)** from the center of the burner to any combustible sidewall, ceiling, or material.
- B. The Outdoor Fire Pit is for outdoor use only. **DO NOT** install or use this appliance inside a building, garage, or any other enclosed area including recreational vehicles and/or boats. **This unit must be installed in such a manner that proper air ventilation is maintained without obstruction at all times, and during all weather conditions.**
- C. **CHECK GAS TYPE** (natural gas or propane): The gas supply you intend to use may not be the same as that intended for use with this fire pit. **THIS FIRE PIT IS CONSTRUCTED FOR USE WITH PROPANE GAS.** If the gas supply is different, or **or you wish to change to natural gas, you MUST have the Fire Pit converted to the gas type you intend to use, by a qualified, professional installer.**
If you are unsure, contact your dealer for assistance.
- D. **DO NOT USE IF GAS PRESSURE IS LOWER THAN THE MINIMUM REQUIREMENT OR EXCEEDS THE MAXIMUM.**
- E. **FOR NATURAL GAS:** The minimum inlet gas supply pressure for purposes of input adjustment is **5 inches** (127 mm) water column and maximum inlet gas supply pressure is **10 inches** (254 mm) water column. **FOR PROPANE:** The minimum inlet gas supply pressure for purposes of input adjustment is **8 inches** (203 mm) water column and the maximum inlet gas supply pressure is **13 inches** (330 mm) water column. **DO NOT INSTALL THIS UNIT IF MINIMUM PRESSURE IS NOT AVAILABLE OR IF MAXIMUM PRESSURE IS EXCEEDED.**
- F. Gas piping system must be sized to provide minimum inlet pressure at the maximum flow rate (BTU/hr). Undue pressure loss will occur if the pipe is too small or the run is too long.
- G. For installations at elevations above 2,000 ft., contact your local dealer or gas supplier before installing as input ratings will be reduced approximately 4% for each 1,000 ft. above sea level. Refer to the National Fuel Gas Code. **Contact the dealer for the required orifice** (Also see page 8 of instructions).
- H. If the Outdoor Fire Pit is connected to Natural Gas, its main gas valve must be disconnected from the gas supply piping system during any pressure testing of that system at test pressures in excess of ½ psi (3.5kPa).
- I. If the Outdoor Fire Pit is connected to Natural Gas, it must be isolated from the gas supply piping system by closing its individual manual shut-off valve during any pressure testing of the gas supply piping system at test pressures equal to or less than ½ psi (3.5kPa).
- J. **INSTALLER NOTE: This unit should be installed so that it can be removed at a later date for service.**
- K. **GAS SUPPLY PLUMBING REQUIREMENTS**
Apply only joint compounds that are resistant to all gasses on all male pipe fittings. Make sure to tighten every joint securely. Do not use pipe joint compound to connect flare fittings.

SAFETY NOTE: An external on/off valve in the gas line is required for safety when your Outdoor Fire Pit is not in use. It also provides for convenient maintenance and repair.

INSTALLATION INFORMATION CONNECTING THE GAS TO THE FIRE PIT

IMPORTANT

BEFORE PROCEEDING, CAREFULLY READ ALL OF THE IMPORTANT SAFETY INFORMATION CONTAINED IN THIS OWNER'S MANUAL, INCLUDING:


- A. Pre-Installation and Outdoor Fire Pit Preparation Safety Guidelines (page 3).
- B. Log Installation Guidelines (Page 5).
- C. Minimum Clearance to Combustibles (page 2).

LP-GAS CYLINDER INFORMATION:

1. Cylinder Size: 20 Lbs. (9kg) Capacity: 4.7 Gallons (17.8 Liters).
2. The LP-gas cylinder(s) to be used must be constructed and marked in accordance with the U.S. Department of Transportation (D.O.T.) Specifications for LP-Gas Cylinders or the Standard for Cylinders, Spheres and Tubes for Transportation of Dangerous Goods and Commission, CAN/CSA-B339 as applicable.
--Use propane cylinders approved for your area such as "Blue Rhino" or "AmeriGas" with this appliance.
--The LP-gas supply cylinder to be used must be provided with a listed overfilling prevention device and with a cylinder connection device compatible with the connection for the appliance.
3. If the appliance is not in use, the gas must be turned off at the supply cylinder.
4. The cylinder must be disconnected when the appliance is not in use.
5. The LP-gas cylinders must be stored outdoors in a well-ventilated area out of the reach of children. Disconnected cylinders must have threaded valve plugs tightly installed and must not be stored in a building, garage, or any other enclosed area.
6. The cylinder supply system must be arranged for vapor withdrawal.
7. The cylinder used must include a collar to protect the cylinder valve.

BEFORE INSTALLATION, BE SURE THE PROPANE TANK IS TURNED OFF.

To connect to the propane gas tank, attach the black hose (with regulator) and tighten down the connector. Follow all instructions and safety warnings supplied with the propane tank. (See diagram below.)



Turn on the gas to the burner system and test for leaks with soapy water solution.

(Never use an open flame for testing). If a leak is found, tighten the connector until no leaks are detected.

The hose and burner should be inspected before each use of the appliance.

The hose assembly must be replaced prior to the appliance being put into operation if there is evidence of excessive abrasion or wear, or if the hose is damaged. The replacement hose shall be that specified by the manufacturer.

OPERATING INSTRUCTIONS

**We recommend that before you install your Fire Pit you familiarize yourself with the control valve layout. This will help you to be confident operating the Fire Pit when fully installed (see figures below for typical control positions).*

FOR YOUR SAFETY, READ BEFORE LIGHTING

WARNING: IF YOU DO NOT FOLLOW THESE INSTRUCTIONS EXACTLY, A FIRE OR EXPLOSION MAY RESULT CAUSING PROPERTY DAMAGE, PERSONAL INJURY OR LOSS OF LIFE.


BEFORE LIGHTING, smell all around the Outdoor Fire Pit area for gas. Be sure to smell next to the floor because some gas is heavier than air and will settle on the floor. **IF YOU SMELL GAS FOLLOW THE INSTRUCTIONS ON PAGE 1.**

DO NOT use this appliance if any part has been under water. Immediately call a qualified, professional service technician to inspect the Outdoor Fire Pit and to replace any part of the control system and any gas control that has been under water.

LIGHTING INSTRUCTIONS

STOP – READ SAFETY INFORMATION ABOVE.

1. Enter the included valve key into the key valve opening.
2. Using a long safety lighter, hold an open flame above the outdie edge of the burner ring.
3. Slowly turn the valve key towards the “ON” position.
4. Once fire ring is lit, remove safety lighter and turn key valve up or down for desired flame height.




Key Valve Opening
with Valve Key

Shutting Off the Fire Pit

To turn off, insert valve key into the key valve opening and rotate to the off position.

CAUTION:
DO NOT turn the main gas valve knob to the “ON” position **FOR 5 MINUTES** after shutting the unit off.

MAINTENANCE AND CARE

 **CAUTION** - Always remove any debris from the burn area.

Clean Regularly. Starfire Direct recommends using our Beeswax surface protectant as a spot cleaner and used regularly to maintain the lustrous finish on the metal. You can contact Starfire Direct's sales team at 866-578-8538 to place an order.

Professional Inspection. This fire pit must be inspected by a qualified serviceman regularly to ensure that all gas connections are tight and check for any leaks, cracked hoses, or burner clogs. Frequency of inspections is dependent on usage.

WARRANTY

Starfire Direct warrants this fire pit against manufacturing defects that prevent safe and correct operation of the product for a period of one year from the date of delivery.

The defective product must be shipped back with an RMA (Return Merchandise Authorization) issued by Starfire Direct for that specific product which states the nature of the defect or warranty claim. Product to be returned should be packed carefully—Starfire Direct is not responsible for damage on returned items. The original purchase information will be required. RMAs are only valid for 30 days from the date of issue and will not be processed if received after the expiration date. The RMA number must be indicated on the outside of the return package and a copy of the RMA in the package with product.

Our warranty does not cover items that have been damaged by over heating, modification, abuse, improper storage, installation, or maintenance. This warranty excludes claims for incidental or consequential damage and indirect-collateral expenses arising from product defects or warranty recovery. Starfire Direct is not responsible for the actions including negligence of the installer.

Starfire Direct is NOT responsible for local codes and/or if any of our products are not approved for installation. Please check with your local building department or governing agencies for proper approvals before purchasing.