

Small 50 Spray and Grout Pump

Setup for pumping only:

1. Attach gauge to pump
2. Attach 1" hose to gauge (see section on fine tuning the pump)
3. Plug in power cord (blue light will illuminate)
4. Plug 5v remote cable into yellow port
5. Fill hopper with water (this lubricates the hose)
6. Turn on pump (yellow dial on right side) from position 0 to 1 (numbers should illuminate on LED read out)
7. Set LED to read 50Hz by using the plus or minus buttons
8. Set the dial (below + / - buttons) to forward (clockwise)
9. Press on the remote switch to begin pumping (material will begin to flow)
10. Add slurry mix of Portland cement based product (only if using cement based materials) to an empty hopper and begin to pump. *This will lubricate hose to allow material to flow easier.*
11. Add your material to be pumped into the hopper
12. Adjust pump speed accordingly



Setup for pumping and spraying of cement based materials:

1. Follow steps 1 – 3 pumping only section (remote cable not used for this operation)
2. Loosen handle clamps and slide handle away from unit
3. Insert compressor into handle and push towards the hopper until the rubber isolators make contact and then tighten knobs to clamp handle
4. Attach air hose from the compressor into either port on the right side of unit when looking at the display panel
5. Attach the air line to the remaining open air port
6. Attach the Koine gun to the end of the material hose (valve on gun should be closed)
7. Select the right nozzle for the application (orifice size and spray pattern)
8. Attach the air line to the gun
9. Follow steps 5 – 8 above
10. Open the air valve on the gun (this will start the compressor and the pump)
11. Follow steps 10 – 12

Setup for pumping and spraying of paints and coatings:

1. Follow steps 1 – 5 in the previous section
2. Attach the finish and coatings gun to the end of the material hose (red valve on gun should be closed)
3. Select the right nozzle for the application (orifice size and spray pattern)
4. Attach the air line to the gun
5. Fill the hopper with water (This lubricates the hose)
6. Set LED to read 25Hz by using the plus or minus
7. Set the dial (below + / - buttons) to forward (clockwise)
8. Open the valve on the gun (this will start the compressor and the pump)
9. Pour the material to be used into the hopper once all the water is out of the hopper
10. Adjust pump speed accordingly and bleed air from valve accordingly from gun

Small 50 Spray and Grout Pump

Cleaning instructions

1. Empty hopper
2. Pull out drain plug from under the hopper
3. Disconnect the material hose
4. Disconnect the gauge
5. Disconnect the gun
6. Rinse hopper and unit clean with water (display panel is splash proof) until all material is rinsed thoroughly
7. Replace the drain plug
8. Fill hopper with water
9. Turn unit on via the remote (if attached) or the valve on the gun (pump will start turning)
10. Clean the end of the stator with the supplied cleaning tool to remove any debris (tool was designed not to interfere with screw)
11. Stop unit
12. Wipe the end of the hose clean (the side to be inserted back into the stator)
13. Insert sponge ball into the end of the pump (this will wipe clean the inside of the hose)
14. Insert the hose back onto the stator
15. Fill hopper with water
16. Turn unit on and set above 50hz
17. Catch the sponge ball from the other side of hose (only one time necessary)
18. Clean gauge, tips and gun thoroughly
19. Drain any excess water left in the hopper and pump

Fine tuning:

Have the unit auto-reverse when pump is stopped

1. Shut off unit by turning the switch on the right side to the 0 position
 2. Hold down the plus & minus buttons simultaneously
 3. Turn the unit back on the 1 position still holding the plus & minus buttons (about 5 seconds) a number 3 will flash and you can now release
- To deactivate, simply follow steps 1 – 3

Adjusting the screw / stator:

1. Attach the gauge to the end of the stator
2. Attach the hose to the end of the gauge
3. Fill unit with water
4. Kink hose to restrict flow
5. Turn on unit
6. Check the gauge to read 150 psi or 10 bar (note that the top numbers measure bar)
 - If more, then loosen the 3 bolts with 19mm wrenches one revolution each until correct
 - If less, then tighten the 3 bolts with 19mm wrenches one revolution each until correct

For technical support you can call us at IMERUSADIRECT toll free at 844-463-7776.
If you are unable to reach us you can call Robert Bacarella @ 917-757-0669