


Model No. MJ-F10

Two Post Lift,

Manual Release

Installation, Operation
and Parts Manual

MAJOR



Distributed by

Please read this entire manual carefully and completely before instal-

the lift.

IMPORTANT NOTES

Before start up, connecting and operating MAJOR products, it is absolutely essential that the operating instructions/owner's manual and, in particular the safety instructions are studied carefully. By doing so you can eliminate any uncertainties in handling MAJOR products and thus associated safety risks up front; something which is in the interest of you own safety and will ultimately help avoid damage to the device, When an MAJOR product is handed over to another person, not only the operating instructions but also the safety instructions and information on its designated use must be handed over to the person.

By using the product you agree the following conditions:

Copy right

The enclosed instructions are the property of MAJOR or its supplier, and are protected against duplication and reproduction by copyright laws, international agreements, and other domestic legislation. The reproduction or disclosure of instructions or an extract thereof is prohibited and offenders are liable to prosecution; MAJOR reserves the right or initiates criminal proceedings and asserts claims for damages in the event of infringements.

Warranty

The use of non-approved hardware will result in a modification of our products and thus to the exclusion of any liability or warranty, even if such hardware has been removed again in the interim.

It is not permissible to make any changes to our products and these are not only to be used together with genuine accessories and genuine replacement parts. Otherwise any warranty claims will be invalid.

Liability

The liability of MAJOR is limit to the amount that the customer has actually paid for this product. This exclusion of liability does not apply to damages caused through willful misconduct or gross negligence on the part of MAJOR.

All information in this manual is believed to be correct at time of publication.

MAJOR reserves the right to amend and alter technical data and composition without prior notice.

Please confirm at time of ordering.

IMPORTANT NOTES	2
SAFETY NOTES	4
1.1 Operation of lifting platforms.....	4
1.2 Checking of the lifting platforms	4
1.3 Important safety notices.....	5
1.4 Warning labels.....	6
1.5 Potential safety risks.....	7
1.6 Noise level.....	7
PACKING, STORAGE AND TRANSPORTATION	8
2.1 The lift was dismantled into the following 3 parts for transportation	8
2.2 Storage	8
2.3 Opening the packs	8
PRODUCTS DESCRIPTIONS	9
3.1 General descriptions.....	9
3.2 Construction of the lift.....	9
3.3 Technical data	9
3.4 Dimensions	10
3.5 Safety devices descriptions.....	11
INSTALLATION INSTRUCTIONS	11
4.1 Preparations before installation.....	11
4.2 Installation attentions	12
4.3 General installation steps.....	12
4.4 Items to be checked after installation	19
OPERATION INSTRUCTIONS	19
5.1 Precautions.....	19
5.2 Operation instructions.....	19
TROUBLE SHOOTING	21
INSPECTION AND MAINTENANCE	22
Annex 1, Floor plan.....	24
Annex 2, Electrical schemes and parts list.....	26
Annex 3, Hydraulic schemes and parts list	28
Annex 4, Mechanical exploded drawings and parts list	30

SAFETY NOTES

1.1 Operation of lifting platforms

This lift is specially designed for lifting motor vehicles. Users are not allowed to use it for any other purposes. The applicable national regulations, laws and directives must be observed.

Only users aged 18 or above who have been instructed on how to operate the lifting platform and have proven their ability to do so to the owner are to be entrusted with unsupervised operation of lifting platforms. The task of operating the lifting platforms must be granted in writing.

Before loading a vehicle onto the lift, users should study the original operation instructions and familiarize themselves with the operating procedures in several trial runs.

Lift vehicle within the rated load. Don't attempt to raise vehicles with excessive weight.

1.2 Checking of the lifting platforms

Checks are to be based on the following directives and regulations:

- Basic principles for testing lifting platforms
- The basic health and safety requirement
- The applicable accident prevention regulations

The checks are to be organized by the user of the lifting platform. The user is responsible for appointing an expert or qualified person to perform checking. It must be ensure that the person chosen satisfies the requirements.

The user bears special responsibility if employees of the company are appointed as experts or qualified persons.

1.2.1 Scope of checking

Regular checking essentially involves performing a visual inspection and a functional test. This includes checking the condition of the components and equipment, checking that the safety systems are complete and functioning properly and that the inspection log book is completely filled in. The scope of exceptional checking depends on the nature and extent of any structural modification or repair work.

1.2.2 Regular checking

After initial commissioning, lifting platforms are to be checked by a qualified person at intervals of not longer than one year.

A qualified person is somebody with the training and experience required to possess sufficient knowledge of lifting platforms and who is sufficiently familiar with the pertinent national regulations, accident prevention regulations and generally acknowledged rules of engineering to be able to assess the safe operating condition of lifting platforms.

1.2.3 Exceptional checking

Lifting platforms with a lift height of more than 2 meters and lifting platforms intended for use with people standing under the load bearing elements of the load are to be checked by an expert prior or reuse following structural modifications and major repairs to load bearing components.

An expert is somebody with the training and experience required to possess specialist knowledge of lifting platforms and who is sufficiently familiar with the pertinent national work safety regulations, accident prevention regulations and generally acknowledged rules of engineering to be able to check and give an expert opinion on lifting platforms.

1.3 Important safety notices

1.3.1 Recommend for indoor use only. DO not expose the lift to rain, snow or excessive moisture.

1.3.2 Only use this lift on a surface that is stable and capable of sustaining the load. Do not install the lift on any asphalt surface.

1.3.3 Read and understand all safety warnings before operating the lift.

1.3.4 Do not leave the controls while the lift is still in motion.

1.3.5 Keep hands and feet away from any moving parts. Keep feet clear of the lift when lowering.

1.3.6 Only these properly trained personnel can operate the lift.

1.3.7 Do not wear unfit clothes such as large clothes with flounces, ties, etc., which could be caught by moving parts of the lift.

1.3.8 To prevent evitable incidents, surrounding areas of the lift must be tidy and with nothing unsecured.

1.3.9 The lift is simply designed to lift the entire body of vehicles, with its maximum weight within the lifting capacity.

1.3.10 Always insure the safety locks are engaged before any attempt to work near or under the vehicle. Never remove safety related components from the lift. Do not use if safety related components are damaged or missing.

1.3.11 Do not rock the vehicle while on the lift or remove any heavy component from vehicle that may cause excessive weight shift.

1.3.12 Check at any time the parts of the lift to ensure the agility of moving parts and the performance of synchronization. Ensure regular maintenance and if anything abnormal occurs, stop using the lift immediately and contact our dealers for help.

1.3.13 Lower the lift to its lowest position and do remember to cut off the power source when service finishes.

1.3.14 Do not modify any parts of the lift without manufacturer's advice.

1.3.15 If the lift is going to be left unused for a long time, users are required to:

a. Disconnect the power;

b. Empty the oil tank;

c. Lubricate the moving parts with hydraulic oil.






WARNING: The warnings, cautions and instructions discussed in this instruction manual cannot cover all possible conditions and situations that may occur. It must be understood by the operator that common sense and caution are factors which cannot be built into this product, but must be supplied by the operator.

1.4 Warning labels

SAFETY ADVICE

S40101441

	Only trained personnel are allowed to operate the lift.
	Always keep lift area clear when lowering or raising vehicle.
	Do not try to raise a vehicle exceeds the rated capacity.
	Always raise a vehicle with four swing arms.
	Position and adjust pads to lifting points recommended by vehicle manufacturers.

	Stop and check lift arm locks and stability of vehicle after short raising, then to desired height.
	Watch closely the vehicle during raising or lowering.
	Always use safety stands when moving/ installing heavy components.
	Avoid excessive rocking of vehicle while on lift.
	Do not climb onto the lift or raised vehicle during lifting or lowering.

1.5 Potential safety risks

1.5.1 Mains voltage



Insulation damage and other faults may result in accessible components being live

Safety measures:

- Only ever use the power cord provided or a tested power cord.
- Replace wires with damaged insulation.
- Do not open the operating unit.

1.5.2 Risk of injury, danger of crushing

In the event of excessive vehicle weight, incorrect mounting of the vehicle or on removing heavy object, there is a risk of the vehicle falling off or tipping up.

Safety measures:

- The lift is only ever to be employed for the intended purpose.
- Carefully study and heed all the information given in Section 1.4.
- Observe the warning notices for operation.

1.6 Noise level

Noise emitted during operating the lift should be less than 70dB(A). For your health consideration, it is suggested to place a noise detector in your working area.

PACKING, STORAGE AND TRANSPORTATION

Packing, lifting, handling, transporting operations must be performed only by experienced personnel with appropriate knowledge of the lift and after reading this manual.

2.1 The lift was dismantled into the following 2 parts for transportation

<i>Description</i>	<i>Packed by</i>	<i>Quantity</i>
<i>Lift -F10</i>	<i>Steel brackets</i>	<i>1</i>
<i>Power unit -F10</i>	<i>Carton</i>	<i>1</i>

2.2 Storage

The packs must be kept in a covered and protected area in a temperature range of -10°C to +40°C. They must not be exposed to direct sunlight, rain or water.

Stacking the packs

We advise against stacking because the packs are not designed for this type of storage. The narrow base, heavy weight and large size of the packs make stacking difficult and potentially dangerous.

If stacking is unavoidable, use all appropriate precautions:


-never stack to more than 2 meters in height.

-never make stacks of single packs. Always stack pairs of packs in a cross pattern so that the base is bigger and the resulting stack is more stable. Once the stack is complete, restrain it using straps, ropes or other suitable methods.

A maximum of two packs can be stacked on lorries, in containers, and in railway wagons, on condition that the packs are strapped together and restrained to stop them falling.

2.3 Opening the packs

The packs can be lifted and transported only by using lift trucks. Never attempt to hoist or transport the unit using lifting slings.



When the lift is delivered make sure that it has not been damaged during transportation and that all the parts specified on the packing list are present.

Packs must be opened adopting all the precautions required to avoid injury to persons (keep at a safe distance when cutting the straps) or damage to parts of the machine (be careful that no parts are dropped while you are opening the packing).

Take special care with the hydraulic power unit, the control panel and the cylinder.

PRODUCTS DESCRIPTIONS


3.1 General descriptions

This is chassis supporting vehicle lift for road vehicles.

It is mainly composed by two posts, two carriages, four swing arms and a power and control unit.

It is driven by an electro-hydraulic system. The gear pump delivers hydraulic oil to oil cylinders and pushes upwards its piston. The cylinder piston drives to raise the carriage and swing arms. It is equipped with mechanical safety locking unit which ensures no risks of slipping off in case of hydraulic failure.

3.2 Construction of the lift





- 1. Post
- 2. Mechanical safety latch
- 3. Hydraulic power unit
- 4. Lifting arm
- 5. Base plate
- 6. Top plate assembly
- 7. Hydraulic cylinder
- 8. Carriage


3.3 Technical data

Maximal Capacity	4500kg (10000 lbs.)
Full rise height	1900mm (74 3/4")
Min height	90mm(3 9/16")
Full rise time (with rated load)	Approx. 70s
Full descent time (with rated load)	Approx. 50s
Oil tank volume	10L(2.64 US gal)

3.4 Dimensions



3.5 Safety devices descriptions



POS.	Description	Function
1	Arm lock	Ensure the supporting arms are locked and avoid swinging during lifting process
2	Steel cable	Balance carriages at both sides.
3	Rubber pad	Safe contact with the wheelbase
4	Mechanical safety locking unit	Catch the carriages in case of hydraulic failure
5	Max height limit switch	Stop rising at max height

INSTALLATION INSTRUCTIONS

4.1 Preparations before installation

4.1.1 Space requirements

Refer to 3.4 for the dimensions of the lift. There must also be a clearance of at least 1 meter between the lifting platform and fixed elements (e.g. wall) in all lifting positions. There must be sufficient space for driving vehicles on and off.

4.1.2 Foundations and connections

The user must have the following work performed before erecting the lift.

Construction of the foundation following consultation with the manufacturer's customer service or an authorized service agent. Routing of the wiring to the installation location. **The user must provide fuse protection for the connection. Electrical system connection must be done by licensed technicians.** Requirements for power supply cable of the installation site: at least 2.5mm² wire core for 3Ph power and 4.0mm² wire core for 1Ph power.

Refer also to the corresponding information on the name plate and in the operation instructions.

Before doing electrical connection, make sure the lift is electrically adapt to the local power supply.

4.1.3 Foundations preparations

Refer to Annex 1 for footing.

To ensure stability and safety under load, the lift shall be installed with the base frame being in direct and firm contact with the concrete foundation. Don't attempt to fix the base frame directly onto floor with ceramic and other decorated surfaces otherwise you put the lift into a very dangerous situation.

C25 concrete foundation with a minimum thickness of 200mm (7 7/8") (continuous footing).

Surface: Horizontal and even (Gradients max. 0.5 %)

Newly built concrete ground must be older than 20days.

4.1.4 Tools and equipment needed for installation

Tool name	Specification	Quantity
Electrical drill	D18 drill bit	1
Open spanner	D17-19	2
Adjustable spanner	bigger than D30	1
Cross socket screw driver	PH2	1
Quick spanner handle adapter/ Ratchet	REB-310	1
Socket spanner	D24	1
Levelling device	Accuracy: 1mm(1/16")	1
Hammer	10 pounds	1
Truck lift	Capacity, 1000kg (2200 lbs.)	1
Lifting string	Capacity, 1000kg (2200 lbs.)	2
Torque spanner	MD400	1

4.2 Installation attentions

4.2.1 Joints of oil hose and wiring must be firmly connected in order to avoid leakage of oil hose and looseness of electrical wires.

4.2.2 All bolts should be firmly screwed up.

4.2.3 Do not place any vehicle on the lift in the case of trial running.


4.3 General installation steps

ONLY TRAINED AND QUALIFIED INSTALLERS CAN PERFORM LIFT INSTALLATION DUTIES.

Step 1: Remove the packaging and take out the accessories attached.

Attention : The packs must be opened adopting all the precautions required to avoid injury to persons (keep at a safe distance when cutting the straps) or damage to parts of the machine (be careful that no parts are dropped while you are opening the packing).

Use proper means (put something supporting under the post or suspend the post by a crane) to suspend the post, unscrew and remove the bolts fixed on the iron rack.



- 1. Hex bolt
- 2. Iron rack

Attention : Please pay special attention not to let the post fall down for it may cause casualty or bring damages to the accessories fixed in the post.


Step 2: Fix the standing position for the two posts. (See Annex 1, floor plan)

1. Decide on which post the power unit is going to be mounted.
2. Draw an outline of the base plate on the installation ground with chalk and ascertain the position for the two posts.



Step 3: Erect and secure the post.

Anchoring bolts: M3/4" * 6 1/2", screw torque (63-74b.ft) 80-100Nm

1. Make the posts face to each other and the distance between the posts equals to the length of the base plate. Use proper means to erect the post.
2. Use suitable means to raise the lifting carriage to the first latching position. All the mounting holes in the base plate are then accessible. Make sure the locking pawl is engaged.
3. Check and align the position of the base plates again.
4. Drill the mounting holes. Remove the drilling dust from the hole.
5. Use a spirit level to check the vertical alignment of the posts. If necessary, place equalizing plates under the base plates.




- A. Nut
- B. Expansion anchoring bolt
- C. Equalizing plate



Anchoring bolt	A1 (foundation thickness)	A2 (drilling depth)	A3 (anchoring depth)	B	C
M19x165	≥200mm (7 7/8")	130mm(5 1/8")	110mm(4 6/15")	240mm (9 7/16")	≤55mm(2 3/16")


(3/4"x6 1/2")

Step 4: Assemble and fix the mechanical locking device



a. Assemble the locking device.


Locking assembly at the power-side post



- 1. Safety hook
- 2. Release plate
- 3. Nut
- 4. Hex socket cylinder head screw
- 5. Hex socket cylinder head screw
- 6. Guiding pulley
- 7. Rope clip

- 8. Rope ring
- 9. Cotter pin
- 10. Handle ball
- 11. Handle
- 12. Shaft
- 13. Pull spring

Locking assembly at the other post




- 1. Safety hook
- 2. Pull spring
- 3. Guiding pulley
- 4. Rope clip
- 5. Shaft
- 6. Cotter pin
- 7. Rope ring

b. Fix the release rope at the power side post


Let one end of the rope (1) go around and the ring (3) and bind it with a special clip (2).

Make the ring wound up with rope go through the shaft as indicated in the following drawing and fix a cylindrical pin onto the shaft so as to prevent the ring from going off the shaft.


Make the other end of the rope go through the pulley above the hook and let it go downwards to the bottom of the column.




c. The release rope goes through pulley at the bottom of the column



d. Fix the rope onto the locking unit at the other post.




e. Fix the protective cover.



15. Protective cover


Step 7: Connect the synchronization steel cable.

1. Route and fix according to the following scheme.
2. Before attempting to route the cables, raise the lifting carriage at both sides to the first latching position making sure that the mechanical safety locking units in each post are fully engaged.
3. After fixed the cables, adjust and make the cables at both sides be under the same tension which could be judged by the sound emitted during lifting process.
4. Grease the cable after being fixed. (It is a must.)



Step 8: Connect the hydraulic system.


1. Install hydraulic power unit onto the power side post.



1. Hex nut M10
2. Flat washer M10
3. Spring washer M10
4. Anti-vibration pad
5. Hex head full swivel screw M10*30

2. Connect oil hoses according to the following diagram.

Don't let any solid substance go into the hydraulic line. Ensure the connectors are screwed tight against leakage.



- 1. Power unit
- 2. Oil hose 1
- 3. Composite connector
- 4. Oil hose 2
- 5. Two-way connector
- 6. Cylinder
- 7. Cylinder fitting
- 8. Oil hose 3
- 9. Cylinder fitting


Step 9: Make the electrical connection.

ONLY qualified electricians are permitted doing the electrical connection.

Read the name plate and check that the supply voltage is adapted to the voltage of the lift.


Read the electrical scheme in Annex 2 for reference.

1. Fix max height limit switch onto the power side post and connect its wire to the terminals reserved at the motor.



- Max height limit switch
- Cross socket cap head screw M4x25
- Cross socket cap head screw M4x12

2. Connect the power supply cable.




- 1. Power unit
- 2. Power supply cable

Step 10: Install lifting arms.

The arm pin shafts (No. 2) must be greased at the installation.

Install the lifting arms onto the carriages and ensure the arm lock could work.

Attention: Install Lifting arms ONLY after the complete assembly has been erected and anchored.



- 1. Carriage
- 2. Pin shaft
- 3. Swing arm
- 4. Pulling rod
- 5. Arm lock

Step 11: Fill with hydraulic oil.

ONLY CLEAN AND FRESH OIL ONLY

Lift must be fully lowered before changing or adding hydraulic oil.

Prepare 3 US gals of anti-abrasion hydraulic oil. Fill about 2.65 gals into the oil tank to run the lift up and down for 2 or 3times after the electrical system is connected.

Add more oil after running the lift for several cycles until the lift can rise to the maximum height.

Note: It is suggested to use HM NO.46 hydraulic oil .It is advised to use HM NO.32 hydraulic oil when temperature is below 10 degree Celsius. Change the oil 6 months after initial use and once per year thereafter.

Step 12: Trial running.

Get familiar with lift controls by running the lift through a few cycles before loading vehicle on lift. This step is of particular importance as it can check if the oil hose is correctly connected. The connection is qualified when there is no abnormal sound or leakage after having been tested for 5-6 cycles .

If the lift doesn't raise, the motor may turn in the wrong direction. In such event, interchange wires U, V in the connection box.

Check the synchronization of both lifting carriages.

Ensure the synchronization by adjusting the balance steel cables at both sides. Make both cables be of the same tightness.

This could be judged by the sound emitted by the safety locking unit during lifting process.

Check the mechanical safety locking unit.

Check and ensure both safety locking hooks can be effectively engaged or released.

4.4 Items to be checked after installation

S/N	Check items	YES	NO
1	Screw torque of expansion bolts : 80-100Nm (63-74b.ft) ;	√	
2	Rising speed $\geq 20\text{mm}(7/8'')/\text{s}$;	√	
3	Noise with rated load $\leq 75\text{dB(A)}$;	√	
4	Grounding resistance: not bigger than 4Ω;	√	
5	Height difference of the two carriages $\leq 5\text{mm}$ (3/16'');	√	
6	Mechanical catch unit is robust and synchronized when running with rated load ;	√	
7	If the control button works as "hold to run"?	√	
8	If limit switches work well?	√	
9	If grounding wire is connected?	√	
10	If rising and lowering smoothly?	√	
11	If there is no abnormal notice during running with rated load?	√	
12	If there is no oil leakage when running with rated load?	√	
13	If expansion bolts, nuts or circlips are well secured?	√	
14	If the max lifting height is reached?	√	
15	If Safety advices, name plate and logos are clear?	√	


OPERATION INSTRUCTIONS

5.1 Precautions

- ONLY authorized persons are permitted in the lift area.

- Do not try to raise the vehicle with excessive length or width. Otherwise there is risk of vehicle falling from lift.
- Inspect the space above and below the load and the loading carrying devices. It shall be free of obstructions before operating.
- Before raising operation, run the lift without load for a complete cycle to ensure it is in good condition.
- Before lifting the vehicle and during all operations on the vehicle, make sure that it is properly stopped by the hand brake.
- Check the vehicle after raising a short distance to ensure that it is correctly and safely positioned.
- It is forbidden for people to stand in the field of motion during raising or lowering movement.
- The load carrying device shall be observed by the operator throughout the motion of the lift.
- Engage the safety locking mechanism before entering under the raised vehicle.
- Avoid excessive rocking of vehicle while on the lift
- Do not climb onto the load or load carrying device when they are raised.

5.2 Operation instructions



POS.	Description	Function
1	Unlocking handle	Release the mechanical locking unit.
2	UP button	Control ascending movement. Disengage the mechanical locking unit.
3	Lowering handle	Control descending movement. Engage the mechanical locking unit.

To avoid personal injury and/or property damage, permit only trained and qualified personnel to operate the lift. After reviewing these instructions, get familiar with lift controls by running the lift through a few cycles before loading vehicle on lift. Always lift the vehicle using all four adapters. Never raise just one end, one corner or one side of vehicle adapters.

Raise the lift

Make sure vehicle is neither front nor rear heavy and center of balance should be midway between adapters and centered over the lift.

1. Park the vehicle between two posts.
2. Adjust the lifting arms until lifting adapters are under the pick-up positions of the vehicle and make sure the gravity of vehicle located over the center of four lifting arms.
3. Push the "UP" button until lifting adapters have touched the pick-up positions of vehicle.
4. Keep on raising the vehicle making its wheels have a bit clearance off the ground and check again the stability.
5. Raise the vehicle to the expected height, push the "Lowering handle" to engage the mechanical safety locking unit. Check again the stability before doing maintenance or repair work underneath.

Lowering

When lowering the lift pay careful attention that all personnel and objects are kept clear.

1. Push the "UP" button to disengage the mechanical locking unit.

2. Push down the unlocking handle to release mechanical locking unit and meanwhile push down the lowering handle.
3. When the lift is fully lowered, position the lift arms and adapters to provide an unobstructed exit before removing vehicle from lift area.
4. Drive the vehicle away.

TROUBLE SHOOTING

ATTENTION: If the trouble could not be fixed by yourself, please do not hesitate to contact us for help. We will offer our service at the earliest time we can. Troubles could be judged and solved much faster when more details or pictures could be provided.

TROUBLES	POSSIBLE CAUSES	SOLUTIONS
Abnormal noise	Abrasion exists on insider surface of the posts.	Grease the inside of the post.
	Trash in the post.	Clear the trash
Motor does not run and will not rise	Loose wire connection	Check and make a good connection.
	Blown motor.	Replace it.
	Damaged limit switch or its wire connection is loose.	Adjust or replace the limit switch.
Motor runs but will not raise	The motor run reversely.	Check the wire connection.
	Overflow valve is not well screwed up or jammed.	Clean or make adjustment
	Damaged gear pump.	Replace it.
	Too low oil level.	Add oil.
	The hose connection is loose.	Tighten it.
Carriages go down slowly after being raised	The cushion valve is not well screwed up or jammed.	Clean or make adjustment
	The oil hose leaks.	Check or replace it.
	Untightened oil cylinder.	Replace the seal.
	The single way valve leaks.	Clean or replace it.
	Unloading valve fails to work well.	Clean or replace it.
Raising too slow	Slack steel cable	Check and adjust the tightness.
	Jammed oil filter	Clean or replace it.
	Too low oil level.	Add oil.
	The overflow valve is not adjusted to the right position.	Make adjustment.
	Too hot hydraulic oil (above 45°) .	Change the oil.
	Abraded seal of the cylinder	Replace the seal.
Lowering too slow	Inside surface of the posts is not well greased.	Add grease.
	Jammed throttle valve	Clean or replace it.


	Dirty hydraulic oil	Change the oil.
	Jammed anti-surge valve	Clean it.
	Jammed oil hose	Replace it.
The steel cable is abraded	No grease at installation or out of lifetime	Replace it.

INSPECTION AND MAINTENANCE

Easy and low cost routine inspection and maintenance can ensure the lift work normally and safely.

Follow the below routine inspection and maintenance schedule with reference to the actual working condition and frequency of your lift.

Lubricate moving parts with NO.1 lithium based grease.



S/N	Components	Methods	Period
1	Swing arm locking units	Push the UP button to raise the lifting arms and check if four swing arms are locked into position. Add grease in case necessary.	Every day
2	Lifting adapter	Check if it can screw UP and DOWN smoothly. Add grease onto the swivel when necessary. Inspect the rubber pads and clean	Every day

Installation, Operation and Parts Manual

MJ-F10

S/N	Components	Methods	Period
		off any objects that may cause sliding or damage.	
3	Cylinder and oil hose connector	Inspect to ensure no leakage before using the lift.	Every day
4	Push button	Check if the button work as "hold- to -run “.	Every day
5	Mechanical safety locking unit	Check if mechanical locking hooks can engage or disengage simultaneously.	Every day
6	Max lifting height limit switch	Use proper means to activate the switch and push UP button to check if the carriage stop rising.	Every 30 days
8	Steel cables	Check the synchronization of both carriages and adjust the tightness of the cable if desynchronization is unacceptable.	Every day
9	Bushing of the upside pulley and circlip of the shaft	Lubricate the bushing with NO.1 lithium based grease. Check if the circlip is in its original position.	Every 3 months
10	Steel cables	Lubricate the cables with NO.1 lithium based grease. It is advised to change with new steel cables every 3 years or ten single wires have broken.	Every 3 months
11	Running track inside the post for carriages	Lubricate path with NO.1 lithium based grease. No obstruction on the path.	Every 3 months
12	Chain and its pins	Lubricate the chain with NO.1 lithium based grease. It is advised to change the chains every 3 years or if any cracks occurred to the pin of the chain.	Every 3 months
13	Bushing of the downside pulley and circlip of the shaft	Lubricate the bushing with NO.1 lithium based grease. Check if the circlip is in its original position.	Every 3 months
14	Expansion bolts	Check with torque spanner. 80-100Nm.	Every 3 months
16	Bushing of the upside pulley and circlip of the shaft	Slacken the steel rope and dismantle the pulley. Measure the abrasive clearance and change the bushing if the clearance is bigger than 0.5mm.	Every year
17	Bushing of the downside pulley and circlip of the shaft	Slacken the steel rope and dismantle the pulley. Measure the abrasive clearance and change the bushing if the clearance is bigger than 0.5mm.	Every year
18	Hydraulic oil	Change the oil 6 months after initial use and once per year thereafter. Inspect the hydraulic oil and change the oil if the oil becomes black or there is dirt in the oil tank.	Every year

If users stick to the above maintenance requirements, the lift will always keep a good working condition and its service life could be extended.


Annex 1, Floor plan


Indoor installation only. There must also be a clearance of at least 1 meter between the lifting platform and fixed elements (e.g. wall) in all lifting positions. There must be sufficient space for driving vehicles on and off.

C25 concrete foundation with a minimum thickness of 200mm (7 7/8").



Surface: Horizontal and even (Gradients max. 0.5 %)

Newly built concrete ground must be older than 20days.






Annex 2, Electrical schemes and parts list



POS.	CODE	Specification	Qty
SB1	320401042	PUSH button	1
KM	320901003	AC contactor CJX2-1210/AC220-380V	1
	320901005	AC contactor CJX2-1210/AC240V -415V	1
SQ1	320301029	Limit switch(TZ8168)	1

Wire connection for 3Ph power



Connect wire L1 to terminal 1L1 and A1


Connect wire L2 to terminal 3L2

Connect wire L3 to terminal 5L3

Connect wire N to terminals at SQ1

Wires U,V,W are to be connected respectively to terminal 2T1, 4T2 and 6T3.

Wire connection for 1Ph power




Connect wire L to terminal A1 ,3L2 and 1L1.


Connect wire N to terminal 5L3 and 13NO

Connect wire U to terminal 2T1 and 4T2

Connect wire W to terminal 6T3 and 14NO

Annex 3, Hydraulic schemes and parts list






POS.	Code	Description	Specification	Qty
1	330103004	Power unit (ETL)	220V-60HZ-1PH-21MPA-10L	1
2	207103025	Composite washer	13.7*20.00*1.50	3
3	310101008	Connector	M14*1.5-G1/4 inside cone	1
4	624001930	Oil hose	L=350	1
5	615022014	612 Elbow connector	612E-A8	1
6	624002051	Oil hose	L=1030	1
7	615006004	Composite connector	6254E-A4-B8	1
8	615001009	Main connector	6254E-A4-B11	1
9	615001008	Short connector	6254E-A4-B10	1
10	624001025	Oil hose	L=2880mm	1
11	615001007	Master cylinder	6254E-A4-B6	1
12	615001006	Slave cylinder	6254E-A4-B5	1


SEAL.	CODE	Description	Specification	Qty
1	207106008B	Y seal ring	TTE 63*48*10	1
2	207102009B	Anti-abrasive ring	AGI 40/S1 40*45*5.6	1
3	207105005	Dust proof ring	DHS40 (40*48*5/6.5)	1

4	207106006	Anti-abrasive ring	AGI 58/S1 58*63*5.6	1
---	-----------	--------------------	---------------------	---

Annex 4, Mechanical exploded drawings and parts list




POS.	Code	Description	Specification	Qty
1	615001010B	Steel cable	6254E-A6(Φ9.3 L=8785)	2
2	203101009	Hex nut	M16	8
3	204101009	Flat washer	φ16	4
4	201201017	Expansion bolt (INCH)	3/4*6.3	10




POS.	Code	Description	Specification	Qty
1	330103004	Power unit (ETL)	220V-60HZ-1PH-21MPA-10L	1
2	624002051	Oil hose	L=1030	1
3	615006004	Composite connector	6254E-A4-B8(6214A-A5-B4)	1
4	207103025	Composite washer	13.7*20.00*1.50(BS224)	2
5	624001930	Oil hose	L=350	1
6	615022014	612 Right angle connector	612E-A8	1
7	615001007	Main cylinder	6254E-A4-B6(6254A-A5-B5)	1
8	206201011	Cotter pin	M4x50	2
9	612001001	Support bracket for chain wheel	6254E-A4-B2(6254A-A5-B1)	2
10	410011211	Spacing sheath	6254E-A4-B12	2
11	410011221	Shaft of chain wheel	6254E-A4-B3	2
12	205101013	Bushing	2548	2


POS.	Code	Description	Specification	Qty
13	410130071	Chain wheel	6255E-A7-B5	2
14	410011233	Stop plate	6255E-A7-B6	2
15	202109017	Hex socket cylinder head screw	M6x8	4
16	208108003	6255E leaf chain	LH1244	2
17	206201008	Cotter pin	M4x30	2
18	410047360B	Chain holder	62B-A3-B3-42T	2
19	203101009	Hex nut	M16	2
20	203204001	Hex open slot nut	M16	2
21	615001009	Main connector	6254E-A4-B11(6254A-A5-B11)	1
22	624001025	Oil hose	L=2880	1
23	615001008	Short connector	6254E-A4-B10(6254A-A5-B10)	1
24	615001006	Slave cylinder	6254E-A4-B5(6254A-A5-B4)	1



POS.	Code	Description	Specification	Qty
1	206201004	Cotter pin	M3x45	2
2	410010031	Washer	6254E-A1-B3(6254A-A1-B2 62*62*1.5)	4
3	410010061	Upside pulley	6254E-A5-B1(6254A-A3-B1 Φ 88 L=19)	2
4	205101008	Bushing	2518	2
5	614066304	Top plate assembly	F10-A4-B1	2




POS.	Code	Description	Specification	Qty
1	206201004	Cotter pin	M3x45	4
2	410010031	Washer	6254E-A1-B3(6254A-A1-B2 62*62*1.5)	4
3	205101007	Bushing	2512	4
4	410040031	Downside pulley	6254E-A1-B2	4
5	420080010B	Slider	C10-A3-B2	16
6	203204011	Knob	50xM10	4
7	410044401	Pull rod	6254E-A2-B1-C1	4
8	410150121	Pressure spring	6254E-A2-B4 (6215-A3-B50	4
9	410151101C	Teeth block	6254E-A2-B7	4
10	206102006	Elastic post pin	M5x35	4
11	614066303	Carriage	F10-A3-B1	2
12	420040160	Protective rubber pad	6254E-A2-B6	4
13	202111004	Hex socket flat head screw	M8x12	4
14	410049031B	Pin shaft	6254E-A12	4
15	204301008	Circlip	M22	4




POS.	Code	Description	Specification	Qty
1	614054003	Safety hook	C12-A1-B4	1
2	430020260	Rope ring		1
3	920203209B	Clip	5mm	2
4	206201001	Cotter pin	M2.5x30	6
5	410540031	Safety shaft	C12-A1-B6	2
6	203101006	Hex nut	M10	1
7	201103004	Hex head full swivel bolt	M10x35	1
9	202109028	Hex socket cylinder head screw	M8x16	2

POS.	Code	Description	Specification	Qty
10	614054006	Release plate	C12-A1-B5	1
11	410150021B	Release handle	6215DZ-A1-B3-C1 (6215-A1-B5-C1)	1
12	208105003B	Handle ball	Black	1
13	410047530B	Pull spring	62B-A10-B9-M	2
14	614054001	Safety lock cover	C12-A1-B9	2
15	202109017	Hex socket cylinder head screw	M6x8	8
16	614006012B	Pulley	6214DS-A9	1
17	410060301	Pulley II	6214DS-A7	5
18	204301001	Circlip	M10	7
19	614066305	Guiding bracket for lock release device	F10-A5-B1	1
20	612056003	The secondary hook	C12-A2-B3	1
21	430020260	Rope ring		1



POS.	Code	Description	Specification	Qty
1	208110001	Release steel rope	2.5	L=7440mm
2	202110004	Hex socket button head screw	M8x12	4
3	410060573	Support bracket for the upside pulley	6214DS-A10	2



POS.	Code	Description	Specification	Qty
1	615064304	Top plate assembly	F10-A4	2
2	204101007	Flat washer	M12	4
3	204201006	Spring washer	M12	4
4	201102026	Hex head full swivel bolt	M12x25	4
5	203101004	Hex nut	M6	8
6	204101004	Flat washer	M6	8
7	410010051	Hook for the covering cloth	6254E-A1-B5(6254A-A1-B6)	4

Installation, Operation and Parts Manual

MJ-F10

POS.	Code	Description	Specification	Qty
8	615001002	Curtain	6254E-A1-B4 2700*140	2
9	614066301	Power side post	F10-A1-B1	1
10	614004006C	Long retractable arm	6254E-A7-B3	2
11	614004008C	Short arm	6254E-A08-B01	2
12	614004010C	Short retractable arm	6254E-A08-B02	2
13	202111004	Hex socket flat head screw	M8x12	8
14	420040250	Round rubber pad	6254E-A7-B4-C4	4
15	615004003D	Lifting tray	6254E-A7-B4	4
16	202101027	Cross socket cap head screw	M6x8	4
17	614004005B	Long support arm	6254E-A7-B1	2
18	202110016	Hex socket button head screw	M12x20	2
19	410040013B	Base covering plate	6254E-A10	1
20	614004017B	Slot base plate	6254E-A9	1
21	204101006	Flat washer	M10	4
22	202109040	Hex socket cylinder head screw	M10x15	4
23	204301013	Circlip	M38	4
24	410151111C	Semicircular teeth block	6254E-A2-B8	4
25	202109085	Hex socket cylinder head screw	M12x30	12
26	410049031B	Pin shaft	6254E-A12	4
27	614066302	The secondary post	F10-A2-B1	1
28	201103004	Hex head full swivel bolt	M10x35	4
29	203101006	Hex nut	M10	4
30	204101006	Flat washer	M10	4
31	204201005	Spring washer	M10	4
32	420040010	Anti-shock ring	6254E-A23	4
33	330103004	Power unit (ETL)	220V-60HZ-1PH-21MPA-10L	1