



LAURA JAMES

CARE GUIDE

OUTDOOR ALL-
WEATHER RATTAN
FURNITURE



HOME - GARDEN - LIFESTYLE

STORAGE AND USE

- All Weather rattan furniture may be kept outdoors all year round. However, doing so will alter the appearance in time as it will naturally age. If you wish to maintain its new-look appearance longer, we recommend the furniture is stored inside a cool dry place such as a shed or outbuilding during poor weather and winter months. Alternately use a furniture protective cover when the items are not in use.

EXPANSION AND MOVEMENT

- All Weather rattan will display movement from season to season because of changes in atmospheric temperature and humidity.
- We do not recommend locating products in excessively high or low temperatures, or where the environment is often damp as this may cause product issues.



LEVELLING, ASSEMBLY AND MOVING PRODUCTS

- Furniture must be positioned on a level surface to ensure that it does not rock, if the product is moved, levels should be rechecked, adjustment of the feet or the use of wedges can assist if the floor is not level.
- Take care when moving products. We recommend they are lifted by two persons as dragging items across the floor will cause damage.
- Large items which are assembled on site from multiple sections should be disassembled before relocation to a new position.
- Items should be assembled at the intended location and lifted carefully into position.
- From time to time the fixings and joints may require tightening to prevent loosening which can create squeaks and movement.



SUNLIGHT, HEAT AND RAIN

- Direct sunlight will cause the colour of the product to change.
- The cushions supplied with the products are showerproof but must be moved to a cool dry place when not in use.
- Never place hot dishes and cups directly on to surface, we recommend you use tablemats and coasters.
- Prolonged use of hot equipment, such as a laptop, on top of furniture may also cause scorching.
- The dark rubber feet used on electrical and other equipment occasionally contain chemicals that can leave a permanent mark on furniture surfaces, care should be taken.



GENERAL MAINTENANCE INSTRUCTIONS

To prolong the life of your furniture we advise the following:

Cleaning

- To maintain the appearance of your product we recommend regular dusting with a soft cloth. It may occasionally be wiped with a soft cloth very lightly dampened with a mild bleach-free detergent solution and dried with a lint-free cloth.
- Clean glass panels using a non-solvent-based glass cleaner and soft cloth.
- Maintain cushions with a soft brush and/or gently vacuuming; periodic cleaning (as per the wash care label) is required to maintain appearance and prevent premature fading and wear.
- Remove all spills immediately. Blot liquid spills with a clean, dry, white cloth, and work towards the centre of the spill. Do not rub or use abrasive cleaners as this may damage the furniture.
- Pieces of food and debris can sometimes get caught down the side or underneath removable surfaces such as glass tops on items like dining and coffee tables. Items like these must be disassembled and all surfaces wiped with a soft cloth very lightly dampened with a mild bleach free detergent solution and dried with a lint-free cloth.

Care - To Avoid Unnecessary Damage

- Never place hot dishes or mugs directly on to surfaces, always use tablemats or coasters.
- Do not drop furniture onto corners or feet or lean backwards on two legs as this will weaken and damage frames, feet or legs.
- Prevent sharp objects such as keys, buckles and heels from coming into contact with your furniture.
- Avoid exposure to water or excessive sun to prolong the life of the product.
- Avoid contact with chemicals such as hair and skin preparations, fake tans, insect repellents and other cosmetics, or household cleaning materials, other than those recommended as these may affect the finish.
- If your furniture becomes soiled, scratched, chipped or suffers other damage we recommend professional help is sought to restore it.
- If you have relevant insurance you may wish to contact your provider for advice.

Following the guidelines above will ensure product performance is maintained. Laura James is not responsible for defects caused by the misuse of your product.



LAURA JAMES

email: customercare@laura-james.co.uk

Address: Unit 2 Provincial Park, Nether Lane,
Ecclesfield, Sheffield, S35 9ZX

www.laura-james.co.uk

