

Instruction Manual for Chameleon Clock



Read through this entire instruction manual BEFORE using your **Chameleon Clock**.

We're dedicated to bringing you well-designed products that make living fun and easy. We stand behind all our products and warrant this to be free from defects in workmanship and materials for 1 year from the date of purchase.

For service claims or questions please consult our website ProtocolNY.com.

POWER SUPPLY

1. Remove the battery compartment cover at the bottom of the speaker.
2. Install 3 'AAA' batteries (not included) into the compartment according to the indicated polarity of "+" and "-".
3. The clock will beep once the batteries are installed.
4. Close the compartment cover.

SCREEN

1. Remove the protective film on the screen by peeling it off and tearing at the bottom.
2. As you change modes, the screen's background will remain lit for 10 seconds once you have selected a mode.

MODES

To change between the Time, Temperature, Date, Countdown Timer, and Alarm modes, press the "M" button located on the bottom of the clock or push the screen back.

OPERATION

Time:

1. After the batteries are inserted, the clock will display the time mode at 12:00.
2. Press either the "▲" or the "▼" buttons on the bottom of the clock to choose 12 hour time or 24 hour time. If you choose 12 hour setting, please note the hour scrolls through to PM.
3. Press the "S" button on the bottom of the clock for 3 seconds and the clock will beep and the hour will begin to flash.
4. Use the "▲" or the "▼" buttons to select the hour.
5. Press the "S" button again and the clock will beep and the minutes will begin to flash.
6. Use the "▲" or the "▼" buttons to select the minute.
7. Once you have set the time, press the "S" button again to set.

Temperature

1. Press the "M" button on the bottom of the clock or push the screen back to switch to the temperature mode.
2. Press either the "▲" or the "▼" buttons on the bottom of the clock to choose Celsius or Fahrenheit.

Date

1. Press the "M" button on the bottom of the clock or push the screen back to switch to the date mode.
2. Press the "S" button on the bottom of the clock for 3 seconds and the clock will beep and the year will begin to flash.
3. Use the "▲" or the "▼" buttons to select the year.
4. Press the "S" button again and the clock will beep and the month will begin to flash.
5. Use the "▲" or the "▼" buttons to select the month.
6. Press the "S" button again and the clock will beep and the day will begin to flash.
7. Use the "▲" or the "▼" buttons to select the day.
8. Once you have set the date, press the "S" button again to set.

Countdown Timer

1. Press the "M" button on the bottom of the clock or push the screen back to switch to the timer mode which can be set from 180 minutes 59 seconds down to 1 second.
2. Press the "S" button on the bottom of the clock for 3 seconds and the clock will beep and the minute will begin to flash.
3. Use the "▲" or the "▼" buttons to select the minute.
4. Press the "S" button again and the clock will beep and the second will begin to flash.
5. Use the "▲" or the "▼" buttons to select the second.
6. Once you have set the countdown timer, press the "S" button again to set.
7. Press either the "▲" or the "▼" buttons on the bottom of the clock to choose to start and stop the countdown timer as needed.
8. Once the countdown timer hits "0", it will beep for 60 seconds and the background colors will light up and change. To turn the beeping off, just push the screen of the clock back or press any button except "S".

Alarm

1. Press the "M" button on the bottom of the clock or push the screen back to switch to the alarm mode.
2. Press the "S" button on the bottom of the clock for 3 seconds and the clock will beep and the hour will begin to flash. If you chose the 12 hour time setting, please note the hour scrolls through to PM.
3. Use the "▲" or the "▼" buttons to select the hour.
4. Press the "S" button again and the clock will beep and the minutes will begin to flash.
5. Use the "▲" or the "▼" buttons to select the minute.
6. Once you have set the alarm time, press the "S" button again to set.
7. The alarm will beep for 60 seconds and the background colors will light up and change.
 - a. Snooze – Once the alarm beeps, press any button (except the "S" button) or push the screen back to activate the snooze function. The alarm will ring again in 3 minutes.
 - b. Press the "S" key to turn the alarm off.
8. To turn the alarm settings off completely
 - a. Make sure the clock is in the alarm mode.
 - b. Press the "▲" or the "▼" buttons to return to the "--:--" display which will turn the alarm settings completely off.
 - c. If you want to turn the alarm back on, just press the "▲" or the "▼" buttons to return to the previously set time.

CAUTION

1. This is not a toy. Please keep away from small children.
2. Please keep the unit away from water.
3. Remove batteries from the unit when it is not used for a long time.