

BAUMANN

3-in-1 grill + skillet
pizza maker

Hot, fresh pizza made right at home

BM-FK2016M



INSTRUCTIONS MANUAL

www.baumannliving.com

Table of Contents

IMPORTANT SAFEGUARDS	2
Additional Important Safeguards	4
Notes on the Cord	4
PARTS AND FEATURES	5
BEFORE FIRST USE	6
USING YOUR 3-IN-1 PIZZA MAKER	6
For Homemade Pizza	7
For Frozen Pizza	8
For Skillet Cooking and Grilling	8
CARE AND CLEANING	9

IMPORTANT SAFEGUARDS

Before using this electrical appliance, the following basic precautions should always be followed, including the following:

1. Read all instructions before operating this appliance.
2. Do not touch hot surfaces. Use handles and knobs where provided. Use hot pads or oven mitts when handling hot surfaces.
3. To protect against electrical shock do not immerse cord, plug, or any part of this unit, apart from the detachable cooking plates, in water or other liquid.
4. Close supervision is necessary when any appliance is used by or near children.
5. Unplug from outlet when not in use and before removing parts and before cleaning.
6. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
7. Do not let the cord hang over edge of table or counter or touch hot surface.
8. Do not place on or near a hot gas or electric burner, or in a heated oven.
9. The use of accessory attachments not recommended by the appliance manufacturer may cause fire, electric shock or injuries.
10. Position this unit near outlet to prevent any hazard of injury due to tripping over cord.
11. Extreme caution must be used when moving this appliance.
12. DO NOT use the appliance for other than its intended use.
13. Do not leave appliance plugged in when it is not being used.

14. Unplug cord from wall outlet when not in use. Allow to cool before cleaning.
15. Children should be supervised to ensure that they do not play with the appliance.
16. DO NOT use outdoors.

SAVE THESE INSTRUCTIONS

HOUSEHOLD USE ONLY

Additional Important Safeguards

1. Always place appliance on a heat resistant surface.
2. Use utensils specifically designed for non-stick surfaces to avoid scratching. Never remove the food item with a cutting device or metal kitchen utensil.
3. When using the appliance, allow 4-6 inches of space above, behind and on either side of the appliance for air circulation.

Notes on the Cord

1. A short power-supply cord is to be provided to reduce risks resulting from becoming entangled in or tripping over a long cord.
2. Extension cords are available and may be used if care is exercised in their use.
3. If a long detachable power-supply cord or extension cord is used:
 - The marked electrical rating of the extension cord should be at least as great as the electrical rating of the appliance.
 - The longer cord should be arranged so that it will not drape over the counter top or table top where it can be pulled on by children or tripped over.

PARTS AND FEATURES



BEFORE FIRST USE

Clean the 3-in 1 Pizza Maker and all of its components prior to assembly and use. Do not touch the Cover, Base, or Cooking plates without heat protective cooking gloves while the appliance is in use.

Unwind the power cord completely and keep the cord away from the hot parts of the appliance.

Note: *During the first use, the unit may emit a slight odor for a few minutes. This is normal. The odor is harmless and should not reoccur after the initial heating.*

USING YOUR 3-IN-1 PIZZA MAKER

1. Place the appliance on a stable and dry surface so that the Base is resting on the table. Attach the 2 detachable cooking plates onto the cover & base. Make sure that the plates are correctly aligned with the notches on the hinges of the cover and base.
2. Using a paper towel or silicone basting brush, grease cooking plates, then wipe off any excess oil. Lower the cover onto the base to close.
3. Plug the cord into a power outlet. Press the UP, DOWN or both power switches to turn on the appliance.
4. Turn the temperature control knob to the desired temperature. Turn the timer to the desired time.

Note: *The power switch/switches will illuminate once the timer knob has been turned.*

5. Once the cooking plates have reached the set temperature, the Ready indicator light will turn on.

As you cook, the Ready indicator light will cycle on and off to regulate the cooking temperature - this is normal. As the heating element goes on and off, you may also hear a clicking sound. This is completely normal.

For Homemade Pizza

1. Wearing oven mitts, carefully lift the Cover by the handle and open the unit 180° so that it lays flat on the table and both cooking plates are facing up.
2. Roll out pizza dough and lay it on the lower skillet plate. Close the 3-in-1 Pizza Maker by lowering the cover onto the base. Let the dough cook for a few minutes (time will vary depending on type of dough and thickness). Open the 3-in-1 Pizza Maker, brush the top of the dough with a little olive oil, flip the dough, and top pizza with your favorite toppings. Close the cover and allow to cook. At the end of the cooking time, a bell signal sounds and the unit turns off automatically.

Note: *If necessary, you can set the timer again to the desired additional baking time.*

Note: *To test if the crust is baked all the way through, insert a toothpick into the center of pizza. If the toothpick comes out dry, then the crust is baked all the way through. You can also use a rubber-tipped spatula to lift the edge of the pizza to check if the bottom crust has browned or not.*

3. Carefully slide pizza onto a board with the supplied spatula, or any heat-resistant nylon or silicone spatula. Let cool and then serve.

For Frozen Pizza

Follow the steps in "For Homemade Pizza" but set the frozen pizza on the lower skillet plate instead.

For Skillet Cooking and Grilling

1. Wearing oven mitts, carefully lift the Cover by the handle and open the unit 180° so that it lays flat on the table and both cooking plates are facing up.
2. Place food on the lower skillet plate and/or place food on the upper grill plate. Stir or turn food with a heat-resistant nylon or silicone cooking utensil.

When you have finished cooking, unplug the unit and allow it to cool completely before moving or cleaning.

Note: *Do not use sharp or metal utensils to remove or place food on the cooking plates as this may damage the non-stick cooking surfaces.*

WARNING! *The cover and base gets hot during use. Always use the handle on the cover. To prevent burns, never touch cooking plates while hot. Always use oven mitts to protect your hands when opening and closing the unit as steam may emit from the sides and can cause burns.*

CARE AND CLEANING

Never use abrasive cleaning agents to clean your appliance as this may damage the cooking plates. To prevent damage to the non-stick cooking surfaces, make sure to dry thoroughly after washing.

Always unplug the unit and allow it to cool completely before cleaning, moving, or storing. Do not submerge in water or any other liquids.

In order to keep your 3-in-1 Pizza Maker in working order, thoroughly clean the unit after each use. This will prevent the build-up of food or oil.

- Unplug the 3-in-1 Pizza Maker and allow it to cool completely.
- Using a damp, soapy cloth, wipe down the cooking plates. Thoroughly rinse the cloth and wipe again.
- Wipe the Base, Cover, and Handle with a soft, damp cloth.
- Thoroughly dry the unit before storing.
- If pizza dough still remains on the cooking plates, pour a small amount of cooking oil on the hardened pizza dough. Allow the oil set for 5 minutes, then wipe clean with a paper towel or soft cloth. To remove stubborn stains, use a soft nylon brush or other cleaning material safe for nonstick surface.