


PH-LT-SLV-05 User Manual




Door Guard Pty Ltd




Door Guard Pty Ltd

Unlocking way	Bluetooth, Code, Mechanical key
Support System	Android 4.3 / IOS 7.0 above
Unlock time	≈ 1.5 sec
Power supply	4pcs AA batteries
Static current	≤30uA
Working current	≤200mA

1-2. Item Dimension:



Door Guard Pty Ltd




2. INSTALLATION GUIDE

2-1. Installation condition

• Door frame \geq 110mm


•Door thickness: 38-50mm

Door Guard Pty Ltd



2-2. Installation instructions step by step

Door Guard Pty Ltd



3. FEATURES (PS: A mobile phone can be connected to more than a smart lock at the same time, when you need to

manage a lock,you should click on the app to enter the door lock device, then proceed with the next operation) Admin Bluetooth key: Mobile phone and door lock connected,the Bluetooth lock unlocks with Bluetooth via the app.

Admin Password: Mobile phone and door lock connected, the Bluetooth lock unlocks with a permanent Master code.

Bluetooth key remote authorization: The Admin can instantly send Bluetooth keys to other people's mobile phone APP, It can limit the use time of the Bluetooth key, and can immediately freeze, thaw and delete the electronic key.

Password remote authorization: The door lock can send a permanent password and a limited time password in the absence of networking.

Password protection: The smart lock will automatically locked for 5 minutes when the wrong password is entered 5 times; You can enter any number of digits before the correct password, make sure the last few digits are the correct password can be unlocked.

Automatically locked: Can be set to automatically locked between 5 to 120 seconds after unlocking. General lock: Press and hold"#"about 5seconds.

Lower Battery Consumption: 4pcs AA batteries can provide 5000 openings (approx. 6 months)

Door Guard Pty Ltd

For more information please visit : www.doorguard.com.au

For Help and Support please send an email to : support@doorguard.com.au

Lower Battery Indicator: When battery power is low, the Bluetooth lock will emit low battery warning sound. The battery level will also be updated on the app during Bluetooth unlock. If battery power runs out, use 9V backup battery or mechanical key.

Real time monitoring: When users use app or password to unlock, the Admin can find unlock records on APP.

Real-time reminder: Mobile phone and door lock connected, click "^C" on the upper right corner of the interface, you can query the record of received Bluetooth key and more user information.

4. PROGRAMMING

4-1. Paring lock to the phone

- 1) Android mobile phone, please scan the QR code as below.
- 2) Apple mobile phone, please search "TTlock" from App Store.





2. Register a new account (phone number or email) or login with an existing account.

3. Turn on Bluetooth and network, login APP, click"+"---"look". (Let the APP interface remain in this state and then operate the next step)

4. Remove 1pc of battery--touch keyboard a few seconds--put back the battery--press"#" immediately--you will

see"

5. After mobile phone and door lock connected, click " on the upper left corner of the interface then there have more functional operations can be performed.

4-2. Unlock(The Admin unlock)

BL01 872f5b

1. After mobile phone and door lock connected, turn on Bluetooth and network--click the connected door lock

device---" [•] to unlock. (The phone is within 5 meters from the door lock)

2. The Admin password unlock, after mobile phone and door lock connected, open the APP---click connected

door lock device--click " 🙄 " on the upper right corner of the interface---see Admin passcode--input passcode ---"#"to unlock.

3. Mechanical key unlock, use a screwdriver to open the round keyhole cover on the front panel, then use mechanical key unlock.

Door Guard Pty Ltd

For more information please visit : www.doorguard.com.au

For Help and Support please send an email to : support@doorguard.com.au

4. When you are in the room, use thumb-turn on back panel to unlock.

4-3. Lock

1.Press and hold"#"about 5seconds to lock.

2.Set auto lock, click the connected door lock device--click "²²⁵" on the upper right corner of the interface---auto lock--choose set time 5s – 120s---OK. (**ps**: This operation must be near the door lock and need to be connected to Bluetooth)

3.Mechanical key lock door, use a screwdriver to open the round keyhole cover on front panel, then use mechanical key lock the door.

4. When you are in the room, use thumb-turn on back panel to lock door.

4-4. Modify the Admin password

Click the connected door lock device---click "

-input the APP account login password---input the new Admin password (7-8digits) --- save. (**ps:** This operation must be near the door lock and need to be connected to Bluetooth)

4-5.Modify the Admin

A door lock can only have one Admin at the same time, you need to delete the original Admin first if you want to modify the Admin. find the door lock device that you want to modify the Admin---slide to the left---delete---click it--input the APP account login password--- ok. (**ps:** This operation must be near the door lock and need to be connected to Bluetooth)

4-6. Bluetooth key remote authorization(Admin' s phone can remotely send electronic keys to other users to unlock)

Click the connected door lock device---"eKey" on the bottom of the interface---choose "Permanent"or"Timed"--input the receiver's APP account (the receiver must be download the APP and register an account) --- "send". (**ps:** This operation need to be connected to Bluetooth and network)

4-7. The Admin' s phone has the right to freeze, delete, authorize, and rename for the electronic key that has been sent

Click the connected door lock device---"User" on the bottom of the interface---"eKey"---"

corner of the interface---choose"Clear ekeys" or "Reset ekeys"or"ekey"according to your needs. If you only need to manage some of the keys, Click the electronic key that you want to manage, according to your needs to choose"Freeze"or"Delete"or"Authorize"or"Rename"; also you can click "2" on the upper right corner of the interface to change the validity of the electronic key that has been sent. (**ps:** This operation need to be connected to Bluetooth and network)

Door Guard Pty Ltd

4-8. Password remote authorization (Admin's phone can remotely send password to other users to unlock) Click the connected door lock device---"Passcode" on the bottom of the interface--- choose"Permanent" or "Timed" or "Cyclic" or "One-time" according to your needs---edit the active time---"Generate"---"Send by Wechat" or "Send by Msg.' (**ps:** This operation need to be connected to network)

4-9. The Admin' s phone has the right to rename, delete the password that has been sent

Click the connected door lock device---"User" on the bottom of the interface---"passcode"---"

corner of the interface---choose"Reset passcode" or "Passcode" according to your needs, If you only need to manage some of the password, click the password that you want to manage, choose"Rename" or "Delete" according to your needs. (**ps:** This operation must be near the door lock and need to be connected to Bluetooth)

5. Changing batteries

To open the battery compartment, unscrew the back panel and put 4pcs AA batteries.(It is recommended to use a better battery, 4 batteries using the same brand).

For Installation Video please visit :

http://www.doorguard.com.au/videos

For any Support questions please send an email to :

support@doorguard.com.au

Door Guard Pty Ltd