

**Cool Energy ecoTech Monoblock Series
R32 EVI Heat Pump Water Heaters**

Version 2.1



Installation and Users Guide

**IMPORTANT SAFETY INSTRUCTIONS
READ AND FOLLOW ALL INSTRUCTIONS**

RETAIN FOR FUTURE REFERENCE

Customer Service and Technical Support

(Open from 9am-4pm Monday- Friday)

Phone: 01472 867497

Email: sales@coolenergyshop.com

Address: Office & Showroom - 163 Cleethorpe Road, Grimsby, DN31 3AX

Website: www.coolenergyshop.com



Table of Contents

IMPORTANT SAFETY PRECAUTIONS.....	3
Health and Safety	3, 4
Important End User Safety Information.....	4
Section 1.....	5
Introduction.....	5
Product Overview.....	5
General Features.....	5
Section 2.....	6
Installation.....	6
Materials needed for installation.....	7
Installation of Outdoor Unit.....	7, 8
Suggested Installation Methods.....	9, 10, 11, 12, 13
Water Connections.....	14
Plumbing Installation Requirements.....	14
Electrical Connections.....	15
General Information.....	15
Electrical Wiring Diagram.....	16
Power Supply.....	17
Grounding and Over Current Protection.....	17
Section 3.....	18
Operating Heat Pump.....	18
LCD User-Friendly Interface Controller.....	18
General Instruction.....	18
Controller Panel.....	18
Operating Controller	18
1. Keys / Icons Explanation.....	19
2. System Status Display Value.....	19
3. On/ Off Setting.....	20
4. Mode Setting.....	20
5. Time / Clock Setting.....	22
6. Engineer Settings.....	23, 24
7. Input / Output Readings.....	25, 26
8. Weather Compensation.....	27
9. Anti-Legionella	28
10. Factory Parameters	29
Product Protection.....	30,31
General Operation.....	32
Section 4.....	33
Commisioning.....	33
Service & Maintenance.....	33
Inspection and Service.....	33
Owner Inspection.....	34
Section 5.....	35
Benchmark.....	35
Commissioning Checklist.....	35
Service Record.....	36

HEALTH AND SAFETY INFORMATION

INFORMATION FOR INSTALLER AND SERVICE ENGINEERS

Under the Consumer Protection Act 1987 and the Health and Safety at Work Act 1974, it is required to provide information on substances hazardous to health (COSHH Regulations 1998). Cool Energy takes every reasonable care to ensure that these products are designed and constructed to meet these general safety requirements, provided they are properly installed and used.

To fulfil this requirement, products are comprehensively tested and examined before dispatch.

When working on the appliance, it is the responsibility of the user/engineer to ensure that any necessary personal protective clothing or equipment is worn when appropriate for parts, which could be considered hazardous or harmful.

This appliance may contain some of the items below:

Refrigerants

The appliance contains R32 refrigerant which is flammable.

If installed and used correctly there is no danger of explosion or combustion.

When handling, avoid inhalation and contact with the skin and eyes. Suitable personal protective equipment (PPE) must be worn (gloves, overalls, eye protection) and a comprehensive first aid kit (containing eyewash) should be easily available.

Site engineers should have a certificate of competence and should know and understand the properties and hazards before handling liquid refrigerants.

When the appliance has come to the end of its life span, an approved engineer must dispose of the equipment and refrigerants in accordance with the EU laws.

Seek urgent medical attention if inhaled or digested. Exposure to eyes and skin should be followed by immediate cleansing of the affected areas and medical attention if necessary.



Insulation

Fibre insulation may be irritating to the skin, eyes, nose, and throat. When handling, avoid inhalation and contact with the eyes. Use disposable gloves, facemasks, and eye protection.

After handling, wash hands and other exposed parts. When disposing, reduce dust with water spray and ensure all parts are securely wrapped.

Glue, Sealants, and Paints

Glue, sealants, and paints are used in this appliance and present no known hazards when used in the manner of which they are intended.

Oils

The compressor contains FV50S oil within the refrigeration system. The compressor itself is hermetically sealed, and this cannot be repaired.

Manual Handling

Air Source Heat Pumps are by nature bulky and heavy items. Please pay attention to the weight of the unit before attempting to move it. It may be necessary to use lifting aids to ensure safe manual handling to avoid injury.

The weight of the heat pumps can be found on data sheets, packaging and product data badges.



Transport of Heat Pump

When transporting your heat pump it's important to keep it upright. The refrigeration system inside contains oil, gas and liquids which can be disturbed when moving your heat pump. If at any stage during transporting your unit, it is inclined more than a 45° angle, it's important to leave the unit upright for at least 4 hours to allow the refrigeration system to stabilise again before use.



IMPORTANT SAFETY INFORMATION FOR THE END-USER

- Installation of the appliance must only be carried out by persons with suitable competence.
- Do not attempt to modify, repair or service the appliance yourself.
- Do not insert body parts or any other items into the air inlet or outlet.
- Do not start or stop the unit by removing the power cable; always use the controls and switches provided.
- If installed outside, ensure the appliance is protected from prolonged exposure to large quantities of water.
- Do not operate the unit or the programmer with wet fingers.
- Keep the programmer unit out of reach of children.
- The electrical supply must be isolated during a heightened risk of lightning strikes.
- Do not attempt to move the appliance once it is installed; this must be carried out by a qualified engineer.
- Isolate the electrical supply to the appliance if an odour presents, or scorching is detected.
- Only use this appliance for the purpose intended.
- Ensure the area around the appliance is clean, well-ventilated and kept free of all obstructions.
- Do not keep items on top of the appliance or use it to support other appliances.
- Do not under any circumstances stand on the appliance.
- Isolate the electrical supply to the appliance if it is to be switched off for a period of more than two months.
- Periodically check the condition of any supports for deterioration.
- Do not wash the unit with water, alcohol, benzene, thinner, glass cleaner or powders.
- During cleaning, isolate the electrical supply to the appliance.

Section 1

Introduction

Product Overview

Air Source Heat Pumps transfer heat from the ambient air to water, providing high-temperature hot water up to 60°C. The unique Cool Energy ecoTech heat pump is widely used for house heating or hot water. With our innovative & advanced technology, the pro mono block range of heat pumps can operate very well down to -20°C ambient temperature with high output temperatures up to 60°C. Compared with traditional Oil / LPG boilers, Cool Energy heat pumps produces up to 50% less CO² whilst saves up to 80% on running costs. Cool Energy heat pumps are not only highly efficient, but also easy and safe to operate.

General Features

1. Low running costs and high efficiency.
 - A high coefficient of performance (COP) of up to 5, results in lower running costs compared with traditional ASHP technology.
 - No immersion heater supplement is required.
2. Reduced Capital Costs.
 - Simple installation
 - Compatible with traditional radiator systems, under floor heating or fan coils.
3. High Comfort Levels.
 - High storage temperature results in increased hot water availability.
4. No potential danger of any inflammable, gas poisoning, explosion, fire, electrical shock which are associated with other heating systems.
5. A digital controller is incorporated to maintain the desired water temperature.
6. Long-life and corrosion resistant composite cabinet stands up to severe climates.
7. The latest compressor technology ensures outstanding performance, ultra-energy efficiency, durability, and quiet operation.
8. Self-diagnostic control panel monitors and troubleshoots heat pump operations to ensure safe and reliable operations.
9. Intelligent digital controller with friendly user interface and blue LED back light.
10. Separate isolated electrical compartment prevents internal corrosion and extends heat pump life.
11. The heat pump can operate down to ambient air temperature of -25°C.

Section 2

Installation

The following general information describes how to install the air source heat pump.

Note: Before installing this product, read and follow all warning notices and instructions. Only a qualified / competent person should install the heat pump.

Materials needed for Installation:

The following items are needed and are to be supplied by the installer for **all** heat pump installations:

1. Plumbing fittings.
2. Level surface with provision for condensate drainage.
3. Suitable anti-vibration feet.
4. Ensure that a suitable electrical supply cable is provided. See the rating plate on the heat pump for electrical specifications. Please take a note of the specific current rating. No junction box is needed at the heat pump; Connections are made inside of the heat pump electrical compartment. Conduit may be attached directly to the heat pump casing.
5. It is advised to use PVC conduit for the electrical supply cables.
6. Ensure correctly sized pipe work to obtain minimum water flow rates required.
7. Flexible hoses are recommended for connection between heat pump and rigid pipework.
8. A filter on the water inlet to the heat pump is required.
9. The plumbing should be insulated to reduce heat losses, and water treated with a suitable inhibited antifreeze.

Note: We recommend installing shut-off valves on the inlet and outlet water connections for ease of serviceability.


Note: For detailed specifications of the units please refer to name plate on the units. Correct installation is required to ensure safe operation. The requirements for Cool Energy heat pumps include the following:

1. Appropriate site location and clearances.
2. Wiring to conform to 18th edition wiring regulations.
3. Adequate water flow. (See Page 31.)

This manual provides the information needed to meet these requirements. Review all application and installation procedures completely before continuing the installation.

Installation of Outdoor Unit

The heat pump should be installed on a solid level base that can take the weight, preferably a concrete foundation. If concrete slabs are used, they must rest on asphalt or shingle.



The heat pump should not be positioned next to sensitive walls, for example, next to a bedroom. Also ensure that the placement does not inconvenience the neighbours. The heat pumps must not be placed so that recirculation of the outdoor air can occur; this causes lower output and impaired efficiency.

Large amounts of condensation water as well as melted waters from defrosting can be produced. Condensation water must be led off to a drain, soakaway or similar.

The outdoor unit should be installed in a ventilated place, with enough space for air inlet and outlet, while without thermal radiation or other heat source. The air outlet should not be against the wind.


Generally, horizontal air flow type heat pump does not generally need sheltering. The structure design has protected all internal components against rain and sunshine. A shelter is necessary to avoid snow burying the heat pump in heavy snow areas.

Please make sure the standardized voltage 220V-240V is available to the heat pump, otherwise the performance would be influenced and could affect your warranty.


The foundation of the heat pump can be a cement or steel structure. Anti-vibration rubber feet and a flat foundation are generally required. The foundation structure can be flexibly designed according to the working weight of the heat pump. (Please see the technical data in this manual.)

Water drainage should be available near the installation location for draining water in an effective way. Do not install the heat pump in a place where there is polluting or corrosive materials like oil, flammable and explosive gas and sulphide ect. Keep it far away from sands, falling leaves and area with high-frequency equipment.

Installation on a balcony or on a roof-top must be in accordance with the allowable stress of the building structure.



The installation space should be referred as follows:




Intake and outlet should not be obstructed. The wall the unit is to be mounted on should be strong enough to bear the weight and vibrations of the unit.


Allow for proper clearances around the unit. Location should allow easy access for maintenance.

For any further guidance on heat pump installations for planning purposes, please consult the latest version of the MCS guidelines or your local authority.

Example Installation Method 1: - Heating only with radiators



Example Installation Method 2: - Heating only with underfloor




Cool Energy

www.coolenergyshop.com

Underfloor Only

Example Installation Method 3: - Heating Only with Underfloor & Radiators



Cool Energy


www.coolenergyshop.com

Radiators & Underfloor

ecoTec Range - Heating Only Example Diagram

Example Installation Method 4: - Hot Water / Thermal Store Only

ecoTec Range Hot Water / Thermal Store Example Diagram




Cool Energy

www.coolenergyshop.com

Cylinder / Thermal Store

Example Installation Method 5: - Hot Water & Heating



Water Connections

Water connections at the heat pump

Flexible pipe fittings are recommended to be installed on the flow and return connections.



The water inlet and outlet connections to the heat pump, accept standard BSP threaded fittings.



CAUTION – Make sure that the required water flow rates can be maintained at all times.


Plumbing Installation Requirements

1. Water pressure should not exceed 3 Bar.
2. Each part connected to the unit needs to be connected with method of loose jointing and installed with intermediate valves.
3. Ensure that all plumbing has been properly flushed and tested. (See Page 31.)
4. All pipelines and pipe fittings must be insulated to prevent heat losses.
5. Install a drain valve at the lowest point of the system to enable the system to be drained fully.
6. Install a check valve on the water outlet connection if back siphoning could occur.
7. In order to reduce the back pressure, the pipes should be installed horizontally.
8. Minimum flow rates detailed on the date badge must be maintained and could void warranty and damage unit if they are not.

Electrical Connections

 **WARNING** – Risk of electrical shock or electrocution.

Ensure that all high voltage circuits are disconnected before commencing heat pump installation. Contact with these circuits could result in death or serious injury to users, installers or others.

 **CAUTION** – Label all wires prior to disconnection when servicing the heat pump. Wiring errors can cause improper and dangerous operation. Check and ensure proper operation after servicing.

General Information

Wiring connections must be done according to the wiring diagram found on the inside of the heat pump access panel or see addendum A for reference.

The heat pumps must also be earthed. A ground lug is provided on the inside of the heat pump electrical compartment.

The supplied controller is pre-wired using a low voltage low loss cable and can be easily moved and located where required.

The controller plugs directly onto the cable supplied with no additional wiring required.

If you wish to extend this cable or any of the sensor cables, please use a shielded low loss cable.

Circuit Breaker Sizing:

CE-ET10	–	20a Type C MCB / RCBO
CE-ET15	–	25a Type C MCB / RCBO
CE-ET22	–	32a Type C MCB / RCBO

Power Supply

1. If the supply voltage is too low or too high, it can cause damage and/or result in unstable operation of the heat pump unit, due to high inrush currents on start up.
2. The minimum starting voltage should be above 90% of rated voltage. The acceptable operating voltage range should be within $\pm 10\%$ of the rated voltage. When heat pump units are installed in parallel, ensure that the voltage difference, between these units, is within $\pm 2\%$ of each other. The voltage difference between phases of a three-phase power supply should be within $\pm 2\%$.
3. Ensure the cable specifications meet the correct requirements for the specific installation. The distance between the installation site and the mains power supply will affect the cable thickness. Follow the 17th edition wiring regulations to select the cables, circuit breakers and circuit breakers.

Earthing and Over Current Protection

In order to prevent electric shock in case of leakage from the unit, install the heat pump according to current electrical wiring regulations.

1. Do not frequently interrupt the voltage supply to the heat pump as this may result in a shorter life expectancy of the heat pump.
2. When installing over current protection, ensure that the correct current rating is met for this specific installation.
3. The compressor, fan coil unit and heat pump water pump all have AC- contactors and thermo relay protection. Therefore, in the process of installation and debugging, firstly measure each of the components' current, and then adjust the current protection range of the thermo relays.

Section 3

Operating Your Heat Pump


LCD User-Friendly Interface Controller

General Instructions

The operation panel features:


1. Touch screen with unlimited key operations.
2. Minimal electromagnetic susceptibility and interference.
3. Stylish appearance of easy viewing purposes.

Controller Panel



Operating Controller

Keys Explanation:



① Heating / Cooling temperature display



Displays the current cooling real-time temperature in blue fonts.

Displays the current real-time heating temperature in orange font.

In the upper left corner of the temperature display, when the ❄️ or 🌊 icon is displayed, it indicates that the unit is running the cooling or heating mode.

② Displays the mode of the heat pump:



day mode



night mode



economic mode



Test mode.

③ Hot water temperature display



Displays the current hot water temperature in red.

In the upper left corner of the temperature display, when there is 🚰 icon, it indicates that the unit is running the hot water mode.

④ Simple display and dynamic display switching:


Click the ⇄ icon to switch between simple display and dynamic display.


⑤ Click 🔔 key to check the active fault alarms and historical fault alarms.


⑥ **The display of heat pump status on the right below corner:**

The running status of the heat pump is displayed here.


⑦ **Timer setting:**

Click  icon to enter into timer setting.


This changes to red when there is a time event set .

White indicates there is no time event set .


⑧ **System parameter setting:**



Click this icon to enter the setting interface .


⑨ **Mode setting:**

Click this icon to enter the mode setting interface .

⑩ **Power on and off:**

Click this icon to power on and off .

It displays red  when it is turned on, and white  when it is turned off.



Dynamic Display



Icon indicates Cooling mode




Icon indicates Heating mode



The current heating or cooling temperature is displayed on each tank icon.


Click either tank icon here to adjust the temperature setting



Mode switching


Click  key to set the unit mode.

After selecting the required mode, click  key to confirm, and click  key to Cancel and exit the page.




Temperature setting

Click the ① or ② position of the real-time temperature to enter the temperature setting interface.



Set the temperature and hysteresis of each mode in the temperature setting interface.



Cooling setp.: Cooling set temperature

Heating setp.: Heating set temperature

Temp. Diff. : Temperature differential for heating & cooling mode.



Hotwater setp.: Hot water tank temperature set temperature setting

Temp. Diff.: Temperature differential for hot water mode.

Timer setting



Press the  key to open the timer setting interface.



Enable period with slider.

Not enabled , Enabled .


ON: Set for the power-on time.

OFF: Set for power-off time.

Time bands 1, 2 & 3, are the three periods that can be set.
Each timer period can have different hot water, heating, and cooling temperature setpoints.


Parameter query and setting

Press  key to enter Main Menu as shown below:




① User Parameters:

Press  **User parameter** for user parameter settings:



- P01 **Cooling setp.:** Cooling set temperature
- P02 **Heating setp.:** Heating set temperature
- P03 **Temp. Diff. :** Temperature differential for heating & cooling mode.
- P04 **Hotwater setp.:** Hot water tank temperature set temperature setting




P05 Temp. Diff.: Temperature differential for hot water mode.

P06 Unit mode: Set mode of operation.

P07 Fan mode:

Modes available to select:

1. **Day mode:** According to the ambient temperature and load requirements, the compressor runs at the maximum frequency, and the fan runs at the maximum speed – **Select for best system response times.**
2. **Night mode:** During the period from 20:00 to 8:00 of the real-time clock, the maximum speed of the fan shall not exceed 500 rpm, and the maximum speed of the compressor shall not exceed 50Hz. These two parameters can be adjustable, and other periods are in accordance with the day mode run. – **Select for quietest operation**
3. **Economy mode:** As shown in the logic below, outside ambient temperatures / heat pump operation modes correspond to compressor maximum speeds and temperature setpoints. – **Select for best system efficiency**





Test mode is not used for homeowners.

② Parameter query:

Click  to set the operating parameters.


Cascade Settings:







When a single unit is running, the 1# Unit icon is green .
Click 1# unit to query the operating parameters of this unit.

If there is a linked network of heat pumps, you can click 2#, 3#...8# to query the operating parameters of the corresponding unit, and the software version number.

If this unit icon is displayed , the unit is not connected.






③ Trend Graphs



Press this icon to display the curves of inlet temperature, outlet temperature, and hot water tank temperature corresponding with running time.




④ Project Parameters








Click the icon and enter the password.

This password is only provided for the approved installers, if needed, please contact Cool Energy.





Weather compensation settings:


Click  icon to enter the setting of relevant parameter on ECO mode
The below settings will influence the weather compensation curve. They can be tailored by the installer to the specific installation requirements.



Anti-legionella settings:

Click  icon to enter parameter settings for high temperature sterilization mode.




Enable function with slider .


Temp. Setpoint: Sterilization temperature setting to enable output.


Weekday: Sterilization days, once a week.


TIMER: Sterilization time setting, once a week.

Language setting:

Press  icon to enter the language selection interface and select language.

Press  to access the relevant settings of project parameters




DC Pump: Inverter water pump disable / enable,  green is enabled

DC Pump work: The working mode of the inverter water pump can be selected as demand, always on, intermittently on.

Start interval: The interval time for the start of the inverter water pump in intermittent mode.

Delta temp. set: The inverter water pump controls the current temperature difference between the incoming and outgoing water.



Auxiliary Heating Heater Output:

Ext.temp. Setp: Start-up ambient temperature of auxiliary electric heater.


Comp. Delay: heating auxiliary heater start delay.


Auxiliary Hot water heater Output:

Ext.temp. Setp: Start-up ambient temperature of hot water electric heater.

Comp. Delay: Hot water auxiliary heater start delay.


⑤ **Factory parameters:**




Press  icon and enter the password to access factory parameters. This password can only be given after obtaining authorization from Cool Energy.

Current / Active Alarm History:

Current Alarm:

The flashing icon  in the upper right corner indicates that there is an active alarm.


Press this icon to open the current alarm interface.




Time	Description
15/02/22 14:01	#01 E67 Low press sensor failure
15/02/22 14:01	#01 E68 High press sensor failure
15/02/22 14:01	#01 E42 Cool coil TP failure
15/02/22 14:01	#01 E29 Return TP failure
15/02/22 14:01	#01 E63 Eco outlet TP failure
15/02/22 14:01	#01 E62 Eco inlet TP failure


Historical Alarms:

Scroll for previous alarm conditions.



Time	Description
15/02/22 14:01	#01 E67 Low press sensor failure
15/02/22 14:01	#01 E68 High press sensor failure
15/02/22 14:01	#01 E42 Cool coil TP failure
15/02/22 14:01	#01 E29 Return TP failure
15/02/22 14:01	#01 E63 Eco outlet TP failure
15/02/22 14:01	#01 E62 Eco inlet TP failure

Press  to show a dialog box for whether to delete historical alarms, press "YES" to delete historical alarms, and press "NO" to cancel the operation.

Press  to switch between current alarm and historical alarm.

Press  to return to main menu.

Alarm Codes:


Code	Description
Er 02	Missing phase
Er 03	Insufficient water flow
Er 04	Antifreeze protection
Er 05	High refrigerant pressure
Er 09	Communication failure
Er 10	Communication failure of inverter driver module (occurs when communication between outer board and driver board is disconnected)
Er 12	Discharge temperature too high
Er 14	Water tank temperature sensor fault
Er 15	Water inlet temperature sensor fault
Er 16	Evaporator coil temperature sensor fault
Er 18	Discharge temperature fault
Er 20	Abnormal protection of frequency conversion module
Er 21	Ambient temperature sensor fault
Er 23	Cooling outlet water temperature supercooling protection
Er 26	Heat sink temperature fault
Er 27	Outlet water temperature sensor fault
Er 29	Return gas temperature sensor fault
Er 32	High outlet water temperature fault
Er 33	Coil temperature too high
Er 34	The temperature of inverter driver module is too high
Er 42	Cooling coil temperature sensor failure
Er 62	Inlet temperature fault of economizer
Er 44	Ambient temp too low
Er 63	Outlet temperature failure of economizer
Er 64	DC fan 1 fault
Er 66	DC fan 2 fault
Er 67	Low pressure switch failure
Er 68	High pressure switch failure
Er 69	Low pressure protection
Er 70	High pressure protection


General Operating Guide

Initial Start-Up Precautions

First boot-strap and running state checks.

1. To ensure the power to the unit is at the correct voltage.
2. Unit electrical connections: Check if power supply wire connections are okay; if earth wire is properly connected; check if water pump and other chain devices are properly connected.
3. Water pipes, heat emitters are check for leaks.
4. Check water system: make sure the water flow is adequate and there is no air or leakages.
5. Check system settings are set at recommended default values.
6. First boot-strap or starting up again after being shut down for a long time, stop, ensure power is on ahead and heating at least 12 hours for crankcase (local loop temperature is zero). Water pump starts up first, fan starts up, and then compressor starts up and begins regular operation.
7. Running checks: check the following items:
 - a. Input and output water temperature.
 - b. Water flow rate.
 - c. Running electric current of compressor and fan.
 - d. High and low-pressure value when heating is running

 **CAUTION** – Refrain from using this heat pump if any technical components have been in contact with water. Immediately call a qualified service technician to inspect the heat pump.

 **CAUTION** – Keep all objects clear from above the heat pump. Blocking air flow could damage the unit and may void the warranty.

Users Guide

1. Rights and Responsibility

1.1 To ensure you have the service guarantee period, only qualified heating engineers can install and repair the unit. If you infract this request and cause any loss and damage, our company will not be held responsible. Please refer to your warranty card for further information.

2. User Guide

2.1 All safety protection devices are set in unit before leaving the factory, don't adjust it by yourself.

2.2 Units have been charged with refrigerant and lubricating oil, if needed owing to a leak; please refer to the charging quantity on nameplate.

2.3 The external water pump must be connected to the output from the unit.

2.4 Use antifreeze / glycol when the environment temperature is less than zero in winter.

2.5 Safety Precautions

- a. Unit must be installed by a competent person, plumber, or heating engineer.
- b. Please check that power supply corresponds with unit size.
- c. The main power switch of unit should have earth leakage protector; the power cable must meet the unit power requirements.
- d. Unit must have a ground wire; don't use the unit if there is no ground wire.
- e. Don't use the unit if the fan grill / fence has been removed.
- f. To avoid electric shock or fire, don't store or use, oil paint, petrol, combustible gas, or liquid around the unit; don't throw water or other liquid on to the unit and don't touch the unit with wet hands.
- g. Don't adjust the switch, valve, controller, or internal data without permission of customer support team.
- h. If a safety protection device is activated at start up, please contact the customer engineer, or support team.

Section 4

Commissioning

- Ensure all pipes have been flushed with cleaner and are free of debris in accordance with Part L Building Regulations. (**Part L** refers to the **Domestic Heating Compliance Guide**. This states that the minimum provision in new and existing dwellings is: Thorough cleaning and flushing out before installing a new heating appliance. During final fill add the corrosion and scale formulation / Glycol as required.
- Water flow should be checked either by a flow metering device either fitted permanently or temporarily to the system. Or measuring the temperature differential between the flow and return pipes when the heat pump is running. The temperature differential should not exceed 5 degrees C. The heat pump itself does also incorporate a flow switch on the return pipe. If a low flow condition is detected, alarm code Er 03 will be displayed on the controller and will not reset until the flow has been restored.
- Visually check installation to ensure all pipework is complete and insulation is applied where required
- Check all electrical connections have been made and tested according to BS7671:2018
- Ensure system is filled and pressure is between 1 & 2 bar
- Ensure all system filters are free from debris
- Check all air has been vented from the system
- Turn all external heating controls and thermostats to on positions
- Activate the heat pump with the Carel control screen
- Check operation of external controls by turning zones on and off and thermostats up and down
- Allow heat pump to reach set temperatures for each zone
- Ensure heat pump settings are correct according to the factory defaults provided in Section 3.
- Set timeclocks and temperature settings to optimise efficiency for homeowner (Weather compensation mode is recommended)
- Fill in benchmark form with the installation details (p33)
- Demonstrate the system to the homeowner

Service & Maintenance – Service Engineer

Inspection and Service

Cool Energy air source heat pumps are designed and built to provide long life and performance, when installed and operated properly under normal conditions. Periodic inspections are important to keep your heat pump running safely and efficiently.

The basic requirements are:

- Clean the outdoor heat exchanger
- Straighten any evaporator fins with a fin comb if required
- Visual inspection for oil or leaks
- Test the primary system water with a refractometer to ensure adequate glycol concentrate
- Check the integrity of the pipework insulation
- Check for loose electrical connections
- Check heat pump control settings are correct for best performance
- Check system controls are set for best performance
- Check compressor operating current
- Complete service record (p34)

Homeowner Inspection

Cool Energy recommends that inspections on heat pumps are done frequently, especially after abnormal weather conditions. The following basic guidelines are suggested for your inspection:

1. Make sure the front of the unit is accessible for service.
2. Keep the top and surrounding areas of the heat pump clear of all debris.
3. Keep all plants and shrubs trimmed and away from the heat pump especially the area around the fan.
4. Keep lawn sprinklers from spraying on the heat pump to prevent corrosion and damage.
5. Ensure that the earth wire is always properly connected.
6. A water filter must be installed and maintained.
7. All the safety protection devices have been set up; please refrain from changing these settings. If any changes are needed, please contact our support team.
8. If the heat pump is installed under roof without a gutter, ensure that all measures are taken to prevent excessive water from entering the unit.
9. Do not use this heat pump if any electrical part has been in contact with water. Contact an authorized service technician.

Troubleshooting

Use the following troubleshooting information to resolve issues with your heat pump.



WARNING — RISK OF ELECTRICAL SHOCK OR ELECTROCUTION.



Ensure that all high voltage circuits are disconnected before commencing heat pump installation maintenance. Contact with these circuits could result in death or serious injury to users, installers or others.

- Keep your hands and hair clear of the fan blades to avoid injury.
- **DO NOT** attempt to adjust or service the unit without consulting your authorized installer/agent.
- **PLEASE** read the complete Installation and/or User's Guide before attempting to operate service or adjust the heater.
- **Your heat pump is equipped with an intelligent control system**
It will try and overcome any problem by itself and automatically recovers from most fault conditions as well as power outages. If for any reason an alarm code is displayed starting Er*** on the controller screen.
Don't worry! -It will only display Alarm codes if it has shut down to protect itself from damage. Normally it will be something very simple such as low water pressure or a blocked filter. Please check the protection codes table in this manual and contact your installer in the first instance.

AIR TO WATER HEAT PUMP COMMISSIONING CHECKLIST

This Commissioning Checklist is to be completed in full by the competent person who commissioned the heat pump and associated equipment as a means of demonstrating compliance with the appropriate Building Regulations and then handed to the customer to keep for future reference.

Failure to install and commission this equipment to the manufacturer's instructions may invalidate the warranty but does not affect statutory rights.

Customer name:										Telephone number:									
Address:																			
Heat Pump Make and Model																			
Heat Pump Serial Number																			
Commissioned by (PRINT NAME):										Certified Operative Reg. No. [1]									
Company name:										Telephone number:									
Company address:																			
										Commissioning date:									
Building Regulations Notification Number (if applicable) [2]																			

CONTROLS - SYSTEM AND HEAT PUMP (tick the appropriate boxes)			
Time and temperature control to heating	Room thermostat and programmer/timer		Programmable Roomstat
	Load/weather compensation		Optimum start control
Time and temperature control to hot water	Cylinder thermostat and programmer/timer		Combined with Heat pump main controls
Heating zone valves (including underfloor loops)	Fitted		Not required
Hot water zone valves	Fitted		Not required
Thermostatic radiator valves	Fitted		Not required
Heat Pump Safety Interlock [3]	Built In		Provided
Outdoor Sensor	Fitted		Not required
Automatic bypass to system	Fitted		Not required
Buffer Vessel Fitted	Yes	No	If YES Volume: Litres

ALL SYSTEMS	
The heating system has been filled and pressure tested	Yes
Expansion vessel for heating is sized, fitted & charged in accordance with manufacturer's instructions	Yes
The heat pump is fitted on a solid/stable surface capable of taking its weight	Yes
The system has been flushed and cleaned in accordance with BS7593 and heat pump manufacturer's instructions	Yes
What system cleaner was used?	
What inhibitor was used?	Quantity litres
Is the system adequately frost protected?	Yes

OUTDOOR UNIT	
Are all external pipeworks insulated?	Yes
Is the fan free from obstacles and operational?	Yes
Has suitable consideration been made for waste water discharge?	Yes

CENTRAL HEATING MODE	
Heating Flow Temperature	°C Heating Return Temperature °C

DOMESTIC HOT WATER MODE Measure and Record:			
Is the heat pump connected to a hot water cylinder?	Unvented	Vented	Thermal Store
Hot water has been checked at all outlets	Yes	Have Thermostatic Blending Valves been fitted?	Yes Not required

ADDITIONAL SYSTEM INFORMATON					
Additional heat sources connected:	Gas Boiler	Oil Boiler	Electric Heater	Solar Thermal	Other:

ALL INSTALLATIONS	
The heating, hot water and ventilation systems complies with the appropriate Building Regulations	Yes
All electrical work complies with the appropriate Regulations	Yes
The heat pump and associated products have been installed and commissioned in accordance with the manufacturer's instructions	Yes
The operation of the heat pump and system controls have been demonstrated to the customer	Yes
The manufacturer's literature, including Benchmark Checklist and Service Record, has been explained and left with the customer	Yes

Commissioning Engineer's Signature
Customer's Signature
(To confirm satisfactory demonstration and receipt of manufacturer's literature)

Notes: [1] Installers should be members of an appropriate Competent Persons Scheme. [2] All installations in England and Wales must be notified to Local Area Building Control (LABC) either directly or through a Competent Persons Scheme. A Building Regulations Compliance Certificate will then be issued to the customer. [3] May be required for systems covered by G3 Regulations

© Heating and Hot Water Industry Council (HHIC)



SERVICE RECORD

It is recommended that your heating system is serviced regularly and that the appropriate Service Interval Record is completed.

Service Provider

Before completing the appropriate Service Record below, please ensure you have carried out the service as described in the manufacturer's instructions. Always use the manufacturer's specified spare part when replacing controls.

SERVICE 01		Date:	SERVICE 02		Date:
Engineer name:		Engineer name:		Engineer name:	
Company name:		Company name:		Company name:	
Telephone No:		Telephone No:		Telephone No:	
Operative ID No:		Operative ID No:		Operative ID No:	
Comments:		Comments:		Comments:	
Signature		Signature		Signature	
SERVICE 03		Date:	SERVICE 04		Date:
Engineer name:		Engineer name:		Engineer name:	
Company name:		Company name:		Company name:	
Telephone No:		Telephone No:		Telephone No:	
Operative ID No:		Operative ID No:		Operative ID No:	
Comments:		Comments:		Comments:	
Signature		Signature		Signature	
SERVICE 05		Date:	SERVICE 06		Date:
Engineer name:		Engineer name:		Engineer name:	
Company name:		Company name:		Company name:	
Telephone No:		Telephone No:		Telephone No:	
Operative ID No:		Operative ID No:		Operative ID No:	
Comments:		Comments:		Comments:	
Signature		Signature		Signature	
SERVICE 07		Date:	SERVICE 08		Date:
Engineer name:		Engineer name:		Engineer name:	
Company name:		Company name:		Company name:	
Telephone No:		Telephone No:		Telephone No:	
Operative ID No:		Operative ID No:		Operative ID No:	
Comments:		Comments:		Comments:	
Signature		Signature		Signature	
SERVICE 09		Date:	SERVICE 10		Date:
Engineer name:		Engineer name:		Engineer name:	
Company name:		Company name:		Company name:	
Telephone No:		Telephone No:		Telephone No:	
Operative ID No:		Operative ID No:		Operative ID No:	
Comments:		Comments:		Comments:	
Signature		Signature		Signature	



Cool Energy Holding Ltd.

163 Cleethorpe Road,
Grimsby,
DN31 3AX.

Email: sales@coolenergyshop.com

www.coolenergyshop.com

