

VICTROLA™



Hampton **Bluetooth® Turntable**

Model: VM-130

Instruction Manual

PLEASE READ THIS INSTRUCTION MANUAL CAREFULLY BEFORE USE
AND KEEP IT FOR FUTURE REFERENCE.


CONTENTS

SAFETY INSTRUCTIONS	2
SPECIFICATIONS	3
WEEE & CE STATEMENTS	4
HOW TO INSTALL / REMOVE POWER ADAPTOR PLUG.....	4
TURNTABLE LAYOUT.....	5
TURNTABLE OPERATION	6
POWER SUPPLY	6
BASIC OPERATION	6
TURNTABLE NEEDLE REPLACEMENT.....	7
BLUETOOTH OPERATION	7
LINE-OUT OPERATION	7

SAFETY INSTRUCTIONS

1. Read these instructions – All the safety and operating instructions should be read before this product is operated.
2. Keep these instructions – The safety and operating instructions should be retained for future reference.
3. Heed all warnings – All warnings on the appliance and in the operating instructions should be adhered to.
4. Follow all instructions – All operating and use instructions should be followed.
5. Do not use this apparatus near water – The appliance should not be used near water or moisture – for example, in a wet basement, near a swimming pool, or near other wet areas.
6. Clean only with a dry cloth.
7. Do not block any ventilation openings. Keep at least 5 cm around the apparatus for sufficient ventilations. Install in accordance with the manufacturer's instructions.
8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9. Do not defeat the safety purpose of the polarized or grounding plug. A polarized plug has two blades with one wider than the other. A grounding plug has two blades and a third grounding prong. The wide blade or the third prong is provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10. Protect the power cord from being walked on or pinched particularly at the plugs, convenience receptacles, and at the point where they exit from the apparatus.
11. Only use attachments/accessories specified by the manufacturer.
12. Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart or rack is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.
13. Unplug the apparatus during lightning storms or when unused for long periods of time.
14. Refer all servicing to qualified personnel. Servicing is required when the apparatus has been damaged in any way, such as power supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
15. Please keep the unit in a well ventilated environment.
16. Only use attachments/accessories specified or provided by the manufacturer
17. To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture. The apparatus shall not be exposed to dripping or splashing and no objects filled with liquids, such as vases, shall not be placed on apparatus.
18. The main plug is used as disconnect device, the disconnected device shall remain readily operable.
19. This product is not intended for commercial use. Household Use Only.



20.  This equipment is a Class II or double insulated electrical appliance. It has been designed in such a way that it does not require a safety connection to electrical earth.

21.

 <p>The lightning flash with arrowhead within an equilateral triangle is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock.</p>	<div style="border: 1px solid black; padding: 5px;">CAUTION RISK OF ELECTRIC SHOCK DO NOT OPEN</div> <p>CAUTION: TO PREVENT RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PROFESSIONAL.</p>	 <p>The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.</p>
--	---	---

Warning: To reduce the risk of fire or electrical shock, do not exposed the apparatus to rain or moisture. No naked flame sources such as candles shall be placed on top of the apparatus.

Caution: Changes or modifications not expressly approved by the manufacturer could void the user's authority to operate this device. Usage of controls or adjustments or performance of procedures other than those specified herein may result in hazardous exposure.

SPECIFICATIONS

Power Supply: AC Adaptor: 100-240, 50-60Hz
..... DC-12V/2.0A

Speaker Impedance: 4", 4ohm/Tweeter 20mm, 4ohm

Max Power Consumption:..... 30W

Included:..... Turntable, Speakers,
Instruction Manual, Turntable
Operation Sheet, 12V/2.0A
Switching Power Supply,
Speaker Cables
and 45 RPM Adaptor

Design and specifications are subject to change without notice.

Bluetooth is a registered trademark of Bluetooth SIG, Inc.
Other trademarks and trade names are those of their respective owners

This product is manufactured and sold by Innovative Technology Electronics LLC. Victrola and the Victrola logo are trademarks of Technicolor or its affiliates and are used under license by Innovative Technology Electronics LLC. Any other product, service, company, trade or product name and logo referenced herein are neither endorsed nor sponsored by Technicolor or its affiliates.

Made In China.

WEEE & CE STATEMENTS



WEEE marking

Disposal of your old product

Your product is designed and manufactured with high quality materials and components, which can be recycled and reused. When this crossed out wheeled bin symbol is attached to a product it means the product is covered by the European Directive 2002/96/EC. Please make yourself aware of the local collection system for electrical and electronic products. Please act according to your local rules and do not dispose of your old products with your normal household waste. The correct disposal of your old product will help prevent potential negative consequences for the environment and human health.



This appliance complies with the following EEC directives: 2014/35/EU Low voltage directive / 2014/30/EU EMC directive


You can download the complete EU conformity declaration from www.victrola.com/eudoc

Imported by:


Exertis Supply Chain Services Ltd.

M50 Business Park, Ballymount Rd. Upper, Dublin 12, D12 T4C2, Ireland

HOW TO INSTALL / REMOVE POWER ADAPTOR PLUG



TURNTABLE LAYOUT



- | | |
|--------------------------------------|----------------------------------|
| 1. Speakers | 10. Power/Function LED Indicator |
| 2. Turntable Platter | 11. Volume Control Knob |
| 3. Felt Mat | 12. Stylus (Needle) Cartridge |
| 4. Lift Lever | 13. External Speaker Jacks |
| 5. Tone Arm Clip/Rest | 14. Function Selection Switch |
| 6. Auto & Manual Stop Control Switch | 15. L/R RCA Output Jack |
| 7. Speed Control Selection Switch | 16. DC IN Power Jack |
| 8. Turntable Shaft | 17. Power ON/OFF Switch |
| 9. Tone Arm | |

TURNTABLE OPERATION

SET UP

An AC/DC adaptor with an output of 12V DC 2.0A is included with the Modern Bluetooth Stereo Turntable. This adaptor is required for operating the unit.

1. Connect the external speaker cables from the EXTERNAL SPEAKER JACK on the back of the unit to each speaker.

NOTE: The external speaker cables are color coded, the red cable is plugged into a red jack on both the unit and speakers (black cable into the black jacks).

2. Firmly and securely insert the DC plug of the adaptor to the DC IN Jack on the back of the unit.
3. Plug the adaptor's AC plugs into a power outlet rated at 220-240V AC ~ 50/60Hz.
4. Turn on the unit by switching the POWER ON/OFF SWITCH to the ON position. The POWER/FUNCTION LED INDICATOR will turn on.

BASIC OPERATION

Before use, be sure to remove the white stylus guard off of the needle. Always make sure that the tone arm is unlocked and free to move across the record while operating. Lock the tone arm in place again when it is not in use.

1. Slide the FUNCTION SELECTION SWITCH to the PHONO position, the FUNCTION LED INDICATOR will turn RED.
2. Place a record on the TURNTABLE PLATTER and select the desired speed (33 1/3 / 45 / 78) by sliding the SPEED SELECTION SWITCH to the speed according to the type of record.

NOTE: When playing a 45 rpm record, use the included 45 rpm adaptor located inside the accessories bag.

3. Open the TONE ARM CLIP to release the TONE ARM. Push the LIFT LEVER backwards to raise the arm. Gently move the tone arm to the desired position over the record. The turntable will begin to spin only when the tone arm is moved toward the record. To begin playing, push the lift lever forward to lower the arm slowly onto the desired position of the record.
4. If the AUTO STOP SELECTION SWITCH is turned ON, the record will stop automatically when finished.

PLEASE NOTE: If the Auto Stop is turned ON, the record will spin only when the tone arm is moved over the record. If the Auto Stop is turned OFF, the record will spin even when the tone arm is in resting position.

5. To select the volume level, turn the VOLUME CONTROL KNOB to adjust the volume.

HOW TO REPLACE THE TURNTABLE NEEDLE (*Replacement Needle # ITNP-Y2*)

Removing the Stylus from the Cartridge

1. Set a screwdriver at the tip of the stylus and push down to the direction "A".
WARNING: When applying force to stylus, too much may damage or break the stylus.
2. Pull the stylus out toward the direction "B".


Installing the Stylus

1. Hold the tip of the stylus and insert the other edge by pressing toward direction "C".
2. Push the stylus up toward direction "D" until it locks at the tip.

Caution:

- Do not remove or bend the stylus needle.
- Do not touch the needle to avoid injury to your hand.
- Turn off the unit's power before you replace the stylus.
- Keep out of reach of children.

Please note: The stylus should last about 50 hours under normal use. It is recommended that the stylus be replaced as soon as you notice a change in sound quality.



BLUETOOTH OPERATION

An external device with Bluetooth Connectivity can be wirelessly connected to this turntable using the Bluetooth function.

1. Turn on the unit by switching the POWER ON/OFF SWITCH to the ON position.
2. Turn the FUNCTION SELECTION SWITCH to the BT (Bluetooth®) position, the FUNCTION LED INDICATOR will begin to flash BLUE.
3. Turn your external device's Bluetooth Setting ON. Wait a moment, then look for the Bluetooth pairing name "VM-130".
4. Select the Bluetooth pairing name, to connect the unit. Once connected, the blue LED light will stop flashing.
5. You are now connected to your external device via Bluetooth.
6. Rotate the VOLUME CONTROL KNOB to adjust the sound level.

NOTE: If a password is required, enter "0000" and press enter to connect.

LINE-OUT OPERATION

This unit can connect to an external Hi-Fi Amplifier or Speaker System using RCA Cables (not included). To connect to external speakers plug the RCA Cables into the L/R RCA OUTPUT JACK on the back of the unit and the auxiliary input jacks on your Hi-Fi Amplifier or Speaker System.