

TOWER FAN 29" with OSCILLATION and TIMER
PPTF290



29 INCHES
**TOWER
FAN**

WITH OSCILLATION

3 SPEED
SETTINGS



GRID AIR
EXPULSION



WITH
OSCILLATION



120 MINS
TIMER

PPTF290



180028-12



Note: This Instruction Manual must be read fully before using the appliance, and retained for future reference.


THIS IS HOME TRULY

Parts & Description

LIST OF COMPONENTS

1. Control Panel
2. Handle (rear)
3. Air Outlet (Front Grill)
4. Air Inlet (Back Grill)
5. Base (2 parts)
6. ON/OFF & Speed selector buttons
7. Timer Dial
8. Oscillation Switch


Oscillation Switch



Timer Dial

Speed Buttons

Control Panel



Control Panel

Main Body

Handle (rear)

Air Outlet (Front)

Air Inlet (Back)

Front Grille

Back Grille


Base (removable)

HOW TO ASSEMBLE

Warning:

DO NOT operate the fan with any of its parts unassembled.
The entire assembled unit works as a single appliance.
The fan must only operate in the upright position.
Any other position will be hazardous.

1. Unpack both parts of the package and place them on a table.
2. The first package contains the 2 parts of the Base.



3. Insert the top part into the bottom and lock them securely in place.



**Groove for
Power Cable
to emerge**

4. The second package contains the Main Body and the power cable.
5. Sitting on a chair, invert the Main Body and place it between your knees for better grip. Remove the Knob Screw by rotating it anti-clockwise.



6. Insert the Main Body through the hole in the middle of the Base. Then attach the Knob Screw and rotate it clockwise to lock it into place.
Remember to allow the power cable to emerge from the groove. (see step 3)



Warnings

ATTENTION :

Read this booklet carefully as it contains important instructions for a safe installation, use and maintenance.

Important instructions to be kept for future reference.

The following basic precautions should always be followed when using electrical appliances:

1. Read all instructions before using the appliance.

The Appliance

2. This appliance must be used only for the purpose it was expressly designed; any use NOT complying with the instructions contained in the manual is considered inappropriate and dangerous. The manufacturer is NOT responsible for possible damages caused by the inappropriate and/or unreasonable use.
3. The installation/assembly of the appliance will be made in accordance with the indications of the manufacturer. A wrong procedure may cause damages to persons, animals or objects, for which the manufacturer cannot be considered responsible.
4. Before use, check the integrity of the appliance and power cable. DO NOT operate the appliance when its Motor Unit is damaged. In case you are not sure, contact a qualified person. If the power cable is damaged, it must be replaced by the manufacturer or its service agent, or a qualified technician in order to avoid a shock hazard.
5. Before powering the appliance make sure the rating (voltage and frequency) corresponding to the grid and the socket is suitable for the plug of the appliance, and that the wall socket is properly grounded. This appliance is fitted with an earth wire for extra safety.
6. Avoid the use of adapters and/or extension cables; if their use is absolutely necessary, use only materials in compliance with the current safety regulations and according to the electrical parameters of the adapters.
7. The appliance must NOT be switched on using external timers and/or other remote control appliances which are not specified in this manual.
8. Only use original components & accessories provided by the manufacturer. Any non-original component or accessory NOT recommended by the manufacturer may cause injuries to persons or damage to the appliance.
9. The packing materials (plastic bags, expanded polystyrene, etc.) must be kept out of the reach of children or disabled persons since they represent potential sources of danger.

Location

10. This appliance is NOT suitable to be used or stored near heat sources (open flame, ovens, heaters, stoves, etc.) and/or in an explosive environment (in the presence of flammable substances such as gas, vapour, mist or dust, in atmospheric conditions when, after ignition, the combustion is spread in the air). Items containing these substances should never be placed in the appliance, and never be used to clean the appliance in order to avert the risk of fire or explosion.
11. The appliance should NOT be placed on a surface, or in the vicinity of, objects which can be damaged by heat, such as carpets or plastics. DO NOT locate multiple portable socket outlets or power supplies at the bottom or rear of the appliance. During operation, as heat is transferred away from the appliance, the surface that the appliance is placed upon as well the surface immediately above or adjacent to it may become very hot. If the appliance is operated on wooden furniture, use a protective pad to prevent damage to delicate finishes. There should be at least 20 cm of free space from the back, left & right sides, and the top of the appliance to allow adequate air circulation. Never put things on top of the appliance.
12. Avoid placing the power cable on abrasive or sharp surfaces or in positions where it can be damaged easily. Avoid placing heavy objects on the cable. The cable must NOT be placed under carpets, or covered with throw rugs, runners or similar. Arrange the cable away from the high traffic area, and where it will NOT be tripped over. DO NOT pull or carry the appliance by the cable.
13. DO NOT operate the fan next to an open window while it is raining. Rainwater splashing onto the fan may cause an electric shock.
14. DO NOT use or store the appliance outdoors. Store and use the appliance only indoors, or in any case, protected from weathering such as rain, direct radiation of the sun and dust.

Operation

15. If you are using the appliance for the first time, you should:
 - a. Clean the exterior parts of the fan thoroughly with warm water & detergent with a non-abrasive sponge and wipe dry. DO NOT use metal scouring pads. Make sure that the Motor Unit DOES NOT come into contact with water.
 - b. Check that the Fan Grilles & Air Inlet/Outlet are NOT damaged.
 - c. Place and use the appliance on a horizontal, stable and dry surface. Damage may occur if the appliance is placed on an incline or decline.
 - d. Assemble the appliance fully before plugging it into the wall socket.
 - e. To turn ON : Turn the Timer Dial to ON.
 - f. (optional) Rotate the Timer Dial clockwise to your desired time duration.
 - g. Press the Speed Button (Low – '1 / 2 / 3' – High) to the fan speed you desire.

- h. Switch ON the Oscillation Switch at the rear of the appliance. To stop the fan from oscillating, switch OFF the Oscillation Switch.
- i. To turn OFF : Press the Speed Button 0 on the Control Panel.
- j. Make sure to remove any label or protective sheet which may prevent its proper functioning.

DO NOT:

- cover the appliance during functioning;
 - obstruct totally nor partially the Air Inlet & Air Outlet;
 - place the appliance on a soft surface such as a mattress, pillow, cushion or sofa, as this could cause the appliance to tip over, blocking the Air Inlet & Air Outlet;
 - insert objects or body parts (including clothing and hair) inside the protection cover of the appliance to avoid personal injury or damage to the machine when the appliance is in operation;
 - attempt to force the fan blades to turn or stop the blades from turning, which may lead to the motor overheating. If the motor is operating, but the Fan Blades do not move, switch the appliance off;
 - touch the inside of the fan while it is operating. The blades are rotating at very high speeds, which may lead to injury to your fingers and hands;
 - push the Speed Buttons too forcefully;
 - use the appliance near curtains or textiles;
 - use the appliance to dry wet clothes or use the appliance in a damp environment;
 - use any of the following agents as a cleaner: gasoline, thinner, or benzene;
 - operate the appliance for more than 6 hours without turning it off for at least 30 minutes to let the appliance cool down for a total usage of 12 hours a day – failure to heed this warning may result in motor failure;
 - leave the appliance unsupervised during operation.
16. During operation, DO NOT touch the appliance with wet body parts, and it is recommended to have between you and the standing surface, an isolating element (for example, wearing shoes with rubber soles).
17. DO NOT soak the Motor Unit in water or other liquids, wash it under the tap, or let any liquid flow into the internal casing of the appliance to prevent electric shock. In case of accidental fall in water, DO NOT try to take it out, but first switch the appliance off.
18. Switch the appliance OFF (press the Speed Button 0 and switch the wall socket off) before unplugging the appliance. Plug and unplug the power cable firmly holding it with dry hands. Always unplug the power cable to avoid overheating and if it is NOT used for a long period, before storing, assembling & disassembling, cleaning or performing any maintenance operation. Before storing, cleaning or maintenance operations, leave to cool for 30 minutes.

19. In case of malfunction or anomaly during the functioning, switch the appliance off immediately, turn off the power and check the cause of the anomaly, if possible, with the support of a qualified person.
20. If smoke is observed coming out of the appliance, switch the appliance off immediately.
21. This appliance is NOT intended for commercial use but to be used in households and similar applications, such as:
 - Staff kitchen areas in shops, offices & other working environments;
 - By clients in dormitories, hotels, motels & other residential environments;
 - Bed and breakfast type environments.
22. This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall NOT play with the appliance. Cleaning and user maintenance shall NOT be made by children unless they are older than 8 and supervised. Keep the appliance and its cable out of reach of children less than 8 years old.
23. Save these instructions.



Safety Features

A Thermal Fuse is installed in the Fan Head. If ever the motor overheats, the Thermal Fuse will be activated and will cut off electric current to the important appliance.

HOW TO USE

1. Press the Speed Button 0 on the Control Panel.
2. Insert the plug directly into the wall socket. Switch the socket switch ON.

To turn ON

3. Turn the Timer Dial to ON. (If the Timer sits at the OFF position, the appliance will not operate even if the appliance is switched on and the Speed Buttons are pressed, so keep the Timer Dial at ON at all times unless you wish to use the Timer.)
4. (optional) Select the desired time for the appliance to be in operation between 0 to 120 minutes if you wish. Rotate the Timer Dial clockwise to your desired time duration. The appliance stops automatically when the Timer Dial reaches OFF.
5. Press the Speed Button (Low – '1 / 2 / 3' – High) to the fan speed you desire.
6. Switch ON the Oscillation Switch at the rear of the appliance. The fan will oscillate side to side, sweeping an arc across the room. To stop the fan from oscillating, switch OFF the Oscillation Switch.

To turn OFF

7. Press the Speed Button 0 on the Control Panel.
8. Switch the socket switch OFF and detach the plug from the socket on the wall.

HOW TO CLEAN

1. Switch the appliance OFF. Wait for the appliance to cool down completely.
2. DO NOT attempt to disassemble the appliance. Warranty will be voided in such instances.
3. Clean the exterior parts of the fan thoroughly with warm water & dish-washing agent and a damp cloth, and immediately wipe dry. Please exercise caution when cleaning around the grilles. Make sure that the Motor Unit DOES NOT come into contact with water.

DO NOT use a scrubbing brush.

DO NOT use any of the following agents as a cleaner: gasoline, thinner, or benzene.

4. Never run water over the appliance as malfunctions may occur if water seeps inside the appliance.
5. Use a vacuum cleaner to suck up dirt from the Air Inlet and Air Outlet and around the Motor Unit periodically, based on the frequency of use and the air quality of the environment.

Dust (including smoke residue, hair, fur/feathers from pets, fibres from clothes, towels, curtains and carpets, etc.) can collect on the Grills, Fan blades and inside the Motor Unit. If not removed, it can build-up over months or years.

During normal operation, the Motor will become hot and this is normal. If not removed, dust can be a fire hazard.

ENVIRONMENTAL TIP

This appliance, along with all other electronic appliances, should, when it is no longer capable of functioning, be disposed with the least possible environmental damage according to the local regulations in your area. In most cases you can discard the appliance at your local recycling centre.

DISPOSAL: Do not dispose this appliance as unsorted municipal waste. Collection of such waste separately for special treatment is necessary.



SPECIFICATION

MODEL	PPTF290
RATED VOLTAGE	220 – 240V ~50 – 60Hz
POWER	50 W

WARRANTY

Warranty Conditions

1. This warranty provides against defective materials and manufacturing faults throughout for two years from the date of purchase of the appliance. The warranty on the Compressor is 10 years subject to the same conditions as above.
2. This warranty also does not cover normal wear and tear, replacement of consumable materials and accessories, and the cost of maintenance of the appliance.
3. This warranty does not cover the repair or replacement of part/s damaged by misuse, accidents, negligence, alterations, or modifications in any way, or repairs done by any repair organisation without the prior consent of PowerPac Electrical Pte Ltd.
4. Repair and service are to be performed at: 5 Changi South Lane #03-01 Singapore 486045. A transport fee will be charged for personal doorstep service.
5. The original purchaser of the appliance must furnish proof of purchase to our Service Centre with the email or number as registered during submission of warranty when this appliance is sent for repair/service. Failure to do so may delay the receipt of said repair/service by the customer.
6. Under no circumstances whatsoever shall the serial number be erased, defaced or altered by the customer and/or his representatives, or the dealer and/or his agents. Failure to ensure this shall invalidate the warranty.
7. This warranty is deemed to be void if the defect is caused by the attack of household pests, fire, lightning, natural disasters, pollution, abnormal voltage or the usage of generators.
8. This warranty is valid in Singapore only.
9. This warranty will be honoured subject to the customer's registration of the warranty inclusive of original invoice or valid purchase receipt. Failure to present these documents will result in denial of service. However, if the customer still requests that the defective appliance be repaired, PowerPac Electrical Pte Ltd may, at its discretion, repair the appliance but impose a labour charge, as well as the costs of the replacement parts, to be borne solely by the customer.
10. Please refer to the attached picture for the location of one of our appliance's serial number, as an example.



Please complete the on-line registration warranty form available on our website. There is no further requirement to send us any hard copy as part of our efforts to save the environment.

In accordance with the terms and conditions of this limited warranty as stated above, PowerPac Electrical Pte Ltd, at its expense shall provide free services for the appliance within the warranty period from its date of purchase from our Authorised dealers.

PowerPac Electrical Pte Ltd

 sales@powerpac.com.sg  [PowerPacSG](https://www.facebook.com/PowerPacSG)
 www.powerpac.com.sg  [@powerpacsg](https://www.tiktok.com/@powerpacsg)