

# AMSCO Maintenance Manual



ORTHOGRAPHIC 2  
ORTHOPEDIC AND FRACTURE TABLE  
(7/86) P-764317-885

## TABLE OF CONTENTS

TOPIC	SECTION	TITLE	GRID
1		<b>GENERAL DATA REVIEW</b>	A-4
	1.1	GENERAL	A-4
2		<b>GENERAL MAINTENANCE GUIDE</b>	B-6
	2.1	GENERAL	B-6
	2.2	TROUBLESHOOTING	B-7 thru B-11
	2.3	LUBRICATION	B-12 and B-13
	2.4	PREVENTIVE MAINTENANCE GUIDE	B-14 and C-1
	2.5	FIELD TEST PROCEDURE	C-1 thru C-4
3		<b>TABLE BASE</b>	C-6
	3.1	GENERAL	C-7
	3.2	HYDRAULIC SYSTEM	C-7
	3.3	COMPONENT REPAIR AND REPLACEMENT	C-9
	3.4	EXPLODED VIEWS AND PARTS LIST	D-2
4		<b>TABLE SUPERSTRUCTURE</b>	E-2
	4.1	GENERAL	E-2
	4.2	COMPONENT REPAIR AND REPLACEMENT	E-3
	4.3	EXPLODED VIEWS AND PARTS LIST	E-6
5		<b>TABLETOP</b>	E-14
	5.1	GENERAL	E-14
	5.2	COMPONENT REPAIR AND REPLACEMENT	E-14 and F-1
	5.3	EXPLODED VIEWS AND PARTS LIST	F-2
6		<b>TABLE ACCESSORIES</b>	F-6
	6.1	GENERAL	F-6
	6.2	INSTALLATION	F-6
	6.3	DRAWINGS AND PARTS LIST	F-8

This document is intended for the exclusive use of AMSCO and its customers. Reproduction in whole or in part is prohibited.

© AMSCO — 1983-1986

Rev. 7/86

Printed in U.S.A.

THIS PAGE  
INTENTIONALLY LEFT  
BLANK

# TOPIC 1 GENERAL DATA REVIEW

## INDEX

SECTION	PARAGRAPH	TITLE	GRID
		GENERAL .....	A-4
	1.1.1	Safety Precautions .....	A-4
	1.1.2	Application and Design .....	A-5
	1.1.3	Operating Instructions .....	A-5

### SECTION 1.1 GENERAL

**NOTE:** This Topic provides a general review of table particulars. You are urged to read this Topic before proceeding with the manual.

#### 1.1.1. SUMMARY OF WARNINGS AND CAUTIONS

The following are personnel (WARNINGS) and equipment (CAUTIONS) **safety precautions** to be observed when operating or servicing this unit. This is a listing of all safety precautions appearing in the text. Carefully read them before proceeding to use or service the unit. Observance of these safety precautions will minimize the risk of personal injury or the possible use of improper maintenance methods which may damage the unit or render it unsafe. It is important to understand that these precautions are not exhaustive. AMSCO could not possibly know, evaluate and advise maintenance departments of all conceivable ways in which maintenance might be done or the possible hazardous consequences of each way.

The operation and maintenance procedures recommended by AMSCO are described in this manual. Only these recommended maintenance procedures should be followed.

**WARNING:** REPAIRS AND ADJUSTMENTS SHOULD BE ATTEMPTED ONLY BY EXPERIENCED PERSONS FULLY ACQUAINTED WITH THIS EQUIPMENT. USE OF INEXPERIENCED, UNQUALIFIED PERSONS TO WORK ON THE EQUIPMENT OR THE INSTALLATION OF UNAUTHORIZED PARTS COULD CAUSE INJURY OR RESULT IN COSTLY DAMAGE.

**WARNING:** MAKE CERTAIN TABLETOP IS PROPERLY SUPPORTED BEFORE PERFORMING MAINTENANCE REQUIRING TOP TO BE MAINTAINED IN RAISED POSITION.

**WARNING:** SUPPORT TABLETOP ASSEMBLY BEFORE REMOVING TRANSLATION SHAFTS.

**WARNING:** WHEN REMOVING TRENDLENBURG GEAR ASSEMBLY, BLOCK SUPERSTRUCTURE TO AVOID SUDDEN TABLETOP MOVEMENT.

**CAUTION:** Do NOT overfill sump with hydraulic oil. Do NOT mix different brands of hydraulic oil.

**CAUTION:** Do not "kink" copper tubing when moving pump and sump assembly.

**CAUTION:** During lift carriage adjustments eccentric locking nuts should be tightened only with slight wrench pressure. Excessive tightening will fracture eccentric at flange.

**1.1.2. APPLICATION AND DESIGN**

The following product literature (SD-313) contains technical data relating to principle description and identifying characteristics of particulars for this table. The literature is informational rather than instructional. It provides, textually and illustratively, a general concept of equipment, its purpose, capabilities, limitations, and technical specifications.

**1.1.3. OPERATING INSTRUCTIONS**


The following instructions (P-129354-375) are intended to guide maintenance personnel when:

- Instructing operators in proper operation of table
- Instructing operators in techniques designed to ensure optimum equipment performance.
- Verifying validity of operator complaints

Refer to Troubleshooting Section of appropriate Topic if table is not operating properly. Refer to Application And Design Section for capabilities of equipment.


**ORTHOGRAPHIC 2  
ORTHOPEdic AND FRACTURE TABLE**
**TECH  
DATA**
**Orthopedic Table**
**DESCRIPTION**

ORTHOGRAPHIC is a mobile, manually operated orthopedic table. It provides flexible, easy to use, articulated posturing of patient for reconstructive and reparative orthopedic procedures. Permits conventional radiography and will interface with mobile image-amplification systems. Folds into a neat, compact package (28-1/2 x 27-1/2 x 41 inches [724x699x1041 mm]) when not in use.



Typical only — some details may vary.

**Application**

Designed primarily for hip and lower extremity procedures: hip pinning, ender nailing, intramedullary nailing of femur, tibia and fibula surgery. However, table (with optional accessories) also allows for upper body procedures: shoulder surgery, arm and hand surgery, non-operative myelograms.

**Applicable Standards**

Image-amplification accessories are designed to meet *Radiation Control for Health and Safety Act*. Suitable for use in nonflammable anesthetizing locations as defined in National Fire Protection Standard for the use of inhalation anesthesia, 56A (1978).

**DESIGN FEATURES**

**Base** affords adequate, comfortable toe space on both sides with sufficient space to receive the support blades of a Mayo-type instrument stand. Raise/Lower and Floor lock pedals are at head end. Height-adjustable floor locks, one at each corner, and casters, two swivel and two fixed, are provided. Fixed casters at foot end eliminate tendency of table to drift sideways. Top of base has an easy to clean stainless-steel cover. A NFPA-approved patient grounding receptacle is also provided at foot-end of base.

**Pedestal** includes tabletop lift cylinder and support column with bearing-mounted saddle frame. Saddle is steel to improve stiffness. Lift cylinder and support column are fully enclosed by stainless-steel, telescoping shrouds. Each shroud is one-piece construction to guard against foreign matter entering elevating mechanism.

**THE SELECTIONS CHECKED BELOW  
APPLY TO THIS EQUIPMENT**
**Optional Accessories**

- |   |   |
|---|---|
| <input type="checkbox"/> BF00-020 Accessory Clamp         | <input type="checkbox"/> BF00-025 Image Amplification                           |
| <input type="checkbox"/> BF00-021 Legholder               | <input type="checkbox"/> BF00-018 Drape Support                                 |
| <input type="checkbox"/> BF00-022 Popliteal               | <input type="checkbox"/> BF08-300 Clark Sockets                                 |
| <input type="checkbox"/> BF00-016 AP Cassette Holder      | <input type="checkbox"/> BF00-026 Arm/Hand Table                                |
| <input type="checkbox"/> BF00-017 Lateral Cassette Holder | <input type="checkbox"/> AMSCO Standard Arm and Leg Support Accessories (SD-42) |
| <input type="checkbox"/> BF00-023 Foot Traction Boot      |   |

Item No. \_\_\_\_\_  
Location(s) \_\_\_\_\_

Because of American Sterilizer Company's continuing program of research and development, all specifications and descriptions are subject to change without notice. This data is intended for the exclusive use of AMSCO customers, including architects or designers. Reproduction in whole or in part by others is prohibited.

**Superstructure** houses Lateral Tilt and Trendelenburg mechanisms. Bearing mounted to elevating mechanism. Covered with two-piece RIM (Reacting Injection Mold - no seams) molded, high density urethane shroud. Shroud is finished with non-conductive urethane paint. Two manual crank handles located on head-end of table control Tilt and Trendelenburg.

**Tabletop** contains translating support rods and locking mechanism. Tabletop can be translated four inches (101 mm) to either side of center to aid in patient transfer and positioning. Translation can be actuated and locked from either side of the table. Two stainless-steel rails for attaching accessories run entire length of top. Rails will also accept standard AMSCO accessories. Tabletop supplied with Velcro® (Velcro Corporation) strip to fasten pad.

**Pad** consists of a one inch (25 mm) thick, one-piece, foam latex sheet covered with Lectrolite Duotone® (Herculite Corporation). Sewn Velcro fasteners simplify application and removal. No other fastening devices required.

**Abductor Bars**, at foot-end of superstructure, feature two-sectional construction for lower extremity positioning flexibility. Each abductor bar has two rotating joints that provide planar rotation and can be locked at any position, from 0 to 160 degrees, by easy to use actuating handles.

### Operating Controls

• **Foot pedals** are easily actuated and clearly identified. Located at head-end of table, they include:

- LOCK/UNLOCK — to engage/disengage floor locks.
- RAISE/LOWER — to raise or lower the tabletop.

• **Tabletop positioning** controls are mounted at the head-end of table at a convenient height on the superstructure. They are arranged for simple, foolproof actuation and include:

- TRENDLENBURG — to lower or raise the head-end (see Figure A) of superstructure from horizontal.
- LATERAL TILT — to tilt superstructure right or left (See Figure B) from horizontal.

### TECHNICAL DATA

#### Performance Capabilities

This table is designed to support up to a 300 pound patient in correct anatomic position for various procedures throughout the complete range of table movements.




Figure A. TRENDLENBURG.




Figure B. LATERAL TILT.

### Material Specifications

Materials not definitely specified herein are of the best quality and finish as required for the purpose in the industry.

- **Base** is cast aluminum, ASTM UNS-A47120 T5 or equivalent, finished with polyurethane texture paint.
- **Superstructure** side frame and inner cross member are cast aluminum; end frame is cast iron to provide ballast to assist Trendelenburg operation.
- **Tabletop** assembly is cast aluminum, texture painted. Bearing rods are case hardened stainless steel. Tabletop measures 31-1/4x20 inches (794x508 mm).

- **Abductor bars** are 2x3x10 inches (51x76x254 mm) for inner bar and 2x3x40 inches (51x76x1016 mm) for outer bar. Bars have a satin polish, chrome plated, finish to prevent corrosion.

### ACCESSORIES

See opposite page.

### WARRANTY


The American Sterilizer Company warrants that each table is carefully tested, inspected and leaves the factory in proper working condition, free of visible defects. Coverage includes one year on parts (except expendables) and 90 days on labor. AMSCO representatives can provide full details of the warranty program upon request.

### MAINTENANCE


This table is designed for dependable operation if properly used and routine preventive maintenance is observed. If additional maintenance is required, a detailed maintenance manual is available. AMSCO also has a nationwide network of professional factory-trained service technicians capable of performing necessary repairs.


AMSCO also provides a low cost PMA (Preventive Maintenance Agreement) to keep your equipment operating efficiently. AMSCO service technicians thoroughly inspect, clean, adjust and perform all necessary repairs... all at an established low rate, plus the cost of any renewal parts.

### STANDARD ACCESSORIES




### OPTIONAL ACCESSORIES





PLAN VIEW



SIDE VIEW

HEAD-END VIEW

DIMENSIONS ARE INCHES (MILLIMETERS) — DRAWING IS NOT TO SCALE

NOTE:

- 1. Approximate weight— 700 lbs (315 kg).

### IMPORTANT

- UNCRATING INSTRUCTIONS AND EQUIPMENT DRAWING — Complete instructions for uncrating this Table, as well as an equipment drawing, have been furnished. If you cannot find them, write, wire or telephone AMSCO giving the **serial, unit** and **model** numbers of the Table. Replacement copies will be sent to you promptly.
- These instructions should be retained in a conveniently accessible area, for quick reference.
- AMSCO table products are designed to safely support and position a 300-pound patient with body weight appropriately distributed to attain standard surgical positions typical of those shown in AMSCO literature. This same design criteria is applied to AMSCO accessories used with tables of our manufacture.

This print is for guidance when planning space and utility services. Actual installation prints may be obtained from any AMSCO office representative.

## LIMITATION OF LIABILITY AND INDEMNITY

In no event, whether as a result of breach of contract, warranty or tort (including negligence and strict liability) shall American Sterilizer Company or its suppliers be liable for any consequential or incidental damages including, but not limited to loss of profits or revenues, loss of use of the Products or any associated equipment, loss of the Buyer's Products, damage to associated equipment, cost of capital, cost of substitute products, facilities, service or replacement power, downtime cost, caused by such Products, or claims of the users for such damages. Buyer and ultimate user hereby agree to indemnify the American Sterilizer Company and to hold the American Sterilizer Company harmless from any and all liability for such consequential or incidental damages. The responsibility of the American Sterilizer Company for damages due to injuries or death of the death of employees of the Buyer or ultimate user of the Product, caused by the Product, shall be limited to that portion of such damages as might be attributable to the negligence or strict liability or other tortious conduct of the American Sterilizer Company. The Buyer and ultimate user agree to indemnify the American Sterilizer Company and hold the American Sterilizer Company harmless from any further damages, indemnity or contribution, if Buyer transfers title to or leases the Products sold hereunder to any third party. Buyer shall obtain from such third party a provision affording American Sterilizer Company and its suppliers the protection of this article relating to Limitations of Liability and Indemnities.

The American Sterilizer Company's liability for any claim of any kind (including negligence and strict liability) for any loss or damage arising out of, or resulting from this agreement, or from the performance or breach thereof, or from the Products or Services furnished hereunder, shall in no case exceed the price of the specified Product, system, component or service which gives rise to the claim. Except as to title, any such liability shall terminate one year from the date of installation of any Product or upon the expiration of the warranty period applicable to each type of Product covered hereby, whichever time period expires first.

## A WORD FROM AMSCO

This manual contains important information on proper use and maintenance of this table. All operators and department heads are urged to carefully review and become familiar with the warnings, cautions and instructions contained herein. This table is specifically designed for use only as specified in the manual.

A thorough preventive maintenance program is essential to safe and proper table operation. You are encouraged to contact AMSCO concerning our Preventive Maintenance Agreement. Under terms of this agreement, preventive maintenance, adjustments, and replacement of worn parts are done on a scheduled basis to assure table performance at peak capability and to help avoid untimely or costly operation schedule interruptions. AMSCO maintains a nationwide staff of well-equipped, factory-trained technicians to provide this service, as well as expert repairs. Contact your AMSCO representative for details.

AMSCO carries a complete line of accessories for all types of surgery. An AMSCO representative will gladly review these with you.

Thank you for choosing this fine AMSCO product. . . you may be confident of our continued interest in your satisfaction with it.

## SUMMARY OF SAFETY PRECAUTIONS

The following are personnel (WARNINGS) and equipment (CAUTIONS) safety precautions to be observed when operating or servicing this table.

**WARNING** REPAIRS AND ADJUSTMENTS SHOULD BE ATTEMPTED ONLY BY EXPERIENCED PERSONS FULLY ACQUAINTED WITH THIS EQUIPMENT. USE OF INEXPERIENCED, UNQUALIFIED PERSONS TO WORK ON THE EQUIPMENT OR INSTALLATION OF UNAUTHORIZED PARTS COULD CAUSE INJURY OR RESULT IN COSTLY DAMAGE.

**WARNING** MAKE CERTAIN TABLETOP IS PROPERLY SUPPORTED BEFORE PERFORMING MAINTENANCE REQUIRING TOP TO BE MAINTAINED IN RAISED POSITION.

**CAUTION:** When filling table with hydraulic oil, do NOT overfill. Do NOT mix different brands of hydraulic oil.

## SECTION 1. INSTALLATION (SEE FIGURE 1)

1.1. Roll table to desired location.

1.2. Fully depress LOCK/UNLOCK pedal. This will lock table in position by simultaneously transferring table weight from casters to floor locks. The table will remain locked (immobile) until pedal is again fully depressed and released.

1.3. Check floor locks. Be sure each lock is snug against floor. If necessary, adjust floor locks as follows.

**NOTE:** Floor locks are factory-adjusted for a level surface. However, as floor surfaces vary, readjustment may be required. When properly adjusted, locks should engage floor simultaneously and table base should rise evenly. Also, casters need not clear floor (i.e., they should not swing freely with table in locked position).

1.3.1. Place LOCK/UNLOCK pedal in its up (unlocked) position. Using a wrench for rear locks and a drive pin for front locks, screw floor locks counterclockwise as far as possible.

1.3.2. Place LOCK/UNLOCK pedal in its down (locked) position. Screw floor locks clockwise until they are just snug against the floor.

1.3.3. Place LOCK/UNLOCK pedal in its up position. Screw floor locks clockwise an additional 1/2 turn.

1.3.4. Operate LOCK/UNLOCK pedal through several cycles. Operation should be smooth and positive; table should rise evenly as floor locks are actuated. With locks engaged table should not rock or move when normal forces are applied. You may also find that a further 1/4 turn in either direction will "fine tune" the operation.

**NOTE:** Your table is furnished with electrically conductive floor locks. Accumulation of foreign materials on their surfaces, and wear over an extended period, can reduce their conductive properties. Routine testing for conductivity should be performed as needed. A patient grounding receptacle (See Figure 1) is provided. Male connector to ground patient is not furnished by AMSCO.

1.4. Unfold abductor bars and lock in desired position. Turn actuating knobs, located at joint, counterclockwise to unlock bars. After properly positioning bars for desired procedure, turn actuating knobs clockwise to lock.




Figure 1. ORTHOGRAPHIC 2 TABLE.

## SECTION 2. TABLETOP POSITIONING CONTROLS (SEE FIGURE 2)

### 2.1. TRENDELENBURG and LATERAL TILT

The controls are conveniently located at the table head end. Two easy-to-use crank handles provide complete maneuverability of the tabletop. The SIDE TILT control is on the right side of the tabletop. The TRENDELENBURG/REVERSE TRENDELENBURG control is on the left. Both handles are within easy reach and may be operated simultaneously, if desired.

#### 2.1.1. LATERAL TILT operation:

2.1.1.1. Turn crank handle until the desired angulation (0-15 degrees from horizontal) is achieved. The direction that crank is turned governs direction of tabletop movement.

2.1.1.2. Releasing the crank handle automatically stops the tabletop and locks it in position.

#### 2.1.2. TRENDELENBURG/REVERSE TRENDELENBURG operation:

2.1.2.1. Turn crank handle clockwise for TRENDELENBURG positioning (0-15 degrees from horizontal). Turn handle counterclockwise for REVERSE TRENDELENBURG.

2.1.2.2. Releasing the crank handle automatically stops the tabletop and locks it in position.

### 2.2. RAISE/LOWER

A clearly labeled foot pedal at head end of base allows the table to be hydraulically RAISED or LOWERED throughout an 18-inch range smoothly and quietly.

#### 2.2.1 RAISE/LOWER operation:

2.2.1.1. Pump pedal to elevate tabletop. Depress fully to lower.

2.2.1.2 Releasing the pedal automatically stops tabletop and locks it at this height.

### 2.3. Translation

Tabletop can be translated laterally and locked in three positions - center line of the table and four inches on either side of the center line. Two spring-loaded handles (not visible from outside), one on either side of tabletop approximately eight inches from head end, just inside tabletop structure, are provided for easy actuation of translation feature.

**NOTE:** Tabletop translation effort may be excessive if a heavier patient is being supported. To ease effort, place table into TILT (2 turns).

#### 2.3.1. Translation operation:

2.3.1.1. Push either handle against tabletop outer wall to unlock.

2.3.1.2. Translate tabletop to desired position.

2.3.1.3. Releasing handle automatically stops tabletop and locks it in position.

### 2.4. Specific Operations

For the positioning of tabletop and accessories for specific operations see Set-up Chart (P-29354-372).




Figure 2. TABLE POSITIONING CONTROLS.

## SECTION 3. INSTALLATION OF PADS AND ACCESSORIES

The one inch (25 mm) thick pad is backed with a Velcro® (Velcro Corporation) strip which fastens to an opposing strip on the tabletop. Removable accessories are positioned and secured by clamps or sockets which are applied to and slide along the side rails and abductor bars.

### 3.1. Pads

3.1.1. To install, place pad in position and press Velcro strips together.

3.1.2. To remove, "peel" pad away from tabletop.

### 3.2. Accessories (See Table 1)

3.2.1. To install accessories on side rail:

3.2.1.1. Slide clark socket onto either end of side rail.

3.2.1.2. Place accessory support into socket opening and adjust socket for proper angulation of accessory.

3.2.1.3. Tighten accessory support and socket to side rail by turning "T" handle clockwise.

**NOTE:** Angulation changes can be made by slightly loosening socket.

3.2.1.4. Turn "T" handle counterclockwise to remove support and to loosen socket on rail.

3.2.1.5. Remove socket by sliding off rail.

3.2.2. To install accessories on abductor bars:

3.2.2.1. Place clamp handle in horizontal (unlocked) position.

3.2.2.2. Place clamp on abductor bar.

3.2.2.3. Lock clamp on bar by swinging handle down to vertical position.

3.2.2.4. If adjustment is needed in clamp position, proceed as follows:

- Pull clamp handle to intermediate position (approximately 35 degrees from vertical).

- Clamp may now be slid along abductor bar.

**NOTE:** Clamp cannot be removed from abductor bar while handle is in intermediate position.

- Remove clamp by pulling handle to horizontal (unlocked) position.

3.2.3. To install the arm/hand table assembly:

3.2.3.1. Place arm/hand table bracket onto side rail.

3.2.3.2. Swing support leg down from clamp.

3.2.3.3. Loosen wing nut to lower foot in place.


3.2.3.4. Tighten wing nut to lock foot in place.

3.2.3.5. Tighten bracket knobs to lock table to side rail.

3.2.3.6. Lock support leg in position by pushing "T" handle in.

3.2.3.7. Remove arm/hand table in reverse order.

### STANDARD ACCESSORIES



### OPTIONAL ACCESSORIES




TABLE 1



## SECTION 4. PREVENTIVE MAINTENANCE

**WARNING: REPAIRS AND ADJUSTMENTS SHOULD BE ATTEMPTED ONLY BY EXPERIENCED PERSONS FULLY ACQUAINTED WITH THIS EQUIPMENT. USE OF INEXPERIENCED, UNQUALIFIED PERSONS TO WORK ON THE EQUIPMENT OR INSTALLATION OF UNAUTHORIZED PARTS COULD CAUSE INJURY OR RESULT IN COSTLY DAMAGE.**

### 4.1. DAILY

4.1.1. After each use . . .

4.1.1.1. Remove drapes from tabletop. Using a soft cloth, wipe off pad with a solution of warm water and a phenolic germicide detergent.

4.1.1.2. Be sure pad is dry and then install a clean drape, completely covering tabletop.

4.1.2. At end of day . . .

4.1.2.1. Remove drapes and pad from table. Clean pad as follows:

- Using a soft cloth, thoroughly wash pad with a solution of warm water and a phenolic germicide detergent.

- Rinse pad with clear water.

- Allow pad to air-dry.

4.1.2.2. Clean table exterior with a mild detergent solution and disinfectant. Rinse and dry table with a lint-free cloth.

4.1.2.3. Operate each table control. Operation should be smooth and quiet; if not, refer to **GUIDE TO MINOR MAINTENANCE**.

### 4.2. QUARTERLY

**WARNING: MAKE CERTAIN TABLETOP IS PROPERLY SUPPORTED BEFORE PERFORMING MAINTENANCE REQUIRING TOP TO BE MAINTAINED IN RAISED POSITION.**

4.2.1. Service base assembly (see Fig. 3):

4.2.1.1. Raise tabletop to maximum height.

4.2.1.2. Support tabletop with sawhorses. Assure sawhorses are not damaging any table components.

4.2.1.3. Remove socket-head screws and raise base cover.

4.2.1.4. Secure base cover in raised position with blocking or by tying to table frame.




Figure 3. BASE ASSEMBLY.

4.2.1.5. Lubricate the following floor lock items with "MOLY-LUBRIPLATE" MS HD No. 2® (Fiske Brothers Refining Co., Newark, New Jersey) or equivalent

- Floor lock bar linkage interlocks.
- Floor lock posts and reamed holes in base.
- Bearings shafts and other moving parts.

4.2.1.6. Clean casters. Clean floor lock feet and check for conductivity . . . see Note page 1.

4.2.1.7. Inspect base assembly and hydraulic system for any sign of damage and loose or misaligned parts.

4.2.1.8. Lower and secure base cover.

4.2.1.9. Remove sawhorses and lower tabletop.

4.2.2. Inspect tabletop assembly for any sign of damage and loose or misaligned parts.

### 4.3. SEMI-ANNUALLY

**WARNING: MAKE CERTAIN TABLETOP IS PROPERLY SUPPORTED BEFORE PERFORMING MAINTENANCE REQUIRING TOP TO BE MAINTAINED IN RAISED POSITION.**

4.3.1. Service lift assembly (see Fig. 3):

4.3.1.1. Raise tabletop to maximum height.

4.3.1.2. Support tabletop with sawhorses. Assure sawhorses are not damaging any table components.

4.3.1.3. Remove socket-head screws and raise base cover

4.3.1.4. Secure base cover in raised position with blocking or by tying to table frame.

4.3.1.5. Coat the two sides of elevator column on which tabletop support assembly rollers **DO NOT** roll with "MOLY-LUBRIPLATE" MS HD No. 2 or equivalent.

4.3.1.6. Lubricate tabletop support assembly shafts and bearings with "MOLY-LUBRIPLATE" MS HD No. 2 or equivalent (Keep roller sides of elevator column free of lubricant)

4.3.1.7. Lower and secure base cover.

4.3.1.8. Remove sawhorses

4.3.2. Check oil level and lubricate caster assemblies (see Fig. 3):

**WARNING: MAKE CERTAIN TABLETOP IS PROPERLY SUPPORTED BEFORE PERFORMING MAINTENANCE REQUIRING TOP TO BE MAINTAINED IN RAISED POSITION.**

4.3.2.1. Raise tabletop to maximum height.

4.3.2.2. Support tabletop with sawhorses. Assure sawhorses are not damaging any table components.

4.3.2.3. Remove socket-head screws and raise base cover.

4.3.2.4. Secure base cover in raised position with blocking or by tying to table frame.

4.3.2.5. Remove pipe plug from sump cover plate

4.3.2.6. Insert a clean, dry object about pencil-size through opening until bottom is reached.

4.3.2.7. Withdraw object and measure indicated height. Depth should be 1-3/4 inches (44.5 mm)

4.3.2.8. If oil level is incorrect, fill system.

**CAUTION: Do NOT overfill. Do NOT mix different brands of hydraulic oil.**

- Place funnel in sump opening.

- Add proper oil. This table can use Chevron AW32, Mobil DTE 24 or Shell Tellus 32 hydraulic oil. Tables are shipped from factory with a tag (see Fig. 4) indicating what oil was used when constructed.

- If changing brand of oil, call your local AMSCO Representative.

4.3.2.9. Inject "LUBRIPLATE" No. 630 AA or equivalent into fittings on sides of casters.

4.3.2.10. Lower and secure base cover

4.3.2.11. Remove sawhorses.




Figure 4. HYDRAULIC OIL TAG.

4.3.3. If oil was added, operate table through all positions. If operation is "spongy", bleed hydraulic system:

**WARNING: MAKE CERTAIN TABLETOP IS PROPERLY SUPPORTED BEFORE PERFORMING MAINTENANCE REQUIRING TOP TO BE MAINTAINED IN RAISED POSITION.**

- 4.3.3.1. Raise tabletop to maximum height.
- 4.3.3.2. Support tabletop with sawhorses. Assure sawhorses are not damaging any table components.
- 4.3.3.3. Remove socket-head screws and raise base cover.

4.3.3.4. Secure base cover in raised position with blocking or by tying to table frame.

4.3.3.5. Loosen bleed screw (see Fig. 3). Pump RAISE/LOWER pedal. Allow fluid to flow until all trapped air has escaped. Tighten the screw; be sure it is completely recessed in piston rod.

**NOTE:** While bleeding, make sure bleed port does not drift below the top of the intermediate cylinder.

- 4.3.3.6. Lower and secure base cover.
- 4.3.3.7. Remove sawhorses.
- 4.3.3.8. Completely lower and then raise tabletop. If any trapped air remains, table will not operate smoothly and entire procedure must be repeated.

## SECTION 5. GUIDE TO MINOR MAINTENANCE

Please call your local AMSCO Representative if you encounter problems other than those mentioned in this manual. Representative will arrange promptly to have your table placed in proper working order by a factory-trained serviceman

**WARNING: REPAIRS AND ADJUSTMENTS SHOULD BE ATTEMPTED ONLY BY EXPERIENCED PERSONS FULLY ACQUAINTED WITH THIS EQUIPMENT. USE OF INEXPERIENCED, UNQUALIFIED PERSONS TO WORK ON THE EQUIPMENT OR INSTALLATION OF UNAUTHORIZED PARTS COULD CAUSE INJURY OR RESULT IN COSTLY DAMAGE.**

- 5.1. Check oil level and add oil if necessary (see **PREVENTIVE MAINTENANCE**) when:
  - 5.1.1. Tabletop will not elevate to maximum height.
- 5.2. Bleed air from hydraulic system if:
  - 5.2.1. Tabletop raise-lower function is erratic.

## SECTION 6. RECOMMENDED SPARE PARTS LIST

PART NUMBER	DESCRIPTION	QUANTITY
P-24265-091	CUP, Splash	1
P-753675-045	WRENCH (For Drive Crank Adjustment)	1
P-754811-091	LUBRIPLATE, 5 Pound Can	1
P-753975-091	MOLY-LUBRIPLATE (Type MS HD No. 2), 5 Pound Can	1
P-80117-091	SPRING, Lock Pedal	1

## TOPIC 2

# GENERAL MAINTENANCE GUIDE

## INDEX

SECTION	PARAGRAPH	TITLE	GRID
2.1		GENERAL .....	B-6
2.2		TROUBLESHOOTING .....	B-7
	2.2.1	Troubleshooting Chart .....	F-7
2.3		LUBRICATION .....	B-12
2.4		PREVENTIVE MAINTENANCE GUIDE .....	B-14
2.5		FIELD TEST PROCEDURE .....	C-1
	2.5.1	General .....	C-1
	2.5.2	Test Instrumentation Required .....	C-1
	2.5.3	Test .....	C-1

## SECTION 2.1 GENERAL

**WARNING: REPAIRS AND ADJUSTMENTS SHOULD BE ATTEMPTED ONLY BY EXPERIENCED PERSONS FULLY ACQUAINTED WITH THIS EQUIPMENT. USE OF INEXPERIENCED, UNQUALIFIED PERSONS TO WORK ON THE EQUIPMENT OR THE INSTALLATION OF UNAUTHORIZED PARTS COULD CAUSE INJURY OR RESULT IN COSTLY DAMAGE.**

This Topic contains general table maintenance procedures. Should a problem occur in operation of table, refer to Section 2, TROUBLESHOOTING. Section 3, LUBRICATION, contains items which require periodic lubrication and gives sample time intervals for lubrication. Section 4 is a sample PREVENTIVE MAINTENANCE RECORD (supplements preventive maintenance procedures listed in **Operating Instructions**) that is suggested the Maintenance Department keep. Such a record will prove helpful in assuring regular maintenance.

Any maintenance should only be attempted by qualified service technicians. Following repairs, test table using applicable section of FIELD TEST PROCEDURE to verify effectiveness of repairs.

## SECTION 2.2 TROUBLESHOOTING

### 2.2.1. TROUBLESHOOTING CHART

TROUBLE	POSSIBLE CAUSE AND/OR CORRECTION	WHERE TO FIND ITEMS IN MANUAL
1. No table Raise Lower operation	<p>1. RAISE/LOWER pedal assembly defective.</p> <p>a. Does pedal strike floor?</p> <p>1) If yes.</p> <p>(a) Loosen set screw on side of pedal.</p> <p>(b) Turn adjusting screw clockwise until table top lowers when pedal is approximately 1/8-inch from floor.</p> <p>(c) After adjustment, tighten set screw.</p> <p>2) If no - proceed.</p> <p>b. Check pedal assembly</p> <p>1) Is pedal connected to pump lever?</p> <p>(a) If yes - proceed.</p> <p>(b) If no - connect.</p> <p>2) Is pump lever connected to actuator?</p> <p>(a) If yes - proceed.</p> <p>(b) If no - connect.</p>	Topic 3
	<p>2. Hydraulic system malfunction:</p> <p>a. Check oil level. With table top at maximum height, the oil level in sump should be 1-3/4 inches.</p> <p>1) If less oil - fill with recommended oil.</p> <p>2) If more - drain to proper level.</p> <p>3) If oil level correct - proceed.</p> <p>b. Broken oil line or leaking fitting?</p> <p>1) If yes - repair or replace.</p> <p>2) If no - proceed.</p> <p>c. Defective check valve</p> <p>1) Replace</p> <p>2) Still no operation - proceed.</p> <p>d. Defective pump.</p>	Topic 3

2-2

B-7

TROUBLE	POSSIBLE CAUSE AND/OR CORRECTION	WHERE TO FIND ITEMS IN MANUAL
2. Slow Raise Lower Movement	<p>1) Check oil pressure. Connect pressure gauge in pressure and return line behind pump and check valve. Pressure should be 570 psig with top at maximum height. Relief valve set at 800 psig.</p> <p>(a) Oil pressure correct - proceed.</p> <p>(b) Oil pressure incorrect:</p> <p>i. Adjust relief valve.</p> <p>ii. Replace pump.</p> <p>e. Lift cylinder defective.</p> <p>1) Check cylinder caps for leaking.</p> <p>(a) If leaking - replace cylinder</p> <p>(b) No leaks - proceed.</p> <p>2) Check POLY-PAC SEALS for leaking</p> <p>(a) If leaking - replace cylinder.</p> <p>(b) No leaks - proceed.</p> <p>3) Check air bleed port for leaking or clogging.</p> <p>(a) Leaking?</p> <p>i. If yes - replace O-ring.</p> <p>ii. If no - proceed.</p> <p>(b) Is screw overtightened?</p> <p>i. If yes - replace O-ring and properly tighten</p> <p>ii. If no - proceed.</p> <p>4) Replace cylinder</p>	Topic 3
	<p>1. Check air bleed port.</p> <p>a. Leaking?</p> <p>1) If yes - replace O-ring.</p> <p>2) If no - proceed</p> <p>b. Screw too tight?</p> <p>1) If yes - replace O-ring and properly tighten.</p> <p>2) If no - proceed.</p> <p>2. Check lift carriage assembly.</p> <p>a. Check cam and roller assembly.</p> <p>1) Out of adjustment - correct</p>	Topic 3

2-3

B-8

TROUBLE	POSSIBLE CAUSE AND/OR CORRECTION	WHERE TO FIND ITEMS IN MANUAL
3. Tabletop won't retain height.	<ul style="list-style-type: none"> <li>2) OK - proceed.</li> <li>b. Check slide bearing assembly. <ul style="list-style-type: none"> <li>1) Out of adjustment - correct</li> <li>2) OK - contact AMSCO regional office</li> </ul> </li> </ul>	Topic 3
4. Noisy tabletop Raise/Lower operation.	<ul style="list-style-type: none"> <li>1. Faulty check valves? <ul style="list-style-type: none"> <li>a. If yes - replace.</li> <li>b. If no - replace lift cylinder.</li> </ul> </li> <li>1. Check lift cylinder. <ul style="list-style-type: none"> <li>a. Are caps and seals leaking? <ul style="list-style-type: none"> <li>1) If yes - replace cylinder.</li> <li>2) If no - proceed.</li> </ul> </li> <li>b. Ensure cylinder rods are not rubbing caps.</li> </ul> </li> <li>2. Check air bleed port. <ul style="list-style-type: none"> <li>a. Leaking? <ul style="list-style-type: none"> <li>1) If yes - replace O-ring.</li> <li>2) If no - proceed.</li> </ul> </li> <li>b. Screw too tight? <ul style="list-style-type: none"> <li>1) If yes - replace O-ring and properly tighten screw</li> <li>2) If no - proceed.</li> </ul> </li> </ul> </li> <li>3. Check lift carriage. <ul style="list-style-type: none"> <li>a. Check cam and roller assembly. <ul style="list-style-type: none"> <li>1) Out of adjustment - correct</li> <li>2) OK - proceed.</li> </ul> </li> <li>b. Check slide bearing assembly. <ul style="list-style-type: none"> <li>1) Out of adjustment - correct.</li> <li>2) OK - call AMSCO regional office</li> </ul> </li> </ul> </li> <li>4. Check pump oil pressure. Connect pressure gauge in pressure and return line behind pump and check valve. Pressure should be 570 psig with top at maximum height. Relief valve set at 800 psig. <ul style="list-style-type: none"> <li>a. If incorrect pressure. <ul style="list-style-type: none"> <li>1) Adjust relief valve.</li> <li>2) Check pump strainer for clogging.</li> </ul> </li> </ul> </li> </ul>	Topic 3 Topic 3 Topic 3 Topic 3 Topic 3 Topic 3

TROUBLE	POSSIBLE CAUSE AND/OR CORRECTION	WHERE TO FIND ITEMS IN MANUAL
5. Sudden drop of tabletop.	<ul style="list-style-type: none"> <li>3) Check pump suction-valve spring.</li> <li>4) Replace pump. <ul style="list-style-type: none"> <li>b. If correct oil pressure - proceed.</li> </ul> </li> <li>5. Ensure proper hydraulic oil was used.</li> </ul>	Topic 3 Topic 3
6. Floor locks won't lock.	<ul style="list-style-type: none"> <li>1. Locate hydraulic leak and repair. <ul style="list-style-type: none"> <li>1. Adjust floor locks assembly. <ul style="list-style-type: none"> <li>a. Is latch out of adjustment? <ul style="list-style-type: none"> <li>1) If yes - adjust.</li> <li>2) If no - proceed.</li> </ul> </li> </ul> </li> <li>2. Check spring. <ul style="list-style-type: none"> <li>a. Is spring connected? <ul style="list-style-type: none"> <li>1) If yes - proceed.</li> <li>2) If no - connect.</li> </ul> </li> <li>b. Is spring stretched or broken? <ul style="list-style-type: none"> <li>1) If yes - replace.</li> <li>2) If no - proceed</li> </ul> </li> </ul> </li> <li>3. Check for pedal linkage binding. <ul style="list-style-type: none"> <li>a. Is linkage binding? <ul style="list-style-type: none"> <li>1) If yes - correct</li> <li>2) If no - continue</li> </ul> </li> </ul> </li> <li>4. Adjust clearance between pedal and floor.</li> </ul> </li></ul>	Topic 3 Topic 3
7. Floor locks won't unlock.	<ul style="list-style-type: none"> <li>1. Grease.</li> <li>2. Check floor lock spring.</li> <li>3. Check bearings.</li> <li>4. Adjust clearance between pedal and floor.</li> </ul>	Topic 3 Topic 3 Topic 3 Topic 3
8. Pedal doesn't return.	<ul style="list-style-type: none"> <li>1. Check spring</li> <li>2. Check for pedal linkage binding.</li> </ul>	Topic 3 Topic 3
9. Faulty, erratic, Trendelenburg Reverse Trendelenburg operation.	<ul style="list-style-type: none"> <li>1. Check linkage assembly for binding.</li> <li>2. Grease gears.</li> <li>3. Check gear assembly for excessive backlash.</li> </ul>	Topic 4 Topic 4 Topic 4

## SECTION 2.3 LUBRICATION

Table 1 lists gears, worms, gear sectors, and other items which require periodic lubrication. The table provides a reference to the Topic where the part may be located, and indicates the time interval at which the part must be lubricated. Refer to the note indicated in the table for applicable lubricant.

TABLE 1. LUBRICATION.

Item	Part Number	Interval (Months)	Figure	Note
<b>TOPIC 3</b>				
Table Support Assembly	136804-033	6	2	5
Bearing, Slide	77528-091	6	2	1
Bearing, Guiderol	46572-091	6	4	1
Shaft, Bearing	77527-091	6	4	1
Bearing, Sleeve	82633-001		6	
Wheel, 3-1/4 Dia	129354-309		6	
Bar, Weldment, Front, LH	93898-176	3	6	7
Bar, Weldment, Front, RH	93898-177	3	6	7
Pin, Clevis, Top	129354-304		6	
Pin, Clevis, Bottom	129354-305		6	
Bearing, Cam Follower	45272-091		6	
Screw, Shoulder	77722-042		6	
Bar, Weldment, Rear, LH	93898-174	3	6	7
Bar, Weldment, Rear, RH	93898-175	3	6	7
Bearing, Floor Lock	77521-091		7	
Shaft, Floor Lock	77524-045	3	7	1
Bearing	78203-091		7	
Pin, Grooved	79878-001	3	7	1
Caster, Swivel	93898-149	6	7	2
<b>TOPIC 4</b>				
Pin, Pivot	93898-072		2	
Washer, Thrust	16340-091		2	
Bearing, Single Row	48270-091	6	2	1
Bearing, Needle Thrust	129354-133	6	2	8
Race, Thrust Bearing	129354-134	6	2	1
Bearing, Single Row	48269-091	6	2	1
Bearing, Single Row	80112-091	6	2	1
Joint, Universal	93898-015	6	2	4
Screw, Power	93898-004	6	2	1
Bearing, Sleeve	75870-091		2	
Tilt Drive Assembly	136804-036		2	
Bearing, Sleeve	129186-174	6	3	4
Joint, Universal	93898-013	6	3	4
Gear Box Assembly	136804-035		3	

TROUBLE	POSSIBLE CAUSE AND/OR CORRECTION	WHERE TO FIND ITEMS IN MANUAL
10 Excessive looseness in Trendelenburg operation.	1. Adjust worm and sector gear assemblies.	Topic 4
	2. Adjust lift carriage assembly.	Topic 3
	3. Check saddle-to-support clearance.	Topic 4
11. Faulty, erratic, tilt operation	1. Check linkage assembly for binding.	Topic 4
	2. Grease gears.	Topic 4
	3. Check gear assembly for excessive backlash.	Topic 4
12. Excessive looseness in tilt operation	1. Adjust side tilt screw assembly.	Topic 4
	2. Adjust lift carriage assembly.	Topic 3
13 Faulty, erratic, translation operation	1. Lubricate.	Topic 5
	2. Check for worn bearings	Topic 5
14 Abductor bars binding in joints.	1. Lubricate.	Topic 5
15. Casters don't swivel freely	1. Check bearings.	Topic 3
	2. Lubricate.	Topic 3

Item	Part Number	Interval (Months)	Figure	Note
<b>TOPIC 5</b>				
Channel, Locking	136804-087		1	
Bearing	129354-077		1	
Pin, Shoulder	129354-075		1	
Bearing, Rear	129354-033	6	1	8
Bearing, Front	129354-246	6	1	8
Shaft, Rear	93898-016	3	1	8
Shaft, Front	93898-152	3	1	8
Screw, Shoulder	129354-350		1	
Channel, Sliding	136804-086		1	

**NOTES:**

- Lubricate with Moly-Lubriplate type MS HD No. 2 (Order specification P-753975-091, 5 pound can).
- Lubricate with Lubriplate type 630 AA (order specification RM 6400-140, 5 pound can).
- Lubricate with Shell Lithium base type EP-2
- Apply a light coat of a good grade of medium-weight lubricating oil (i.e. 3-in-1 etc.) to the inner diameter of sleeve bearings, the faces of thrust bearings, shafts, and other moving parts when replacing a part.
- Coat the sides of the square column on which the rollers do not roll with Moly-Lubriplate. Do not lubricate sides of the column on which the rollers roll.
- Lubricate the reamed holes where rods 41530 come up through base casting with Moly-Lubriplate.
- Lubricate bars 93898-174 and 93898-175 where they interlock with rods 41530 Moly-Lubriplate.
- Lubricate bearings 129354-033 and 129354-246 with Alvania EP-2.

**SECTION 2.4 PREVENTIVE MAINTENANCE GUIDE**

EQUIPMENT: **Orthographic 2 Table**

This form is to be used as a preventive maintenance record and a guide to performing maintenance.

(Circle "X" In **Monthly** Column When Service Is Performed)

SERVICE PERFORMED	1	2	3	4	5	6
<b>1.0 PREPARATION FOR PREVENTIVE MAINTENANCE</b>						
1.1 Discuss equipment operation with department personnel.	X	X	X	X	X	X
1.2 Remove pads. Examine pad covers and velcro tape on both pads and table.	X	X	X	X	X	X
1.3 Examine clamps and other side rail hardware.	X	X	X	X	X	X
1.4 Tighten side rails.	X	X	X	X	X	X
<b>2.0 HYDRAULIC OIL</b>						
2.1 Check hydraulic oil level, add if necessary.	X		X		X	
<b>3.0 HYDRAULIC SYSTEM LEAK CHECK</b>						
3.1 Inspect floor directly beneath the table and all tubing, fittings and components of hydraulic system for oil leaks.	X	X	X	X	X	X
3.2 Inspect for proper operation of table Raise/Lower.	X	X	X	X	X	X
<b>4.0 CASTERS</b>						
4.1 Clean and inspect casters		X			X	
4.2 Lubricate casters	X		X		X	
<b>5.0 LUBRICATION</b>						
5.1 Examine all lubricated parts	X			X		
<b>6.0 FLOOR LOCK OPERATION</b>						
6.1 Check floor lock mechanism for proper operation.	X	X	X	X	X	X
<b>7.0 TABLE TOP</b>						
7.1 Check for proper operation and smooth translation		X		X		X
7.2 Check for table drift or sloppiness, adjust.	X	X	X	X	X	X
<b>8.0 LATERAL TILT OPERATION</b>						
8.1 Check tilt operation of table top.	X	X	X	X	X	X

SERVICE PERFORMED:	1	2	3	4	5	6
<b>9.0 TRENDLENBURG AND REVERSE TRENDLENBURG OPERATION</b>						
9.1 Check Trendelenburg then reverse Trendelenburg operation of table top.	X	X	X	X	X	X
<b>10.0 RAISE AND LOWER OPERATION</b>						
10.1 Check raise and lower operation of table top.	X	X	X	X	X	X
<b>11.0 ABDUCTOR BAR OPERATION</b>						
11.1 Check movement of each arm for proper locking, smoothness of operation and proper positioning.	X	X	X	X	X	X
<b>12.0 FINAL TEST</b>						
12.1 Secure all covers.	X	X	X	X	X	X
12.2 Install all pads.	X	X	X	X	X	X
12.3 Police work area to ensure removal of all materials used during inspection.	X	X	X	X	X	X

## SECTION 2.5 FIELD TEST PROCEDURE

### 2.5.1. GENERAL

Every table must be tested and inspected according to this procedure whenever a part is adjusted, repaired or replaced. Items of non-compliance must be corrected and retested. Keep a record of all readings, measurements, discrepancies, corrections, retests, and reinspections. Each test must meet the standards of material, workmanship, and performance set forth in this procedure. Refer to appropriate Topic should mechanical problems arise or adjustments be required.

### 2.5.2. TEST INSTRUMENTATION REQUIRED

- Milliohmmeter - Fluke #8800 A multimeter or equivalent.
- 50 lb (-5%, -0) weight and hanger.
- Spring Scale - 60 lb minimum range.
- 48-inch Rule.
- Patient Transfer Board - used as a fixture.

- 300 lb Patient Load (Distributed) or helper.

### 2.5.3. TEST

**2.5.3.1. Mobility** - Move table across floor in at least two directions to ensure swivel casters operate satisfactorily, resulting in smooth and easy maneuvering of table.

**2.5.3.2 Floor Locks** - Position table on level floor and depress pedal to engage floor lock. The locking action should be smooth and positive. Ensure that all four feet engage floor to prevent table from rocking. Depress the pedal again to release the floor locks. Repeat locking/unlocking to make sure operation is consistent.

- With floor locks engaged, extend one abductor bar and lock it in line with table length. Apply a 50 lb horizontal pull at the end of the abductor bar, perpendicular to bar. Table should remain immobile; if not, adjust floor locks.

- Check floor clearance under each foot in unlocked position. It must be  $5/16 \pm 1/16$  inch.

**2.5.3.3. D.C. Resistance** - Check D.C. resistance between end of one abductor bar (not the plastic cap) and grounding jack receptacle. Resistance must not exceed 0.1 ohm. Repeat test for base cover, Raise/Lower pedal, floor lock pedal, and both table top side rails to grounding jack receptacle.

**2.5.3.4. Raise/Lower** - Check raise/lower operation by fully raising and lowering table several times. Operation must be smooth and quiet (a slight bump occurring at staging point of cylinder is permissible).

- With tabletop levelled, fully lower table and measure top height (adjacent to the column) from floor. It must not exceed 29 inches.

- Fully raise table and measure height (adjacent to the column) from floor. It must not be less than 45 inches.

- Time required for table (without a load on the top) to move from maximum to minimum height must not exceed 18 seconds. If excessive time, adjust flow valve.

**2.5.3.5. Top Translation** - Fully translate table top to ensure no binding or high spots. Allow top to lock at each of three locking positions and ensure that lock actuation is positive and without binding. Repeat using the lock release handle on one side of the table top to make sure operation is consistent. Repeat using opposite side release handle.

**2.5.3.6. Abductor Bar and Lock** - Rotate each joint on both abductor bars through full range of travel (ref. 180° min.). Ensure no binding and smooth rotation.

- Check for positive locking/unlocking function of each joint at six different locations through range of travel. Check to ensure no lateral (horizontal) freplay in joints.

- Check that each locking knob locks joint tightly in a maximum of two rotations from the fully unlocked position.

- Check that both locking knob setscrews are in place and adjusted to prevent knob from backing off joint locking stem.

**2.5.3.7. Rigidity Tests** - Position leveled table top at maximum height, lower 4 inches and conduct the following test. (Floor locks engaged.)

- **Lateral** - Hang fifty lbs from one side rail approximately in line with side tilt drive screw. Measure total movement at the location shown in Figure 2 when the fifty lb load is moved to opposite

side. Movement must not exceed approximately 1/8 inch. (Movement is total of drive mechanism backlash, column deflection, floor lock pad compression, and table top backlash and deflection.)

- **Longitudinal** - Hang fifty lbs from the sacral rest slot in the table top. Measure the movement at the head-end of the table top (see Figure 2) when the 50 lb weight is moved to head end pin holes. This movement must not exceed approximately 3/16 inch.

**2.5.3.8. Trendelenburg and Side Tilt** - Manipulate tabletop through articulations. Operation should be smooth and without binding. Repeat to ensure operation is consistent.

**2.5.3.9. Raise/Lower Operation** - Check again. Raise table to maximum height, lower approximately 4 inches and allow to stand for 1 hour. It must not settle more than 1/16-inch in that time.

**2.5.3.10. Patient Load Tests** (Distribute patient load as shown in Figure 1) -

- Operate the floor lock mechanism to ensure satisfactory function under patient load

- Check tabletop translation and locking functions to ensure satisfactory operation under a patient load.

- **Raise/Lower** - Check raise/lower operation by fully raising and lowering table. Operation must be smooth and quiet (a slight bump occurring at staging point of cylinder is permissible)

- Remove patient load.

**2.5.3.11. Accessories' Interface** - Check following tabletop accessory attachment features to ensure that accessories will interface without binding.

- slot (sacral rest fixture).
- pin holes - perineal end of patient transfer board
- pin holes - head end (headrest fixture)

### 2.5.3.12. General Observations -

- Check for excessive backlash in control handles.
- Check entire table for proper finish of all exposed parts (general appearance for scratches, dents, loose parts and good workmanship).
- Check for sharp edges and burrs on side rails and other exposed parts.
- Check table and surrounding floor for oil leaks. Make repairs, if necessary.

**2.5.3.13. Performance Requirements -**


Should there be any doubt regarding performance of table, use the performance limits as guidelines to verify compliance.

**Table Maneuvering Efforts** (with 300 lb patient simulator)

Floor lock actuation effort	75 lb maximum
Raise/lower effort	150 lb maximum at maximum height 105 lb maximum at less than maximum height
Initiate motion on casters	60 lb maximum
Crank handle efforts with tabletop positioned at center	13 lb maximum with spring scale on the handle 72 in lbs. maximum with torque wrench
Tabletop translation effort	45 lb maximum
Crank handle backlash (Trend.)	12° maximum
Crank handle backlash (tilt)	5° maximum

**Abductor Bars**


Vertical freeplay (no deflection) measured at the end of the bar with joints locked	3/4 inches maximum
Horizontal force at the end of the bar to cause rotation	2 lb maximum



**NOTES**

- 1 Each hook is located through C.G. of weight
- 2 Weights to be secured in position shown, no shifting permitted

**Figure 1.**



**Figure 2.**



THIS PAGE  
INTENTIONALLY LEFT  
BLANK

**TOPIC 3**  
**TABLE BASE**  
**INDEX**

SECTION	PARAGRAPH	TITLE	PAGE
3.1		GENERAL .....	C-7
3.2		HYDRAULIC SYSTEM .....	C-7
	3.2.1	General Description .....	C-7
	3.2.2	System Testing .....	C-7
	3.2.3	Properly Supporting Tabletop .....	C-7
	3.2.4	Checking Oil Level .....	C-7
	3.2.5	Adding Oil .....	C-7
	3.2.6	Changing Brand Of Oil .....	C-8
	3.2.7	System Bleeding .....	C-8
	3.2.8	Repair/Replacement Of Dirty Or Plugged Strainer .....	C-8
	3.2.9	Repairing Hydraulic Leaks .....	C-8
	3.2.10	Replacing Faulty Lift Cylinder .....	C-8
	3.2.11	RAISE/LOWER Pedal Adjustment .....	C-8
	3.2.12	RAISE/LOWER Pedal Replacement .....	C-9
3.3		COMPONENT REPAIR AND REPLACEMENT .....	C-9
	3.3.1	General .....	C-9
	3.3.2	Properly Supporting Tabletop .....	C-9
	3.3.3	Removing Superstructure From Base .....	C-9
	3.3.4	Lift Carriage Cam And Roller Adjustment .....	C-10
	3.3.5	Lift Carriage Slide Bearing Adjustment .....	C-10
	3.3.6	Adjusting Floor Locks .....	C-11
	3.3.7	Binding Of LOCK/UNLOCK Pedal Linkage .....	C-11
	3.3.8	Insufficient Clearance Between LOCK/UNLOCK Pedal And Floor .....	C-11 C-12
	3.3.9	LOCK/UNLOCK Pedal Sticks In UP Position .....	C-11
	3.3.10	LOCK/UNLOCK Pedal Does Not Return To Maximum UP Position .....	C-12
	3.3.11	Removal Of Pin And Foot Assembly .....	C-12
	3.3.12	Removal Of Caster Assemblies .....	C-13
3.4		EXPLODED VIEWS AND PARTS LISTS .....	D-1 thru D-14

## SECTION 3.1 GENERAL

This Topic contains all table base data. Table base consists of hydraulic assembly, pedestal assembly and mobility assembly. Base can withstand patient load of 300 pounds under both reversed and normal positioning without exhibiting permanent set or failure. Base is constructed of cast aluminum and covered with polyurethane texture paints.

Any maintenance should only be attempted by qualified service technicians. Following repairs, test table using applicable section of FIELD TEST PROCEDURE to verify effectiveness of repairs.

## SECTION 3.2 HYDRAULIC SYSTEM

### 3.2.1. GENERAL DESCRIPTION (See Figure 1)

Actuating RAISE/LOWER pedal to within 1/8-inch of floor forces oil from pump cavity to lift cylinder. Releasing pedal, oil is drawn from sump through strainer into pump cavity. Continued pump operation will elevate table.

With table in any position, depressing RAISE/LOWER pedal to floor will cause piston to unseat ball check and hold it open as long as pedal is held to floor. This allows oil to gravitate from lift cylinder to sump.

**WARNING: REPAIRS AND ADJUSTMENTS SHOULD BE ATTEMPTED ONLY BY EXPERIENCED PERSONS FULLY ACQUAINTED WITH THIS EQUIPMENT. USE OF INEXPERIENCED, UNQUALIFIED PERSONS TO WORK ON THE EQUIPMENT OR THE INSTALLATION OF UNAUTHORIZED PARTS COULD CAUSE INJURY OR RESULT IN COSTLY DAMAGE.**

### 3.2.2. SYSTEM TESTING (using 300 pound simulated weight)

Testing is required when any hydraulic line is broken or component has been replaced. Place table at maximum height and leave in this position for at least two hours and preferably eight hours (or overnight). Measure how much top has dropped during this time. Table must not drop more than 1/16-inch in one hour. A greater drop indicates hydraulic problem, probably leaking fitting, cylinder, or defective check valve.

### 3.2.3. PROPERLY SUPPORTING TABLETOP

**WARNING MAKE CERTAIN TABLETOP IS PROPERLY SUPPORTED BEFORE PERFORMING MAINTENANCE REQUIRING TOP TO BE MAINTAINED IN RAISED POSITION.**

3.2.3.1. Raise tabletop to maximum height.

3.2.3.2. Remove screws securing base cover to casting.

3.2.3.3. Lift and support base cover and shrouds by blocking from base or tying to frame.

3.2.3.4. Support tabletop (See Figure 2) by inserting a spacer (ten-inch wrench or equivalent) between top of steel post and underside of elevator carriage end plates (roller side).

**NOTE:** Make certain spacer is **NOT** bending. If it is, remove and replace with a stronger item.

3.2.3.5. Depress RAISE/LOWER pedal and allow elevator carriage to settle on top of spacer. Release and again depress pedal to be sure tabletop is securely supported (cannot lower).

### 3.2.4. CHECKING OIL LEVEL

3.2.4.1. Raise and support tabletop (See Paragraph 3.2.3.).

3.2.4.2. Remove pipe plug from sump cover plate.

3.2.4.3. Insert clean, dry object about pencil-size through opening until bottom is reached.

3.2.4.4. Withdraw object and measure indicated height. Depth should be 1-3/4 inches (44.5 mm)

3.2.4.5. If oil level incorrect, fill or bleed (See Paragraphs 3.2.5. and 3.2.7.).

### 3.2.5. ADDING OIL

**CAUTION: Do NOT overfill. Do NOT mix different brands of hydraulic oil.**

3.2.5.1. Raise and support tabletop (See Paragraph 3.2.3.).

3.2.5.2. Remove pipe plug from sump cover plate.

3.2.5.3. Place funnel in sump opening.

3.2.5.4. Add proper oil. This table can use Chevron AW32, Mobil DTE 24 or Shell Tellus 32 hydraulic oil. Tables are shipped from factory with a tag (See Figure 3) indicating what oil was used when constructed.

### 3.2.6. CHANGING BRAND OF HYDRAULIC OIL

3.2.6.1. Raise and support tabletop (See Paragraph 3.2.3.).

3.2.6.2. Remove sump cover plate and gasket.

3.2.6.3. Drain and discard all oil from table sump, pump, tubing and lift cylinder.

3.2.6.4. Wipe out sump. Refill system using an approved oil.

3.2.6.5. Operate table through all positions at least once

3.2.6.6. Drain sump, pump, tubing and lift cylinders. Discard oil

3.2.6.7. Refill system again and operate table through all positions

3.2.6.8. Replace gasket and sump cover plate.

3.2.6.9. Mark tag (See Figure 3) with type of oil now being used. Reattach tag to table base.

### 3.2.7. SYSTEM BLEEDING

3.2.7.1. Raise and support tabletop (See Paragraph 3.2.3.).

3.2.7.2. Back out buttonhead screw (bleed port on lift cylinder) and pump the RAISE/LOWER pedal. When oil starts to flow through setscrew, the majority of air is out of system. Tighten screw.

**NOTE:** While bleeding, make sure bleeding port does not drift below top of intermediate cylinder.

### 3.2.8. REPAIR/REPLACEMENT OF DIRTY OR PLUGGED STRAINER

3.2.8.1. Raise and support tabletop (See Paragraph 3.2.3.).

3.2.8.2. Remove sump cover and gasket.

3.2.8.3. Reach inside sump and disconnect hydraulic line from fitting.

3.2.8.4. Remove pump assembly from sump.

3.2.8.5. Unscrew valve assembly from nipple and backflush to clean strainer.

3.2.8.6. If cleaning fails, replace valve assembly.

3.2.8.7. After cleaning strainer or replacing valve assembly, assemble in reverse order. Replace gasket on reassembly.

### 3.2.9. REPAIRING HYDRAULIC LEAKS

3.2.9.1. Raise and support tabletop (See Paragraph 3.2.3.).

3.2.9.2. Check and tighten all fittings.

3.2.9.3. Check lift cylinder seals. Replace cylinder if seals are leaking.

3.2.9.4. Check lift cylinder bleeder port. Replace O-ring and properly tighten screw.

3.2.9.5. Remove pump assembly and inspect ball check valves for scratches. Replace if necessary.

**NOTE:** Expect small leakage past pump piston rod as pump pedal is released and returns to unactuated position.

### 3.2.10. REPLACING FAULTY LIFT CYLINDER

**NOTE:** Check all other hydraulic system components for leaks before assuming faulty lift cylinder.

3.2.10.1. Raise and support tabletop (See Paragraph 3.2.3.).

3.2.10.2. Depress RAISE/LOWER pedal to floor and force cylinder pistons down to vacate oil from cylinder. This will prevent an oil spill when line is disconnected.

3.2.10.3. Disconnect line to fitting at base of lift cylinder and line to fitting on cylinder collector sleeve.

3.2.10.4. Remove screws securing lift cylinder to base and remove cylinder.

3.2.10.5. Replace with new cylinder and reassemble.

3.2.10.6. Bleed system (see Paragraph 3.2.7.).

### 3.2.11. RAISE/LOWER PEDAL ADJUSTMENT

Pump RAISE/LOWER pedal to raise table to maximum height. Depress pedal to approximately 1/8-inch from floor and note if table descends. If not, adjust pedal as follows:

**WARNING: MAKE CERTAIN TABLETOP IS PROPERLY SUPPORTED BEFORE PERFORMING MAINTENANCE REQUIRING TOP TO BE MAINTAINED IN RAISED POSITION.**

- 3.2.11.1. Raise tabletop to maximum height.
- 3.2.11.2. Support tabletop using sawhorses. Assure sawhorses are not damaging any table components.
- 3.2.11.3. Remove screws securing base cover to casting.
- 3.2.11.4. Lift and support base cover and shrouds by blocking from base or tying to frame.
- 3.2.11.5. Loosen setscrew on side of pedal to release adjusting screw.
- 3.2.11.6. Remove sawhorses.
- 3.2.11.7. Turn adjusting screw clockwise until top descends when pedal is depressed to approximately 1/8-inch from floor. Again support tabletop using sawhorses

## SECTION 3.3 COMPONENT REPAIR AND REPLACEMENT

### 3.3.1. GENERAL

This section contains instructions for disassembly, repair, and replacement of selected base components. See section containing Exploded Views And Assemblies as an aid in understanding and completing instructions.

**WARNING: REPAIRS AND ADJUSTMENTS SHOULD BE ATTEMPTED ONLY BY EXPERIENCED PERSONS FULLY ACQUAINTED WITH THIS EQUIPMENT. USE OF INEXPERIENCED, UNQUALIFIED PERSONS TO WORK ON THE EQUIPMENT OR THE INSTALLATION OF UNAUTHORIZED PARTS COULD CAUSE INJURY OR RESULT IN COSTLY DAMAGE.**

### 3.3.2. PROPERLY SUPPORTING TABLETOP

**WARNING: MAKE CERTAIN TABLETOP IS PROPERLY SUPPORTED BEFORE PERFORMING MAINTENANCE REQUIRING TOP TO BE MAINTAINED IN RAISED POSITION.**

- 3.3.2.1. Raise tabletop to maximum height.
- 3.3.2.2. Remove screws securing base cover to casting.

3.2.11.8. After completion of adjustment, retighten setscrew.

3.2.11.9. Replace cover and shroud, remove sawhorses and lower table.

### 3.2.12. RAISE/LOWER PEDAL REPLACEMENT

3.2.12.1. Raise and support tabletop (See Paragraph 3.2.3.).

3.2.12.2. Remove base plate.

**CAUTION: When moving pump and sump assembly, be careful not to "kink" copper tubing.**

3.2.12.3. Loosen pump and sump assembly and shift slightly to provide access to pedal.

3.2.12.4. Remove and replace pedal

3.2.12.5. Reassemble pedal assembly

3.3.2.3. Lift and support base cover and shrouds by blocking from base or tying to frame

3.3.2.4. Support tabletop (See Figure 2) by inserting a spacer (ten-inch wrench or equivalent) between top of steel post and underside of elevator carriage end plates (roller side).

**NOTE:** Make certain spacer is **NOT** bending. If it is, remove and replace with a stronger item

3.3.2.5. Depress RAISE/LOWER pedal and allow elevator carriage to settle on top of spacer. Release and again depress pedal to be sure tabletop is securely supported (cannot lower)

### 3.3.3. REMOVING SUPERSTRUCTURE FROM BASE

**WARNING: MAKE CERTAIN TABLETOP IS PROPERLY SUPPORTED BEFORE PERFORMING MAINTENANCE REQUIRING TOP TO BE MAINTAINED IN RAISED POSITION.**

3.3.3.1. Engage floor locks.

3.3.3.2. Raise tabletop to maximum height.

3.3.3.3. Support tabletop with sawhorses or blocks. Assure sawhorses or blocks are not damaging any table components. Superstructure is counterweight biased at head end.

3.3.3.4. Remove screws securing telescoping shrouds and lower them to base.

3.3.3.5. Remove four nuts and washers that secure superstructure to elevator carriage

3.3.3.6. Depress RAISE/LOWER pedal and allow elevator carriage to settle and to clear bolts from mounting holes.

3.3.3.7. Depress RAISE/LOWER pedal and force lift cylinder to minimum height.

3.3.3.8. Release floor locks and roll base from under superstructure.

### 3.3.4 LIFT CARRIAGE CAM AND ROLLER ADJUSTMENT

Elevator guide assembly on table support assembly has eight bearings that regulate amount of tabletop movement. Measurement of top movement can be made at head or foot-end of table. If adjustments are required to reduce amount of play or movement, proceed as follows:

**NOTE:** To simplify adjustment, always adjust eccentrics on one side of square pedestal only; however, check four eccentrics on opposite side to ensure all are set in same relative position and turned in same amount. Eccentrics have a locating mark on low side. When adjusting, ensure mark is in same relative position for all eccentrics

3.3.4.1. Raise and support tabletop (See Paragraph 3.3.2.).

3.3.4.2. Back-off hex nuts that secure setscrews.

3.3.4.3. Loosen setscrews as required to allow bearing slides to hang free. Slides will remain free until completion of procedure.

3.3.4.4. Loosen four setscrews that lock eccentrics.

3.3.4.5. Back-off four nuts that seat against eccentric faces on adjusting side.

3.3.4.6. Set bearing pressure against column by rotating eccentrics, two in line at same time, for required adjustment. This adjustment should be minimal. Adjust top two eccentrics first, then repeat for bottom two. Locating mark should be in same relative position on all four eccentrics.

3.3.4.7. Check bearing adjustment by sliding support assembly through entire column length. Make certain all eight bearings have contact, through entire length, with column. Readjust if necessary.

**CAUTION: Eccentric locking nuts should be tightened only with slight wrench pressure. Excessive tightening will fracture eccentric at flange.**

3.3.4.8. After adjustment is complete, tighten setscrews and lock eccentrics with nuts. Make certain eccentric setting is not disturbed.

3.3.4.9. Check slide bearing adjustment (See Paragraph 3.3.5.).

### 3.3.5. LIFT CARRIAGE SLIDE BEARING ADJUSTMENT

The elevator guide assembly on table support assembly has two bronze slide bearings that regulate tabletop movement from side to side. If adjustments are required to reduce amount of play or movement, proceed as follows:

3.3.5.1. Support tabletop so that slide bearings are approximately half-way up column.

3.3.5.2. Centralize carriage assembly laterally about column by adjusting eight setscrews on sides of carriage. (**Note:** Adjust setscrews on both sides equally when bringing bearing faces against column to ensure parallel adjustment.)

3.3.5.3. Tighten setscrews against slide bearings to form a seat in bearing surface, then back-off screws slightly.

3.3.5.4. Adjust setscrews so that slide bearings are snug against square column, eliminating all possible side movements of tabletop but still allowing free movement of carriage along full length of column.

3.3.5.5. Lock setscrews in place with nuts.

3.3.5.6. To test adjustment, try to rock tabletop from side to side. If necessary, readjust.

### 3.3.6. ADJUSTING FLOOR LOCKS

**NOTE:** Improper adjustment is main reason for difficult floor lock operation. Force required to operate floor locks should not change appreciably, whether or not the table is occupied. When floor locks are properly adjusted, casters **need not be raised off floor** (i.e., they **should not swing** freely with table in locked position). Each floor lock should be *equally* engaged and, therefore adjusted individually. Some other reasons for difficult floor lock operation are: binding of pedal linkage, insufficient clearance between pedal and floor, pedal sticking in up (unlocked) position, or pedal failing to return to maximum up position.

**Be sure to read and understand** entire procedure before attempting to make any adjustments.

3.3.6.1. Place LOCK UNLOCK pedal in up (unlocked) position. Adjust four feet clockwise as far as possible. (**Note:** Feet should not turn freely by hand; adjustment requires a wrench for head-end locks and a drive pin for leg-end locks. Feet that turn freely will not hold adjustment, replace.)

3.3.6.2. Place LOCK UNLOCK pedal in down (locked) position. Adjust four feet counterclockwise until snug (slight resistance noticed) on floor.

3.3.6.3. Place LOCK UNLOCK pedal in up position. Adjust four feet counterclockwise 1/2-turn.

3.3.6.4. Operate pedal through several cycles. Operation should be smooth and positive; base should rise evenly (not one side before the other) as floor locks are actuated. With locks engaged, table should not rock or move when normal forces are applied. An additional 1/4-turn of feet in either direction will "fine tune" operation.

### 3.3.7. BINDING OF LOCK/UNLOCK PEDAL LINKAGE

If binding is evident during pedal operation, place LOCK/UNLOCK pedal in unlocked position and proceed as follows:

3.3.7.1. Raise and support tabletop (See Paragraph 3.3.2.).

3.3.7.2. Press down on top of floor locks rods and release, allowing lever arms to spring back. If action is not free, proceed as follows:

3.3.7.2.1. Check reamed floor lock holes in base casting for proper lubrication.

3.3.7.2.2. Check pivot holes in lever arms. Excessive plating in hole could result in binding on shoulder screws.

3.3.7.2.3. Check shoulder screws. They should not be so tight that they bind locking feet.

3.3.7.2.4. Check for interference between any two parts which would require an increased effort to operate (e.g., ends of lever arms riding on base casting during operation).

3.3.7.2.5. Depress LOCK/UNLOCK pedal slightly, not enough to lock, and release. Repeat several times. Check for pedal rubbing on base casting, drip pan or other surfaces. Pedal should spring back rapidly when released; if it does not, proceed as follows:

- With top at maximum height, lean table against wall (shield wall from damage) and block base to prevent slipping.

- Remove screws in each bearing block. Take out floor lock cross shaft. If necessary, remove a caster to aid in disassembly.

- Measure free length of pedal return spring. Replace spring if it is not  $2-1/4 \pm 1/16$ -inches long.

- Check pedal return spring hole in underside of base. Be sure chamfer (1/8-inch by 45 degrees) is sufficient to prevent spring from catching.

- Replace cross shaft, pedal return spring and bearing blocks. Operate cross shaft to ensure no binding. If necessary, loosen screws and reposition bearing blocks. (**Note:** The cross shaft may bind if bearing blocks are not in line.)

- Check adjustment of pedal return spring set-screw. It should be adjusted to extend approximately 7/16-inch above base casting. Turn screw clockwise to increase spring tension and aid pedal return.

- Inspect cams located at ends of cross shaft. Replace if cam surfaces are not smooth. Ensure cams are parallel and contact lever arm rollers simultaneously. The rollers can be repositioned by moving supports for locking arms.

### 3.3.8. INSUFFICIENT CLEARANCE BETWEEN LOCK/UNLOCK PEDAL AND FLOOR

3.3.8.1. Raise and support tabletop (See Paragraph 3.3.2.).

3.3.8.2. Loosen four screws securing bearing blocks which support latch casting.

3.3.8.3. Place an equal number of shims under both bearing blocks at each screw.

3.3.8.4. Operate floor locks and observe latch operation. Ensure pedal arm pin engages latch during locking and that latch swings clear of pin during unlocking. If necessary, increase height of latch spring on base stud by repositioning two nuts. Distance between bottom nut and casting should be approximately 1-5/16-inches. Floor locks are designed to operate on a relatively level floor. If table is used in a room with a slope to floor drain, further adjustments may be necessary.

### 3.3.9. LOCK/UNLOCK PEDAL STICKS IN UP POSITION

3.3.9.1. Raise and support tabletop (See Paragraph 3.3.2.).

3.3.9.2. Ensure pin is centered in pedal arm.

3.3.9.3. Ensure latch operates properly.

3.3.9.4. If necessary, increase height of latch spring on base stud by repositioning two nuts. Distance between bottom nut and base casting should be approximately 1-5/16-inches.

### 3.3.10. LOCK/UNLOCK PEDAL DOES NOT RETURN TO MAXIMUM UP POSITION

If pedal does not return to maximum up position, pedal arm pin will not properly engage latch during next lock cycle. Proceed as follows:

3.3.10.1. Raise and support tabletop (See Paragraph 3.3.2.).

3.3.10.2. Ensure pedal leveling screws are properly adjusted and not preventing pedal from returning to maximum up position.

3.3.10.3. Operate floor locks and observe latch operation. Ensure pedal arm pin engages latch during locking and that latch swings clear of pin during unlocking. If necessary, increase height of latch spring on base stud by repositioning two nuts. Distance between bottom nut and base casting should be approximately 1-1/16-inches.

3.3.10.4. Measure free length of pedal return spring. Replace spring if it is not  $2-1/4 \pm 1/16$ -inches long as follows:

- Remove setscrew from top of base.
- If possible, remove spring through hole.

- If not, lift base with hoist or tilt and support table.

- Remove bearing blocks.
- Lower shaft assembly to provide access to spring.

- Remove spring.

### 3.3.11. REMOVAL OF PIN AND FOOT ASSEMBLY

**NOTE:** With exception of replacing foot, following disassembly procedures require base cover to be raised and supported. It may be necessary to tilt table for access to parts on underside of base assembly.

3.3.11.1. Raise and support tabletop (See Paragraph 3.3.2.).

3.3.11.2. Pin And Foot Assembly contains a foot, rubber locking slug, and rod which may be replaced. Replace foot as follows:

- Engage floor locks. Tilt table as necessary to provide access to foot.

**NOTE:** There is a flat on head-end foot which allows (using wrench) removal of foot from rod. Depressing LOCK pedal forces rod down and exposes the flat.

- Remove foot from rod by turning counterclockwise.

3.3.11.3. Remove Rod as follows (**Note:** The two linkages are connected to each other by a non-adjustable line.):

- Disconnect spring and remove cotter and clevis pins.

- Remove screw and pull bars free of rod.

- Tilt table and pull rod through bottom of base.

3.3.11.4. Abductor-bar-end feet screw directly into locking foot casting. Remove each foot by using a drive pin and turning counterclockwise.

3.3.11.5. Remove Pedal as follows:

- Lift base with a hoist or tilt and support table.

- Remove bearing blocks. Lower shaft assembly.

- Back out setscrew in cam. Remove cam from pedal ends of shaft.

- Pull bearing blocks from shaft assembly.

- Remove setscrew and slide pedal assembly from shaft.

3.3.11.6. Remove Cam Roller by removing attaching nuts and washers.

### 3.3.12. REMOVAL OF CASTER ASSEMBLIES

3.3.12.1. Remove Head-end Caster as follows:

- Tilt and support table
- Remove nut and washer.
- Remove caster by dropping out of base.

3.3.12.2. Remove Leg-end Caster as follows:

- Remove set screw from bottom of caster support bracket.
- Place small rod through caster access hole (outside edge of floor locking foot) and drive axle out of support bracket.
- Caster will fall from support bracket.




Figure 1.




Figure 2.

**THIS EQUIPMENT WAS ORIGINALLY FILLED WITH**

- CHEVRON AW HYDRAULIC OIL GRADE 32
- MOBIL DTE 24 HYDRAULIC OIL
- SHELL TELLUS 32 HYDRAULIC OIL

NO SUBSTITUTIONS ARE TO BE USED UNLESS SPECIFIED IN THE OPERATORS MANUAL

AMSCO PT. NO. PT. NO. 54397-013

Figure 3.

## SECTION 3.4 EXPLODED VIEWS AND PARTS LISTS

### MINI INDEX

- Figure 1. GENERAL COMPONENT LOCATION.
- Figure 2. HYDRAULIC ASSEMBLY.
- Figure 3. COVER ASSEMBLY.
- Figure 4. TABLE SUPPORT ASSEMBLY.
- Figure 5. PUMP AND SUMP ASSEMBLY.
- Figure 6. FLOOR LOCK AND CASTER ASSEMBLY (Part 1 of 2).
- Figure 7. FLOOR LOCK AND CASTER ASSEMBLY (Part 2 of 2).

(NOT USED)




Figure 1. GENERAL COMPONENT LOCATION.





Figure 2. HYDRAULIC ASSEMBLY.

FIG. & INDEX NO.	PART NUMBER	DESCRIPTION	UNITS PER ASSEMBLY
2-		HYDRAULIC ASSEMBLY.....	X
1		FLOOR LOCK ASSEMBLY (See Fig. 6 or 7).....	1
2	P 78216 045	SCREW, Hex Head Cap, 7/16-20 x 5.....	6
3	P 19688 045	LOCKWASHER, 7/16.....	1
4	P 52728 091	COVER, Support.....	4
5	P 19677 041	LOCKWASHER, #10.....	9
6	P 16425 041	SCREW, Socket Head Cap, 10-32 x 3/4.....	8
7	P 11266 045	SCREW, Socket Head Cap, 1/4-20 x 1.....	8
8	P 19678 045	LOCKWASHER, 1/4.....	1
9	P 52689 010	BRACKET, Sump Mounting.....	1
10	P 99313 091	PUMP & SUMP ASSEMBLY (See Fig. 5).....	1
11	P 52736 091	ELBOW, Male, 5/16 ODT x 1/4 NPT.....	1
12	P 55094 091	TUBING.....	1
13	R 3500 810	TUBING, Polyethylene, 3/8 OD x 17-1/2.....	2
14	P 41324 091	CLIP.....	1
15	P 23418 063	SCREW, Set, 3/8-24.....	1
16	P 36628 051	WASHER, Special.....	1
17	P 12551 061	SCREW, Hex Hd. Cap, 5/16-18 x 5/8, Monel.....	1
18	P 10585 041	SCREW, Allen Cup Pt. Set, 10-32 x 1/4.....	1
19	P 22436 091	PLUG, Nylon.....	1
20	P 136804 178	PEDAL, RAISE/LOWER.....	1
21	P 93898 188	DECAL, RAISE/LOWER.....	1
22	P 99386 001	PLATE, Front Base.....	12
23	P 16383 045	SCREW, Socket Head Cap, 3/8-16 x 1.....	4
24	P 19680 041	LOCKWASHER, 3/8.....	4
25	P 5503 045	WASHER, Flat, 13/32 ID x 1 OD x 1/16.....	9
26	P 19013 091	BUMPER, Rubber.....	1
27	P 79593 001	SCREW, Set, 1/4-20 x 1-1/4.....	1
	P 136804 034	TABLE LIFT ASSEMBLY.....	1
28	P 43237 091	• SCREW, Button Head, 3/8-16 x 3/4.....	2
29	P 52682 001	• STOP, Elevator.....	1
30	P 55131 010	• ELEVATOR ASSEMBLY.....	1
31	P 136375 001	• CYLINDER, Lift.....	8
32	P 13796 045	• SCREW, Soc. Head Cap, 3/8-16 x 1-1/2.....	1
33	P 19680 041	• LOCKWASHER, 3/8.....	1
34	P 24265 091	• CUP, Splash.....	1
35	P 136804 033	• TABLE SUPPORT ASSEMBLY (See Fig. 4).....	2
36	P 77528 091	• BEARING, Slide.....	1
37	P 133699 002	PAN, Oil Drip.....	2
38	P 41012 061	SCREW, Socket Head Cap, 10-32 x 1/2, SS.....	2
39	P 5511 041	WASHER, Flat, #10.....	2



DETAIL A




Figure 3. COVER ASSEMBLY.

FIG. & INDEX NO.	PART NUMBER	DESCRIPTION	UNITS PER ASSEMBLY
3-		COVER ASSEMBLY.....	X
1	P 99324 001	COVER, Top.....	1
2	P 52718 091	SCREW, Socket Head Cap, 1/4-20 x 2.....	4
3	P 44086 045	NUT, Speed (U-Type), 1/4-20.....	4
4	P 99327 001	SHROUD, Intermediate.....	1
5	P 99326 001	SHROUD, Upper.....	1
6	P 99425 003	COVER, Top.....	1
7	P 46123 043	SCREW, Flat Head, 10-32 x 1/2.....	4
8	P 41535 001	SCREW, Flat Head.....	2
9	P 82333 001	BAR, Mounting.....	1
10	P 82312 001	RECEPTACLE, Grounding.....	1
11	P 90991 091	LOCKWASHER, #8.....	2
12	P 3038 041	NUT, Hex, 8-32.....	2
13	P 15324 042	SCREW, Round Head, 1/4-20 x 3/8.....	1
14	P 76230 091	LOCKWASHER, 1/4.....	1
15	P 80541 091	WIRE, Ground.....	1






Figure 4. TABLE SUPPORT ASSEMBLY.

FIG. & INDEX NO.	P	PART NUMBER		DESCRIPTION	UNITS PER ASSEMBLY
4-	P	136804	033	TABLE SUPPORT ASSEMBLY.....	X
1	P	146647	062	CASTING, Support.....	1
2	P	150823	073	LOCKNUT, Nylon Insert.....	8
3	P	80116	042	SCREW, Oval Pt. Allen Set, 1/2-20 x 1.....	8
4	P	16250	091	PIN, Dowel, 3/8 x 1.....	4
5	P	46478	091	CAM, Loading.....	8
6	P	77526	045	SPACER.....	8
7	P	46572	091	BEARING, Guiderol.....	8
8	P	46485	045	SPACER.....	4
9	P	77527	091	SHAFT, Bearing.....	4
10	P	90383	091	BUMPER.....	4
11	P	43223	091	SCREW, Oval Pt. Socket, 10-32 x 1/4.....	8
12	P	150823	074	LOCKNUT, Nylon Insert.....	8




Figure 5. PUMP AND SUMP ASSEMBLY.

FIG. & INDEX NO.	PART NUMBER	DESCRIPTION	UNITS PER ASSEMBLY
5-	99313 091	PUMP AND SUMP ASSEMBLY.....	X
1	P 99310 091	SUMP.....	1
2	P 46055 091	ELBOW, Male, 1/4 IPS x 3/8 ODT.....	1
3	P 77624 031	FITTING, Special.....	1
4	P 45565 091	CONNECTOR, Male, 1/4 IPS x 1/4 ODT.....	1
5	P 77613 091	BEARING, Sleeve.....	2
6	P 36587 091	KEY, Special Square.....	1
7	P 56397 012	ACTUATOR.....	1
8	P 10585 041	SCREW, Allen Cup Pt. Set, 10-32 x 1/4.....	1
9	P 13324 091	RING, Retaining, Waldes Truarc, 5103-87..	1
10	P 40622 061	WASHER, 1-1/4 OD x 7/8 ID x 3/16.....	1
11	P 77506 091	GASKET.....	1
12	P 77507 010	COVER, Sump.....	1
13	P 37891 041	SCREW, Socket Head Cap, 10-24 x 5/8.....	8
14	P 19685 061	LOCKWASHER, #10, SS.....	8
15	P 20580 042	PLUG, Pipe, 1/4 NPT.....	1
16	P 13411 091	SCREW, Socket Head Cap, 1/4-20 x 5/8.....	4
17	P 55087 001	PUMP ASSEMBLY.....	1
18	P 30379 041	SCREW, Flat Head, 8-32 x 5/8.....	3
19	P 77516 091	SHAFT, Pump.....	1
20	P 77533 091	O-RING, Precision, 118, Neoprene.....	1
21	P 77537 045	CAP, O-Ring.....	1
22	P 77610 091	O-RING, Precision, 026, Neoprene.....	1
23	P 118441 045	LOCKNUT, Hex.....	1
24	P 24960 091	BEARING.....	
25	P 129109 045	SCREW, Shoulder.....	




Figure 6. FLOOR LOCK AND CASTER ASSEMBLY (Part 1 of 2).

FIG. & INDEX NO.	PART NUMBER	DESCRIPTION	UNITS PER ASSEMBLY
6-		FLOOR LOCK AND CASTER ASSEMBLY (Part 1 of 2).....	X
		BASE (See Fig. 2).....	1
2	P 82633 001	BEARING, Sleeve.....	1
3	P 150202 001	PIN AND FOOT ASSEMBLY.....	2
4	P 129354 369	AXLE.....	2
5	P 129354 309	WHEEL, 3-1/4 Dia.....	2
6	P 36883 061	SCREW, Set, 10-32 x 3/8 w/nylok.....	2
7	P 3862 044	SCREW, Hex Head Cap, 3/8-16 x 2-1/2.....	8
8	P 10412 042	WASHER, Flat, .390 ID x .750 OD x .062.....	16
9	P 129354 310	SCREW, Socket Head Shoulder, 3/8 x 2-3/4.....	2
10	P 136804 180	BRACKET, Support, LH.....	1
11	P 136804 181	BRACKET, Support, RH.....	1
12	P 89809 061	LOCKWASHER, 3/8.....	8
13	P 3099 042	NUT, Hex, 3/8-16.....	8
14	P 93898 173	LOCK, Floor, Front.....	2
15	P 146647 078	FOOT, Locking.....	2
16	P 129354 308	KEY.....	1
17	P 93898 176	BAR, Weldment, Front, LH.....	1
18	P 93898 177	BAR, Weldment, Front, RH.....	1
19	P 13102 045	SCREW, Socket Head Cap, 10-32 x 1.....	4
20	P 129354 304	PIN, Clevis, Top.....	2
21	P 129354 305	PIN, Clevis, Bottom.....	2
22	P 129354 298	LINK, Non-Adjustable.....	2
23	P 2945 041	NUT, Hex, 3/8-24.....	2
24	P 19680 041	LOCKWASHER, 3/8.....	2
25	P 43754 045	WASHER, Flat, 3/8 ID x 5/8 OD.....	2
26	P 45272 091	BEARING, Cam Follower.....	2
27	P 77722 042	SCREW, Shoulder.....	2
28	P 93898 174	BAR, Weldment, Rear, LH.....	1
29	P 34510 091	WASHER, Nylon.....	2
30	P 93898 175	BAR, Weldment, Rear, RH.....	2
31	P 41012 061	SCREW, Socket Head Cap, 10-32 x 1/2.....	2
32	P 19677 041	LOCKWASHER, #10.....	2
33	P 129354 311	SUPPORT, Spring.....	2
34	P 42577 042	SCREW, Button Head, 10-32 x 5/8.....	2
35	P 47777 091	SPRING.....	2
36	P 91540 041	SPACER, Latch, 3/8 OD x 7/32.....	4
37	P 8897 091	PIN, Cotter, 1/16 x 1/2.....	4




Figure 7. FLOOR LOCK AND CASTER ASSEMBLY (Part 2 of 2).

FIG. & INDEX NO.	PART NUMBER	DESCRIPTION	UNITS PER ASSEMBLY
7-		FLOOR LOCK AND CASTER ASSEMBLY (Part 2 of 2).....	X
1	P 3097 041	NUT, Hex.....	2
2	P 47939 061	STUD, SS.....	1
3	P 19680 041	LOCKWASHER, 3/8.....	10
4	P 31838 042	SCREW, Hex Head Cap, 3/8-16 x 1.....	10
	P 55980 001	LATCH ASSEMBLY.....	1
5	P 47777 091	•SPRING, Extension.....	1
6	P 77521 091	•BEARING, Floor Lock.....	2
7	P 77524 045	•SHAFT, Floor Lock.....	1
8	P 31820 091	•RING, Retaining, Walde Truarc, 5100-50.....	2
9	P 55088 091	•LATCH, Floor Lock.....	1
10	P 38968 061	•PIN, Roll, 1/4 x 1/2.....	1
	P 136804 032	LIFT CAM ASSEMBLY.....	1
11	P 77731 001	•CAM, Lift.....	2
12	P 77729 045	•SPACER.....	2
13	P 40006 061	•SCREW, Set, 1/4-20 x 5/16.....	3
14	P 78203 091	•BEARING.....	3
15	P 16261 091	•KEY, Woodruff, 90.....	3
16	P 55084 010	•SHAFT.....	1
17	P 79878 001	•PIN, Grooved.....	1
18	P 136804 179	•PEDAL, LOCK/UNLOCK.....	1
19	P 80117 091	SPRING, Compression.....	1
20	P 93898 149	CASTER, Swivel.....	2
21	P 19681 045	LOCKWASHER, 1/2.....	2
22	P 13397 041	NUT, Hex, 1/2-13 x 5/16.....	2
23	P 80196 045	SCREW, Set.....	1

**THIS PAGE  
INTENTIONALLY LEFT  
BLANK**

**TOPIC 4  
TABLE SUPERSTRUCTURE  
INDEX**

<b>SECTION</b>	<b>PARAGRAPH</b>	<b>TITLE</b>	<b>GRID</b>
4.1		GENERAL .....	E-2
4.2		COMPONENT REPAIR AND REPLACEMENT .....	E-3
	4.2.1	General .....	E-3
	4.2.2	Tabletop Removal .....	E-3
	4.2.3	TRENDELENBURG Worm and Sector Adjustment .....	E-3
	4.2.4	TRENDELENBURG End Play Adjustment .....	E-3
	4.2.5	TRENDELENBURG Gear Assembly Removal .....	E-3
	4.2.6	LATERAL TILT End Play Adjustment .....	E-3
	4.2.7	LATERAL TILT Longitudinal Play Adjustment .....	E-4
	4.2.8	LATERAL TILT Saddle Adjustment .....	E-4
	4.2.9	LATERAL TILT Gear Assembly Removal .....	E-4
	4.2.10	Abductor Bar Adjustment .....	E-4
4.3		EXPLODED VIEWS AND PARTS LISTS .....	E-6 thru E-12

**SECTION 4.1 GENERAL**

This Topic contains all table superstructure data. Table superstructure consists of shroud, abductor bar, and gear assemblies. Superstructure can withstand patient load of 300 pounds under both reversed and normal positioning without exhibiting permanent set or failure. Superstructure side frame and cross members are constructed of cast aluminum and end frame is constructed of cast iron for ballast to assist Trendelenburg operation.

Any maintenance should only be attempted by qualified service technicians. Following repairs, test table using applicable section of FIELD TEST PROCEDURE to verify effectiveness of repairs.

## SECTION 4.2 COMPONENT REPAIR AND REPLACEMENT

### 4.2.1. GENERAL

This Section contains instructions for disassembly, repair and replacement of selected superstructure components. See Section containing Exploded Views and Assemblies as an aid in understanding and completing instructions.

By correctly manipulating positioning controls it should be possible to adjust tabletop to any position within its specified limits. Action of positioning mechanisms should be positive and smooth.

**WARNING: REPAIRS AND ADJUSTMENTS SHOULD BE ATTEMPTED ONLY BY EXPERIENCED PERSONS FULLY ACQUAINTED WITH THIS EQUIPMENT. USE OF INEXPERIENCED, UNQUALIFIED PERSONS TO WORK ON THIS EQUIPMENT, OR THE INSTALLATION OF UNAUTHORIZED PARTS, COULD CAUSE INJURY OR RESULT IN COSTLY DAMAGE.**

### 4.2.2. TABLETOP REMOVAL

Before performing the following gear assembly adjustments or removal, the tabletop (see appropriate Topic) and upper shroud must be removed.

- 4.2.2.1. Disconnect ground strap by removing screw and washer.
- 4.2.2.2. Remove side rails by removing nuts and washers.
- 4.2.2.3. Remove flat-head screws and retaining washers from one side of tabletop.

**WARNING: SUPPORT TABLETOP ASSEMBLY BEFORE REMOVING TRANSLATION SHAFTS.**

- 4.2.2.4. Push front and rear translation shafts out of tabletop.
- 4.2.2.5. Lift tabletop from table.
- 4.2.2.6. Remove upper shroud by removing screws and washers.

### 4.2.3. TRENDELENBURG WORM AND SECTOR ADJUSTMENT

- 4.2.3.1. Loosen six screws holding gear box to side frame.

**NOTE:** Table may shift when screws are loosened. May need to support tabletop weight.

- 4.2.3.2. Align worm vertically into sector of saddle using setscrew to achieve minimum clearance but retain free movement.

- 4.2.3.3. Tighten screws.

### 4.2.4. TRENDELENBURG END PLAY ADJUSTMENT

- 4.2.4.1. Loosen setscrew in adjusting nut.
- 4.2.4.2. Tighten adjusting nut until worm gear cannot be rotated by hand.
- 4.2.4.3. Back-off adjusting nut slowly until hand rotation of worm is possible.
- 4.2.4.4. Tighten setscrew to lock adjusting nut.

### 4.2.5. TRENDELENBURG GEAR ASSEMBLY REMOVAL

**WARNING: BLOCK SUPERSTRUCTURE TO AVOID SUDDEN TABLETOP MOVEMENT.**

- 4.2.5.1. Remove handle assembly by removing pin.
- 4.2.5.2. Loosen two setscrews.
- 4.2.5.3. Remove six screws holding gear box to side frame.
- 4.2.5.4. Pull gear box from side frame.
- 4.2.5.5. Disassembly of shaft and bearing assembly can be accomplished by referring to appropriate figure.

### 4.2.6. LATERAL TILT END PLAY ADJUSTMENT

- 4.2.6.1. Tighten hex nut and socket-head pivot pin to remove possible excessive clearance in bearings.
- 4.2.6.2. Shimming of bevel gear is required if above step fails to eliminate excessive tabletop movement.
  - Remove support bracket by removing four screws and two taper pins.
  - Add or remove shims as required.

### 4.2.7. LATERAL TILT LONGITUDINAL PLAY ADJUSTMENT

- 4.2.7.1. Check for gap between saddle and mounting plate.
- 4.2.7.2. If gap exists, tighten screw as necessary.  
**NOTE:** Overtightening screw may result in binding of tilt function.

### 4.2.8. LATERAL TILT SADDLE ADJUSTMENT

- 4.2.8.1. Loosen nut on hex-head cap screw.
- 4.2.8.2. Loosen hex-head cap screw.
- 4.2.8.3. Tighten hex nut until side tilt movement becomes difficult.
- 4.2.8.4. Back-off nut 1/4 turn.
- 4.2.8.5. Tighten cap screw as tight as possible while still allowing free rotation of saddle assembly.
- 4.2.8.6. Tighten nut.

### 4.2.9. LATERAL TILT GEAR ASSEMBLY REMOVAL

- 4.2.9.1. Drive out taper pins and remove screws and washers from support bracket.
- 4.2.9.2. Swing assembly clear of table to permit drive shaft and bearing removal.
- 4.2.9.3. Disassembly of shaft and bearing assembly can be accomplished by referring to appropriate figure.

### 4.2.10. ABDUCTOR BAR ADJUSTMENT

The abductor bar joints may need lubrication if binding occurs.

- 4.2.10.1. Remove tabletop (see Paragraph 4.2.2.).
- 4.2.10.2. Remove upper shroud by removing screws and washers.
- 4.2.10.3. Remove indicator decal (only on C and D joints).
- 4.2.10.4. Back-off setscrews enough to remove knob handle.
- 4.2.10.5. Remove plug retainer and bearing.
- 4.2.10.6. Slide out thrust bearing.
- 4.2.10.7. Remove upper rosette, dowel pin and locking shaft.
- 4.2.10.8. Clean parts and apply thin film of Moly-lubriplate type MS HD No. 2 grease, on upper and lower rosettes, bearing and key.
- 4.2.10.9. Reassemble joints.
- 4.2.10.10. After knob is assembled, thread set screws until they stop. Then back-off approximately 1/2 turn to allow free rotation of knob.

**NOTE:** Each joint is custom fitted to allow least freeplay. It is important that parts from one joint not be mixed with parts from another.

## SECTION 4.3 EXPLODED VIEWS AND PARTS LISTS

### MINI INDEX

- Figure 1. GENERAL COMPONENT LOCATION.
- Figure 2. TABLE SUPERSTRUCTURE ASSEMBLY (Part 1 of 2).
- Figure 3. TABLE SUPERSTRUCTURE ASSEMBLY (Part 2 of 2).
- Figure 4. ABDUCTOR BAR ASSEMBLY.

(NOT USED)




Figure 1. GENERAL COMPONENT LOCATION.




Figure 2. SUPERSTRUCTURE ASSEMBLY (Part 1 of 2).

FIG. & INDEX NO.	PART NUMBER	DESCRIPTION	UNITS PER ASSEMBLY
2-		TABLE SUPERSTRUCTURE ASSEMBLY (Part 1 of 2)	X
1	P 146647 013	SUPERSTRUCTURE ASSEMBLY	1
2	P 93898 072	PIN, Pivot	1
3	P 16340 091	WASHER, Thrust	2
4	P 48270 091	BEARING, Single Row	AR
5	P 93898 241	SHIM, Pivot Pin	AR
6	P 93898 242	SHIM, Pivot Pin	AR
7	P 93898 243	SHIM, Pivot Pin	1
8	P 150083 001	PLATE, Bearing	2
9	P 129354 133	BEARING, Needle Thrust	3
10	P 129354 134	RACE, Thrust Bearing	1
11	P 93898 206	SADDLE ASSEMBLY	1
12	P 129354 130	NUT, Finished Hex, Self-Locking, 5/8-11	1
13	P 129354 046	KEY, Woodruff, #605, 3/16 x 5/8	1
14	P 93898 075	SHAFT, Drive, 5/8-18	1
15	P 48269 091	BEARING, Single Row	2
16	P 129354 132	SPACER, Bearing	3
17	P 50527 061	SCREW, Socket Head Cap, 8-32 x 1/2	3
18	P 79588 001	LOCKWASHER, Inner Tooth, #8	1
19	P 93898 006	PLATE, Stop	2
20	P 80112 091	BEARING, Single Row	1
21	P 136804 114	PLATE, Mounting	1
22	P 93898 005	NUT, Lateral, 3/4-10 Acme	1
23	P 93898 015	JOINT, Universal	4
24	P 150823 057	PIN, Taper, #3 x 1-3/8	8
25	P 80213 045	SCREW, Button Head Socket, 1/4-20 x 1/2	2
26	P 80111 010	PLATE, End	1
27	P 93898 004	SCREW, Power, 3/4-10 Acme	1
28	P 129354 202	STOP	1
29	P 5575 045	WASHER, Plain	1
30	P 79253 045	SCREW, Socket Head Cap, 1/4-20 x 1/2	1
31	P 52734 061	PIN, Support	1
32	P 75870 091	BEARING, Sleeve	1
33	P 80115 045	NUT, Hex-Thin, 3/4-16	1
34	P 129354 131	SPACER, Gear	1
35	P 136804 036	TILT DRIVE ASSEMBLY	1
36	P 129354 031	NUT, Hex-Thin, 5/8-18	1
37	P 12176 041	SCREW, Socket Head Cap, 1/4-20 x 3/4	4
38	P 76230 091	LOCKWASHER, External Tooth, 1/4	4
39	P 93898 231	SHIM, Tilt Gear, .001 (Amber)	AR
40	P 93898 232	SHIM, Tilt Gear, .003 (Green)	AR
41	P 93898 233	SHIM, Tilt Gear, .005 (Blue)	AR
42	P 14413 042	PIN, Taper, #2 x 7/8	2
43	P 3099 042	NUT, Hex, 3/8-16	5
44	P 17168 091	SCREW, Hex Head	1
45	P 129180 171	SCREW, Flat Head Socket, 3/8-16 x 2	4
46	P 19680 041	LOCKWASHER, 3/8	2
47	P 8897 091	PIN, Cotter	4






Figure 3. SUPERSTRUCTURE ASSEMBLY (Part 2 of 2).

FIG. & INDEX NO.	PART NUMBER	DESCRIPTION	UNITS PER ASSEMBLY
3-		SUPERSTRUCTURE ASSEMBLY (Part 2 of 2)....	X
1	P	SUPERSTRUCTURE ASSEMBLY (See Fig. 1).....	1
2	P 15339	045 SCREW, Socket Head-Cap, 3/8-16 x 1-1/4....	4
3	P 89809	061 LOCKWASHER, Internal Tooth, 3/8.....	4
4	P 10412	042 WASHER, Flat, 3/8.....	4
5	P 11266	045 SCREW, Socket Head Cap, 1/4-20 x 1.....	2
6	P 26962	061 LOCKWASHER, Internal Tooth, 1/4.....	2
7	P 31599	041 WASHER, Flat, 1/4.....	2
8	P 129186	174 BEARING, Sleeve.....	2
9	P 146647	036 SHROUD, Lower.....	1
10	P 93898	246 HANDLE ASSEMBLY, Tilt.....	1
11	P 93898	247 HANDLE ASSEMBLY, Trendelenburg.....	1
12	P 129180	173 PIN, Roll, 5/32 Dia. x 7/8.....	3
13	P 93898	013 JOINT, Universal.....	1
14	P 136804	035 GEAR BOX ASSEMBLY.....	1
15	P 38900	061 SCREW, Socket Head Set, 1/4-20 x 3/8.....	2
16	P 42598	045 SCREW, Socket Head Cap, 5/16-18 x 2-1/4....	2
17	P 19679	041 LOCKWASHER, 5/16.....	2
18	P 129354	337 STOP, Trendelenburg Gear.....	2
19	P 12786	091 PIN, Taper, #7 x 1-1/4.....	2
20	P 12695	045 SCREW, Socket Head Cap, 1/2-13 x 1-1/4....	2
21	P 93898	025 SECTOR, Worm Gear.....	1
22	P 93898	215 SHIM, Trendelenburg Gear (Amber - .001)...	AR
23	P 93898	216 SHIM, Trendelenburg Gear (Red - .002)....	AR
24	P 93898	217 SHIM, Trendelenburg Gear (Green - .003)...	AR
25	P 93898	218 SHIM, Trendelenburg Gear (Tan - .004)....	AR
26	P 93898	219 SHIM, Trendelenburg Gear (Blue - .005)....	AR
27	P 93898	220 SHIM, Trendelenburg Gear (Brown - .010)...	AR
28	P 93898	221 SHIM, Trendelenburg Gear (Pink - .015)....	AR
29	P 93898	222 SHIM, Trendelenburg Gear (Yellow - .020)...	AR
30	P 93898	223 SHIM, Trendelenburg Gear (White - .025)...	AR
31	P 93898	224 SHIM, Trendelenburg Gear (Coral - .030)...	AR
32	P 146647	037 SHROUD, Upper.....	1




Figure 4. ABDUCTOR BAR ASSEMBLY.

FIG. & INDEX NO.	P	PART NUMBER		DESCRIPTION	UNITS PER ASSEMBLY
4-		146647	027	ABDUCTOR BAR ASSEMBLY.....	X
1				SUPERSTRUCTURE ASSEMBLY (See Fig. 1).....	1
2	P	19680	041	LOCKWASHER, 3/8.....	4
3	P	16868	041	SCREW, Socket Head Cap, 3/8-16 x 7/8.....	4
4	P	11266	045	SCREW, Socket Head Cap, 1/4-20 x 1.....	4
5	P	19678	045	LOCKWASHER, 1/4.....	4
6	P	84079	216	WASHER, Flat, 1/4.....	4
7	P	136804	117	SUPPORT, Abductor Bar.....	1
8	P	136804	115	ABDUCTOR BAR, Inner.....	2
9	P	136804	089	ABDUCTOR BAR, Outer.....	2
10	P	93898	164	INDICATOR, Abductor Bar Outer, LH.....	1
11	P	93898	163	INDICATOR, Abductor Bar Outer, RH.....	1
12	P	93898	140	PLUG, Retainer.....	4
13	P	129354	196	BEARING.....	4
14	P	93898	225	SHAFT, Locking.....	4
15	P	129354	361	PIN, Dowel.....	4
16	P	93898	120	ROSETTE, Upper.....	4
17	P	43362	061	WASHER, Spring, 3/8.....	16
18	P	93898	121	ROSETTE, Lower.....	4
19	P	129354	349	BEARING, Thrust.....	8
20	P	150823	047	PIN, Dowel, 1/4 x 3/4.....	16
21	P	93898	227	KNOB, Abductor Bar.....	4
22	P	150763	001	SCREW, Set, 8-32 x 1/4.....	8
23	P	93898	137	CAP, End.....	2

**TOPIC 5**  
**TABLETOP**  
**INDEX**

SECTION	PARAGRAPH	TITLE	GRID
5.1		GENERAL .....	E-14
5.2		COMPONENT REPAIR AND REPLACEMENT .....	E-14
	5.2.1	General .....	E-14
	5.2.2	Tabletop Removal .....	F-1
	5.2.3	Locking and Sliding Channel Removal .....	F-1
5.3		EXPLODED VIEWS AND PARTS LISTS .....	F-2 thru F-4

(NOT USED)

**SECTION 5.1 GENERAL**

This Topic contains all tabletop data. Tabletop consists of top and translation assemblies. Tabletop can withstand patient positioning without exhibiting permanent set or failure. Tabletop is constructed of cast aluminum and texture painted. Translation bearing rods are case-hardened stainless steel.

Any maintenance should only be attempted by qualified service technicians. Following repairs, test table using applicable section of FIELD TEST PROCEDURE to verify effectiveness of repairs

**SECTION 5.2 COMPONENT REPAIR AND REPLACEMENT**

**5.2.1. GENERAL**

This Section contains instructions for disassembly, repair and replacement of selected tabletop components. See Section containing Exploded Views And Assemblies as an aid in understanding and completing instructions.

**WARNING:** REPAIRS AND ADJUSTMENTSSHOULD BE ATTEMPTED ONLY BY EXPERIENCED PERSONS FULLY ACQUAINTED WITH THIS EQUIPMENT. USE OF INEXPERIENCED, UNQUALIFIED PERSONS TO WORK ON THIS EQUIPMENT OR THE INSTALLATION OF UNAUTHORIZED PARTS COULD CAUSE INJURY OR RESULT IN COSTLY DAMAGE.

### 5.2.2. TABLETOP REMOVAL

5.2.2.1. Remove side rails by removing nuts and washers.

5.2.2.2. Remove screws and retaining washers from one side of tabletop.

**WARNING: SUPPORT TABLETOP ASSEMBLY BEFORE MOVING TRANSLATION SHAFTS.**

5.2.2.3. Push front and rear translation shafts out of tabletop.

5.2.2.4. Lift tabletop from table.

### 5.2.3. LOCKING AND SLIDING CHANNEL REMOVAL

5.2.3.1. Remove tabletop (see Paragraph 5.2.2., TABLETOP REMOVAL ).

5.2.3.2. Drive out roll pins from sliding channel. Remove locking channel.

5.2.3.3. Remove shoulder screws from sliding channel. Remove sliding channel.

## SECTION 5.3 EXPLODED VIEWS AND PARTS LISTS

### MINI INDEX

Figure 1. TABLETOP ASSEMBLY.




Figure 1. TABLETOP ASSEMBLY.

5-4

F-3

FIG. &  
INDEX  
NO.

1-  
1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35

PART  
NUMBER

P	146647	032
P	136804	077
P	9961	041
P	136804	087
P	150044	001
P	10412	042
P	37344	048
P	5511	041
P	129354	059
P	37676	061
P	118442	045
P	129354	077
P	129354	075
P	136804	079
P	129354	078
P	129354	033
P	32320	061
P	129354	076
P	146647	030
P	129354	246
P	93898	016
P	129354	032
P	129354	043
P	93898	152
P	146647	077
P	136804	103
P	19686	061
P	129354	350
P	136804	078
P	93898	052
P	136804	086
P	93898	156
P	129354	244
P	19691	061
P	3098	045

DESCRIPTION

TABLETOP ASSEMBLY.....
BRACKET, Linkage, RH.....
SCREW, Round Head, 10-32 x 5/8.....
CHANNEL, Locking.....
SCREW, Socket Head Shoulder, 3/8 x 3/8.....
WASHER, Flat, 25/64 ID x 3/4 OD x 1/16.....
SCREW, Socket Head, 10-24 x 3/8, Nylock.....
WASHER, Flat, 3/16 ID x 7/16 OD x .035.....
BAR, Linkage.....
SCREW, Socket Head, 1/4-28 x 1/2, Nylock.....
NUT, Self-Lock, #10-32.....
BEARING.....
PIN, Shoulder.....
BLOCK, Rear Bearing.....
PIN, Roll.....
BEARING, Rear.....
SPRING, Compression.....
STUD, Shoulder.....
BLOCK, Front Bearing.....
BEARING, Front.....
SHAFT, Rear.....
WASHER, Retaining.....
SCREW, Flat Head Socket, 1/4-20 x 7/8.....
SHAFT, Front.....
TABLETOP, Painted.....
STRIP, Velcro.....
PAD.....
LOCKWASHER.....
SCREW, Shoulder, 10-32 x 3/4.....
BRACKET, Linkage, RH.....
ANGLE, Weldment.....
CHANNEL, Sliding.....
SIDE RAIL ASSEMBLY.....
SPACER, Side Rail.....
LOCKWASHER.....
NUT, Hex.....

UNITS PER  
ASSEMBLY

X  
1  
2  
1  
2  
4  
2  
10  
2  
2  
2  
2  
1  
1  
1  
2  
2  
2  
2  
1  
2  
1  
1  
1  
4  
4  
1  
1  
1  
1  
2  
2  
1  
1  
2  
6  
6  
6

5-5

F-4

**TOPIC 6**  
**TABLE ACCESSORIES**

**INDEX**

SECTION	PARAGRAPH	TITLE	GRID
6.1		GENERAL .....	F-6
6.2		INSTALLATION .....	F-6
	6.2.1.	Accessory Clamp .....	F-6
	6.2.2.	Clark Socket .....	F-6
	6.2.3.	Arm/Hand Table .....	F-7
6.3		DRAWING AND PARTS LIST .....	F-7

(NOT USED)

**SECTION 6.1 GENERAL**

This Topic contains all pertinent table accessory data. Table accessories are constructed to meet same design criteria as table which can withstand patient load of 300 pounds under both reverse and normal positioning without exhibiting permanent set or failure.

**SECTION 6.2 INSTALLATION**

**6.2.1. ACCESSORY CLAMP**

Clamp is used to attach accessories to abductor bars. Accessories include: Foot Traction Unit, Leg-holder, Popliteal Support, AP Cassette Holder, and Drape Support. To install clamp proceed as follows:

- 6.2.1.1. Place clamp handle in horizontal (unlocked) position.
- 6.2.1.2. Place clamp on abductor bar.
- 6.2.1.3. Lock clamp on bar by swinging handle down to vertical position.
- 6.2.1.4. If adjustment is needed in clamp position, proceed as follows:
  - Pull clamp to intermediate position (approximately 35 degrees from vertical).
  - Clamp may now be slid along abductor bar.

**NOTE:** Clamp cannot be removed from abductor bar while handle is in intermediate position.

- Remove clamp by pulling handle to horizontal (unlocked) position.

**6.2.2. CLARK SOCKET**

Socket is used to attach accessories to side rails. Accessories include: Lateral Cassette Holder, Drape Supports, and selected AMSCO standard accessories. To install socket proceed as follows:

- 6.2.2.1. Slide socket onto either end of side rail.
- 6.2.2.2. Place accessories support into opening and adjust socket for proper angulation of accessory.
- 6.2.2.3. Tighten accessory support and socket to side rail by turning "T" handle clockwise.

**NOTE:** Angulation changes can be made by slightly loosening socket.

6.2.2.4. Turn "T" handle counterclockwise to remove accessory support and to loosen socket.

6.2.2.5. Remove socket by sliding off rail.

### 6.2.3. ARM/HAND TABLE ASSEMBLY

6.2.3.1. Place arm/hand table bracket onto side rail.

6.2.3.2. Swing support leg down from clamp.

6.2.3.3. Loosen wing nut to lower foot to floor.

6.2.3.4. Tighten wing nut to lock foot in place.

6.2.3.5. Tighten bracket knobs to lock table to side rail.

6.2.3.6. Lock support leg in position by pushing "T" handle in.

6.2.3.7. Remove arm/hand table in reverse order.

## SECTION 6.3 DRAWING AND PARTS LIST

### MINI INDEX

- Figure 1. LEG TRACTION UNIT WITH BOOT.  
Figure 2. ARM/HAND TABLE ASSEMBLY.  
Figure 3. LEG HOLDER ASSEMBLY.  
Figure 4. CASSETTE HOLDERS.  
Figure 5. INTRAMEDULLARY COUNTER-TRACTION DEVICE AND HIP REST.  
Figure 6. CLAMP ASSEMBLIES.  
Figure 7. CLAMP ASSEMBLIES (After 5/84)




Figure 1. LEG TRACTION UNIT WITH BOOT.

FIG. & INDEX NO.	PART NUMBER	DESCRIPTION	UNITS PER ASSEMBLY
1-	P 142703 003	LEG TRACTION UNIT WITH BOOT (RH).....	X
1	P 136804 149	BOOT, (Sales Item).....	1
2	P 33195 056	FOOT PLATE ASSEMBLY.....	1
3	P 129354 211	TRACTION BUSHING ASSEMBLY.....	1
4	P 31967 091	PIN, Drive Lock.....	1
5	P 17285 045	WASHER.....	1
6	P 93898 145	RACK, Leg Traction.....	1
7	P 53229 056	BOX, Traction.....	1
8	P 26134 061	PIN, Drive Lock, 1/4 x 1-1/4.....	1
9	P 12283 041	SCREW, Round Head, #10-32 x 1/4.....	1
10	P 33191 056	HANDLE AND PINION ASSEMBLY.....	1
11	P 17269 056	DOG, Traction Box.....	1
12	P 11606 045	SPRING, Clutch Key.....	1
13	P 10583 091	SCREW, Set (Cup Point), #10-32 x 3/16.....	2
14	P 93898 144	KNOB ASSEMBLY, 1/2-13.....	1
15	P 24883 045	PLUNGER.....	1
16	P 24884 056	RETAINER, Piston.....	1
17	P 24869 061	STEM, Ball.....	1
18	P 25681 061	PIN, Groove, 3/16 x 1-1/4.....	1
19	P 136804 108	SUPPORT, Heel.....	1
20	P 93898 142	KNOB ASSEMBLY.....	1
21	P 93898 143	KNOB ASSEMBLY, 3/8-16.....	1
22	P 129354 212	RETAINER.....	1
23	P 33206 045	PLUNGER.....	1
24		CLAMP, Traction (See Fig. 6).....	1
25	P 9374 041	SCREW.....	3
26	P 24881 045	PISTON.....	1
27	P 24882 091	SPACER.....	1
28	P 26548 091	PLUG.....	1
29	P 33383 045	SHOE.....	1
30	P 51176 091	SCREW.....	1
31	P 92312 002	ELBOW TRACTION ASSEMBLY.....	1







Figure 2. ARM/HAND TABLE ASSEMBLY.

FIG. & INDEX NO.	PART NUMBER	DESCRIPTION	UNITS PER ASSEMBLY
2-	P 146647 054	ARM AND HAND TABLE ASSEMBLY.....	X
1	P 4433 041	SCREW, Set, 1/4-20 x 5/16 Long.....	2
2	P 9661 041	SCREW, #10-32 x 5/16 Long.....	2
3	P 27642 042	SCREW, #8-32 x 3/8 Long.....	2
4	P 42656 041	SCREW, 1/4-20 x 1 Long, Flat Head.....	4
5	P 93898 211	SLEEVE ASSEMBLY, Leg.....	1
6	P 93898 248	TEE HANDLE ASSEMBLY.....	1
7	P 93898 249	LEG, Extension.....	1
8	P 93898 250	NUT, Wing.....	1
9	P 93898 251	MOUNT, Support, R.H.....	1
10	P 93898 252	MOUNT, Support, L.H.....	1
11	P 93898 254	CLEVIS, Leg.....	1
12	P 129354 316	FASTENER, Hook.....	4
13	P 129354 319	KNOB LOCK ASSEMBLY.....	2
14	P 129354 326	INSERT, Keylocking, 1/4-20 x 3/8 Long.....	2
15	P 129354 328	PAD, Mount.....	2
16	P 129354 344	PIN, Driv-Lok, 3/8 x 2-1/4.....	1
17	P 129354 345	SCREW, *8-32 x 5/8 Long.....	12
18	P 129354 346	SHAFT.....	1
19	P 129354 381	BRACKET.....	1
20	P 129354 382	CLIP, Spring.....	2
21	P 136804 140	PAD (Not Shown).....	1
22	P 146647 052	TOP.....	1
23	P 146647 079	FRAME, Support.....	1
24	P 150200 001	FOOT.....	1
24	P 150763 001	SCREW, Set, 8-32 x 1/4 Half Dog Point.....	2





Figure 3. LEG HOLDER ASSEMBLY.

FIG. & INDEX NO.	PART NUMBER	DESCRIPTION	UNITS PER ASSEMBLY
3-	P 146647 018	LEG HOLDER ASSEMBLY	X
1	P 136804 040	MOLDED PAD ASSEMBLY	1
2	P 129354 115	CLAMP, Scrap	1
3	P 129354 116	BRACKET, Swivel	1
4	P 31689 045	RING, Retaining	2
5	P 129354 122	SHAFT, Bearing	1
6	P 41992 061	SCREW, Socket Head Cap, 1/4-20 x 5/8	2
7	P 19686 061	LOCKWASHER, 1/4	2
8	P 129354 119	BUSHING, Clamp	1
9	P 129354 118	COLLAR, Clamp	1
10	P 8316 056	KNOB	2
11	P 129354 127	POST	1
12	P 129354 389	HANDLE	1
13	P 129354 117	BAR	1
14	P 129354 126	STRAP, Velcro	1
15		CLAMP, Accessory (See Fig. 6)	1




A. Lateral Cassette Holder

B. A.P. Cassette Holder


Figure 4. CASSETTE HOLDERS.

FIG. & INDEX NO.	PART NUMBER	DESCRIPTION	UNITS PER ASSEMBLY
4-		CASSETTE HOLDERS	X X
A	P 129354 386	LATERAL CASSETTE HOLDER ASSEMBLY*	X
	P 136804 039	LATERAL CASSETTE HOLDER ASSEMBLY*	X
1	P 129354 110	• ROD	1
2	P 48941 034	• BRACKET	2
3	P 44522 056	• KNOB	2
4	P 150763 001	• SCREW, Set (Dog Point)	2
5	P 129354 333	• SLEEVE	1
6	P 129354 327	• COLLAR	1
7	P 15419 044	• SCREW, Thumb, 1/4-20 x 1/2	1
8	P 9276 041	• SCREW, Round Head, #8-32 x 3/16	1
9	P 43348 091	• CLARK SOCKET*	1
B	P 129354 385	A. P. CASSETTE HOLDER ASSEMBLY*	X
	P 146647 055	A. P. CASSETTE HOLDER ASSEMBLY	X
11	P 93898 194	• BAR, Slide	1
12	P 136804 133	• SLIDE, Weldment	2
13	P 93898 142	• KNOB ASSEMBLY	2
14	P 136804 132	• BAR, Pivot (Weldment)	1
15	P 3958 041	• SCREW, Round Head, #4-36 x 1/8	2
16	P 50527 061	• SCREW, Socket Head Cap, #8-32 x 1/2	1
17	P 129354 327	• COLLAR	1
18	P 15419 044	• SCREW, Thumb, 1/4-20 x 1/2	1
19		CLAMP, Accessory* (See Fig. 6)	1

**A. I.M. NAILING REST ASSEMBLY —  
ORTHOGRAPHIC 2 TABLE.**



**B. T-SHAPE SACRAL REST ASSEMBLY —  
ORTHOGRAPHIC 2 TABLE.**



**C. WEDGE SHAPE SACRAL REST ASSEMBLY —  
ORTHOGRAPHIC 2 TABLE.**





Figure 5. INTRAMEDULLARY COUNTER-TRACTION DEVICE AND HIP REST.

FIG. & INDEX NO.	PART NUMBER	DESCRIPTION	UNITS PER ASSEMBLY		
			X	X	X
5-	P 146647 080	INTRAMEDULLARY COUNTER-TRACTION DEVICE ASSEMBLY (SALES ITEM).....	X	X	X
1	P 146647 075	BRACKET, Support.....	1		
2	P 136804 129	REST, Leg.....	1		
3	P 46124 056	SCREW, Flat Head Socket, 1/4-20 x 3/4.....	2		
4	P 136804 186	SLIDE ASSEMBLY.....	1		
5	P 93898 228	SUPPORT, Vertical Adjustment.....	1		
6	P 93898 257	KNOB ASSEMBLY.....	1		
7	P 150763 001	SCREW, Set, #8-32 x 1/4 (Half Dog).....	1		
8	P 129354 355	PLUNGER, Spring.....	1		
A	P 136804 137	I. M. NAILING REST ASSEMBLY			
1	P 129354 082	• SCREW, Flat Head Socket, 3/8-16 x 3/4 Lg.....	3		
2	P 129354 238	• FASTENER, Hook.....	1		
3	P 136804 100	• REST, Sacral.....	1		
4	P 136804 102	• PAD, Sacral Rest.....	1		
5	P 136804 131	• SUPPORT, Sacral Rest.....	1		
8	P 136804 138	T-SHAPE SACRAL REST ASSEMBLY			
1	P 93898 031	• SOCKET, Perineal Post.....		1	
2	P 129354 082	• SCREW, Flat Head Socket, 3/8-16 x 3/4 Lg.....		2	
3	P 129354 139	• FASTENER, Hook, 2 x 6 Velcro Tape.....		1	
4	P 136804 041	• REST, Sacral, T-Shaped.....		1	
5	P 136804 048	• PAD.....		1	
5	P 136804 128	• SUPPORT.....		1	
C	P 136804 139	WEDGE SHAPE SACRAL REST ASSEMBLY			
1	P 93898 031	• SOCKET, Perineal Post.....		1	
2	P 129354 082	• SCREW, Flat Head Socket, 3/8-16 x 3/4 Lg.....		2	
3	P 129354 139	• FASTENER, Hook, 2 x 6 Velcro Tape.....		1	
4	P 136804 006	• SACRAL REST.....		1	
5	P 136804 010	• PAD.....		1	
6	P 136804 128	• SUPPORT.....		1	




Figure 6. CLAMP ASSEMBLIES.




Figure 7. CLAMP ASSEMBLIES (After 5/84).

FIG. & INDEX NO.	PART NUMBER	DESCRIPTION	UNITS PER ASSEMBLY		
6-	P 146647	034 TRACTION CLAMP ASSEMBLY (SALES ITEM).....	X		
6-	P 146647	035 ACCESSORY CLAMP ASSEMBLY (SALES ITEM).....		X	
1	P 52336	061 SCREW, Set, Socket Head, #6-32 x 1/8.....	1	1	
2	P 129354	367 PIN, Dowel, 3/32 x 5/16.....	1	1	
3	P 136804	104 LEVER, Cam.....	1	1	
4	P 129354	286 PLUNGER, Spring.....	1	1	
5	P 129354	288 WASHER, Belleville.....	16	16	
6	P 129354	287 RETAINER, Spring.....	1	1	
7	P 136804	106 LOCK, Clamp.....	1	1	
8	P 129354	250 PIN, Grooved, 3/16 x 1-1/2.....	2	2	
9	P 93898	161 PLATE, Accessory Clamp.....	1	1	
10	P 136804	105 BODY, Clamp.....	1	1	
11	P 93898	101 KNOB ASSEMBLY.....	1	1	
12	P 93898	162 PLATE, Traction Clamp.....	1		

FIG. & INDEX NO.	PART NUMBER	DESCRIPTION	UNITS PER ASSEMBLY		
7-	P 141210	012 CLAMP ASSEMBLY.....	X		
1	P 141210	011 BODY, Clamp.....	1		
2	P 129354	261 PIN, Grooved.....	1		
3	P 56397	037 LEVER ARM, Assembly.....	1		
4	P 81674	002 PIN, Spring.....	1		
5	P 56397	036 PLATE, Clamp.....	1		
6	P 56397	040 KNOB-CLAMP.....	1		
7	P 56397	071 KNOB-PLATE CLAMP.....	1		
8	P 36879	091 RING, Retaining.....	2		



AMSCO  
SERVICE

ORTHOGRAPHIC 2  
ORTHOPEDIC AND FRACTURE TABLE  
P-764317-886

7/86

1 of 1