

espresso company AUSTRALIA

SPII and SCODY II Grinder demonstration – customer support staff only

Cleaning SP II OD / SCODY II (including burr chamber) ...

We recommend spout and spring chamber to be cleaned every 10 – 15 kg of coffee (end of day) to maximise grinder performance – both sensory and consistency.

(with a vacuum cleaner if available and allen key provided).

1. Pull hopper gate out (close position) and grind out residual beans
2. Switch off power
3. remove the 3 hopper mounting nuts and remove bean hopper
4. Unscrew the top collar worm drive via the two 3mm cap screws
5. Remove / unwind top burr collar anti-clockwise
6. Unscrew the two 3mm cap screws on spout plate, remove spout and recessed spring
7. Vacuum all / brush the channel between burrs and spout, and clean internal of spout.
8. Seat spring back into its recess in the body panel making sure the spring isn't sticking out but is flat with panel.
9. Remount spout with two 3mm cap screws
10. Re-mount top burr collar, keeping in mind if the collar isn't turning with ease then the thread isn't aligned and you should start again. A trick here is turn collar anti clockwise (like you are removing them) until you hear a click that is the sound of thread aligning. Then screw clockwise moving collar with one finger (very little force is required).
11. Screw collar in until burrs touch then go back 1/4 turn back which will be about a coarse grind
12. Mount the worm drive back with two 3mm cap screws.
13. Position bean hopper and replace 3 hopper mounting nuts and push in hopper gate (open position).
14. Switch on power
15. Start-up is important, you want to purge coffee grind through the spring chamber and spout, then stop and brush or poke away any static coffee from the inside surface of the spout. Once the spring chamber is full of grind you'll not see any more static. (this precautionary clean is for the initial grind that has picked up static flying through the empty spring chamber).
16. Grind away...

Fan Filter, outer cover pulls off on the inwards fan. The filter mesh can be flicked clean or washed and completely dried over night before re-inserting back.

Group handle activation switch keep it clean and free from coffee grind and oils build up

Programming and adjustments...

Grind size adjustment

The worm drive is turned clockwise for finer grind and anti-clockwise for coarser grind.

Grind Time adjustment

1. Select button (single or double cup) you want to adjust timer and press for 3 seconds
2. Screen displays “programming” when in mode and ‘seconds’ digit will flash
3. Adjust second time up (+) or done (-), and press selected button
4. Adjust 10th second time up (+) or done (-), and press selected button
5. Screen displays selected button (single or double cup) and ready for operation.

Grind mode changing SP II OD / SCODY II

There are three grind modes:

- i. Actuator button with interruption
- ii. Actuator button single touch
- iii. Touch pad activation

Instruction to change mode:

1. Turn off power switch on grinder (located right side)
2. Press and hold “single or double cup” buttons together and turn power on and continue to hold “single or double cup” buttons until screen displays “adjust illumination”.
3. Scroll menu using the “one cup” button
 - a. Illumination of LCD screen (– or +)
 - b. Languages selection
 - c. Life cycle disc (scroll throw each digits)
 - d. User Mode
4. User Mode, for “Actuator button with interruption” and “Touch pad activation” leave in ‘Time Lag’.
5. User Mode, for “Actuator button single touch” mode option change ‘Time Lag’ using + & - button to ‘single touch’. To operate in this mode, press “double cup” button to save.
6. Otherwise...
7. To option “Actuator button with interruption” or “Touch pad activation” scroll to next screen “Time lag”
8. Time lag, to option “Actuator button with interruption” set SEC number to 05,0 by scrolling using single cup button and adjust using + & - buttons. To operate in this mode, press “double cup” button to save.
9. Time lag, to option “Touch pad activation” set SEC number to 00,0 by scrolling using single cup button and adjust using + & - buttons. To operate in this mode, press “double cup” button to save.
10. Return to normal operation by pressing “double cup” button


Warning should the grinder's operator not press "double cup" to save and exit the programming mode they may inadvertently proceed and engage the grinder's Hardware Test Mode

Anfim Hardware Test

This mode was only ever set up for technical staff. Hardware mode has been reached because the operator has changed the e.g. lag time but not saved the setting (T2). Instead the T1 button has been pushed through to activate this mode.




If T1 is pressed at this stage, the grinder will enter test mode and will not terminate until all hardware tests have been satisfied. PUSH T1



LCD Test


These characters will roll across the screen so that you can identify any abnormalities in the LED display.

Push T1



Contrast Test

The Display will now go through the high and low of its contrast test until you Push T1.



At this point you will no longer push through with the T1 button but follow the commands on the display screen in order to proceed.



2 cup Button Test.

At this point, your command function may have defaulted to Italian like this one. Now push the "Two Cups Button".



Plus Button Test

To continue, you must push the "Plus Button" on the touch pad.




Minus Button Test

To continue, you must press the "Minus Button" on the touch pad.

Note: The next screen is for an Auxiliary test which does not relate to the build of our grinders. Skip this test by pressing T2 and T3 simultaneously.

For -SCODY or CODY- Skip this Test pressing T2 and T3 simultaneously





The display will now tell you that Aux has been skipped



The next screen will ask you to push the “1 Cup Button”.



1 Cup Button Test

The next screen will ask you to push the “1 Cup Button” again to test the LED.



1 Cup Button LED Test

The next screen will ask you to press the “Plus” and the “Minus” buttons together to test the motor.



Motor Test

At this point the motor will have activated and a display will tell you that a five second motor test is in progress.



Now the screen will tell you that the Hardware Test is finished. To get out of this last screen and return to normal menu, Press T1. Now you are finished the hardware test.

