



Change the way you think about time

SAIDEA

INSTRUCTION MANUAL

Button B

Button A



1. How to read the time

- This watch uses an LCD “always on” display to show the time.
- At night time, you can illuminate the display for a short time with the LED backlight by pressing button A.
- The time is displayed using four hexagonal shaped digits.
- Progressing from the outside, hours are shown in the outer two rings and minutes are shown on the inner two rings.

Examples

04:36



12:38



2. How to read the date

- Press button B to display the date.
- The date icon indicates that you are in date mode.
- At night time, you can illuminate the display for a short time with the LED backlight by pressing button A.
- The date is displayed using four hexagonal shaped digits.
- Progressing from the outside, months are shown in the outer two rings and days are shown on the inner two rings.
- The display will change back to time mode after a short time.

Examples

March 29th



date icon

October 15th



3. How to set the time

- When the time is displayed, press and hold button B for 3 seconds to enter setting mode.

*Note after 10 seconds of inactivity setting mode will deactivate

I. Setting the hour

- The hour digits will flash when you are in hour setting mode.
- The PM icon in setting mode indicates that you are setting the time in PM.
- The PM icon only appears in 12 hour time setting mode.
- Press button A to increase the hour as required.
- Press button B to confirm and move to the minutes.

II. Setting the minutes

- The minute digits will flash when you are in minute setting mode.
- Press button A to increase the minutes as required.
- Press button B to confirm and move to 12/24 hour setting.

III. Setting 12/24 Hour Mode

- The time can be displayed in 12 or 24 hour mode.
- Press button A to change the time mode as required.
- Press button B to confirm and move to the animation.



12 hour mode



24 hour mode

IV. Setting the animation

- The display will either animate or flash when you are in animation setting mode.
 - When the animation is off, the display will flash. When the animation is on, the display will animate.
 - Press button A to turn the animation on or off.
 - The animation will appear on 00, 15, 30 and 45 minutes past each hour.
 - Press button B to confirm and exit setting mode.
- *Note after 10 seconds of inactivity setting mode will deactivate

4. How to set the date

- When the date is displayed, press and hold button B for 3 seconds to enter date setting mode.

*Note after 10 seconds of inactivity setting mode will deactivate

I. Setting the year

- The date mode icon will be displayed
- The year digits will flash when you are in year setting mode.
- Press button A to increase the year as required.
- Press button B to confirm and move to the month.



2013

II. Setting the month

- The month digits will flash when you are in month setting mode.
- Press button A to increase the month as required.
- Press button B to confirm and move to the date.

III. Setting the date

- The date digits will flash when you are in date setting mode.
- Press button A to increase the date as required.
- Press button B to confirm and exit setting mode.

*Note after 10 seconds of inactivity setting mode will deactivate

5. User information

I. Battery

- This watch uses two SR626SW replaceable watch batteries.
- Battery lifetime will vary depending on use, but is estimated to last for at least 10 months.
- To maximize battery life you should limit use of the LED backlight.

II. Warranty

- This watch is covered by a 1 year warranty. This warranty does not cover water damage, accidental damage, neglect or unauthorized repair.

III. Caution

- This watch is water resistant to 3ATM. Please do not use the watch in the shower, for swimming or for other water related activities.

SPECIFICATIONS

Case Material	Stainless Steel
Strap Material	Stainless Steel
Case Dimensions	40 mm x 51 mm x 10 mm
Finish	Polished
Maximum Fit Wrist Size	210mm (approx.)
Weight	140g
Display	LCD with LED backlight
Battery	SR626SW
Water Resistance	3ATM

