

get started

INSTANT POT® DUO™ CRISP
MULTI-COOKER + AIR FRYER

Instant™

IMPORTANT SAFEGUARDS



At Instant Brands™, your safety always comes first. The Instant Pot® Duo™ Crisp Multi-Cooker + Air Fryer was designed with your safety in mind.

When using electrical appliances, basic safety precautions should always be followed:

- 01 READ THIS ENTIRE DOCUMENT BEFORE OPERATING THE APPLIANCE. FAILURE TO FOLLOW THESE SAFEGUARDS AND INSTRUCTIONS MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.
- 02 Use only the Instant Pot Duo Crisp multi-cooker lid and Duo Crisp air fryer lid with the Instant Pot Duo Crisp multi-cooker base. Using any other multi-cooker lids or air fryer lids may cause injury and/or damage.
- 03 To reduce the risk of pressure leakage, cook only in an authorised stainless-steel Instant Pot inner pot. DO NOT use the appliance without the removable inner pot installed.
- 04 Always use an Instant Pot stainless-steel inner pot when using the air fryer lid. DO NOT use a ceramic coated inner pot.
- 05 **⚠ CAUTION** When pressure cooking, do not open the appliance until it has depressurised, and all internal pressure has been released. If the float valve is still up and/or the lid is difficult to open, this indicates that the appliance is still pressurised—do not force it open. Any pressure in the appliance can be hazardous. Refer to **Releasing pressure: Venting methods** for information on releasing pressure. Opening the appliance while it is still pressurised may lead to sudden release of hot contents and may cause burns or other injuries.
- 06 Always operate the appliance on a stable, non-combustible, level surface.
- 07 Do not use the appliance for anything other than its intended use. Failure to follow this instruction may result in injury or property damage.
- 08 For household use only. Do not use outdoors. Not for commercial use.

⚠ WARNING

Read this manual carefully and completely and retain for future reference. Failure to adhere to safety instructions may result in serious injury or damage.

IMPORTANT SAFEGUARDS



- 09 **⚠ CAUTION** Do not place the appliance on or in close proximity to a hot gas or electric burner, or a heated oven. Heat from an external source will damage the appliance. Failure to follow these instructions may result in injury or property damage.
- 10 **⚠ CAUTION** Do not use the appliance near water or flame. Keep out of direct sunlight. Failure to follow these instructions may result in injury or property damage.
- 11 **⚠ CAUTION** Do not touch hot surfaces. Only use side handles for carrying or moving. Extreme caution must be used when moving the appliance containing hot liquids. Do not move the appliance when it is under pressure.
- 12 **⚠ CAUTION** The multi-cooker base and air fryer lid contain electrical components. To avoid electrical shock, do not put liquid of any kind into multi-cooker base or air fryer lid, and do not immerse power cord, plug, or the appliance in water or other liquid. Do not rinse the appliance under tap.
- 13 **⚠ CAUTION** Do not fill over **PC MAX – 2/3** as indicated on the inner pot. When cooking foods that expand during cooking such as rice or dried vegetables, do not fill the inner pot over – **1/2** line. Overfilling may cause a risk of clogging the steam release pipe and developing excess pressure. Refer to **Cooking: Pressure Cook and Steam**.
- 14 **⚠ WARNING** This appliance cooks under pressure. Make certain the appliance is properly closed before operating. Failure to do so may result in burns, injury and/or property damage. Refer to **Pressure Control Features: Multi-cooker lid - Closing the lid**.
- 15 When cooking meat with skin (e.g., sausage with casing), the skin can swell when heated. Do not pierce the skin while it is swollen; this could result in scalding injury.
- 16 **⚠ CAUTION** When pressure cooking food with a doughy or thick texture, or a high fat/oil content, contents may splatter when opening the lid. Please follow recipe instructions for pressure release method. Refer to **Releasing pressure: Venting methods**.
- 17 **⚠ CAUTION** Before using the multi-cooker lid, check the steam release valve, steam release pipe, anti-block shield and float valve for clogging. Failure to do so may result in injury or property damage.

⚠ WARNING

Read this manual carefully and completely and retain for future reference. Failure to adhere to safety instructions may result in serious injury or damage.

IMPORTANT SAFEGUARDS



- 18 Do not use this appliance for deep frying or pressure frying with oil.
- 19 Do not lean over or place your hands or face over the steam release valve or float valve when the appliance is in operation or has residual pressure. Do not touch the metal portion of the lid when the appliance is in operation as this could result in injury.
- 20 Do not cover or obstruct the steam release valve and/or the float valve with cloth or any other objects. Covering or obstructing the steam release valve and/or float valve can create a safety issue and may cause injury.
- 21 Turn the appliance off if steam escapes from the steam release valve and/or float valve in a steady stream for longer than 3 minutes. There may be residual pressure in the appliance. Allow the appliance to depressurise naturally or release all excess pressure before opening. Refer to **Releasing pressure: Venting methods** for information on safe depressurisation.
- 22 Turn the appliance off if steam escapes from the sides of the lid and ensure sealing ring is properly installed. Refer to **Care, cleaning and storage: Removing and installing parts** for information on checking the sealing ring.
- 23 To disconnect, press **Cancel**, then remove plug from power source.
- 24 Unplug from the outlet when not in use, as well as before adding or removing parts or accessories, and before cleaning. To unplug, grasp the plug and pull from the outlet. Never pull from the power cord.
- 25 Regularly inspect the appliance and power cord. Do not operate the appliance if the power cord or plug is damaged, or after the appliance malfunctions or is dropped or damaged in any manner. For assistance, contact Customer Care by email at support@instantpot.com.au or by phone at 1800 251 643 or (02) 9317 1000.
- 26 **⚠ CAUTION** Spilled food can cause serious burns. A short power-supply cord is provided to reduce the hazards resulting from grabbing, entanglement and tripping.
 - Keep the appliance and cord away from children.
 - Never drape the power cord over edges of tables or counters.
 - Never use below-counter power outlets, and never use with an extension cord.

⚠ WARNING

Read this manual carefully and completely and retain for future reference. Failure to adhere to safety instructions may result in serious injury or damage.

IMPORTANT SAFEGUARDS



- 27 **⚠ CAUTION** Do not let the power cord hang over edges of tables or counters, or touch hot surfaces or open flame, including the stovetop.
- 28 Intended for countertop use only. Keep the appliance on a stable, heat-resistant platform. Do not place on anything that may block the vents on the bottom of the multi-cooker base or on the air fryer lid. Leave at least 13 cm of space around the air fryer lid when in use. Do not place the appliance on a hot stove. Do not operate the appliance on or near combustible materials such as tablecloths and curtains.
- 29 **⚠ CAUTION** Do not cover the air vents while the air fryer lid is in operation. Doing so will prevent even cooking and may cause damage to the appliance.
- 30 **⚠ CAUTION** Do not use any accessories or attachments not authorised by Instant Brands LLC. The use of attachments not recommended by the manufacturer may cause a risk of injury, fire or electric shock.
- 31 **⚠ CAUTION** Before inserting the inner pot into the appliance, wipe the outer surface of the inner pot as well as the heating element, located at the bottom of the interior of the multi-cooker base, with a clean dry cloth. Ensure they are dry and free of debris. Refer to **Care, Cleaning and Storage**. Failure to do so may result in injury or property damage.
- 32 Do not attempt to repair, replace or modify components of the appliance, as this may cause electric shock, fire or injury, and will void the warranty.
- 33 Do not tamper with any of the safety mechanisms as this may result in injury or property damage.
- 34 Avoid contact with moving parts as this may result in injury.
- 35 Do not use the appliance in electrical systems other than 220-240 V~ 50-60 Hz. Do not use with power converters or adapters.
- 36 This appliance is NOT to be used by children or by persons with reduced physical, sensory or mental capabilities. Close supervision is necessary when any appliance is used near children and these individuals. Children should not play with this appliance.
- 37 To prevent personal injury and damage to the appliance, only replace the sealing ring with an authorised Instant Pot sealing ring. Visit our online store for purchasing details.
- 38 The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.

⚠ WARNING

Read this manual carefully and completely and retain for future reference. Failure to adhere to safety instructions may result in serious injury or damage.

IMPORTANT SAFEGUARDS



- 39 Proper maintenance is recommended after each use. Refer to **Care, Cleaning and Storage**. Let the appliance cool to room temperature before cleaning or storage.
- 40 When using the air fryer lid, do not overfill the air fryer basket. Overfilling may cause food to contact the heating element, which may result in fire and/or personal injury.
- 41 Never connect this appliance to an external timer switch or separate remote-control system.
- 42 **⚠ CAUTION** DO NOT touch accessories during or immediately after cooking. To avoid personal injury,
- Always use heat-resistant hand protection when removing accessories, and to handle the inner pot.
 - Always place hot accessories on a heat-resistant surface or cooking plate.
 - Only place the air fryer lid on the protective pad provided; do not place on countertop.
 - Use extreme caution when disposing of hot grease. Failure to do so may result in serious injury or property damage.
- 43 While cooking, the internal temperature of the appliance reaches very high temperatures. To avoid personal injury, never place unprotected hands inside the appliance until it has cooled to room temperature.
- 44 **⚠ CAUTION** When the air fryer lid is in operation, hot air is released through the air vents. Keep your hands and face at a safe distance from the air vents and take extreme caution when removing hot accessories from the appliance. Failure to do so may result in injury or property damage.
- 45 Should the unit emit black smoke when using the air fryer lid, press Cancel and unplug the appliance immediately. Wait for smoking to stop before removing the lid, then clean thoroughly. For further information refer to **Troubleshooting**.
- 46 Do not leave the appliance unattended while in use.

⚠ WARNING

Read this manual carefully and completely and retain for future reference. Failure to adhere to safety instructions may result in serious injury or damage.

IMPORTANT SAFEGUARDS



- 47 **⚠ CAUTION** Extreme caution must be used when the inner pot contains hot food, hot oil or other hot liquids. Improper use, including moving the air fryer lid or multi-cooker base, may result in personal injury. Do not move the appliance while it is in use.
- 48 Oversized foods and/or metal utensils must not be inserted into the inner pot or air fryer basket as they may cause risk of fire and/or personal injury.
- 49 Do not store any materials in the multi-cooker base or inner pot when not in use.
- 50 Do not place any combustible materials in the multi-cooker base or inner pot, such as paper, cardboard, plastic, Styrofoam or wood.
- 51 Do not use the included accessories in a microwave, toaster oven, convection or conventional oven, or on a ceramic cooktop, electric coil, gas range, or outdoor grill.
- 52 The removable inner pot can be extremely heavy when full of ingredients. Care should be taken when lifting the inner pot from the multi-cooker base to avoid burn injury.
- 53 Use caution when removing the lid. Heat and steam escape as soon as the lid is removed. Never place your face, hands or exposed skin over the appliance opening where heat and steam escape when removing the lid.

SAVE THESE INSTRUCTIONS.

Find your model name and serial number

Model Name: Find it on the rating label on the back of the multi-cooker base, near the power cord.

Serial Number: You can find the serial number on a white sticker near the rating label.

⚠ WARNING

Read this manual carefully and completely and retain for future reference. Failure to adhere to safety instructions may result in serious injury or damage.

IMPORTANT SAFEGUARDS



⚠ WARNING

To avoid injury, read and understand the instructions in this manual before attempting to use this appliance.

⚠ WARNING

Electrical shock hazard. Use grounded outlet only.

- DO NOT remove ground.
- DO NOT use an adapter.
- DO NOT use an extension cord.

Failure to follow these instructions may result in electric shock and/or serious injury.

⚠ WARNING

THE FAILURE TO FOLLOW ANY OF THE IMPORTANT SAFEGUARDS AND/OR THE INSTRUCTIONS FOR SAFE USE IS A MISUSE OF YOUR APPLIANCE THAT CAN VOID YOUR WARRANTY AND CREATE THE RISK OF SERIOUS INJURY.

Special cord set instructions

Per safety requirement, a short power supply cord is provided to reduce the hazards resulting from entanglement and tripping.

This appliance has a 3-prong grounding plug. To reduce the risk of electric shock, plug the power cord into a grounded electrical outlet that is easily accessible.

Product specifications

				
Model: Duo Crisp AF 6	1500 W	220-240 V~ 50-60 Hz	5.7 Litres	8.9 kg
Model: Duo Crisp AF 8	1500 W	220-240 V~ 50-60 Hz	8 Litres	10.06 kg

	Duo Crisp AF 6		Duo Crisp AF 8	
	With Multi-Cooker Lid: cm: 34.5 L x 34.5 W x 33 H		With Multi-Cooker Lid: cm: 37.5 L x 34.5 W x 36 H	
	With Air Fryer Lid: cm: 34.5 L x 34.5 W x 35.5 H		With Air Fryer Lid: cm: 37.5 L x 34.5 W x 38.8 H	


⚠ WARNING

Read this manual carefully and completely and retain for future reference. Failure to adhere to safety instructions may result in serious injury or damage.


Product, parts and accessories

See **Care, cleaning and storage: Removing and installing parts** to find out how everything fits together.


Top of multi-cooker lid




Bottom of multi-cooker lid



Inner pot




Multi-cooker base




*Illustrations in this document are for reference only and may differ from the actual product.
Always refer to the actual product.*

Product, parts and accessories


Air fryer lid







Back



Interior



Accessories



*Illustrations in this document are for reference only and may differ from the actual product.
Always refer to the actual product.*

Get started

01 Pull that Duo Crisp out of the box!

 Always use a stainless-steel inner pot, not the non-stick ceramic coated variety, with the air fryer lid.

02 Remove the packaging material and accessories from in and around the multi-cooker and make sure all the parts are accounted for. See **Product, parts and accessories** for a full parts breakdown.

 Make sure to check under the inner pot!

03 Wash the inner pot in a dishwasher or with hot water and dish soap. Rinse it well with warm, clear water and use a soft cloth to thoroughly dry the outside of the inner pot.

04 Wipe the heating element with a soft, dry cloth to make sure there are no stray packaging particles left in the multi-cooker base.

 Don't remove the safety warning stickers from the lid or the rating label from the back of the multi-cooker base.

05 You may be tempted to put the Duo Crisp on your stovetop – *but don't do it!* Place the multi-cooker base on a stable, level surface, *away* from combustible material and external heat sources.

Is something missing or damaged?

Get in touch with Customer Care by email at support@instantpot.com.au or by phone at **1800 251 643** or **(02) 9317 1000**.

WARNING

Read the **Important safeguards** before using the appliance. Failure to read and follow those instructions for safe use may result in damage to the appliance, property damage or personal injury.

Do not place the appliance on a stovetop or upon another appliance. Heat from an external source will damage the appliance.

Do not place anything on top of the appliance, and do not cover or block the steam release valve or anti-block shield, located on the appliance lid.

Get started

Initial test run (water test)

Do you *have* to do the water test? No – but getting to know the ins and outs of your Duo Crisp prepares you for success in the kitchen!

- 01** Remove the inner pot from the multi-cooker base. Add 750 mL of water to the inner pot, then insert it back into the multi-cooker base.
- 02** Connect the power cord to a 220-240V~ power source.
The display shows **OFF**.
- 03** Place and close the multi-cooker lid as described in **Pressure control features: Multi-cooker lid**.
- 04** Select **Pressure Cook**.
- 05** Use the **- / + Time** buttons to adjust the cooking time to 5 minutes (**00:05**).
- 06** Press **Keep Warm** to turn the automatic Keep Warm setting off.
- 07** Press **Start**. The display shows **On**.
 While the multi-cooker does its thing, read **Pressure cooking 101** on the next page to find out how the magic happens.
- 08** When the Smart Programme finishes, the display shows **End**.

- 09** Follow instructions for a Quick Release in **Releasing pressure: Venting methods**.

⚠ CAUTION Pressurised steam releases through the top of the steam release valve. Keep exposed skin away from the steam release valve.

- 10** Wait for the float valve to drop, then carefully open and remove the lid as described in **Pressure control features: Multi-cooker lid**.

⚠ DANGER **DO NOT attempt to remove the lid while the float valve is up and NEVER attempt to force the lid open.** Contents are under extreme pressure. Float valve must be down before attempting to remove the lid. Failure to follow these instructions may result in serious personal injury and/or property damage.

- 11** Using proper hand protection, remove the inner pot from the multi-cooker base, discard the water and thoroughly dry the inner pot.

⚠ CAUTION The inner pot will be hot after cooking. Always use appropriate heat protection when handling a hot inner pot.

Pressure cooking 101

When pressure cooking, the Duo Crisp goes through 3 stages.

Pre-heating

What you see	What you don't see	Tips
The display shows On .	While the multi-cooker pre-heats, it vapourises liquid to create steam. Once enough steam has built up, the float valve pops up and locks the lid in place.	Frozen foods have the longest pre-heating time. For the fastest results, thaw your food before cooking it.  The time it takes the Instant Pot to pressurise depends on the amount of food and liquid in the inner pot. More food means a longer pre-heating time.

Cooking

What you see	What you don't see	Tips
The display switches to the cooking countdown timer.	When it reaches the required pressure level, cooking begins. The multi-cooker automatically maintains the cooking pressure at High or Low pressure.	A higher pressure means a higher temperature. Smart Programme settings (e.g., cooking time, pressure level, etc.) can be adjusted at any time during cooking.

Depressurisation

What you see	What you don't see	Tips
If Keep Warm is on after cooking, the timer counts up from 00:00 . If not, the multi-cooker returns to standby and displays End .	Although food has finished cooking, the multi-cooker is still pressurised and hot. Reducing the pressure level allows you to safely remove the lid.	Follow your recipe instructions to depressurise the multi-cooker. See Releasing pressure: Venting methods on the next page for safe venting techniques.

DANGER

DO NOT attempt to remove the lid while the float valve is up and NEVER attempt to force the lid open. Contents are under extreme pressure. Float valve must be down before attempting to remove the lid. Failure to follow these instructions may result in serious personal injury and/or property damage.

WARNING

Steam ejected from the steam release valve is hot. **DO NOT** place hands, face, or any exposed skin over the steam release valve when releasing pressure. **DO NOT** cover the steam release valve.

NOTICE

Do not use QR when cooking fatty, oily, thick or high-starch foods (e.g., stews, chilis, pasta and congee) or when cooking foods that expand when cooked (e.g., beans and grains).

Releasing pressure

You **must** release pressure after pressure cooking before attempting to open the lid. Follow your recipe's instructions to choose a venting method.

Venting methods

Natural Release (NR or NPR)

Cooking stops gradually. As the temperature within the multi-cooker drops, the multi-cooker depressurises naturally over time.


What to do	What to expect
<p>Leave the quick release button in the Seal position (popped-up) after cooking completes.</p>  <p>Seal Position</p> <p>Turn Keep Warm off.</p>	<p>Your meal continues to cook even after the Smart Programme ends.</p> <hr/> <p> Instant Tip: This is called “carryover cooking” or “resting”, and it’s great for large cuts of meat.</p> <p>The depressurisation time may vary based upon the volume, type and temperature of food and liquid. It can take up to 40 minutes with some dishes, so plan ahead – it’s well worth the wait!</p> <p>When pressure has been fully released, the float valve drops into the lid.</p>

NOTICE

Use NR to depressurise the multi-cooker after cooking high-starch foods (e.g., soups, stews, chilis, pasta, oatmeal and congee) or after cooking foods that expand when cooked (e.g., beans and grains).

Quick Release (QR or QPR)

Stops cooking quickly and prevents overcooking. Perfect for quick-cooking vegetables and delicate seafood!

What to do	What to expect
<p>Press the quick release button down until it clicks and locks into the Vent position.</p>  <p>Vent Position</p>	<p>When pressed down, a jet of steam ejects through the top of the steam release valve.</p> <p>This is normal!</p> <p>When pressure has been fully released, the float valve drops into the lid.</p>  <p>Venting</p>

Control Panel



Smart Programmes	Multi-cooker lid <ul style="list-style-type: none"> • Pressure Cook • Sauté • Slow Cook • Steam • Sous Vide 	Air fryer lid <ul style="list-style-type: none"> • Air Fry • Roast • Bake • Grill • Dehydrate
Time display	The time display shows the time in HH:MM format. Counts up or down, depending on the Smart Programme.	
Temperature/ pressure display	Multi-cooker lid: Displays Lo (Low) or Hi (High) pressure level.  When using the Sous Vide Smart Programme, the display indicates temperature in °C (Celsius) or °F (Fahrenheit). Air fryer lid: Displays temperature in °C or °F.	
- / + Temp	Adjust the cooking temperature in °C or °F.	
- / + Time	Adjust time for cooking, Delay Start and Keep Warm.	
Keep Warm	Turns the Keep Warm setting on or off.	
Delay Start	Delay the start of cooking.	
Start	Begins the selected Smart Programme.	
Cancel	Stop a Smart Programme at any time.	

Pressure control features


See **Care, cleaning and storage** for installation and removal of parts.

Multi-cooker lid

What we love about it	What you should know about it
<p>When you close it, it sets to Seal automatically, for seriously easy pressure cooking.</p> <p>While plugged in, the Duo Crisp plays a little jingle when you open and close the lid.</p>	<p>The lid is removable during non-pressure cooking so you can taste-test as you go.</p> <p>When you're pressure cooking, the lid only locks into place once the multi-cooker has pressurised. Try not to remove the lid unnecessarily while the steam builds inside!</p>


Removing the lid

- 01** Grip the lid handle and turn it counter-clockwise to align the symbol ▼ on the lid with the symbol ▢▲ on the rim of the multi-cooker base.
- 02** Lift the lid up and off the multi-cooker base towards your body.



Closing the lid


- 01** Align the symbol ▼ on the lid with the symbol ▢▲ on the multi-cooker base, then lower the lid onto the track.
- 02** Turn the lid clockwise until the symbol ▼ on the lid aligns with the symbol ▲ on the multi-cooker base.



Pressure control features

Quick release button

The quick release button controls the steam release valve – the part controls whether pressure is released or not.



Seal position
Flick to seal.



Vent position
Press to vent.


What we love about it	What you should know about it
It's really easy to use, and keeps our hands far away from the steam!	The lid says Turn to Seal , but it's more like a flicking motion. Don't turn the quick release button more than 45° and let it spring back to its original position.

See **Releasing pressure: Venting methods** for safe depressurisation techniques.

Steam release valve

The steam release valve sits loosely on the steam release pipe. When the multi-cooker releases pressure, steam ejects from the top of the steam release valve.

The steam release valve is integral to product safety and necessary for pressure cooking.



⚠ WARNING
Do not cover or block the steam release valve in any way.


Pressure control features

Sealing ring

When the multi-cooker lid is closed, the sealing ring creates an airtight seal between the lid and the inner pot.

The sealing ring must be installed before using the multi-cooker. Only one sealing ring should be installed in the lid at a time.

 **Instant Tip:** Silicone is porous, so it absorbs strong aromas and certain flavours. Keep extra sealing rings on hand to limit the transfer of aromas and flavours between dishes.



CAUTION

Only use authorised Instant Pot sealing rings. DO NOT use a stretched or damaged sealing ring.

- Always check for cuts, deformation and correct installation of the sealing ring before cooking.
- Sealing rings stretch over time with normal use. The sealing ring should be replaced every 12-18 months or sooner if you notice stretching, deformation, or damage.

Failure to follow these instructions may cause food to discharge, which may lead to personal injury or property damage.


Pressure control features

Float Valve

The float valve is a visual indication of whether there is pressure in the multi-cooker (pressurised) or not (depressurised). It appears in 2 positions:


Pressurised

The float valve has visibly popped up above the surface of the lid.



Depressurised

The float valve has descended, and the top is flush with the lid.



The float valve and silicone cap work together to seal in pressurised steam. These parts must be installed before use. Do not attempt to operate the Instant Pot without the float valve properly installed. Do not touch the float valve during use.


⚠ DANGER

DO NOT attempt to remove the lid while the float valve is up and NEVER attempt to force the lid open. Contents are under extreme pressure. Float valve must be down before attempting to remove the lid. Failure to follow these instructions may result in serious personal injury and/or property damage.

Anti-block shield

The anti-block shield prevents food particles from coming up through the steam release pipe, assisting with pressure regulation.

The anti-block shield is integral to product safety and necessary for pressure cooking.



Cooking

The Duo Crisp is super versatile in the kitchen – whether you want to pressure cook first and use the air fryer lid to crisp up your dish, or if you'd prefer to cook your meal just using the air fryer lid – you can!


Multi-cooker lid

- Pressure Cook
- Sauté
- Slow Cook
- Steam
- Sous Vide



Air fryer lid

- Air Fry
- Roast
- Bake
- Grill
- Dehydrate



Instant Tip: A jingle sounds when the lids are in the correct position, and the display indicates **OFF**.

⚠ WARNING

Do not fill inner pot higher than the **PC MAX – 2/3** line as indicated on the inner pot.

When cooking foods that expand (e.g., rice, beans, pasta) do not fill the inner pot higher than the **– 1/2** line as indicated on the inner pot

Always cook with the inner pot in place. Do not pour food or liquid into the multi-cooker base. To avoid risk of personal injury and/or property damage, place food and liquid ingredients in the inner pot, then insert the inner pot into the multi-cooker base.

Cooking

⚠ CAUTION

Always inspect the lid and inner pot carefully to make sure they are clean and in good working condition before use.

- To avoid personal injury or damage to the appliance, replace the inner pot if it is dented, deformed or damaged.
- Use only authorised Instant Pot inner pots made for this model when cooking.

Always make sure the heating element is clean and dry before inserting the inner pot into the multi-cooker base.

Failure to follow these instructions may damage the multi-cooker. Replace damaged parts to make sure safe function.

Pressure Cook and Steam

The Pressure Cook and Steam Smart Programmes are pressure cooking programmes. Using pressurised steam ensures your dish is cooked evenly and deeply, for predictably delicious results every time.

The Duo Crisp features two pressure levels to choose from:

Pressure level	Suggested use	Notes
Lo (Low) 5.0 - 8.0 psi (35-55 kPa)	Fish and seafood, soft vegetables and rice.	The pressure level controls the temperature, so a higher pressure results in a higher cooking temperature.
Hi (High) 9.4 - 12.3 psi (65-85 kPa)	Eggs, meat, poultry, root vegetables, oats, beans, grains, bone broth, stew, chili.	

Instant Pot size	Minimum liquid required*
5.7 Litres	1 ½ cups (375 mL)
8 Litres	2 cups (500 mL)

**Unless otherwise specified by your recipe*

Liquids for pressure cooking should be water-based, such as broth, stock, soup or juice. If using canned, condensed or cream-based soup, add water as directed below.

⚠ CAUTION

To avoid scorching or scalding injury, be cautious when pressure cooking with more than 1/4 cup (60 mL) oil, oil-based sauces, condensed cream-based soups, and thick sauces. Add suitable liquid to thin sauces. Avoid recipes that call for more than 1/4 cup (60 mL) of oil or fat content.

Cooking

To get pressure cooking, follow the same basic steps as you did in the Initial test run (water test) – but add food this time!

 **Instant Tip:** Using the stainless steel steam rack will ensure your food items are steamed and not boiled. It helps heat food evenly, prevents nutrients from leeching into the cooking liquid, and stops food items from scorching on the bottom of the inner pot.

When the Smart Programme finishes, follow your recipe's directions to select the appropriate venting method. See **Releasing pressure: Venting methods** for safe venting techniques.

DANGER

DO NOT attempt to remove the lid while the float valve is up and NEVER attempt to force the lid open. Contents are under extreme pressure. Float valve must be down before attempting to remove the lid. Failure to follow these instructions may result in serious personal injury and/or property damage.

Slow Cook

The Slow Cook Smart Programme is comparable to the cooking process of traditional slow cookers, and is compatible for use with any of your slow cooker recipes. Follow recipe directions for slow cooking.

The float valve should not rise during Slow Cook. The lid is removable throughout the cooking process for easy access. If the float valve rises, make sure the quick release button is set to the **Vent** position. Refer to **Releasing pressure: Venting methods**.

Temperature	Suggested use	Notes
Lo (Low)	Commonly used for low and slow, all-day cooking. Set for a minimum of 10 hours for best results.	You can use a lid for slow cooking, if it has a venting hole.
Hi (High)	Slow cooking, but a little bit faster.	Make sure the quick release button is set to Vent .

Cooking

Sauté

Sauté can be used in place of a frying pan, griddle or flat-top grill. Sautéing meat and vegetables before pressure cooking is the perfect way to boost flavours.

Temperature	Suggested use	Notes
Lo (Low)	Simmer, reduce and caramelize.	The display switches from On to Hot when the inner pot has reached cooking temperature.
Hi (High)	Pan sear, stir-fry, sauté and brown.	As a safety precaution, 30 minutes is the maximum cooking time.

When pressure cooking after using Sauté, deglaze the inner pot to make sure food items do not scorch.

To deglaze: remove food items from the inner pot and add a thin liquid (e.g., water, broth, wine) to the hot surface. Use a wooden or silicone scraper to loosen anything that may be stuck to the bottom of the inner pot.

WARNING

The Sauté Smart Programme reaches high temperatures. If unmonitored, food may burn on this setting. Do not use the lid and do not leave your multi-cooker unattended while using Sauté.

Sous Vide

Sous Vide cooking involves cooking food underwater, in an airtight, food-safe bag, for a long period of time. Food cooks in its own juices and comes out delicious and unbelievably tender.

Default time	Time range	Default temperature	Temperature range	Notes
3 hours (03:00)	00:30 - 99:30	56°C	21 - 93°C	Ensure the food in the bag is completely submerged.

Cooking

Air Fry, Roast, Bake, Grill and Dehydrate

Using the air fryer lid is an amazing way to ramp up your meal's flavour and texture.

NOTICE

If the **Food burn** error appears while using the air fryer lid, deglaze the bottom of the inner pot as necessary, according to **Cooking: Sauté** instructions.

⚠ CAUTION

Always ensure the stainless-steel inner pot is present in the multi-cooker base when using the air fryer lid. **DO NOT** use a non-stick ceramic coated inner pot.

Smart programme	Default time	Time range	Default temperature	Temperature range	Notes
Air Fry*	18 mins (00:18)	00:01 - 01:00	204°C	82 - 204°C	Place food in air fryer basket or in stainless-steel inner pot.
Suggested uses	Fresh or frozen fries, chicken wings, nuggets, fish sticks and more.				
Roast*	40 mins (00:40)	00:01 - 01:00	193°C	82 - 204°C	Place food in air fryer basket or in stainless-steel inner pot.
Suggested uses	Beef, lamb, pork, poultry, vegetables, scalloped potatoes and more.				
Bake	30 mins (00:30)	00:01 - 01:00	185°C	82 - 204°C	Pour cake batter into oven safe non-stick metal baking dish and cover for baking.
Suggested uses	Light and fluffy cakes, buns, pastries and more.				
Grill	8 mins (00:08)	00:01 - 00:40	204°C	Not adjustable	Place food on grill/dehydrating tray in air fryer basket.
Suggested uses	Melt cheese on nachos or French onion soup.				
Dehydrate	7 hours (07:00)	00:01 - 72:00	52°C	41 - 74°C	Place food under grill/dehydrating tray in air fryer basket.
Suggested uses	Make your own meat jerky, fruit leather strips, kale chips and more.				

*You can place food in the air fryer basket or directly in the stainless-steel inner pot, but the air fryer basket allows for the best air flow and an even crisp all over.

Cooking

Air Fry, Roast, Bake, Grill and Dehydrate


01 Insert food into the multi-level air fryer basket, oven safe non-stick metal baking dish, or directly into the inner pot, according to your recipe.

If using an accessory, insert the accessory into the inner pot.

02 Insert the stainless-steel inner pot into the multi-cooker base.

03 Place the air fryer lid on the multi-cooker base by lining up the lid fins and inserting them into the base handles.

 Press the lid down to ensure the power and sensor connectors are in full contact with each other.



⚠ CAUTION If the power and sensor parts are not fully connected, you may get a **Lid** message or **C9** error. Failure to ensure a proper connection could result in damage to the multicooker.

04 Select a Smart Programme: **Air Fry, Grill, Bake, Roast** or **Dehydrate**.

05 Use the **+ / -** buttons to adjust the Time and Temperature.

06 Press **Start**.

The display shows **On** as the air fryer lid Preheats. After preheating, the display changes to the set time and counts down.

During Air Fry and Roast, the multi-cooker beeps partway through cooking and the display shows **turn Food**.

07 If you need to remove the lid, carefully lift the air fryer lid off the multi-cooker base and place it on the protective pad provided. Lifting the lid automatically pauses cooking.

08 Carefully turn, flip, or rotate your food, then place the air fryer lid back on the multi-cooker base to resume cooking.

⚠ CAUTION The inner pot and accessories will be hot during and after cooking. To avoid injury, use hand protection and do not touch the inner pot accessories with bare skin.

 Some food doesn't need to be flipped. If you don't remove the lid after the **turn food** indicator appears, cooking continues after 10 seconds.

09 When one minute remains, the display counts down by seconds.

When the Smart Programme completes, the multi-cooker beeps and the display shows **End**.

Settings

To do this	Do this
Turn sound on/off.	<p>When in standby, press and hold + above Time until display indicates S On (sound on) or SOFF (sound off).</p> <p> Audible safety and error message alerts cannot be turned off.</p>
Change display temperature °C / °F.	<p>Press and hold + above Temp until the display indicates °C or °F. The temperature is displayed in the unit indicated.</p>
Adjust and save custom cooking times and temperatures.	<p>Once a Smart Programme is selected, changes to the cooking time, temperature and pressure level are saved once the Smart Programme begins.</p>
Reset an individual smart programme.	<p>When in standby, press and hold one Smart Programme button until the multi-cooker returns to Standby and displays OFF.</p> <p>The Smart Programme's pressure level, cooking time and temperature are restored to the factory default setting.</p>
Reset all smart programmes.	<p>When in standby, press and hold Cancel until the multi-cooker beeps.</p> <p>All Smart Programme pressure levels, cooking times and temperatures are restored to the factory default setting.</p>

Status messages

OFF	The Duo Crisp is in standby mode.
Lid	May indicate that the lid is missing, not properly secured, or that the wrong lid is being used for the Smart Programme selected.
On	The multi-cooker is pre-heating.
Hot	The Sauté Smart Programme has reached cooking temperature and food may be added to the inner pot.
00:00	Display shows one of the following: <ul style="list-style-type: none">• When Delay Start is running, the multi-cooker counts down until the Smart Programme begins;• When a Smart Programme is running, the multi-cooker counts down the remaining cooking time;• When Keep Warm is running, the multi-cooker counts the length of time that food has been warming.
End	The Smart Programme has ended and Keep Warm is off.
Food burn	The multi-cooker is overheating. See Troubleshooting for more information.
E*	An error has occurred. See Troubleshooting for information on error codes.

Care, cleaning and storage

Clean your Duo Crisp and its parts after each use. Failure to follow these cleaning instructions may result in catastrophic failure, which may lead to property damage, severe personal injury and/or death.

Always unplug your multi-cooker and let it cool to room temperature before cleaning. Never use metal scouring pads, abrasive powders or harsh chemical detergents on any of the Instant Pot's parts or accessories.

Let all surfaces dry thoroughly before use, and before storage.

Parts	Cleaning methods and instructions
Accessories <ul style="list-style-type: none"> Stainless steel steam rack Protective pad and storage cover Grill/dehydrate tray Multi-level air fryer basket Basket base 	Dishwasher safe if placed on top rack, otherwise clean with a damp cloth and mild dish soap and rinse well with clear, warm water. <ul style="list-style-type: none"> Disassemble the air fryer accessories before cleaning. Optionally, spray the grill/dehydrate tray and/or basket interior with non-stick cooking spray before adding food. Use the reverse side of the protective pad to cover the Air Fryer Lid when storing.
Multi-cooker lid and parts <ul style="list-style-type: none"> Condensation collector Anti-block shield Sealing ring Steam release valve Float valve Silicone cap 	Remove all the parts from the lid before cleaning. See Care, cleaning and storage: Removing and installing parts. <ul style="list-style-type: none"> With the steam release valve and anti-block shield removed, clean the interior of the steam release pipe to prevent clogging. To drain water from the lid after dishwashing, grasp the lid handle and hold the lid vertically over a sink, then turn it 360°— such as turning a steering wheel. After cleaning, store the lid upside down on the multi-cooker base. Check the condensation collector after each use and empty as needed. Do not allow food or moisture to stagnate in the condensation collector. Store sealing rings in a well-ventilated area to decrease residual odour of flavourful meals. To eliminate odours, add 1 cup (250 mL) water and 1 cup (250 mL) white vinegar to inner pot, and run Pressure Cook for 5-10 minutes, then QR pressure.
Air fryer lid	Clean with a barely-damp cloth and mild dish soap, then use a clean, barely-damp sponge to remove the soap residue. DO NOT machine wash. <ul style="list-style-type: none"> Wipe it dry with a soft cloth. Always check the element cover for oil spatter and food debris and remove it before turning on the air fryer lid. To remove baked-on grease and food residue, spray the element cover with a mixture of baking soda and vinegar and wipe clean with damp cloth. For stubborn stains, allow the mixture to sit on the affected area for several minutes before scrubbing clean. Note: Make sure not to use anything more abrasive than a toothbrush to scrub the element cover. DO NOT remove the element cover. DO NOT rinse or immerse the air fryer lid in water or other liquid.
Multi-cooker base	Clean with a barely-damp cloth and mild dish soap, then use a clean, barely-damp sponge to remove the soap residue. DO NOT machine wash. <ul style="list-style-type: none"> Make sure to clean the inside of the outer pot as well as the condensation rim. Allow the area to dry completely before inserting the inner pot. Clean the stainless-steel exterior and control panel with a soft, barely damp cloth or sponge.
Power cord	Wipe clean with a barely-damp cloth as needed.

Some discolouration may occur after machine washing, but this will not affect the multi-cooker's safety or performance.

Care, cleaning and storage

⚠ WARNING

The Instant Pot multi-cooker base contains electrical components. To avoid fire, electric leakage or personal injury, make sure the multi-cooker base stays dry.

- DO NOT immerse the multi-cooker base in water or other liquid, or attempt to cycle it through the dishwasher.
- DO NOT rinse the heating element.
- DO NOT submerge or rinse the power cord or the plug.

Removing and installing parts


Silicone sealing ring

Remove the sealing ring

Grip the edge of the silicone and pull the sealing ring out from behind the circular stainless-steel sealing ring rack.

With the sealing ring removed, inspect the steel rack to make sure it is secured, centered, and an even height all the way around the lid. Do not attempt to repair a deformed sealing ring rack.



 **The sealing ring** is easiest to remove when it is wet and soapy.



Install the sealing ring

Place the sealing ring over the sealing ring rack and press it into place. Press down firmly to prevent puckering.

When installed properly, the sealing ring is snug behind sealing ring rack and should not fall out when the lid is turned over.



Incorrect


Care, cleaning and storage

Steam release valve

Remove the steam release valve

Pull the steam release valve up and off the steam release pipe.


The steam release valve must be installed before using the multi-cooker.



Install the steam release valve

Place the steam release valve on the steam release pipe and press down firmly.


The steam release valve sits loosely on the steam release pipe when installed properly but should remain in place when the lid is turned over.



Anti-block shield

Remove the anti-block shield


Grip the lid like a steering wheel and use your thumbs to press firmly against the side of the anti-block shield (pressing towards the side of the lid and up) until it pops off the prongs underneath.



Install the anti-block shield

Place the anti-block shield over the prongs and press down until it snaps into position.

Do not attempt to operate the multi-cooker without the anti-block shield installed.



Care, cleaning and Storage

Float valve and silicone cap

Remove the float valve from the lid

Place one finger on the flat top of float valve, then turn the lid over. Detach the silicone cap from the bottom side of the float valve.

Remove the float valve from the top of the lid. Do not discard the float valve or silicone cap.




Top

Install the float valve

Drop the narrow end of the float valve into the float valve hole on the top of the lid. Place one finger on the flat top of the float valve, then turn the lid over. Firmly attach the silicone cap to the bottom of the float valve.

Do not attempt to operate the multi-cooker without the float valve and/or silicone cap properly installed in the pressure cooking lid.



Bottom

Condensation collector

The condensation collector sits at the back of the multi-cooker base and catches any overflow from the condensation rim.


It should be installed before cooking, then emptied and rinsed out after each use.

Remove the condensation collector

Pull the condensation collector away from the multi-cooker base; do not pull down. Note the tabs on the multi-cooker base and the grooves on the condensation collector.

Install the condensation collector

Align the grooves on the condensation collector over the tabs on the back of the multi-cooker base and slide the condensation collector into place.



Troubleshooting

Register your Instant Pot Duo Crisp today at instantpot.com.au/support/register.

Get in touch with Customer Care by email at support@instantpot.com.au or by phone at **1800 251 643** or **(02) 9317 1000**.

Problem	Possible reason	Try this
The display remains blank after connecting the power cord.	Bad power connection or no power.	Inspect power cord for damage. If damage is noticed, contact Customer Care . Check outlet to make sure it is powered.
	Multi-cooker's electrical fuse has blown.	Contact Customer Care .
Steam leaks from side of lid.	No sealing ring in the lid.	Install a sealing ring.
	The sealing ring is damaged or not installed properly.	Replace the sealing ring.
	Food debris attached to the sealing ring.	Remove the sealing ring and clean it thoroughly.
	The lid is not closed properly.	Open, then close the lid.
	The sealing ring rack is warped or off-centre.	Remove the sealing ring from the lid, then check the sealing ring rack for bends or warps. Contact Customer Care .
	The inner pot rim may be misshapen.	Check for deformation and contact Customer Care .
Minor steam leaking or hissing from the steam release valve during the cook cycle.	Quick release button is not in the Seal position.	Flick the quick release button to make sure it is in the Seal position.
	Multi-cooker is regulating excess pressure.	This is normal; no action required.
Steam gushes from the steam release valve when the quick release button is in the Seal position.	Not enough liquid in the inner pot.	Add thin, water-based liquid to the inner pot according to its size: 5.7L: 1 ½ cups (375 mL) 8L: 2 cups (500 mL)
	Pressure sensor control failure.	Contact Customer Care .
	Steam release valve is not seated properly.	Flick the quick release button to make sure it is in the Seal position.

Troubleshooting

Problem	Possible reason		Try this
Black smoke is coming from the air fryer lid.	CAUTION Cancel the Smart Programme, unplug the multi-cooker and allow it to cool to room temperature.		
	Using an oil with a low smoke point.		Choose a neutral oil with a high smoke point, such as Canola, Avocado, Soybean, Safflower, or Rice Bran.
	Food residue on the bottom of the inner pot or around the element on the air fryer lid.		Remove all accessories from the inner pot and clean the inner pot, air fryer lid, and all accessories thoroughly.
	Appliance malfunction.		Contact Customer Care .
Error code appears on the display and the multi-cooker beeps continuously.	C1 C2 C6 C6H C6L	Faulty sensor.	Contact Customer Care .
	C5	Temperature is too high because the inner pot is not in the multi-cooker base.	Press Cancel and wait for heating element to cool; make sure there are no foreign objects in multi-cooker base; insert or reposition inner pot in multi-cooker base and re-enter commands.
		Temperature is too high.	Check for scorching on bottom of inner pot. Add thin, water-based liquid to the inner pot according to its size.
	C7	Heat element has failed.	Contact Customer Care .
		Not enough liquid.	Add thin, water-based liquid to the inner pot according to its size
		Quick release button is in the Vent position.	Flick quick release button to make sure it is in the Seal position.
	Lid	Lid is not in the correct position for the selected programme.	Open and close the lid. Do not use a lid when using Sauté.
	Food burn	High temperature detected at bottom of inner pot; multi-cooker automatically reduces the temperature to avoid overheating.	Starch deposits at the bottom of the inner pot may have blocked heat dissipation. Turn the multi-cooker off, release pressure according to the recipe, and inspect the bottom of the inner pot.
	PrSE	Pressure has accumulated during a non-pressure cooking programme.	Press quick release button down until it clicks into Vent position.

Any other servicing must be performed by an authorised representative.

Warranty

Limited Warranty

This Limited Warranty is issued by Corelle Brands (Australia) Pty Ltd (Corelle Brands Australia) and is effective for one year from the date of original consumer purchase. Proof of original purchase date and return of your appliance is required to obtain service under this Limited. Return of your appliance to us will be done in accordance with our instructions only. Provided that this appliance is operated and maintained in accordance with written operating instructions attached to or furnished with the appliance or published operating instructions on www.instantpot.com.au, Corelle Brands Australia will, in its sole and exclusive discretion, either: (i) repair defects in materials or workmanship; or (ii) replace the appliance. In the event that your appliance is replaced, the Limited Warranty on the replacement appliance will expire 12 months from the date of original consumer purchase.

We remind you the appliance you purchased is for personal use only (not commercial use).

Any modification/alteration or attempted modification/alteration to your appliance will void this Limited Warranty, unless such modification/alteration or attempted modification/alteration was expressly authorised by a Corelle Brands Australia Representative in writing.

This Limited Warranty only covers Corelle Brands Australia's appliances/products and is not extended to any other appliances, products, equipment, components, or devices that you use or may use in conjunction with the Corelle Brands Australia's appliances.

To claim under this Limited Warranty:

1. Contact Corelle Brands Australia at:
Sydney Corporate Park
Level 1, 184 Bourke Road, Alexandria, NSW 2015
Email: sales.australia@instantbrands.com
2. Provide a description of the appliance you believe has malfunctioned due to defective parts or workmanship.
3. If it is necessary for the appliance to be sent to Corelle Brands Australia for repair or replacement, Corelle Brands Australia will send you a pre-paid shipping label and you must send the appliance and your dated sales receipt to Corelle Brands Australia along with the appliance. If you do not have your dated sales receipt, please advise Corelle Brands Australia in advance, and Corelle Brands Australia will attempt to verify your purchase.
4. If Corelle Brands Australia determines that the appliance has malfunctioned due to defective parts or workmanship, and is covered under this Limited Warranty, Corelle Brands Australia will repair and return the appliance, or send you a replacement appliance, at Corelle Brands Australia's cost.
5. Any repaired or replaced appliance will be covered by this Limited Warranty for the remainder of the original warranty period or ninety (90) days following your receipt of the replacement or repaired appliance, whichever is greater.

Warranty

6. If Corelle Brands Australia confirms the appliance has not malfunctioned due to defective parts or workmanship, and/or is in working order, or if proof of purchase is not verified, Corelle Brands Australia reserves the right to return the appliance to you at your pre-paid cost. If this cost is not met, Corelle Brands Australia reserves the right to dispose of the appliance after 45 days' notice to you.

Limitation and Exclusions

To the maximum extent permitted by law, the maximum liability of Corelle Brands Australia, if any, for any allegedly defective appliance or part shall in no circumstances exceed the purchase price of a comparable replacement appliance or part of the same age.

This Limited Warranty does not cover:

Damage resulting from accident, modification/alteration (unless expressly authorised by a Corelle Brands Australia Representative in writing), misuse, abuse, neglect, unreasonable use, use contrary to the written operating instructions attached to or furnished with the appliance or published operating instructions on www.instantpot.com.au, normal wear and tear, commercial use, improper assembly by you or anyone, disassembly by you or anyone, repair by you or anyone, failure to provide reasonable and necessary maintenance, force majeure event including but not limited to fire, flood, acts of God;

Repairs where your appliance is used for other than normal, personal use or when it is used in a manner that is contrary to the written operating instructions attached to or furnished with the appliance or published operating instructions on www.instantpot.com.au ; or

Use of unauthorised parts and accessories, or repairs to parts and systems resulting from unauthorised repairs or modifications/alterations made to your appliance.

The cost of repair or replacement under these excluded circumstances shall be borne by you. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Distributed by Corelle Brands (Australia) Pty Ltd.
Sydney Corporate Park
Level 1, 184 Bourke Road, Alexandria, NSW 2015.
1800 251 643 or (02) 9317 1000.
Email: sales.australia@instantbrands.com

©2022 Corelle Brands (Australia) Pty Ltd.

Distributed by Corelle Brands (Australia) Pty Ltd.

An Instant Brands Company.

Sydney Corporate Park
Level 1, 184 Bourke Road, Alexandria, NSW 2015, Australia.

instantpot.com.au

©2022 Instant Brands LLC.