


TAOTRONICS

Questions or Concerns?
support@taotronics.com



TAOTRONICS
**RECHARGEABLE
FLOOR FAN**



TT-TF013
User Manual

THANK YOU

FOR BEING OUR CUSTOMER



Your purchase is truly appreciated!
We hope you are over-the-moon with our product!

CONTENTS

IMPORTANT SAFETY INSTRUCTIONS	02
ASSEMBLING YOUR FLOOR FAN	05
USING YOUR FLOOR FAN	08
CLEANING AND MAINTENANCE	11
TROUBLESHOOTING	13

01

IMPORTANT SAFETY INSTRUCTIONS

Summon A Cool
Breeze Into Your
Space




DANGER

BEFORE USING THIS APPLIANCE, READ ALL INSTRUCTIONS AND CAUTIONARY MARKINGS IN YOUR USER MANUAL AND ON THE APPLIANCE


READ AND SAVE THESE INSTRUCTIONS



DO NOT touch or hold the power adapter with wet hands.



DO NOT block or cover air flow to or from the fan while in operation.



DO NOT insert fingers or objects through the grille while in operation.

RELATED TO USE

- DO NOT use this fan to ventilate areas where flammable liquids or vapors are used, stored or are present.
- DO NOT attempt to disassemble, repair, modify or replace any part of your product. All servicing should be performed by qualified personnel only.
- Always make sure to place the fan on a flat, level surface before operation.
- Always unplug the appliance before cleaning, making any repairs or servicing, or whenever not in use.
- It is normal that there is noise during operation. If too loud, please set the fan to lower speed.

FOR HOUSEHOLD USE ONLY



Regular Check

HAVE YOUR FLOOR FAN CHECKED REGULARLY FOR ANY SIGN OF MALFUNCTION!

Check if plug, cord or appliance is damaged
Stop using, check FAQ and contact TaoTronics Support Team.

INTENDED USE

- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning the use of the appliance by person responsible for their safety.
- Close supervision is necessary when any appliance is used by or near children. Children should be supervised to ensure that they do not play with the appliance. Cleaning and user maintenance shall not be done by children unless they are older than 8 and supervised.
- Use the appliance only for intended household purposes as described in this User Manual. Any other use is not recommended that may cause fire, electric shock, or injury to persons.

ELECTRICITY SAFETY

- This appliance must be provided with correct voltage via a professionally installed power socket. Make sure the voltage indicated on the label of the appliance is the same as your local supply.
- DO NOT operate the fan with a damaged cord or plug or if the product malfunctions, is dropped or damaged in any manner.
- To reduce the risk of fire or electric shock, DO NOT use this fan with any solid-state speed control device.
- DO NOT incinerate this fan, even if it is severely damaged. The batteries can explode in a fire. Dispose of the fan in accordance with the Disposal instructions.



SPECIFICATIONS

Model	TT-TF013
Fan Size	12 inch
Power Adapter Output	DC30V
Rated Power	24W


02

ASSEMBLING YOUR FLOOR FAN

Summon A Cool
Breeze Into Your
Space



Install Bracket




Attach the bracket to the fan following the arrow direction until hearing a click.

03

USING YOUR FLOOR FAN


Adjustable Fan Angle



- 1 Loosen the thumb screw.
- 2 Adjust the fan angle as desired.
- 3 Tighten the thumb screw.

Summon A Cool
Breeze Into Your
Space

Control Panel




Battery Indicators

- 1) Each one indicates 20%.
- 2) Charging: Blinking on the current battery level.
- 3) Fully Charged: 5 lights turn solid and stop blinking.
- 4) Battery Low: First light on the left is blinking red to remind charging.

Control Knob

- 1) Rotate clockwise to Max to turn on.
- 2) Adjust fan speed
Max: Highest speed
Min: Lowest speed
(+): anti-clockwise to increase speed
(-): clockwise to reduce speed
- 3) Rotate to OFF to turn off.

This fan can be run by battery or power adapter.



1. Remove the rubber stopper.
2. Connect the adapter with the power supply jack.
3. Plug the adapter to a suitable electrical outlet. (operating voltage:100-240V)



WARNING:


- Recharge only with the charger specified by the manufacturer. A charger that may be suitable for one type of battery may create a risk of fire when used with another battery. Do not use the adapter to charge other products.
- Unplug the power adapter when charging is finished and cover power supply jack with the rubber stopper.
- When the fan is run by battery, the fan will shut off if the battery becomes too low. If this happens, use the power adapter to supply power and recharge the battery.
- Do not use the power adapter outdoor. When use the product in damp environment, please make sure the power supply jack is protected by rubber stoppers.

04

CLEANING AND MAINTENANCE

Summon A Cool
Breeze Into Your
Space

Always turn off the fan and disconnect power supply from fan before cleaning.



Wipe grill with a mild soap. Always reinstall the front grill before use.



Clean fan grill periodically with a vacuum cleaner.



For heavy build up, remove the front grill by removing the four screws located in the rear of the fan.



- Always unplug the fan when assembling part, making adjustments, cleaning, performing maintenance, or when the product is not in use. This will prevent accidental starting that could cause serious injury.
- When serving, only use original manufacturer's replacement parts, accessories and attachments. Use of any other parts may create a hazard or cause product damage.
- Do not let brake fluids, gasoline, petroleum-based product, penetrating oils, etc., come in contact with plastic parts at any time. Chemicals can damage, weaken or destroy plastic which may result in serious personal injury.
- Avoid using solvents when cleaning plastic parts. Most plastics are susceptible to damage from various types of commercial solvents and can be damaged by their use. Use dry cloths to remove dirt, dust, oil, grease, etc.
- For greater safety and reliability, all repairs should be performed by an authorized service center



For storage, you may leave the floor fan covered to protect it from dust. Store it in a cool, dry location.

05

TROUBLE- SHOOTING

Summon A Cool
Breeze Into Your
Space

**The fan fails to
power on.**

**Air flow is weak
or slow.**

**Battery fails to
get charged.**

- Ensure fan speed setting is selected.
- Battery power is too low. Use the power adapter to recharge.

- The fan is set to a low speed setting. Adjust to a higher speed setting.
- Airflow is blocked. Remove obstructions.
- Adjust direction of airflow towards the user.

- Ensure the original power charger is used.
- The outlet is worn or damaged. Try another outlet or contact a qualified electrician.

The troubleshooting guide addresses the most common problems. If problems persist, feel free to contact the Customer Support at

support@taotronics.com



WARRANTY AND SERVICE

Thanks for choosing TaoTronics Rechargeable Floor Fan.


This product is covered with TaoTronics product and labor warranty for 12 months from the date of its original purchase.

The warranty will not apply in cases of:

- Accident, misuse, or repairs performed by unauthorized personnel.
- Any unit that has been tampered with or used for commercial purpose.
- Normal wear and tear of wearable parts.
- Use of force, damage caused by external influences.
- Damage caused by non-observance of the User Manual, e.g. connection to an unsuitable mains supply or non-compliance with the instructions.
- Partially or completely dismantled appliances.
- Defects caused by or resulting from damages from shipping or from repairs, service, or alteration to the product or any of its parts that have been performed by a repair person not authorized by TaoTronics.

We can only provide after sales service for products that are sold by TaoTronics or TaoTronics authorized retailers and distributors. If you have purchased your unit from a different place, please contact your seller for return and warranty issues.

※ **Please have your invoice and order ID ready before contacting Customer Support.**



DISPOSAL

- We encourage you to participate in electronics recycling program, so please observe local regulations for proper disposal of discarded electronic products.
- Recycle raw material instead of disposing of as waste. The machine, accessories and packaging should be sorted for environmental-friendly recycling.

FCC COMPLIANCE

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.



support@taotronics.com



www.taotronics.com



Manufacturer: Shenzhen NearbyExpress Technology Development Co., Ltd.
Address: Floor 7, Building E, Galaxy World Phase II, Shenzhen, China



Made In China

尺寸：140*210mm

装订成册

材质：封面120克铜版纸，内页80克书纸

印刷：双色印刷