


MAXOAK®
Laptop Power Bank
K3



After-sale service commitment 12 month warranty
Email:service@kayomaxtar.com
www.kayomaxtar.com/www.maxoak.net/www.maxoak-shop.com
we suggest fully charge our K3 power bank every six months

Product Parameter

Battery: Li-Polymer
Capacity: 36000mAh/133.2Wh
Input: 12-20V/Max 3A
Output: USB1 5V/2.1A
USB2 5V/2.1A
DC 16.8V/4.6A
Input/Output: Type-C PD2.0 5V/9V/12V/15V/20V-3A
Charging Time: 5-8 hours
Life Cycles: ≥1000 times
Working Temperature: 0°C-45°C
Storage Temperature: -10°C-45°C
Product Size: 198X136X26mm

Package Includes



K3 Power Bank ----- X1
K3 charger ----- X1
DC to Macbook T Connector ----- X1
DC to Macbook F Connector ----- X1
Type-C to Type-C Cable ----- X1
Multifunctional Bag ----- X1
Manual ----- X1

Safety Guidelines

- Do not use K3 in damp environment.
- Keep K3 out of children's reach.
- Do not put K3 into the fire or high temperature(above 60 °C) environment.
- Do not bump/beat/shake K3 to avoid damaging the internal circuit.
- Use the original adapter to charge K3.
- Only our company's technicians or authorized maintenance agencies are allowed to disassemble or repair K3.
- Please check the charging voltage of laptop, cell phone first, make sure the charging voltage is consistent with the output voltage of K3.



Product Introduction



- ❶ On-off Function Button
- ❷ Capacity indicating lights
- ❸ Input port: 12-20V/Max 3A
- ❹ Output port: DC16.8V/4.6A
- ❺ Input/Output port: Type C PD2.0
- ❻ Output port: DC5V/2.1A
- ❼ Output port: DC5V/2.1A



Attention Please!


Please do not charge your cell phone (or other 5V USB powered devices) with output port ❹. it may damage your device.

Function instruction

1. K3 supports charging and discharging at the same time.
2. Power on: press "On/Off" button to switch on, Led lights shows current capacity of the power bank.
3. Power off: long press (2s) to switch off.
4. Automatic Power off: K3 will power off automatically after 60 seconds if there is no charging or discharging.
5. LED discharging display:
0~25%: 1st led light (on the left) on
25%~50%: 1st-2nd led light on
50%~75%: 1st-3rd led light on
75%~100%: 1st-4th led light on
Low voltage indicating: When 1st led light (on the left) blinks, please charge the power bank in time
6. LED charging display
0~25%: 1st led light blinks (on the left) blinks
25%~50%: 1st led light on, 2nd led light blinks
50%~75%: 1st-2nd light on, 3rd led light blinks
75%~100%: 1st-3rd led light on, 4th led light blinks
Fully charged: 1st-4th led light on

How to Charge K3 Power Bank

Connect the DC port of the charger to the input port of K3 power bank, and the other end to the wall outlet



Connect one side of the TYPC-C cable to the power bank, the other side to the wall outlet, to charge the power bank




How to use K3 charge digital device

This product has a smart identification function, can charge apple laptops, smart phones and other digital devices, especially devices with Type-C connector.


1. Charge Apple laptop, cell phone

- Two USB output ports: 5V/2.1A, can charge Apple and other brand cell phone and tablet.
- Type-C output ports: cell phone, tablet and laptop with PD 2.0 Type C connector.
- Power bank starts charging automatically when connected with the charging device. Power bank turns off automatically after 60s when disconnected the charging device.



2. How to charge MacBook & Type C devices

- Please check the input voltage of your Macbook carefully to choose the appropriate output port before charging your MacBook.
- Type-C output ports: 5V/9V/12V/15V/20V-3A, can charge 12inch Type-C MacBook, as pic 1 and other Type C PD2.0 C cell phone, tablet, laptop and more.
- Output port: DC16.8V/4.6A, can charge Apple laptop - MacBook with T head or F head, as pic 2.
- Power bank starts charging automatically when connected with the charging device. Power bank turns off automatically after 60s when disconnected the charging device.



Warranty Card

Manufacture Date _____
Sale Date _____
File No. _____
Manufacturer _____

Warranty Instructions

1. 12-months warranty
2. In warranty period, if any quality problem happens, Please contact service@kayomaxtar.com for free service
3. Following situations will go against the warranty terms:
A. Any problems, malfunction or damages due to incorrect using methods or caused by unauthorized disassembly or repair.
B. The damage caused by force majeure, fire and other extreme abnormal conditions.
C. Without the warranty card or the card records is not clear, complete, or without the sales company seal