# FLYCAM Flowline Master Female with Pro Vest (FLCM-FLN-MSTR-FM)

#### Assembly Manual



### What's In The Box

Please inspect the contents of your shipped package to ensure you have received everything that is listed below.

**Note:** If you have purchased **(FLCM-FLN-MSTR-FM)**, you will get a jacket that fits small, medium, and large sizes. If you have purchased **(FLCM-FLN-MSTR-FM-01)**, you will receive a jacket that fits the XL and XXL sizes. The assembly point will remain the same in both jackets.



All rights reserved.

No part of this document may be reproduced, stored in a retrieval system, or transmitted by any form or by any means, electronic, mechanical, photo-copying, recording, or otherwise, except as may be expressly permitted by the applicable copyright statutes or in writing by the Publisher.

#### Flowline Master Female **Setup**

**NOTE:** It is recommended to attach the minimum required (weight 4kg / 9lb )for pulling down the balancing rope to ensure proper operation of your Flycam Flowline system.

 Join section-1 of the support bar to section-2 with a simple push-fit technique.



 Overlap both sides of the vest (chest area) through the provided velcro, then adjust and buckle them up as per your requirements.





 You can stretch or loosen the adjustment strap of the jacket, Then adjust until you find it comfortable as shown in the image.



 Overlap both sides of the vest (waist area) through the provided velcro and buckle them up as per your requirements.





 Adjust or tighten the vest around the waist area through the provided strap.





 Use the strap to adjust the chest Velcro properly, Then adjust until you find it comfortable and you can set the side support adjustment rods according to your body type.

**Note:** The side support adjustable vest rods on the sides enable a comfortable fit for all body types.

• For proper fitting from the shoulder, pull the strap down from the backside, as shown in the image.







 Loosen the knob of the camera hook and attach the camera to it. Tighten the knob to ensure a slip-free connection.





 Attach the vest safety hook to your camera, as shown in the images, for more safety & protection.





 Rotate the tension adjustment knob anti-clockwise to adjust the tension according to the weight of your setup.

**Note:** You can change the spring tension to balance the load placed on the suspension rope by turning the knob on the back of the jacket.

**CAUTION:** Do not release the lever without removing the setup. It may result in severe damage to the camera.





## YOUR FLYCAM FLOWLINE MASTER FEMALE WITH PRO VEST ALL DRESSED UP AND READY TO GO!



(SHOWN WITH OPTIONAL ACCESSORIES)

**Warranty:** We offer one year warranty for our products from date of purchase. Within this period of time, we will repair it without charge for labor or parts. Warranty doesn't cover transportation costs nor does it cover a product subjected to misuse or accidental damage. Warranty repairs are subjected to inspection and evaluation by us.

**Liability:** We are not liable for damage caused by products that we do not supply or from mishandling in transit, accident, misuse, neglect, lack of care of the product, or service by anyone other than our company.

**Contact Us:** In case of any kind of dissatisfaction, please Contact us immediately and we promise our utmost support and care until you use our product.