

■ **Deutsch**

Bei Abweichungen aufgrund der Verwendung außerhalb Deutschlands auf unterschiedlichen Längen- und Breitengraden kann die Waage vom Benutzer kalibriert werden.

- Waage einschalten. Bevor die Waage auf Null geht, Taste »kg/lb« zweimal drücken.
- Taste »kg/lb« gedrückt halten, bis im Display »CAL« erscheint.
- Wenn im Display »5.00« erscheint, Waage mit 5 kg belasten, dann erscheint »ISN« im Display.
- Wenn im Display »10.00« erscheint, Waage mit weiteren 5 kg belasten bis wieder »ISN« angezeigt wird.
- Die Kalibrierung ist beendet, bitte schalten Sie die Waage wieder aus.

English

Depending on the different attitude and latitude, it could be necessary that users should recalibrate the scale.

- Switch on the scale and press button »kg/lb« twice, before the display set to zero.
- Keep button »kg/lb« pressed till »CAL« appears in the display
- Wait till »5.00« will appears, load 5 kg at the scale and wait till »ISN« appears
- Wait till »10.00« will appears, load 10 kg at the scale and wait till »ISN« appears
- Calibration is finished, switch the scale off an on.