



INDEX

- English
- Deutsch
- Français

01 Safety Instructions

READ ALL INSTRUCTIONS BEFORE USING.

Check before Using

Note for Battery

02 Contents

Maintenance Work

03 Using the Nail Drill

Step 1: Insert the drill bit firmly into the drill head.

Step 2: Press the ON/OFF button for 3 seconds to turn on the device.

Step 3: Press the +/- button to accelerate or decelerate the rotation speed between 25 speeds.

Step 4: Press the F/R button twice quickly to switch the rotation direction to forward when the LCD screen shows "F" or reverse when the LCD screen shows "R".

04 ON/OFF Pause/ON F/R Button

Charging

05 Specifications

06 Warranty and Customer Service

01 Problem and Terms of Settlement

Malfunction	Reasons	Solutions
Changing the nail drill bit when the power is on	1. Motor burns out 2. Bearing damages (Load Noise)	Turn off the power by unplugging the nail drill bit
The power is on when not in use	1. Motor burns out	Turn off the power when not in use
Long time, large load work	1. Motor burns out 2. Device lifespan shortens 3. Bearing damages (Load Noise) 4. Handpiece damages	This continuous working time should not be too long when in a heavy load. When the device is working, it should be stopped to make it return to normal temperature.
Insert into a mismatched power supply	1. Motor burns out	According to the device voltage, insert the matching power supply.
Put the power cord at random F/R the power cord	1. Device lifespan shortens 2. Power cord breaks 3. Fire connection 4. Battery to cause short circuit	Do not pull the power cord.
Reduce the original charge intensity	1. Device damages 2. Battery to cause short circuit	Use the original specification charger.
Dust into device	1. Bearing damages (Load Noise) 2. Motor burns out 3. Rotational speed slows down 4. The potentiometer speed regulation fails 5. Handpiece damages	Clean dust; add the special protection of the dustproof hood.
Overcharge	1. Battery lifespan shortens	Not exceed the specified charging time

03 Specifications

06 Warranty and Customer Service

07 Hinweise zur Sicherheit

BITTE LESEN SIE ALLE ANWEISUNGEN VOR DER VERWENDUNG.

08 Hinweise zur Verwendung

Hinweise zur Batterie

Instandhaltungsarbeit

Hinweis zur Verletzung

02 Inhalten

Wiederaufladbarer Nagelfräser*1	USB-Kabel*1
Bedienungsanleitung*1	Schleifband*56
Nagelwächter*1	Nagelbürste*1

03 Wie zu verwenden?

04 Probleme und Lösungen

Fehlbildungen Mögliche Probleme Lösungen

01 Probleme und Lösungen

Fehlbildungen	Mögliche Probleme	Lösungen
Der Nagelbohrer wird während des Betriebes des Geräts erstickt.	1. Motor brennt ab	Schalten Sie das Gerät aus, wenn Sie den Nagelbohrer erstickt.
Das Gerät ist eingeschaltet, wenn es nicht benutzt wird.	2. Lagerrollen (Laute Geräusche)	Schalten Sie das Gerät aus, wenn Sie es nicht benutzen wird.

Fehlbildungen Mögliche Probleme Lösungen

03 Utiliser la Ponceuse à Ongles

Conseils

05 Spezifikationen

06 Garantie und Kundendienst

01 Instructions de Sécurité

02 Contenu

Précautions d'Utilisation

Précautions en Matière de Blessure

02 Contenu

03 Utiliser la Ponceuse à Ongles

Conseils

01 Problèmes et Solutions

Erreur opération	Problèmes pouvant être causés	Mesures de solution
Remplacement de l'embout, interrupteur d'alimentation n'est pas désiré	1. L'alimentation a été brûlée 2. Roulements endommagés (bruit élevé)	Évitez l'alimentation lorsque vous changez l'embout à ongles. Évitez l'alimentation lorsqu'il n'est pas utilisé.
L'alimentation est allumée lorsqu'elle n'est pas utilisée		Utilisez le chargeur d'origine au besoin.

Erreur opération Problèmes pouvant être causés Mesures de solution

Erreur opération Problèmes pouvant être causés Mesures de solution

05 Specifications

06 Garantie & Service à la Clientèle

01 Instructions de Sécurité

02 Contenu

Précautions d'Utilisation

Précautions en Matière de Blessure

02 Contenu