NOTES:	
• This function is supported.	
	which depends on the actual condition of the vehicle.
O This function is not supported.	
▲ This function is the new feature	
Vehicle	BMS
ESQ	\bullet
EX25/EX35	•
EX25/EX37	
EX35	
EX37	•
FX35/FX45	•
FX35/FX50	•
FX35/FX50/FX30d	•
FX37	•
FX37/FX50	•
FX37/FX50/FX30d	•
G20	•
G25/G37 Sedan	•
G35	•
G37	•
130	•
135	•
InfinitiM35/M45	•
InfinitiQ70L	•
JX35	•
M25/M37	\bullet
M25/M37/M56	•
M35h	•
M37	•
M37/M30d	•
M37/M56	\bullet
M37/M56/M30d	\bullet
M45	•
Q40 Sedan	•
Q45	•
Q50	•
Q60	•
Q70	•
QX4	•
QX50	•
QX56	•
QX60	•
QX70	•
QX80	•

INFINITI_V01.15 Diag Function L	ist (Note:For	reference on	1v)	
NOTES:				
 This function is supported. 				
* This function may be supported, which depends on t	he actual con	dition of the	vehicle.	
O This function is not supported.				
▲ This function is the new feature in this version.				
Vehicle	Model Year			
EX25	ALL			
EX35	ALL			
EX37	ALL			
FX30d	ALL			
FX45	ALL			
FX50	ALL			
G20	ALL			
G35	ALL			
G37	ALL			
130	ALL			
135	ALL			
M25/M37	ALL			
M35/M45	ALL			
M37/M56	ALL			
M37/M56/M30d	ALL			
M45	ALL			
Q45	ALL			
QX4	ALL			
QX56	ALL			
Systemlist	EcuInfo.	ReadCodes	EraseCodes	LiveData
Engine	•	•	•	•
Transmission		-	-	
ABS	•	•	•	•
	-			
Air Bag	-		•	
Air Bag Meter/M&A	-		•	
Air Bag	•	•	•	•
Air Bag Meter/M&A SUB Meter EPS/DAST 3	•	•	•	•
Air Bag Meter/M&A SUB Meter EPS/DAST 3 Air Pressure Monitor	•	•	• • • •	•
Air Bag Meter/M&A SUB Meter EPS/DAST 3 Air Pressure Monitor HVAC	• •		• • • • • •	•
Air Bag Meter/M&A SUB Meter EPS/DAST 3 Air Pressure Monitor HVAC BCM	•	•	• • • •	• •
Air Bag Meter/M&A SUB Meter EPS/DAST 3 Air Pressure Monitor HVAC BCM Motor Control	• •		• • • • • • • • • • • • •	• •
Air Bag Meter/M&A SUB Meter EPS/DAST 3 Air Pressure Monitor HVAC BCM Motor Control ICC/ADAS	• •			• •
Air Bag Meter/M&A SUB Meter EPS/DAST 3 Air Pressure Monitor HVAC BCM Motor Control ICC/ADAS All Mode AWD/4WD	• •	• •	• •	• •
Air Bag Meter/M&A SUB Meter EPS/DAST 3 Air Pressure Monitor HVAC BCM Motor Control ICC/ADAS All Mode AWD/4WD E-4WD	• •		• •	• •
Air Bag Meter/M&A SUB Meter EPS/DAST 3 Air Pressure Monitor HVAC BCM Motor Control ICC/ADAS All Mode AWD/4WD E-4WD 4WAS (MAIN)/RAS/HICAS	• •	• •	• • <td< td=""><td>• •</td></td<>	• •
Air Bag Meter/M&A SUB Meter EPS/DAST 3 Air Pressure Monitor HVAC BCM Motor Control ICC/ADAS All Mode AWD/4WD E-4WD 4WAS (MAIN)/RAS/HICAS 4WAS (Front)	• •			
Air Bag Meter/M&A SUB Meter EPS/DAST 3 Air Pressure Monitor HVAC BCM Motor Control ICC/ADAS All Mode AWD/4WD E-4WD 4WAS (MAIN)/RAS/HICAS 4WAS (Front) Difference Lock	0 0		• •	• •
Air Bag Meter/M&A SUB Meter EPS/DAST 3 Air Pressure Monitor HVAC BCM Motor Control ICC/ADAS All Mode AWD/4WD E-4WD 4WAS (MAIN)/RAS/HICAS 4WAS (Front) Difference Lock CAN Gateway	• •		• • <td< td=""><td></td></td<>	
Air Bag Meter/M&A SUB Meter EPS/DAST 3 Air Pressure Monitor HVAC BCM Motor Control ICC/ADAS All Mode AWD/4WD E-4WD 4WAS (MAIN)/RAS/HICAS 4WAS (Front) Difference Lock CAN Gateway Accele Pedal ACT	• •		• • <td< td=""><td></td></td<>	
Air Bag Meter/M&A SUB Meter EPS/DAST 3 Air Pressure Monitor HVAC BCM Motor Control ICC/ADAS All Mode AWD/4WD E-4WD 4WAS (MAIN)/RAS/HICAS 4WAS (Front) Difference Lock CAN Gateway Accele Pedal ACT Brake	0 0			
Air Bag Meter/M&A SUB Meter EPS/DAST 3 Air Pressure Monitor HVAC BCM Motor Control ICC/ADAS All Mode AWD/4WD E-4WD 4WAS (MAIN)/RAS/HICAS 4WAS (Front) Difference Lock CAN Gateway Accele Pedal ACT Brake Chassis Control	0 0	• • <td< td=""><td>• <td< td=""><td>• •</td></td<></td></td<>	• • <td< td=""><td>• •</td></td<>	• •
Air Bag Meter/M&A SUB Meter EPS/DAST 3 Air Pressure Monitor HVAC BCM Motor Control ICC/ADAS All Mode AWD/4WD E-4WD 4WAS (MAIN)/RAS/HICAS 4WAS (Front) Difference Lock CAN Gateway Accele Pedal ACT Brake Chassis Control Adaptive Light	• •		• • <td< td=""><td></td></td<>	
Air Bag Meter/M&A SUB Meter EPS/DAST 3 Air Pressure Monitor HVAC BCM Motor Control ICC/ADAS All Mode AWD/4WD E-4WD 4WAS (MAIN)/RAS/HICAS 4WAS (Front) Difference Lock CAN Gateway Accele Pedal ACT Brake Chassis Control	0 0	• • <td< td=""><td>• <td< td=""><td>• •</td></td<></td></td<>	• • <td< td=""><td>• •</td></td<>	• •

Intelligent Key	•	•	•	
Smart Entrance	•	•	•	•
Auto Slide Door	•	•	•	•
Auto Slide Door Right	•	•	•	•
Auto Back Door	•	•	•	•
Precrash Seatbelt	•	•	•	•
Convertible Roof	•	•	•	•
EV/HEV	•	•	•	•
HV Battery	•	•	•	•
Charger/PD Module	•	•	•	•
PTC Heater	•	•	•	•
Laser/Radar	•	•	•	•
Side Radar Left	•	•	•	•
Side Radar Right	•	•	•	•
Lane Camera	•	•	•	•
Rearview Camera	•	•	•	•
S/Blind Camera	•	•	•	•
Multi Display	•	•	•	•
Multi AV	•	•	•	•
Sonar	•	•	•	•
BSW/Buzzer	•	•	•	•
EHS/PKB	•	•	•	•
IPDM E/R	•	•	•	•
BAC	•	•	•	•
DIU	•	•	•	•
Shift	•	•	•	•
E-SUS	•	•	•	•
ANC	•	•	•	•
Telematics	•	•	•	•
HAS	•	•	•	•
AVM	•	•	•	•
DAST 1	•	•	•	•
DAST 2	•	•	•	•
Cluster	•	•	•	•
PMAS	•	•	•	•
Radio	•	•	•	•
VSP	•	•	•	•
Nats Immu	•	•	•	•
Air Levelizer	•	•	•	•
Motor Assist	•	•	•	•
	-	-	-	-

	INFINITI_V01.15 DPF Func	ction List (Note:For reference only)
NOTES:		
• This function	is supported.	
※ This function i	may be supported, which depends or	n the actual condition of the vehicle.
O This function is not supported.		
▲ This function is the new feature in this version.		
Vehicle	Years	DPF
All vehicle	All years	*

INFINITI_V01.15 ETC Function List (Note:For reference only)		
NOTES:		
● This function is	supported.	
X This function may be supported, which depends on the actual condition of the vehicle.		
O This function is not supported.		
▲ This function is the new feature in this version.		
Vehicle	Years	ETC
All vehicle	All years	*

	INFINITI_V01.15 INJ Fund	ction List (Note:For reference only)
NOTES:		
• This function is	s supported.	
X This function may be supported, which depends on the actual condition of the vehicle.		
O This function is not supported.		
▲ This function is	s the new feature in this versio	n.
Vehicle	Years	INJ
All vehicle	All years	*

INFINITI_V01.15 OIL Function List (Note:For reference only)

NOTES	•
NULES	•

• This function is supported.

X This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

▲ This function is the new feature in this version. Vehicle EX35 ۲ FX35 lacksquareFX45 • FX50 G25 • G35 • G37 • M35 • M37 • M45 M56Q45 QX56 •

<pre>INFINITI_V01.15 SAS Function List (Note:For reference only)</pre>		
NOTES:		
● This function is	supported.	
X This function may be supported, which depends on the actual condition of the vehicle.		
O This function is not supported.		
▲ This function is the new feature in this version.		
Vehicle	Years	SAS
All vehicle	All years	*