

この度は、本製品をお買上げ頂きまして、誠にありがとうございました。

ご購入いただきました商品を末永く安全にご使用いただくために、この取扱説明書をよくお読みいただき内容をご理解いただいた上でご使用下さい。

また、この取扱説明書は必要に応じて、いつでもご確認できるよう保管して下さい。

■設置について

- 商品は平らな場所に水平に設置して下さい。傾斜、段差のある場所など、不安定な場所でのご使用は、転倒、破損、ガタツキの原因となります。
- 室内で使用する場合、エアコン・ストーブなどの冷暖房器の近くや、直射日光が当たる所、高温多湿の場所での設置、使用はしないで下さい。
火災、変色、変形、破損の原因になります。
- フローリングや畳などの表面の傷防止の為に、商品と床の設置場所にカーペットなどを敷く事をお勧めします。
- 新品のうちは塗装臭、接着臭が残っている場合があります。しばらくは換気をし、風通しの良い場所で放置して下さい。

■ご使用上の注意

- この商品は家庭用として企画されたものです。業務用としてのご使用はできません。
- 座る、寝る以外の目的では使用しないで下さい。また、肘掛けや背もたれの上に、腰掛けたり乗ったりしないで下さい。
- ご使用の際、片寄った位置でご使用になるとウレタンや布地等の消耗が均等でなくなります。末永くお使いいただく為にもバランスよくご使用下さい。
- 遊具的なご使用や踏み台代わりに商品の上に立ち上がらないで下さい。転倒、ケガ、破損などの原因になります。
- 極端に湿度の高い場所や濡れた状態でご使用いただくと衣服への色移りやカビ、におい等の発生原因になります。風通しのよい場所でご使用下さい。
- 濃色の為、摩擦により色落ち、色移りします。白や淡色製品と組み合わせての使用は避け下さい。
- 直射日光や照明に長時間照らされると変色する場合があります。
- 背もたれ上部の左右いずれかに過度の荷重を掛けしないで下さい。ギア故障の原因となります。
- ご使用場所によって必要な場合は脚部底面に市販の床保護材をご使用下さい。
- ファスナーは生地をかぶせて仕上げるのに必要な為に使用していますが、開け閉めは出来ません。
- ストレッチ(背伸ばし)運動はしないで下さい。ギア故障の原因となります。

■保守・点検

- お客様による商品の改造、修理は行なわないで下さい。強度が弱くなり、破損、ケガなどの原因になります。
- 製品に使用される塗料や接着剤にはホルムアルデヒドが含まれることがありますので、室内で使用する場合は普段からこまめに換気をして下さい。
換気の際は、2力以上の窓を広く開けたり、換気扇や扇風機を併用することをお勧めします。

■お手入れ方法

- 本製品は洗濯できません。汚れが付着した場合は、硬く絞った布等で軽く拭き取って下さい。硬い布地を使用されますと商品に細かな傷がつくことがあります。
汚れのひどい場合は、市販されている汚れ落としなどをお使い下さい。その際必ず汚れ落としの説明文をよく読みご使用下さい。
汚れ落としの種類、使用方法によっては、シミ等が発生し症状を悪くする恐れがあります。
- 本体は化学雑きん、アルコール、ベンジン、シンナー、除光液などを使用したお手入れは避けて下さい。変色、しみ、塗装剥離などの原因となります。
- 粘着テープを使用したお手入れは、お勧め出来ません。毛羽の抜け落ちや汚れ付着の原因となります。

Thank you for purchasing a Francfranc product.

Please read these instructions carefully for long-term safe use, and keep them for future reference.

■ Environment

- Avoid placing the furniture near cooling/heating equipment or in any place subjected to direct sunlight or high temperatures/humidity to prevent fire, discoloration, deformation or damage.
- Place the furniture on a flat floor and avoid unstable place to prevent falling, damage or rattle.
- It is recommended to lay a carpet under the furniture to prevent scratches on the floor.
- It is recommended to open the window or doors while you're assembling furniture to get a fresh air because there is an odor left from the furniture materials as well as sub-materials.

■ Caution

- This furniture is intended for household use only.
- Please be noted that it may cause wearing breakage if it is used incorrectly.
- Please be noted that it may cause wearing deforming or breakage on seat if it is used incorrectly.
- Do not play with or stand on the furniture. It may cause falling, injury or damage.
- Please be reminded that it may cause mold or odor from mold while it is placed in the air with extraordinary humidity.
- Please be reminded that the dark color may cause the color running from the fabric by rubbing.
- Avoid placing the furniture in any place subjected to direct sunlight, which may cause color change or fading.
- Raised fabric looks dark or light depend on the direction of fabric. Brushing is recommended to adjust the shade of fabric.
- Please do not put too much weight on the upper right or left part of backrest. It will cause a gear breakage.
- Please do not touch the zipper as this is not for opening or closing.
- Please don't do back stretch exercise on the item. It will cause a gear breakage.

■ Maintenance

- Do not remodel/repair the furniture by yourself. The strength of the furniture will decrease and cause damage or injury.
- Please be noted that paintings and adhesives used for this product contain a certain amount of formaldehyde.
It is recommended to ventilate your room frequently if it is used indoors.
It is ideal to leave two or more windows wide open, or use ventilation fan or electric fan at the same time.

■ Cleaning Care Instructions

- This item can't be washed. Wipe clean with a soft well-wrung cloth regularly. Avoid abrasive cloth to prevent scratches.
- Use a commercially available dirt cleaner if the dirt is serious. Read the instruction manuals carefully before applying.
- Avoid using chemically treated cloth, alcohol, benzine, thinner and polish remover to prevent discoloration, stain or peel-off of coating.
- Avoid using sticky tape for maintenance. It may cause fabrics to fall out or get dirty.