IV. Syncing Your Keypad to Your Operator

- Locate the Eagle Chrome series receiver. You may have to remove the operator cover to do so.
- Press and release the black learn button on the receiver. By doing so the LED on the receiver will turn from green to red.
- Enter your 4-digit code on the keypad followed by pressing button A.
- For the second time, enter your 4-digit code on the keypad followed by pressing button A.
- The red light will flash and turn back to green which will indicate that the receiver is now synced with your keypad.

Please follow the same instruction above for syncing your keypad to your channel B operator. Replace any action involving button A with button B

V. Regular Operation

Operating instructions for channel A

- Enter your code followed by pressing button A.
- Note: If more than 4 seconds pass between entering your code and pressing button A, the signal will NOT transmit.

Operating Instruction for Channel B

- Enter your code followed by pressing button B
- Note: If more than 4 seconds pass between entering your code and pressing button B, the signal will NOT transmit.

VI. Resetting Your Password

If your password has been forgotten or lost please follow the instruction below to reset

- Using the key provided, open the lock located at the bottom of the keypad.
- Locate the battery inside and remove it.
- Press and hold any button on the keypad while remounting the battery.
- Once the battery is in place release the button you are holding down on the keypad.
- All 4 LED lights will turn on and then proceed to turn off one by one.
- At this point the password has now been reset back to the factory setting of 0000.
- Note: The keypad will have to be synced to your Eagle Chrome Series receiver after this procedure.

VII. Installation

- It is important to test the functionality and the effective working range before installation.
- The range of the wireless keypad might be reduced 25-30% if the battery is low on power.
- Keep the clear cover closed after each use of the keypad to prevent dust and dirt accumulation.
- Do not install the product near any metal objects otherwise your signal will be shielded

Step 1 – Insert the key inside the lock and turn clockwise
Step 2 – Remove the face plate of the keypad
Step 3 – Locate the 5 open holes and mark them where they need to be fixed
Step 4 – Create 5 holes in area where you will mount the keypad and then install the expansion screws
Step 5 – Insert the 5 metal screws while securing the base to where you are mounting the keypad
Step 6 – Install the cover of the keypad and turn the key counter clockwise to lock.

For any questions please contact us at 800-708-8848 or go to Eagleoperators.com