XBOX

SERIES X

LEVEL UP

BY GAMERS FOR GAMERS

DREAM™
CONTROLLER
MODS GUIDE

MAXFIRE MOD

OVERVIEW

Many features can be used in combination allowing for greater flexibility and a more enhanced gaming experience. Features that conflict are Jump Shot and Drop Shot, these cannot be used together.

DEACTIVATE ALL MOD FEATURES by holding in both thumbsticks and Up or Left on the D-pad as demonstrated below.

HOLD (R) + (L) TAP (⬅) OR (⬆)

RAPID FIRE MODES:

Below are 10 built in modes which each is programed with a specific speed. To change to each mode while Rapid Fire is active:

HOLD (+) FOR 4 SECONDS

THE MAIN LED (MIC LED) WILL FLASH AQUA, THE NUMBER OF TIMES THE LED FLASHES IS EQUAL TO WHICH MODE YOU ARE IN.

You can switch back to any of the previous modes by:

HOLD (LT)(RT) TAP (+)

MODE	SPEED
Mode 1:	7.7sps
Mode 2:	9.3sps
Mode 3:	13.8sps
Mode 4:	16.67sps
Mode 5:	20sps
Mode 6:	16sps
Mode 7:	12sps
Mode 8:	10sps
Mode 9:	7sps
Mode 10:	5sps

FIRING FEATURES

RAPID FIRE:

HOLD (+) WHILE PRESSING (RT)

OR TAP (+) 2 TIMES

REPEAT IN ORDER TO DEACTIVATE

BURST FIRE:

HOLD (+) AND TAP (X)

REPEAT IN ORDER TO DEACTIVATE

AKIMBO FIRE:

HOLD (+) TAP (LT)

REPEAT IN ORDER TO DEACTIVATE

LT & RT BECOME RAPID FIRE

MIMIC FIRE:

HOLD (+) TAP (RT)

REPEAT IN ORDER TO DEACTIVATE

RT BECOMES RAPID FIRE & CONTROLS LT

TACTICAL FEATURES

ADJUSTABLE FAST RELOAD:

HOLD (+) TAP RELOAD BUTTON

REPEAT IN ORDER TO DEACTIVATE

ONCE MOD IS ACTIVATED HOLD THE RELOAD BUTTON UNTIL THE VERY SECOND THE AMMO INDICATOR SHOWS A FULL MAGAZINE THEN RELEASE, REPEAT THIS STEP FOR DIFFERENT WEAPONS

DROP SHOT:

HOLD (+) TAP CROUCH BUTTON (B)

REPEAT IN ORDER TO DEACTIVATE

WHEN RT IS PRESSED & HELD THEN THE CHARACTER WILL AUTOMATICALLY CROUCH & THEN PRONE IF AVAILABLE

JUMP SHOT:

HOLD (+) TAP JUMP BUTTON

REPEAT IN ORDER TO DEACTIVATE

WHEN RT IS PRESSED THEN JUMP WILL ACTIVATE

AUTO SNIPER BREATHE:

HOLD (+) TAP STEADY AIM BUTTON

REPEAT IN ORDER TO DEACTIVATE

WHEN AIMING DOWN SIGHTS SNIPER BREATHE WILL BE AUTOMATICALLY ACTIVATED

QUICK SCOPE:

HOLD (+) TAP

REPEAT IN ORDER TO DEACTIVATE

WHEN AIMING DOWN SIGHTS OF A SNIPER OR SEMI-AUTO WEAPON IT WILL QUICKLY SHOOT ONE BULLET

AUTO RUN:

HOLD (+) TAP SPRINT BUTTON

REPEAT IN ORDER TO DEACTIVATE

ZOMBIES AUTO AIM:

HOLD (+) TAP

REPEAT IN ORDER TO DEACTIVATE
ENABLE AIM ASSIST & TARGET ASSIST IN-GAME SETTINGS
ONLY WORKS WITH ZOMBIES