

CS-501R/CS-502R/CS-503R

|ロダッチポット |ロダッチカプセル |ロダッチオーバル

取扱説明書 ver.1.00

このたびはスノーピーク製品をお買い上げいただき誠にありがとうございます。この製品は、鋳鉄製の小型鍋です。安全にご使用いただくためにも必ずこの取扱説明書をよく読んでからご使用ください。また、読み終わった 後も大切に保管してください。製品は万全を期しておりますが、フィールドでご使用する前に安全な場所で組立、取扱い方法及び付属品の確認をしてください。説明内容で理解できない点及び製品に不具合が確認 された際には、直ちに使用を中止しご購入いただきました販売店様もしくは弊社ユーザーサービスまでお問い合わせください。

セット内容

●セット内容 リッド×1 ポット×1 取扱説明書(本書)×1







CS-503R/コロダッチオーバル



スペック

CS-501R/コロダッチポット

本体/ダクタイル鋳鉄(シリコン耐熱塗装) ズ: 162×130×89(h)mm

(リッド/162×130×32(h)mm、 ポット/162×130×60(h)mm) リッド/220ml、ポット/460ml

●満水容量:リッド/2 ●総 重 量:1.4kg

CS-502R/コロダッチカプセル

質:本体/ダクタイル鋳鉄(シリコン耐熱塗装)

ズ: 282×90×68(h)mm (リッド/282×90×31(h)mm、ポット/282×90×40(h)mm) リッド/330ml、ポット/520ml

●満水容量: リッド/3 ●総 重 量: 1.9kg

CS-503R/コロダッチオーバル

質:本体/ダクタイル鋳鉄(シリコン耐熱塗装)

ズ:242×160×89(h)mm (リッド/242×160×29(h)mm、 ポット/242×160×63(h)mm)

リッド/430ml、ポット/1,130ml ●総 重 量:2.6kg

ご使用の前に よく読んで予測される事故を回避し安全にご使用ください

合に隙間が生じる場合があります。

危険 明らかに生命に関わる重大な事故が予測される行為を示します。

、警告 取扱いを誤った場合、使用者が死亡または重症を追う可能性があることを示します

↑ 注意 ケガや本体破損、物品破損として拡大損害の原因となる行為を示します。

安全上の注意事項

⚠ 危険 明らかに生命に関わる重大な事故が予測される行為を示します。

□直結式のガスストーブ(GS-220を除く)で使用しないでください。輻射熱によりガス缶が爆発する恐れがあります。

取扱いを誤った場合、使用者が死亡または重症を追う可能性があることを示します。

- |傾斜地や不安定な場所での使用は本体の転倒などにつながり重大な事故を招く恐れがありますので避けてください。
- □ | 微索がという文定は多数がでいた。 □燃えやすいもの(タープなど)の下及び近くでの使用はしないでください。火災の原因になります。 □使用中及び使用直後は非常に高温になります。取扱の際はファイヤーサイドグローブ等、難燃性の厚手の手袋及び専用のリフター(CS-310別売)をご使用ください。
- 手袋をしていても濡れた手袋や長時間触れていると火傷をする恐れがあります。また、お子様が触れない様常に注意してください。
-]シングルバーナー(直結式・分離式)で使用しないでください。輻射熱によりテーブル等が高温になる為、火傷及びテーブルのコゲや炎上の恐れがあります。
- □使用するこんろ等の取扱説明書に従ってご使用ください。

/||注意 ケガや本体破損、物品破損として拡大損害の原因となる行為を示します。

- □はじめてご使用になる時は、柔らかいスポンジたわしなどに中性洗剤を付けてよく洗ってください。金属製のたわしや、磨き粉などは使用しないでください。塗装の剥がれや本体の傷
- の原因になります。]本製品は重いので取扱に注意してください。特に使用中や持ち運びの際は周囲に気を配り、落とさない様に注意してください。
- □酸性・アルカリ性の強い食品は調理しないでください。サビの原因となります。 □食材を保存しないでください。サビの原因となります。
- □シリコン耐熱塗装は初回に使用するまでの防錆を目的とした塗装です。初回使用後は洗剤を使わずお湯で洗浄し、よく乾燥させてからオリーブオイル等の植物油をまんべんなく 涂って収納してください
- □長時間の空焼きやそれに近い状態が続くと塗装が焼け飛ぶ場合があります。
- □密閉性の高い収納ケースの中に長期間保管しないでください。結露などによってサビの原因となります。
-]保管の際は高温多湿な場所を避け、通気性の良い場所に保管してください。
-]長時間使用しないと表面に薄いサビが発生する事があります。このような場合は柔らかいスポンジたわしなどで表面の赤いサビを落として使用してください。
- □焚火等の強火で使用することにより変形することがあります。変形してしまった場合、鍋の安定性を損なう可能性があります。あらかじめご了承ください。

メンテナンス方法

使用後は洗剤を使わずに柔らかいスポンジたわしなどを使ってお湯で洗ってください。強い 汚れは水を入れ煮沸させてから洗ってください。 ②洗浄後は火にかけ空焚きをして完全に 水分を取り除き、熱いうちに内・外側をまんべんなく植物油や植物性ショートニングを薄く塗っ

てください。(少量の油を馴染ませた布で拭く程度) ③保管の際は高温多湿な場所を避け、 通気性のよい場所に保管してください。

品質保証について

お買い求めいただきました製品は万全を期してますが、万一不備な点がございましたら、お買い求めの販売店様または弊社に ご相談ください。製品上の欠陥が原因の場合は無償で修理または交換させていただきます。その他の場合は適切な価格で修 理させていただきます。修理、交換の判断は、弊社の裁量によるものとさせていただきます。また、以下の場合は修理できない場合もありますので、予めご了承ください。

- 1.取扱説明書に従わなかったと判断した場合。
- 2.素材の経年劣化による製品の寿命。 3.改造及び粗雑な扱いによる製品の故障。
- 4.不測の事故による製品の故障。
- 5.その他製造上の欠陥以外による製品の故障。
- 6.ゴミやサビによる故障。
- 7.分解したことによる不具合の発生または破損。 8.落下やその他の衝撃による部品の変形や破損による不具合。
- 9.消耗品の劣化、破損、故障及び付随する不具合。 10.他社製品との組合せによる故障。

不明な点やお気付きの点がございましたら、販売店様 または弊社ユーザーサービスまでお問い合わせください。

スノーピークユーザーサービス **0120-010-660** (9:00~17:00) Email:userservice@snowpeak.co.jp

> 株式会社スノーピーク 〒955-0147 新潟県三条市中野原456

> tel:0256-46-5858 fax:0256-46-5860 w w w . s n o w p e a k . c o . j p



CS-501R/CS-502R/CS-503R Micro Pot Micro Capsule

Instruction manual ver.1.00


Thank you for your purchase of Snow Peak products. This product is casted iron small pot. At Snow Peak we enjoy nature and we hope that this product takes you back to the natural side of life. Please read the instruction carefully before use and keep for future reference. Confirm you have received all the necessary components as indicated in the user manual. If product is damaged upon purchase please stop using it immediately and contact Snow Peak customer service or the Snow Peak Dealer where you purchased.

Name of Part

Set included

 $Lid \times 1$ Pot $\times 1$ Instruction manual \times 1 Recipe leaflet \times 1

CS-501R/Micro Pot



CS-502R/Micro Capsule





Specifications		
CS-501R/Micro Pot	CS-502R/Micro Capsule	CS-503R/Micro Oval

Before use Please read the instructions carefully before use to avoid any accident.

This product doesn't require inside wall of the pot to be heated and coated by oil before use because the surface of this product is coated by heat-resistant silicone. \square It is natural that casted iron products have slight warp, and therefore, there might be a slight openings between lid and pot

Danger The following action may result in severe injury and in some cases death.

!\ Warning The following action may result in severe injury.

Caution The following action may result in severe injury or damage to product or valuables.

Cautions for the safety use

• Danger The following action may result in severe injury and in some cases death.

Never use any direct mount gas stove except snow peak two burner stove GS-220 in order to avoid gas explosion caused by radiant heat onto gas canister.

!\ Warning The following action may result in severe injury.

- □ Avoid using this product on unstable ground, or on a slope, or uneven ground. Otherwise, the pot may fall down and it may be resulted in a serious accident.
- \sqsupset Avoid using the pot near or under the things which are flammable such as tarp or tent because it may cause a fire.
- \Box This pot will be extremely hot once it is heated. It is very hot for a while even after use. Use fireside gloves and a lifter(CS-310) for your safety.
- \square Make sure the gloves are not wet, otherwise you might get burnt by heat coming through wet gloves.
- \square Avoid touching hot pot or lid for a long time even putting fireside gloves on, otherwise you might get burnt.
- \square Pay special attention for children not to touch hot pot and lid, and get burnt.
- □Never use single burner gas stove when you cook with this product in order for you to avoid getting burnt or causing a fire burning table top because of the radiant heat.
- \square Follow the instruction manual of the stoves or any kind of heating appliances when you heat this product.

! Caution The following action may result in severe injury or damage to product or valuables.

- □ Wash thoroughly with soft sponge with synthetic detergent before use for the first time. Do not use metal brush or polishing powder in order to avoid
- this product gets damaged or the coating gets peeled off.

 This product is heavy. Handle with care not to drop it when you use it or carry it.
- \square Do not put acidic or alkaline foods into this product to avoid rust.
- \Box Do not store foods in this product. Foods cooked in this product should be removed and store it in a proper container.
- □ A heat-resistant silicone coating is applied to create a rust-resistant layer for storage. After your first use, wash pot with hot water without any soap or detergent then dry completely. Once dry, apply a coat of vegetable oil or olive oil to season before storing.
- \square Heat it a little bit and dry it, then spread oil slightly on this product and store it.
- \Box Be careful not to heat this product for a long time without putting foods or liquid. It may cause a damage to a heat-resistant silicone coating.
- Do not store in an airtight container for a long period of time in order to avoid causing drips and rust.
- □Store it in a well ventilated place and avoid high temperature and humidity.
 □Rusts might be on all over the pot and lid if these are stored for a long time. Wash and remove rusts with soft sponge or brush before use.
- □Please note that cooking over a large open flame such as a campfire can cause deformation of the product (ex. Warping, bulging, etc). If deformed, the pot will lose its stability and may be dangerous to use.

Maintenance

 ${\mathbb D}$ Wash it with soft sponge or brush with warm water without using detergent. When a stain doesn't come off easily, put water into this product and heat it to boil, then wash it up. ②After it's washed up, heat this product to dry it up.

③Spread vegetable oil or vegetable shortening on to the inside and out side wall of this product when it is still very warm. Use only a little bit of oil and spread it with cloth.

Warranty

Snow Peak guarantees its products quality. We have made every effort to insure our products are free from any defect or flaws. In the rare event that you feel this product has a defect or needs repair please contact the Snow Peak customer service or go to your local Snow Peak dealer where you purchased this product. Snow Peak will replace or repair any defect that may have been caused due to manufacturing. Snow Peak will not be able to replace this product if any dameges occurred due to any of the following.

- 1. Damage due to improper handling which is prohibited as shown in instruction.
- 2. Material quality has changed due to aging of product.
- 3. Damage by altering or careless handling.
- 4. Product failure due to user accidents.
- 5. Any damege except with product defects due to manufacturing.
- 6.Damage by dirt and rust.
- 7.Damage by disassembly.
- 8. Deformation and failure of parts damaged by dropping or other similar incidents.
- 9. Product failure due to wear and tear by user.
- 10.Damage caused by use with other products.

Snow Peak Inc. A Corporation of Japan 410 NW 14th Ave., Portland Oregon, 97209 , USA TEL:+1-503-697-3330 FAX:+1-503-699-1396

MADE IN JAPAN