

ESC-003
クリスタルシェード

この度は、スノーピーク製品をお買い上げいただき、誠にありがとうございます。本製品はランタンシェードです。取扱説明書をよく読み、安全にご使用ください。また、読み終わった後も大切に保管してください。説明内容で理解出来ない点及び製品に不具合が確認された際は直ちに使用を中止し、ご購入いただきました販売店様もしくは弊社ユーザーサービスまでお問い合わせください。

スペック

- サイズ: φ81×57(h)mm
- 材質:シリコーンゴム
- 重量: 52g

対応品番

本製品は以下の品番に取り付けることができます。
(ES-041 WH・GR・BR) たねほおずき ゆき/もり/つち/
(ES-070 WH・GR・BR) ほおずき ゆき/もり/つち/

安全上の注意事項 ご使用前によく読んで予想される事故を回避し安全にご使用ください。

△ 注意 ケガや本体破損、物品破損として拡大被害の原因となる行為を示します。

- ご使用の前に、本製品を点検し各部に異常がないことを確認してください。異常が発見された場合は、直ちに使用を中止しお買い求めいただいた販売店様、または弊社ユーザーサービス係に点検または修理を依頼してください。
- 本製品の取り付け方法に関してはES-041たねほおずき/ES-070ほおずきの取扱説明書に記載されております電池の入れ方をお読みください。
- 本製品はランタンシェードです。製品本来の用途以外では使用しないでください。
- 本製品を、燃焼式のランタンやコンロ、ヒーターなどの熱源や、マッチ、ローソク、ライター、タバコなどの裸火や炎のそばに置かないでください。製品破損の原因になります。
- 本製品を直射日光など強い光に当て続けると変色したり、変形したりする場合があります。あらかじめご了承ください。
- 乳幼児や小さいお子様の手の届かない場所で保管してください。
- 本製品を幼児だけのご使用は絶対にお避けください。お子様がご使用になる場合は必ず大人と一緒に安全にご使用ください。
- 本製品はたねほおずきとほおずきを同時に取り付けないでください。
- 鋭利な物や硬い物との接触を避けてください。キズや破損の原因となります。
- 製造時に発生する酢のようなにおいがありますが、人体には影響なくお使いいただけます。
- 本製品はシリコン製です。本製品に変形する力が掛かったまま保管しないでください。変形するおそれがあります。

お手入れ方法

- 粉塵やほこりは硬く絞った柔らかい布で水拭きしてください。クレンザー、金属製のたわしや磨き粉は、本体をキズつける原因になりますので使用しないでください。
- ご使用後は汚れを早めに落とし、十分に乾燥させ、高温多湿の場所を避けて保管してください。
- シミの原因となりますので、シンナー、ベンジンなどの溶剤、漂白剤、クレンザーやアルカリ性洗剤は使用しないでください。

品質保証について

お買い求めいただきました製品は万全を期していますが、万一不備な点がございましたら、お買い求めいただいた販売店様もしくは弊社または各製品に記載された連絡先にご相談ください。製造上の欠陥が原因の場合は無償で修理または交換させていただきます。その他の場合は適切な価格で修理させていただきます。修理、交換の判断は弊社の裁量によるものとさせていただきます。また、以下の場合は修理できない場合もありますので予めご了承ください。

1.素材の経年劣化による損害など商品の寿命 / 2.改造および粗雑な取扱いによる故障 / 3.取扱説明書で禁止されている取扱いによる故障 / 4.不測の事故による商品の故障 / 5.その他製造上の欠陥以外による製品の故障 / 6.ゴミやさびによる故障 / 7.分解したことによる不具合の発生または破損 / 8.落下やその他の衝撃による部品の変形や破損による不具合 / 9.摩擦によるパーツの変化及びそれによる故障 / 10.他社製品との組み合わせによる故障

修理について

- 本格的な修理が必要な場合は、お買い求めになった販売店様または弊社ユーザーサービスまでお問い合わせください。
 - 修理を依頼される場合は、必ず十分に乾燥させ、汚れをきれいに落としてください。
 - 修理品には修理箇所がはっきりと解るように、必ずメモまたは荷札を付けてください。また破損時の状況をできるだけ詳しく書いたメモを添えてください。
 - 修理品の運賃並びに修理費については以下のように規定させていただきます。
- 1.保証対象の場合/往復運賃並びに修理費は弊社にて負担いたします。
 - 2.保証対象以外の場合/往復運賃並びに修理費は、お客様のご負担とさせていただきます。

ESC-003 Crystal Shade

Thank you for purchasing a Snow Peak product. This product is a lantern shade. For safety, read the following instruction manual before use. Please keep it safe for future reference. Finally, if you find anything that you do not understand in the description or any problems with the product, please stop use immediately and contact the retailer or Snow Peak Customer Service.

Specifications

- Size: dia. 81x57(h)mm / dia. 3.2" x 2.2"(h)
- Material: Silicone Rubber
- Weight: 52g / 1.8 oz

Supported Item Code

This product can be installed in the following item.
(ES-041 WH / GR / BR) MINI HOZUKI Snow / Green / Bark /
(ES-070 WH / GR / BR) HOZUKI Snow / Green / Bark /

Safety Precautions: Before use, please read thoroughly to ensure safety and avoid accidents.

⚠ CAUTION / Misuse could result in injury to the user and/or damage to property.

- Before using the product, check each part for abnormalities. If there are abnormalities, take the product to the dealer or Snow Peak Customer Service for inspection or repair.
- For the installation method of this product, please refer to the instruction manual of ES-041 Mini Hozuki / ES-070 Hozuki.
- This product is a lantern shade. Do not use this product for anything other than its intended purpose.
- Do not place this product near a source of heat such as a combustion lantern, stove, or heater, or near open flames such as matches, candles, lighters, or cigarettes. It may damage the product.
- If this product is continuously exposed to strong light such as direct sunlight, it may discolor or deform. Please understand in advance.
- Please keep out of reach of small children.
- Please do not use this product by children only. When used by children, be sure to use safely with an adult.
- Do not install Mini Hozuki and Hozuki on this product at the same time.
- Avoid contact with sharp or hard objects. It may cause scratches or damage.
- There may be a smell like vinegar generated during the manufacturing process, but it can be used without affecting the human body.
- This product is made of silicone. Do not store the product under deforming force. It may deform.

How to care

- Wipe dust and dirt with a soft, tightly wrung cloth. Do not use cleanser, metal scrubbing brush or polishing powder as it may damage the body.
- After use, remove dirt as soon as possible, dry thoroughly and store away from high temperature and humidity.
- Do not use solvents such as thinner or benzine, bleach, cleanser or alkaline detergent as it may cause stains.

Warranty

Snow Peak has taken all possible measures to ensure every product is durable and functions correctly. If you find any product defects, please contact the retailer where you purchased the product or Snow Peak Customer Service. If there are apparent defects in the product's manufacturing, the defective product will be repaired or exchanged free of charge. In other cases, Snow Peak will repair the product for an appropriate fee. The decision to repair or replace the product will be at our discretion. Snow Peak will not repair the product for any damage that occurred due to the following:

1. Material deterioration caused by age / 2. Damage caused by modifications or rough handling / 3. Damage caused by inappropriate use not mentioned in the instruction manual / 4. Damage caused by unexpected accidents / 5. Any damage other than defects in the manufacturing process / 6. Damage caused by dust or rust / 7. Damage and defects caused by dismantling the product / 8. Damage and defects caused by dropping, jolting or other shocks / 9. Deterioration or failure of parts due to friction / 10. Damage caused by the use of the product in combination with another manufacturer's products

Repair

- For repairs, please contact the retailer where you purchased the product or Snow Peak user service.
- When you ask for repair, please make sure that the product is dry and clean.
- Please attach a memo or some kind of tag indicating the needed repair, and please write details of when and how the damage occurred.
- Shipping cost and repair fee for the repair as follows.
 1. Within warranty: Return shipping cost and repair fee will be covered by Snow Peak
 2. Outside warranty: Return shipping cost and repair fee will be covered by the user.