BUTTONS LAY-OUT SCHEMA PULSANTI

BUTTONS FUNCTION TABLE SCHEMA DI FUNZIONAMENTO DEI PULSANTI

Type	PS2® Digital	PS2® / Analog	PS2® / Neg	PS3™	PC
Action buttons	X	X	RY	X	3
	○	○	A	○	2
	□	□	LX	□	4
	△	△	B	△	1
	R1	R1	R1	R1	6
	L1	L1	LY	L1	5
	R2	R2	R1	R2	8
	L2	L2	LY	L2	7
	/	R3	/	R3	12
	/	L3	/	L3	11
D-PAD	UP	UP	UP	UP	↑
	DOWN	DOWN	DOWN	DOWN	↓
	LEFT	LEFT	LEFT	LEFT	←
	RIGHT	RIGHT	RIGHT	RIGHT	→
Function button	START	START	START	START	10
	SELECT	SELECT	/	SELECT	9
	←/→	LX	RX	LX	←/→
LEFT Wing	□	□	LX	□	4
RIGHT Wing	X	X	RY	X	3
LEFT Pedal	□	□	LX	□	4
RIGHT Pedal	X	X	RY	X	3
MODE / PS button	MODE	MODE	MODE	PS	/

ver. 3.0

NITHO™

NITHO DRIVE PRO

for PS3™, PS2® and PC

INSTRUCTION MANUAL
MANUALE D'ISTRUZIONI

WWW.NITHO.COM

ENGLISH

Thank you for having selected NITHO PS3™ DRIVE PRO and welcome in the fantastic World of Nitho.
NITHO PS3™ DRIVE PRO is a professional wheel 100% compatible with PSX®, PS2®, PS3™ and PC.

SPECIFICATIONS

- Four LEDs indicate the selected channel, when used with PS3™
- PS button for setting on PS3™ console
- Compatible with all PS3™ and PS2® consoles (USA, Japan and European versions)
- 4 analog inputs D-pad: UP / DOWN / LEFT / RIGHT
- 6 analog input function buttons: X,○,□,△, L1, R1
- 6 digital input function buttons: START, SELECT, L2, R2, L3 and R3
- 3 function modes for PS2®: DIGITAL / ANALOG / NEG
- Vibration function on all the platforms (on PS3™ with PS3™ games supporting vibration function)

HOW TO USE THE NITHO DRIVE PRO WITH PS3™

HOW TO CONNECT THE WHEEL TO THE CONSOLE

1) Connect the wheel to PS3™ console
2) Power on the PS3™ console. All the LEDs will flash
3) Press PS button for establishing the connection with the PS3™ console.

OPERATION METHOD: CHANNEL SELECTION

1. After having connected the wheel to the PS3™ console, all the LEDs will flash. Press PS button to select the channel and establish the connection with the console. The LEDs will stop to flash and only one LED will light indicating the selected channel.
2. Press and keep pressing the PS button for more than two seconds to enter into setup menu. Digital mode will be not active and analog mode will be active

The LEDs will display the selected channel as below:
LED 1 to 4 = Player 1 to 4
LED 1 + 4 = Player 5
LED 2 + 4 = Player 6
LED 3 + 4 = Player 7

Remarks: Every time you plug or unplug the USB connector of the wheel or you restart the PS3™ console, you should press the PS button for starting.

HOW TO USE THE NITHO DRIVE PRO WITH PS2®

1. Connect the wheel to the PS2® console utilizing the PS2® dedicated plug.

HOW TO USE THE NITHO DRIVE PRO WITH PC

1. System Requirements:
   a) USB Port
   b) Windows98/ME/2000/XP/Vista
   c) DirectX 7.0 version or up
2. Installation
   a) Install the driver on the CD provided with the wheel following the instruction on the screen
   b) Connect the wheel to the USB port of your PC
   c) In the CONTROL PANEL, click on GAME CONTROLLER. Then "LS-USBMX1/2/3 STEERING…" will be displayed
3. Testing
   a) Go on PROPERTY to enter in the test page
   b) Test the wheel rotation, buttons 1 to 12 and POV with the D-PAD.
   c) In the EFFECT PAGE, you can test the vibration of the right motor using the left/right wing. To test the left motor rotate the wheel.

PROGRAM FUNCTION (Reset at the end of each session)

Programmable buttons are: X,○,□,△, L1, L2, R1 ,R2.
Buttons that can be remapped: Left and Right Wing, Foot Pedals, L3, R3.
The buttons cannot be programmed in NEG mode.
1. Press SELECT+START for more than 3 seconds, the green LED will be on
2. Press a button you want to remap. The green LED will start to blink
3. Press a programmable buttons. The green LED will be off

PROGRAM RESET

1. To delete the program, press and hold SELECT+START for more than 3 seconds, so that the green LED is on.
2. Press and hold START buttons for 4 seconds. The wheel will be back to default mode.

SENSITIVITY ADJUSTING

1. Press and hold SELECT+START buttons for 3 seconds, so that the green LED is on
2. Press SELECT to cycle through the levels:
   Lowest: green LED will flash slowly
   Middle: green LED will be on
   Highest: green LED will flash quickly
3. Press up direction on the D-PAD to exit from the sensitivity adjusting function.

ITALIANO

Grazie per aver scelto NITHO PS3™ DRIVE PRO e benvenuto nel fantastico mondo di Nitho.
NITHO PS3™ DRIVE PRO è un volante professionale totalmente compatibile con PSX®, PS2®, PS3™ and PC.

CARATTERISTICHE

- Quattro LED segnalano il canale selezionato, quando il volante è utilizzato con PS3™
- Pulsanti PS per la configurazione sulla console PS3™
- Compatibile con tutte le console PS3™ e PS2® (versioni USA, Giappone ed Europa)
- 4 D-pad analogici: SOPRA / SOTTO / SINISTRA / DESTRA
- 6 pulsanti analogici: X,○,□,△, L1, R1
- 6 pulsanti digitali: START, SELECT, L2, R2, L3 ed R3
- 3 modalità di funzionamento per PS2™: DIGITAL / ANALOG / NEG
- vibrazione disponibile su tutte le piattaforme (su PS3™ richiede giochi per PS3™ con supporto alla vibrazione)

COME FUNZIONA IL NITHO DRIVE PRO CON PS3™

COME COLLEGARE IL VOLANTE ALLA CONSOLE

1) Collega il volante alla console PS3™
2) Accendi la PS3™. Tutti i LED lampeggeranno
3) Premi il pulsante PS per stabilire la connessione con la PS3™

MODALITA' OPERATIVA: SELEZIONE DEL CANALE

1. Dopo avere collegato il volante alla PS3™, tutti i LED lampeggeranno. Premi il pulsante PS per selezionare il canale e stabilire la connessione con la console. I LED smetteranno di lampeggiare e solo uno di loro indicherà il canale selezionato.
2. Tieni premuto il pulsante PS per più di due secondi per entrare nel menu di configurazione. La modalità digitale non sarà attiva: solo quella analogica sarà attiva.

I LED mostreranno il canale selezionato come da indicazioni qui sotto:
LED 1 to 4 = Giocatore da 1 a 4
LED 1 + 4 = Giocatore 5
LED 2 + 4 = Giocatore 6
LED 3 + 4 = Giocatore 7

Attenzione: ogni volta che inserisci o togli il connettore USB del volante o riavvii la PS3™, dovrai premere il pulsante PS per iniziare a giocare.

COME FUNZIONA IL NITHO DRIVE PRO CON PS2®

1. Collega il volante alla PS2® utilizzando il connettore PS2® dedicato.

COME FUNZIONA IL NITHO DRIVE PRO SUL PC

1. Requisti di sistema:
   a) porta USB
   b) Windows98/ME/2000/XP/Vista
   c) DirectX 7.0 o superiore
2. Installazione
   a) Installare i driver sul CD fornito nella confezione seguendo le istruzioni sullo schermo
   b) Collegare il volante al PC
   c) Sul PANNELLO DI CONTROLLO, cliccare su PERIFERICHE DI GIOCO. Apparira' "LS-USBMX1/2/3..."
3. Test
   a) Andare su PROPRIETA' per entrare nella pagina dei test
   b) Testare la rotazione del volante, i pulsanti da 1 a 12 e i POV tramite il D-PAD.
   c) Nella EFFECt PAGE, si puo' testare il motore destro usando le alette destra/sinistra. Per testare il motore sinistro basta ruotare il volante.

PROGRAMMAZIONE DEI PULSANTI (Si cancella ad ogni sessione)

I pulsanti programmabili sono: X,○,□,△, L1, L2, R1 ,R2.
I pulsanti rimappabili L3, R3, alette destra e sinistra e la pedaliera. Non si possono programmare in modalita' NEG.
1. Premere SELECT+START per piu' di 3 secondi, cosi' da accendere il LED verde.
2. Premere il pulsante che si vuole rimappare. Il LED verde lampeggera'
3. Premere un pulsante programmabile. Il LED verde si spegnera'

CANCELLARE LA PROGRAMMAZIONE

1. per cancellare la progammazione, tenere premuti SELECT+START, cosi' da accendere il LED verde.
2. Tener premuto il pulsante START per 4 secondi. Il volante tornera' alla modalita' di default.

REGOLAZIONE DELLA SENSIBILITA'

1. Tener premuti SELECT+START per 3 secondi, cosi' da accendere il LED verde
2. premere SELECT per scorrere tra i livelli:
   Bassa: il LED verde lampeggera' a lenti intervalli
   Media: il LED verde rimarra' fisso
   Alta: il LED verde lampeggera' a veloci intervalli
3. Premere verso su il D-PAD per uscire dalla regolazione della sensibilita'.