LIQUID EARS

WIRELESS + WIRED
HEADPHONES

LEWTV4M

Specifications:
Driver Size: 40mm
Impedance: 32 Ohm
Sensitivity: 93dB ± 3dB at 1kHz
Frequency Response: 20Hz - 20kHz
Wireless Range: 10m
Play Time: 12 Hours
Battery Size: 250mAh
Charge Time: 2.5 Hours

Included:
1 x Wireless Headphone
1 x USB to USB-C charging cable
1 x 3.5mm Audio cable - 4 metres

Battery Charge:
This wireless headphone is powered by a rechargeable Li-ion battery.
When the battery is low the headphones will emit a sound to remind you to recharge it.

1. Insert USB charging cable into a suitable USB port for charging.
2. Connect the USB charging cable with the USB-C port on the headphone.
3. The LED indicator turns red to show battery is charging.
4. The LED indicator turns blue when battery is fully charged.
5. It takes about 2.5 hours to fully charge the headphone.

How to use this Headphone:

A. Power ON/OFF

Function	Operation	LED indicator
Power ON	Slide towards the ON side	LED indicator turns blue and the headphone issues a voice prompt 'Power On'
Power OFF	Slide towards the OFF side	LED indicator flashes red, then goes out and headphone issues a voice prompt 'Power Off'

B. Pairing the Headphone

1. When the headphone is switched on, it automatically enters pairing mode and the LED indicator will flash blue and red. A voice prompt "The bluetooth device is ready to pair" can be heard.

2. On your device search for the pairing name: LEWTV4M
Once connected the voice prompt 'The bluetooth device is connected successfully' can be heard.

   (Note: The headphones can also be connected directly via the 3.5mm audio cable).

Overview:

1. Power button
2. USB-C charging port
3. Built-in microphone
4. 3.5mm Audio cable port
5. LED indicator
6. Decrease volume/Previous track
7. Pairing/Play/Pause/Answer call/End call/Reject call
8. Increase volume/Next track

Function	Operation
Pause	Press button (7)
Play	Press button (7)
Next Song	Press and hold button (8)
Previous Song	Press and hold button (6)
Volume Up	Press button (8)
	When the volume is
	adjusted to maximum you
	will hear an indication tone
Volume Down	Press button (6)
Answer Call	Press button (7)
End Call	Press button (7)
Reject Call	Press and hold button (7)
	for 2 seconds

For WIRED connection to TV:

If your TV has a 3.5mm headphone jack, just plug the supplied 3.5mm cable into your headphones and the other end into the headphone ouput jack on your TV. If your TV doesn't have a 3.5mm jack, but has RCA stereo outputs, you will need to get an RCA-to-3.5mm adapter and use your headphones that way.

For WIRELESS connection to TV:

Follow your TV manual on how to add a bluetooth device (headphone) to the list of connected devices. When searching to add device - make sure that the headphone is in pairing mode (as per previous instruction) and you are looking for the name "LEWTV4M" in the list.

Once a connection (either wired or wireless) is established with the TV you are most likely going to have to go into your TV settings and adjust where the audio is sent to.

Every TV is different, so please consult your TV manual to go into your TV settings and make sure

that the audio output is going to the right place. Most manufacturers will have the option of the audio going to one of the following:

1. TV Speakers (Default)

2. TV Speakers + Headphone

3. Headphone

4. Bluetooth - Wireless Speaker / Headphone

5. TV Speakers + Wireless Speaker / Headphone

6. HDMI or Optical Output

Select the option that suits your situation and now the audio should be coming through the headphone.

Volume Adjustment:

If using a wireless connection to the TV, you can adjust the volume by using the controls on your headset.

If using the 3.5mm cable to connect to the TV you will need to control the volume via the TV.