

witchBot ボット 取扱説明書



七

-

訛里

- The diagram illustrates the installation process. On the left, a grey rectangular object representing a wall or surface is shown with a red arrow pointing to it. An arrow points from this surface to a larger diagram on the right. This larger diagram shows a white rectangular frame representing a recessed area in a wall. Inside this frame, there is a horizontal barcode-like pattern and a small white square labeled "SwitchBot". A red arrow points from the "SwitchBot" label to a smaller diagram at the bottom right. This smaller diagram shows a white rectangular device standing upright. A red arrow points from the text "両面テープの貼付位置" (Double-sided tape application position) to the bottom edge of the device, where a dashed red arrow indicates the direction of application.

スクエアスイッチ

- ボットヘルパーに貼り付けます。

両面テープの貼付位置

②

ボットの設定画面の「詳細設定」から操作モードを変更できます。

「押す」モード：ボットが「押す」動作を実行します。

「スイッチ」モード：ボットが「押す」「引き上げる」動作を実行し、スイッチのオン・オフができます（「スイッチモード専用パーツ」を使う必要あり）。

mbot.jp

