

EPEIOS



取扱説明書 | User Guide
EPEIOS Hummingbird コールドブリューメーカー | Cold Brew Electric Coffee Maker
Model: EPC0800

目次

安全にご使用いただくために.....01
効果に影響が出たり、故障の原因になったりすることがありますので、家庭用電源が適切かどうか確認してください。
高温の場所での使用や保管はしないでください。
使用しない時や本製品を洗浄する際は、電源を切ってください。
本製品は、テーブルの上や平らな場所に置くようにしてください。また、USB充電ケーブルをテーブルやカウンターの端におろさないでください。
充電する際は、メインユニット以外に付けたままの充電はしないでください。
内蔵電池式なので、本製品は低湿度な環境で保管してください。
本製品の破損や人身事故、危険の原因となりますので、付属品以外のパーツなどを使用しないでください。
8. 運転開始前に本体を含むパーツを全て組み立ててから、スイッチを押してください。
9. カップには定格容量の範囲内で水を入れてください。
10. 本製品に不具合がある場合、またはその他の原因で正常に動作しない場合において、自分で分解しないでください。危険を避けるため、購入した店舗またはカスタマーサポートにお問い合わせください。
11. 電源コードが破損した場合は、メーカーまたはカスタマーサポートにお問い合わせください。
12. 以下に該当する方は取扱いに注意が必要です。
---身体的、感覚的、または精神的な障碍をお持ちの方(子どもを含む)、またはその使用に関する経験や知識が不足している方は、当人の安全に責任を負う人が監督または指示していない場合において本製品を使用しないようしてください。
---お子様が本製品で遊ばないよう、必ず保護者の方が監視してください。
---器具の洗浄とお手入れは、保護者の方がいない子どものみで行わないでください。
---使用していない時やお手入れ中は、本機の電源を切り、子どもが手に取って遊んでしまわないようご注意ください。

Contents

Important Safety Cautions.....09
Get to Know the Product.....10
Specifications.....10
How to install.....11
How to Use.....12
Cleaning and Maintenance.....15
Troubleshooting Guide.....15
Warranty Card.....16

目次

安全にご使用いただくために.....01
効果に影響が出たり、故障の原因になったりすることがありますので、家庭用電源が適切かどうか確認してください。
高温の場所での使用や保管はしないでください。
使用しない時や本製品を洗浄する際は、電源を切ってください。
本製品は、テーブルの上や平らな場所に置くようにしてください。また、USB充電ケーブルをテーブルやカウンターの端におろさないでください。
充電する際は、メインユニット以外に付けたままの充電はしないでください。
内蔵電池式なので、本製品は低湿度な環境で保管してください。
本製品の破損や人身事故、危険の原因となりますので、付属品以外のパーツなどを使用しないでください。
8. 運転開始前に本体を含むパーツを全て組み立ててから、スイッチを押してください。
9. カップには定格容量の範囲内で水を入れてください。
10. 本製品に不具合がある場合、またはその他の原因で正常に動作しない場合において、自分で分解しないでください。危険を避けるため、購入した店舗またはカスタマーサポートにお問い合わせください。
11. 電源コードが破損した場合は、メーカーまたはカスタマーサポートにお問い合わせください。
12. 以下に該当する方は取扱いに注意が必要です。
---身体的、感覚的、または精神的な障碍をお持ちの方(子どもを含む)、またはその使用に関する経験や知識が不足している方は、当人の安全に責任を負う人が監督または指示していない場合において本製品を使用しないようしてください。
---お子様が本製品で遊ばないよう、必ず保護者の方が監視してください。
---器具の洗浄とお手入れは、保護者の方がいない子どものみで行わないでください。
---使用していない時やお手入れ中は、本機の電源を切り、子どもが手に取って遊んでしまわないようご注意ください。

Contents

Important Safety Cautions.....09
Get to Know the Product.....10
Specifications.....10
How to install.....11
How to Use.....12
Cleaning and Maintenance.....15
Troubleshooting Guide.....15
Warranty Card.....16

安全にご使用いただくために

使用前に取扱説明書をよく読み、大切に保管してください
1. 効果に影響が出たり、故障の原因になったりすることがありますので、家庭用電源が適切かどうか確認してください。
2. 高温の場所での使用や保管はしないでください。
3. 使用しない時や本製品を洗浄する際は、電源を切ってください。
4. 本製品は、テーブルの上や平らな場所に置くようにしてください。また、USB充電ケーブルをテーブルやカウンターの端におろさないでください。
5. 充電する際は、メインユニット以外に付けたままの充電はしないでください。
6. 内蔵電池式なので、本製品は低湿度な環境で保管してください。
7. 本製品の破損や人身事故、危険の原因となりますので、付属品以外のパーツなどを使用しないでください。
8. 運転開始前に本体を含むパーツを全て組み立ててから、スイッチを押してください。
9. カップには定格容量の範囲内で水を入れてください。
10. 本製品に不具合がある場合、またはその他の原因で正常に動作しない場合において、自分で分解しないでください。危険を避けるため、購入した店舗またはカスタマーサポートにお問い合わせください。
11. 電源コードが破損した場合は、メーカーまたはカスタマーサポートにお問い合わせください。
12. 以下に該当する方は取扱いに注意が必要です。
---身体的、感覚的、または精神的な障碍をお持ちの方(子どもを含む)、またはその使用に関する経験や知識が不足している方は、当人の安全に責任を負う人が監督または指示していない場合において本製品を使用しないようしてください。
---お子様が本製品で遊ばないよう、必ず保護者の方が監視してください。
---器具の洗浄とお手入れは、保護者の方がいない子どものみで行わないでください。
---使用していない時やお手入れ中は、本機の電源を切り、子どもが手に取って遊んでしまわないようご注意ください。

製品紹介

メインユニット(本体) フィルター ストレーナー 携帯用フタ

1. カップ: 水や牛乳などの液体を入れる容器です。容量は220ml-350mlです。
2. メインユニット(本体): フィルターとストレーナーに接続し、加圧と減圧を繰り返す装置です。
3. フィルター: コーヒー粉、茶葉、その他の材料を入れる容器です。材料の上層はMAX線までです。
4. ストレーナー: 水や砂糖などの調味料を入れることができます。ストレーナーに入れられる調味料は最大で半分程度が目安になります。
5. 携帯用フタ: 本体と組み合わせて飲み口となり、持ち運び用のカップにすることができます。※密封力は真ん中のみ、バッキングに入れて持ち運ぶとこぼれる場合があります。

ボタン操作の説明

1. ボタンを押して電源をオンにする。メインユニットのインジケータランプが点灯します。
2. 充電モードではインジケータランプが点滅します。
3. 充電が完了するとインジケータランプが点灯します。
4. 電池が足りなくなると点滅がなくなり、スイッチタッチのLEDライトが点滅して充電するようお知らせします。

製品仕様

製品名	EPEIOS Hummingbird コールドブリューメーカー
モデル	EPC0800
定格使用電圧	DC3.7V
電源	アダプター入力 100-220V 50/60Hz 出力 DC 5V1A
電池容量	900mAh
定格カップ容量	液体容量350ml(材料容量Max線まで(材料により重量は変動))
サイズ	φ55x85
カップ耐熱温度	50℃まで 50℃以上の液体は使用しないでください
抽出濃度	4~0.8PPM
製品重量	0.54kg

取り付け図

本体 ストレーナー フィルター 上部カップ カップボディ

ステップ1 本体 ストレーナー

ステップ2 ストレーナー フィルター

ステップ3 上部カップ カップボディ

ステップ4 本体

製品の使用方法

初期使用時

1. 初めてお使いになる際は、メインユニット以外のパーツを食用洗剤で洗い、水でしっかり洗っていただきます。メインユニットは濡った布で拭くのみとし、水に浸けないようにしてください。
2. 製品を初めてお使いになる前に、しっかりとフル充電したうえで、食品が触れる部分は十分に洗浄してください。

充電モード

1. 定格出力5V=1Aのアダプターに磁気充電ケーブルを差し込み、充電ケーブルの磁気ヘッドをメインユニットに取り付けて製品を充電してください。最初の充電は完全に充電するのに約2時間かかります(図1)。
※磁気ヘッドは正しい向きでなければ磁気が反応してメインユニットに装着しない仕様となっております。

2. 充電モードでは、インジケータランプが点滅し、製品は起動しません。(図2)

3. 充電が完了すると、インジケータランプが点灯に変わります。(図3)
注: 製品が低電力状態(起動できない状態)になると、電源ボタンを押した際に点滅して充電するよう知らせます。

抽出モード(コーヒー抽出を例とします)

1. 水や牛乳、カップに飲料水を加えてください。(図4)
※濃縮した水や熱湯の使用は故障の原因となりますので使用しないでください。本製品は水出し飲料を目的に設計されており、冷水や常温水以外の使用は推奨致しません。

2. フィルターにコーヒー粉をお好みの量加入(目安20g前後)、ストレーナーをセットします。この際ストレーナーに砂糖やミルクを加えることもできます。(スタンダードを例として、深煎りで中細挽きのコーヒー粉20g/水240mlをお勧めします)(図5)

3. 組み立てたメインユニット、フィルター、ストレーナーをカップボディに差し込んでください。(図6参照)

4. オン/オフボタンを押すと、インジケータランプが長時間点灯しながら抽出を開始します。約10分の抽出作業が終了すると、インジケータランプが消えます。抽出中にオン/オフボタンを押すと抽出を終了します。(図7)

使用上の注意

① 抽出中にフィルターとストレーナーに水が残っている場合は、オン/オフボタンを長押しすることで空になります。
② フィルターが完全に水に浸かるよう220ml以上の水を加えてください。220mlを下回る量だと抽出ができません。
③ 本体や入れている粉の種類、量によって加圧や減圧に掛かる時間が変わるため、抽出時間が十分前後する場合があります。

携帯用カップの使用

1. コーヒーの抽出が終了したら、メインユニット、フィルター、ストレーナー、上部カップを取り出し、携帯用フタをカップボディに取り付け、時計回りに締めます。(図8)

2. 携帯用フタのシールリボンを開け、図9のよりに約90°回転させてはめ込み、注ぎ口を開けてお楽しみください。(図9)。
※完全に密封はできません。カップを逆さまにしないでください。

洗浄・お手入れ

1. 洗浄する前に、メインユニットが停止していることを確認してください。
2. ワイヤーボール、研磨剤、腐食性液体(ガソリン、アセトンなど)で製品を洗浄しないでください。
3. メインユニットは濡らしてしっかり拭いた布で拭いてください。電気部品の損傷や製品裏れを避けるため、水やその他の液体で洗ったり、スプレーしたりしないでください。
4. メインユニット以外の部品は、食用洗剤で洗って、スプレーしたりしないでください。
5. 保管する際は製品を清潔に保ち、直射日光を避けて乾燥した風通しの良い場所に置いてください。
注: 機器を効果的にお使いいただくために、お住まいの地域の水質や機器の使用頻度に応じて、次のように定期的に洗浄してください。
カップに容量の半分程度(約14、243ml)を注ぎ、コーヒー粉を入れず、抽出を開始します。この作業を数回繰り返していただきます。その都度新しいお湯水を使用してください。その後新しい臭いがないまで、水でしっかり洗い流してください。

トラブルシューティング

トラブル	原因分析	処理方法
抽出されたドリンクが薄い、または味が明らかに悪い	コーヒー粉や茶葉の量が少なすぎ、または電池の残量が少なく、途中で動作が停止してしまっている	コーヒー粉や茶葉の量を規定量内で増やす、または充電してください。
メインユニットから異常音が出る等正常に動いていない	メインユニットの裏面のプロンプが故障した可能性がある	プロンプを布で綺麗に拭いてください。直らない場合は修理に出してください。
飲み出しと泡が絡まない	プロンプに異物が付着している、または正常に動作していない	ストレーナーに入れる水や調味料を減らし、プロンプを綺麗にしてください。
パネルLEDの点滅	電池の残量が足りない	フル充電で使用してください。
抽出する際の圧力変化による往復運動ができない	カップの接合部にあるパッキンが外れている、または壊れている	パッキンが外れているら直し、壊れている場合は交換が必要です。

保証書

保証期間(無料修理)は、購入日から適用されます。
1. 保証を受ける際は、この保証書とシールなどの保証請求書をご用意ください。
2. この保証書は、販売国または地域に限定されています。
3. 以下のいずれかの場合、保証期間中であっても保証の対象とはなりません。が、有料で修理を行うことができます。
a. 製品取扱説明書の要件に従わずに使用、保守、保管しなかったために生じた損傷。
b. 不適切な操作、異常な電源、損傷(落下など)によって引き起こされた損傷。
c. EPEIOSの確認なしに分解したことによって引き起こされる損傷。
d. この保証書と有効な購入請求書の提示ができない場合。
e. 保証書に記載されている情報が、製品の物理的識別と矛盾しているか、変更されている。
f. 不可抗力要因(雷、地震、火災、洪水など)によって引き起こされた損傷。
4. この保証条項は、お客様が個人消費のニーズのために購入して使用する場合のみ適用されます。商用利用には適用されません。

Warning

1. Do not disassemble or alter the battery or use it for other purposes.
2. Do not throw the battery into fire to avoid explosions.
Please dispose of the battery according to local regulations.

販売店印 (住所・店名・電話番号)

こちらに販売店印もしくは購入証明を添付のうえ保管ください。

Important Safety Cautions

Please read this guide thoroughly before use and retain it properly.
1. Please make sure this product works with your household power supply to achieve the best performance and avoid damages.
2. Do not use this product in high temperatures.
3. Please disconnect from power when cleaning this brewer or when not in use.
4. Place this product onto a countertop or other even surfaces. Do not hang the USB cable over the edges of a table or countertop.
5. Do not place this product in high temperatures.
6. Do not use this product while it is being charged.
7. Come with a built-in battery. Place this product in a dry environment.
8. Use spare parts provided by the manufacturer only to avoid damages or injuries.
9. Cup the main unit before you power it on.
10. Please add water as per the rated capacity.
11. If the brewer malfunctions or can not perform normally due to other reasons, do not disassemble it by yourself. Take it to the authorized retailer or distributor center for test and repair in case of dangers.
12. If the power cable is damaged, replace it with the dedicated cable or cable provided by the manufacturer or repair center.
13. This product is not intended for use by people with physical, sensory, or mental defects or people lack of experience (including children) unless they are instructed or supervised by a responsible person.
---Take care of your children so they won't play with this product.
---Never let children clean or repair this product without supervision.
---When not in use, during assembly, or before cleaning, please disconnect the product from a power source. Never let children use this product unattended.

Get to Know the Product

Filter Inner Body Cup Lid

1. Main Body: Hold water, milk or other liquid, the capacity is 220ml-350ml.
2. Main Unit Module: Control part, including filter and inner body.
3. Filter: Hold coffee and tea residues, the capacity is 20g coffee residues and 10g tea leaves.
4. Inner Body: Hold ice cubes and sugar. We recommend you to fill it half full.
5. Cup Lid Module: Combine with the main body for a portable cup for use on the go.

Button and indicator

1. Press the Power Button for 1s to start working, the indicator stays on.
2. The indicator flashes when charging.
3. The indicator turns solid when the charge completes.
4. When the product enters low voltage mode (can not be activated), the Power Button indicator flashes reminding you to charge the product.

Specifications

Product Name	Cold Brew Electric Coffee Maker
Model	EPC0800
Product Specifications	DC3.7V
Power	Adapter Input 100-220V 50/60Hz Output: DC 5V1A
Battery Capacity	900mAh
Capacity	350ml (Liquid)/20g (Coffee Residues)/10g (Tea Leaves)
Noise	<55dB
Body Heat-Resistance Temperature	≤50°C (Do not fill water or other liquid higher than that temperature)
Brewing Density	4~0.8PPM
Product Weight	0.54kg

How to Install

*The images are for reference only

Main Unit Inner Body Filter Upper Cup Base Body

Step 1 Main Unit Inner Body

Step 2 Inner Body Filter

Step 3 Upper Cup Base Body

Step 4 本体

How to Use

Initial Use

1. Before the first use, clean all the parts (except the main unit) with mild detergent and rinse them thoroughly with clean water. Wipe the main unit with a wet cloth, do not soak it in water.
2. For a better use experience, please fully charge the unit before the first use, and wash parts with direct contact with food.

Charging Mode

1. Plug the magnetic charging cable into a power adapter with a rated output of 5V=1A, and attach the charging contact onto the main unit for charging. It takes around 2 hours to get it fully charged (Pic. 1).
2. In charging mode, the indicator keeps flashing and the product can not be activated now. (Pic. 2).
3. When charging completes, the indicator turns solid on (Pic. 3). Note: When the product enters low-voltage mode (can not be activated), the Power Button will flash to remind you to charge the unit.

Brewing Mode (Coffee)

1. Put the whole machine onto an even surface. Take out the main unit, inner body and filter. Add 220-350ml drinking water into the body, do not exceed the max water level line. (Pic.4)

2. Take out the filter, add 10-20g of ground coffee powder into the filter. You can adjust the amount according to your preference, do not exceed the max water level line, install the filter back. (We recommend you to use medium roast and medium ground beans, 20g coffee powder for 240ml water) (Pic.5).

3. Assemble the main unit, inner body and filter and put them into the main body. (Pic. 6)

4. Press the Power Button to start brewing. The Indicator will turn on. When brewing done, the indicator turns off. Press the Power Button to stop brewing immediately. Duration for one brewing is 10 minutes by default (Pic.7).

Note:
1. When brewing done, press and hold the Power Button to drain water inside the filter.
2. Add a minimum of 220ml water so the filter can be soaked, or brewing won't start.

Use It As a Portable Cup

1. When brewing done, remove the main unit, inner body, filter and upper cup base, install the portable cup lid and rotate it clockwise to tighten it (Pic.8).

2. Open the sealing silicone on the cup lid and rotate it 90° as shown below and cup it. Open the water outlet and enjoy (Pic.9)

Cleaning and Maintenance

1. Make sure the product has stopped working before cleaning.
2. Do not use hard objects, abrasive detergent or corrosive liquids (gas, acetone) to wash this product.
3. Wipe the main unit with a wet towel, do not put it into water or other liquid. Do not soak or rinse it with water to avoid damages or electric leakage.
4. All the other parts except the main unit can be washed with mild detergents.
5. When storing the product, make sure it is clean and dry. Place it in a dry and ventilated place, and avoid direct sunshine.
Note: To ensure further performance, we recommend you regularly clean the mineral residues inside the body according to local water quality and use frequencies.
Instructions: Pour proper amount of white vinegar solution (vinegar 1: water 5) into the cup and start brewing without adding any coffee powder. Repeat the process if needed. Drain the solution and rinse it with clean water till the vinegar smell is gone.

Troubleshooting Guide

Problem	Possible Cause	Solution
Brewed coffee is tasteless	Insufficient coffee powder or machine stops working due to low battery	Add coffee powder as per the instructions/ fully charge the device
Water being sucked into the main unit and water leakage	Detection needle failure or covered by coffee residues	Send it for repair or wipe the detection needle clean
Constantly blowing and bubbling	Detection needle dislocated	Do not put too many ice cubes or other ingredients into the body, clean the detection needle
LED keeps flashing	Low battery	Charge the device
Failed to cycle water for brewing	Check the sealing ring	Change the sealing ring if broken or send it for repair

Warranty Card

From the date of purchase, this product comes with free repair within the warranty period.
1. Please show this warranty card and your purchase receipt to claim your warranty.
a) We will not issue another warranty card if you lose your original one.
b) This warranty card only applies to the country or region of your purchase.
2. From the date of purchase and within the warranty period, repair policy for the malfunctions under proper use.
Main Body:----Free in 1 year
3. The warranty is void if one of the following terms happens. But we can repair it at a charge.
A. Damages caused by failure of following the instructions, maintenance, and store conditions as stated in this user guide.
B. Damages caused by disassembly of an unauthorised repairing man.
C. Filled to provide the warranty card and valid purchase invoice.
D. Product information in this guide does not conform with that on the product or has been altered.
E. Damages caused by force majeure (thunder, earthquake, fire hazards, flood).
4. This warranty card only applies to customers who purchased this product for personal care use and does not apply for commercial use.

Model EPC0800
Purchase date (Address・Store name・Telephone number)

Please keep it with the store stamp or purchase certificate attached here.