Ginour

Dual Action Polisher

Model GP02

Please read the user guide carefully and follow the instructions when using this product. Keep this guide for future reference.

Contents

EN 01-16
FR 16-30
DE 30-45
ES 45-60
ITT 60-74

Ginour

Tool Needs, Fast Fixes

Ginour Tools is a brand dedicated to the development, production and sales of power tools and accessories. Our products are widely used in the fields of automotive repair, construction, home improvement, and DIY projects.

Ginour

型号	YSC1040 一代 / 二代
额定电压	220-240V~ 50/60Hz
功率	700 瓦
转速	单挡 3,000-6,000 转/分钟
抛盘直径	180 毫米
偏心距	5.0 毫米
净重	2.1 千克
电源线长度	3.5 米
防护等级	IP20

EN

⚠ Warning!

When using the electric appliance basic safety precautions should always be followed to reduce the risk of fire, electric shock and personal injury including the following:

- Do not use the tool for purposes not intended.
- Only qualified technicians should be allowed to perform repairs.
- Use only identical replacement parts. Follow the instructions in the Maintenance and Lubrication section.
- Do not use the tool if the switch does not turn it on and off.
- Never dispose of the product in fire or water as this increases the risk of explosion or electrical shock.
- Do not use the device for anything other than the intended purpose.

General Power Tool Safety Warnings

⚠ **WARNING!** Read all safety warnings and all instructions. Any power tool specifications provided with this user guide must be listed to avoid electrical shock, fire and/or serious injury. Save all warnings and instructions for future reference.

The term "power tool" in the warnings refers to your mains-operated (corded) power tool or battery-operated (cordless) power tool.

1. Work area safety
   - Keep work area clean and well lit. Cluttered or dark areas invite accidents.
   - Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases or dust. Power tools create sparks which may ignite the dust or fumes.
   - Keep children and bystanders away while operating a power tool. Distractions can cause you to lose control.
2. Electrical safety
   - Power tool plugs must match the outlet. NEVER modify the plug in any way. Do not use any adapter plugs with earthed (grounded) power tools. Unmodified plugs and matching outlets will reduce risk of electric shock.
   - Avoid body contact with earthed or grounded surfaces, such as pipes, radiators, ranges and refrigerators. There is an increased risk of electric shock if your body is earthed or grounded.
   - Do not expose power tools to rain or wet conditions. Water entering a power tool will increase the risk of electric shock.
   - Do not abuse the cord. Never use the cord for carrying, pulling or unplugging the power tool. Keep cord away from heat, oil, sharp edges or moving parts. Replace damaged cords immediately. Damaged cords increase the risk of electric shock.
   - When operating a power tool outdoors, use an extension cord suitable for outdoor use. The use of a cord suitable for outdoor use reduces the risk of electric shock.
   - If operating a power tool in a damp location is unavoidable, use a residual current device (RCD) protected supply. Use of an RCD reduces the risk of electric shock.
3. Personal safety
   - Stay alert, watch what you are doing, and use common sense when operating a power tool. Do not use a tool while you are tired or under the influence of drugs, alcohol or medication. A moment of inattention while operating power tools may result in serious personal injury.
   - Use personal protective equipment. Always wear eye protection. Protective equipment such as a dust mask, non-skid safety shoes, hard hat, or hearing protection used for appropriate conditions will reduce personal injuries.
   - Prevent unintentional starting. Ensure the switch is in the off-position before connecting to power source and/or battery pack, picking up or carrying the tool. Carrying power tools with your finger on the switch or energising power tools that have the switch on invites accidents.
   - Remove adjusting key or wrench before turning the power tool on. A wrench or a key left attached to a rotating part of the power tool may result in personal injury.
   - Do not overreach. Keep proper footing and balance at all times. This enables better control of the power tool in unexpected situations.
   - Dress properly. Do not wear loose clothing or jewellery. Keep your hair, clothing and gloves away from moving parts. Loose clothes, jewellery or long hair can be caught in moving parts.
   - If devices are provided for the connection of dust extraction and collection facilities, ensure these are connected and properly used. Use of dust collection can reduce dust-related hazards.
4. Power tool use and care
   - Do not force the power tool. Use the correct power tool for your application. The correct power tool will do the job better and safer at the rate for which it was designed.
   - Do not use the power tool if the switch does not turn it on and off. Any power tool that cannot be controlled with the switch is dangerous and must be repaired.
   - Disconnect the plug from the power source and/or the battery pack from the power tool before making any adjustments, changing accessories, or storing power tools. Such preventive safety measures reduce the risk of starting the power tool accidentally.
   - Store idle power tools out of the reach of children and do not allow persons unfamiliar with the power tool or these instructions to operate the power tool. Power tools are dangerous in the hands of untrained users.
   - Maintain power tools and accessories. Check for misalignment or binding of moving parts, breakage of parts and any other condition that may affect the power tool's operation. If damaged, have the power tool repaired before use. Many accidents are caused by poorly maintained power tools.
   - Keep cutting tools sharp and clean. Properly maintained cutting tools with sharp cutting edges are less likely to bind and are easier to control.
   - Use the power tool, accessories and tool bits etc. in accordance with these instructions, taking into account the working conditions and the work to be performed. Use of the power tool for operations different from those intended could result in a hazardous situation.
   - Keep handles and grasping surfaces dry, clean and free from oil and grease. Slippery handles and grasping surfaces do not allow for safe handling and control of the tool in unexpected situations.
5. Service
   - Have your power tool serviced by a qualified repair person using only identical replacement parts. This will ensure that the safety of the power tool is maintained.

Intended Use

This Ginour dual action polisher is designed for any beginner, DIY enthusiast or professional detailer to polish, buff, and wax vehicle bodywork, delivering a flawless finish. It is suitable for removing light to moderate swirl marks, oxidation, and minor scratches on paint, clear coat, and other smooth surfaces.

Package Contents

Specifications

Model	GP02
Rated Voltage	220-240V~ 50/60Hz
Power Supply	AC
Rated Power	700 W
Speed Range	3,000 - 6,000 RPM
Polisher Class	Dual Action (DA)
Backing Plate Size	180 mm
Orbital Diameter	5.0 mm
Weight (Net)	2.1 kg
Cable Length	3.5 m
Protection Class	II / Double Insulation
Ingress Protection	IP20

Know Your Tool



⚠ WARNING!

Carefully remove the product from the packaging and inspect for any signs of damage that may have happened during the journey. Do not plug in or use any tool that's tagged as faulty and return it to the point of purchase. If any parts are missing or damaged, please contact our customer support team at support@ginour.com.

Assembling and Adjusting the Handle

⚠ **WARNING!** Always switch off and unplug the polisher from the power source before attaching or removing any accessories, and allow all moving parts to come to a complete stop. Failure to do so can result in serious injury.

A side handle is also provided with the tool and can be used as an additional support for better control, especially when working on vertical surfaces. Attach the side handle to one of the two threaded holes on the gear case, as shown in the figure above.

⚠ **WARNING!** To avoid finger injuries, hold the side handle by the rubber grip area. Do not touch the buffer pad while the tool is running or immediately after use, as it may be hot.

Attaching Pads and Loop Backing plate

⚠ **WARNING!** Ensure the backing plate is fully locked before starting the tool. Do not run the tool without a pad attached, as this may damage the backing plate.

Using the Tool

⚠ **CAUTION!** Operate only when under load conditions or in presence of foam / wool pads.

⚠ **WARNING!** DO NOT let children come into the work area. Supervision is required when children are in the area of the tool.

Selecting Polishing Pads

⚠ **WARNING!** Always switch off and unplug the polisher from the power source before changing pads. Failure to do so may result in serious injury.

Speed Control Wheel

The maximum speed of the tool can be changed by rotating the speed control wheel on the top of the tool. Turn the wheel to the desired speed setting, as shown in the figure below.

SETTING	SPEED (RPM)	SUITABLE FOR
1	3000	Spreading & buffing
2	3500	Spreading & buffing
3	4000	Spreading & buffing
4	4500	Polishing & cleaning
5	5000	Removing paint
6	5500	Removing paint

You should use the soft pad with a polishing compound at a low speed setting to remove scratches and swirl marks. It is also important to use the correct pressure while polishing when using a rotary tool.

Remove different paints at different levels. As the paint becomes smoother, you can increase the speed. Always start at a low speed and slowly increase it. Do not judge the strength or cleaning ability of the work to be done by the speed of the machine.

Keep the polishing surface moving at a constant speed to avoid heat buildup and damage to the paint. Too much pressure can overheat the paint and cause it to burn through. Too little pressure will not allow the polish to work properly.

Switching On and Off

Hooking and Wiping

⚠ **WARNING!** Before using, ensure the polishing pad is securely attached to the backing plate and that the backing plate is properly locked in place. Failure to do so may result in the pad detaching during use, causing injury or damage to the surface.

Care and Maintenance

Proper care and regular maintenance are required for the continued safe and efficient operation of this tool.

Cleaning

Clean the air vents as often and constantly as possible with dry cloth. Keep the housing of the tool clean. Do not use any solvent to clean plastic parts.

⚠ **WARNING!** Always wear proper eye protection and respiratory protection when cleaning the tool with compressed air.

⚠ **WARNING!** Never allow any liquid to enter the tool; do not immerse any part of the tool in liquid.

Storage

Store the tool in a dry, well-ventilated area, out of the reach of children and locked up. Do not store the tool in extreme temperatures.

Troubleshooting

Problem	Possible Cause	Solution
Tool won't start	No power supply	Check power cord and outlet
	Faulty switch	Contact service center
Pad wobbles	Loose backing plate	Tighten backing plate
	Damaged pad	Replace pad
Swirl marks after polishing	Wrong pad or compound	Use finer pad/compound
	Speed too high	Reduce speed
Overheating	Pad too dry	Add more polish
	Pressure too high	Reduce pressure
Vibration	Loose pad or plate	Secure pad properly
	Worn bearings	Contact service center

⚠ WARNING!

To reduce the risk of serious personal injury, turn the tool off and disconnect the tool from the power source before making any adjustments or removing/installing attachments or accessories. An accidental start-up can cause injury. Before reconnecting the tool, make sure the switch is in the off-position.

Maintenance

⚠ **WARNING!** To reduce the risk of serious personal injury, turn the tool off and disconnect the tool from the power source before servicing it or removing any assembly. To avoid the injury from an accidental start-up, turn the switch to the off-position.

Lubrication

Before starting operation, the tool has been properly lubricated and is ready to use. However, the tool should be lubricated regularly to ensure optimum performance. Lubricate the gears with a high-quality gear grease.

⚠ **CAUTION!** To reduce the risk of serious personal injury, do not remove or disassemble the gear case cover. Only a qualified technician should perform lubrication of the gears.

Accessories

⚠ **WARNING!** Unless otherwise stated, the accessories listed below are sold separately. Use of any accessories or attachments not listed in this manual is not recommended. Use of such parts could cause serious personal injury.

Step 1: Remove and replace the wool / foam pad by hook and loop.

Step 2: Fix the wool / foam pad on the backing plate.

Troubleshooting

1. Why is the polisher not working after unboxing? 01
2. Why does the polisher vibrate excessively? 01
3. Why is the polisher overheating? 01
4. Why does the polisher make odd noises? 01
5. Why is the polishing result poor? 01
6. Why is the polisher not working after a period of use? 01
7. Why is the polisher suddenly stopped? 01
8. Warranty 01
9. Why does the polisher overheat? 01
10. Why is the polisher easy scratching after only a few months of use? 01
11. Why is the polishing result not as expected? 01
12. Why is the polisher not working after using the wrong polishing compound? 01

1. Why is the polisher not working after unboxing?

- Check if the power cord is properly connected to the power outlet.
- Ensure the power switch is turned on.
- Verify that the power outlet is working by testing with another device.

2. Why does the polisher vibrate excessively?

- Check if the polishing pad is securely attached to the backing plate.
- Ensure the backing plate is properly locked in place.
- Inspect the polishing pad for damage or wear and replace if necessary.

3. Why is the polisher overheating?

- Avoid prolonged use at high speeds.
- Take breaks every 15-20 minutes to allow the tool to cool down.
- Ensure adequate ventilation around the tool.

4. Why does the polisher make odd noises when I switch it on?

- Check for loose screws or components and tighten them if necessary.
- Inspect the motor brushes and replace them if they are worn out.

5. Why is the polishing result poor?

- Ensure you are using the correct polishing compound for your paint type.
- Check if the polishing pad is clean and free of debris.
- Adjust the speed and pressure according to the paint condition.

6. Why is the polisher not working after a period of use?

- Check if the power cord or plug is damaged and needs replacement.
- Inspect the internal components for any signs of damage or wear.
- Contact customer support for assistance if the issue persists.

7. Why is the polisher suddenly stopped?

- The polisher may have overheated and triggered the thermal protection. Allow it to cool down before restarting.
- Check if the power supply is stable and not fluctuating.
- Inspect the motor brushes and replace them if they are worn out.

8. Warranty

Our polishers come with a 12-month warranty. If you encounter any issues with your polisher during this period, please contact our customer support team at support@ginour.com. We will be happy to assist you with repairs or replacements.

9. Why does the polisher overheat?

- Avoid prolonged use at high speeds.
- Take breaks every 15-20 minutes to allow the tool to cool down.
- Ensure adequate ventilation around the tool.

10. Why is the polisher easy scratching after only a few months of use?

- Ensure you are using the correct polishing compound for your paint type.
- Check if the polishing pad is clean and free of debris.
- Adjust the speed and pressure according to the paint condition.

11. Why is the polishing result not as expected?

- Ensure you are using the correct polishing compound for your paint type.
- Check if the polishing pad is clean and free of debris.
- Adjust the speed and pressure according to the paint condition.

12. Why is the polisher not working after using the wrong polishing compound?

- Check if the power cord or plug is damaged and needs replacement.
- Inspect the internal components for any signs of damage or wear.
- Contact customer support for assistance if the issue persists.

Warranty

- 12-month warranty
- Lifetime technical support

Warranty does not cover damage from:

- Misuse or improper maintenance
- Unauthorized repairs or modifications
- Normal wear and tear
- Use in commercial or rental applications

Environmental Protection

- Do not dispose of the product with household waste.
- Take it to a local recycling center for proper disposal.
- Follow local regulations for the disposal of electronic waste.

Safety Use Unit

- Wear safety glasses when using the polisher.
- Keep hands and body parts away from the rotating pad.
- Unplug the polisher before changing pads or accessories.
- Do not use the polisher in wet conditions.
- Avoid using the polisher on surfaces that are too hot or too cold.

Warranty

- 12-month warranty
- Lifetime technical support

Warranty does not cover damage from:

- Misuse or improper maintenance
- Unauthorized repairs or modifications
- Normal wear and tear
- Use in commercial or rental applications

Environmental Protection

- Do not dispose of the product with household waste.
- Take it to a local recycling center for proper disposal.
- Follow local regulations for the disposal of electronic waste.

Safety Use Unit

- Wear safety glasses when using the polisher.
- Keep hands and body parts away from the rotating pad.
- Unplug the polisher before changing pads or accessories.
- Do not use the polisher in wet conditions.
- Avoid using the polisher on surfaces that are too hot or too cold.

DE

⚠ Warnung!

Bei der Verwendung von Elektrogeräten sollten stets grundlegende Sicherheitsvorkehrungen befolgt werden, um das Risiko von Brand, Stromschlag und Verletzungen zu verringern, einschließlich der folgenden:

- Verwenden Sie das Werkzeug nicht für andere als vorgesehene Zwecke.
- Nur qualifizierte Techniker sollten Reparaturen durchführen dürfen.
- Verwenden Sie nur identische Ersatzteile. Befolgen Sie die Anweisungen im Abschnitt zu Wartung und Schmierung.
- Verwenden Sie das Werkzeug nicht, wenn der Schalter es nicht ein- und ausschaltet.
- Entsorgen Sie das Produkt niemals in Feuer oder Wasser, da dies das Explosions- oder Stromschlagrisiko erhöht.
- Verwenden Sie das Gerät nicht für andere als den vorgesehenen Zweck.

Allgemeine Sicherheitshinweise für Elektrowerkzeuge

Der Begriff „Elektrowerkzeug" in den Sicherheitshinweisen, unabhängig davon, ob Sie mit einem Netzanschluss oder einem Akkuwerkzeug arbeiten. Die Nichtbeachtung aller unten aufgeführten Anweisungen kann zu Stromschlägen, Bränden und/oder schweren Verletzungen führen. Bewahren Sie alle Sicherheitshinweise und Anweisungen für zukünftige Referenzzwecke auf.

1. Sicherheit am Arbeitsplatz
   - Halten Sie Ihren Arbeitsbereich sauber und gut beleuchtet. Unordentliche oder dunkle Bereiche können Unfälle begünstigen.
   - Betreiben Sie Elektrowerkzeuge nicht in explosionsgefährdeten Umgebungen, wie beispielsweise in Gegenwart von brennbaren Flüssigkeiten, Gasen oder Staub. Elektrowerkzeuge erzeugen Funken, die den Staub oder die Dämpfe entzünden können.
   - Halten Sie Kinder und Unbeteiligte während der Benutzung eines Elektrowerkzeugs fern. Ablenkungen können dazu führen, dass Sie die Kontrolle verlieren.
2. Elektrische Sicherheit
   - Stecker müssen in die Steckdose passen. Der Stecker darf in keiner Weise verändert werden. Verwenden Sie keine Adapterstecker zusammen mit geerdeten Elektrowerkzeugen. Unveränderte Stecker und passende Steckdosen verringern das Risiko eines elektrischen Schlags.
   - Vermeiden Sie Körperkontakt mit geerdeten oder geschützten Oberflächen, wie beispielsweise Rohren, Heizkörpern, Herden und Kühlschränken. Es besteht ein erhöhtes Risiko eines elektrischen Schlags, wenn Ihr Körper geerdet oder geschützt ist.
   - Setzen Sie Elektrowerkzeuge nicht Regen oder Nässe aus. Wasser, das in ein Elektrowerkzeug eindringt, erhöht das Risiko eines elektrischen Schlags.
   - Missbrauchen Sie das Kabel nicht. Verwenden Sie das Kabel niemals zum Tragen, Ziehen oder Trennen des Elektrowerkzeugs vom Stromnetz. Halten Sie das Kabel von Hitze, Öl, scharfen Kanten oder beweglichen Teilen fern. Ersetzen Sie beschädigte Kabel sofort. Beschädigte Kabel erhöhen das Risiko eines elektrischen Schlags.
   - Wenn Sie ein Elektrowerkzeug im Freien betreiben, verwenden Sie ein Verlängerungskabel, das für den Außenbereich geeignet ist. Die Verwendung eines für den Außenbereich geeigneten Verlängerungskabels verringert das Risiko eines elektrischen Schlags.
   - Wenn der Betrieb eines Elektrowerkzeugs in einer feuchten Umgebung unvermeidbar ist, verwenden Sie eine durch einen Fehlerstromschutzschalter (RCD) geschützte Stromversorgung. Die Verwendung eines RCD verringert das Risiko eines elektrischen Schlags.
3. Persönliche Sicherheit
   - Bleiben Sie aufmerksam, achten Sie darauf, was Sie tun, und gehen Sie mit Vernunft an die Arbeit mit einem Elektrowerkzeug heran. Verwenden Sie kein Elektrowerkzeug, wenn Sie müde sind oder unter dem Einfluss von Drogen, Alkohol oder Medikamenten stehen. Ein kurzer Moment der Unachtsamkeit bei der Verwendung von Elektrowerkzeugen kann zu schweren Verletzungen führen.
   - Verwenden Sie persönliche Schutzausrüstung. Tragen Sie immer Augenschutz. Schutzausrüstung wie eine Staubmaske, rutschfeste Sicherheitsschuhe, Schutzhelm oder Gehörschutz, die für entsprechende Bedingungen verwendet wird, verringert das Risiko von Verletzungen.
   - Vermeiden Sie eine unbeabsichtigte Inbetriebnahme. Vergewissern Sie sich, dass der Schalter in der Aus-Position steht, bevor Sie den Akku einsetzen, das Werkzeug aufnehmen oder tragen. Wenn Sie beim Tragen von Elektrowerkzeugen den Finger am Schalter haben oder Elektrowerkzeuge, bei denen der Schalter eingeschaltet ist, einschalten, kann es zu Unfällen kommen.
   - Entfernen Sie Einstellwerkzeuge oder Schraubenschlüssel, bevor Sie das Elektrowerkzeug einschalten. Ein Werkzeug oder Schlüssel, das an einem rotierenden Teil des Elektrowerkzeugs befestigt ist, kann zu Verletzungen führen.
   - Vermeiden Sie eine unnatürliche Körperhaltung. Sorgen Sie stets für einen sicheren Stand und halten Sie das Gleichgewicht. Dadurch können Sie das Elektrowerkzeug in unerwarteten Situationen besser kontrollieren.
   - Kleiden Sie sich angemessen. Tragen Sie keine weite Kleidung oder Schmuck. Halten Sie Haare, Kleidung und Handschuhe von beweglichen Teilen fern. Weite Kleidung, Schmuck oder langes Haar können von beweglichen Teilen erfasst werden.
   - Wenn Vorrichtungen für den Anschluss von Staubabsaug- und -auffangeinrichtungen vorhanden sind, stellen Sie sicher, dass diese angeschlossen und ordnungsgemäß verwendet werden. Die Verwendung einer Staubabsaugung kann staubbedingte Gefahren verringern.
4. Verwendung und Pflege von Elektrowerkzeugen
   - Überlasten Sie das Elektrowerkzeug nicht. Verwenden Sie für Ihre Anwendung das richtige Elektrowerkzeug. Mit dem richtigen Elektrowerkzeug lässt sich die Arbeit besser und sicherer in dem Tempo ausführen, für das es ausgelegt wurde.
   - Verwenden Sie das Elektrowerkzeug nicht, wenn sich der Schalter nicht betätigen lässt. Ein Elektrowerkzeug, das sich nicht mit dem Schalter steuern lässt, ist gefährlich und muss repariert werden.
   - Ziehen Sie den Akku ab, bevor Sie Einstellungen vornehmen, Zubehörteile wechseln oder das Elektrowerkzeug weglegen. Durch diese Vorsichtsmaßnahmen wird das Risiko verringert, dass das Elektrowerkzeug versehentlich in Gang gesetzt wird.
   - Bewahren Sie unbenutzte Elektrowerkzeuge außerhalb der Reichweite von Kindern auf. Lassen Sie Personen, die mit dem Elektrowerkzeug oder diesen Anweisungen nicht vertraut sind, das Elektrowerkzeug nicht benutzen. Elektrowerkzeuge sind in den Händen unerfahrener Benutzer gefährlich.
   - Pflegen Sie Elektrowerkzeuge und Zubehör. Achten Sie auf fehlerhafte Ausrichtung oder Blockierung beweglicher Teile, Beschädigungen von Teilen und alle anderen Bedingungen, die den Betrieb des Elektrowerkzeugs beeinträchtigen können. Lassen Sie das Elektrowerkzeug vor dem Gebrauch reparieren, wenn es beschädigt ist. Viele Unfälle werden durch schlecht gewartete Elektrowerkzeuge verursacht.
   - Halten Sie Schneidwerkzeuge scharf und sauber. Sorgfältig gepflegte Schneidwerkzeuge mit scharfen Schneidkanten verklemmen sich seltener und lassen sich leichter führen.
   - Verwenden Sie das Elektrowerkzeug, das Zubehör, die Einsatzwerkzeuge etc. gemäß diesen Anweisungen und berücksichtigen Sie dabei die Arbeitsbedingungen und die auszuführende Tätigkeit. Die Verwendung des Elektrowerkzeugs für Tätigkeiten, die nicht vorgesehen sind, kann zu gefährlichen Situationen führen.
   - Halten Griffe und Greifflächen trocken, sauber und frei von Öl und Fett. Rutschige Griffe und Greifflächen verhindern eine sichere Handhabung und Kontrolle des Werkzeugs in unerwarteten Situationen.
5. Service
   - Lassen Sie Ihr Elektrowerkzeug nur von qualifiziertem Fachpersonal und nur mit Originalersatzteilen reparieren. Nur so ist gewährleistet, dass die Sicherheit des Elektrowerkzeugs erhalten bleibt.

Was ist im Paket

Wenn etwas fehlt oder beschädigt ist, wenden Sie sich bitte an support@ginour.com.

Technische Daten

Modell	GP02
Nennspannung	220-240V~ 50/60Hz
Stromversorgung	AC
Nennleistung	700 W
Drehzahlbereich	3.000 - 6.000 U/min
Exzenterdurchmesser	5,0 mm
Schutzklasse	II / Doppelisolierung
Schutzart	IP20
Netzkabellänge	3,5 m
Gewicht (netto)	2,1 kg
Abmessungen (Länge x Breite x Höhe)	280 x 180 x 180 mm

Kennenlernen Ihres Werkzeugs

Montage und Einstellen des Griffs

⚠ **WARNUNG!** Schalten Sie die Poliermaschine immer aus und ziehen Sie den Netzstecker, bevor Sie Zubehörteile anbringen oder entfernen. Lassen Sie alle beweglichen Teile vollständig zum Stillstand kommen. Andernfalls kann es zu schweren Verletzungen kommen.

Ein Seitengriff ist im Lieferumfang enthalten und kann als zusätzliche Stütze für eine bessere Kontrolle verwendet werden, insbesondere beim Arbeiten an vertikalen Flächen. Befestigen Sie den Seitengriff an einer der beiden Gewindebohrungen am Getriebegehäuse, wie in der Abbildung oben dargestellt.

⚠ **WARNUNG!** Um Verletzungen durch Reibung zu vermeiden, halten Sie den Seitengriff am Gummigriff. Berühren Sie das Polierpad während des Betriebs oder unmittelbar nach der Verwendung nicht, da es heiß sein kann.

Anbringen von Polierpads und Stützteller

⚠ **WARNUNG!** Vergewissern Sie sich, dass der Stützteller vollständig verriegelt ist, bevor Sie das Werkzeug einschalten. Betreiben Sie das Werkzeug niemals ohne aufgesetztes Polierpad, da dies den Stützteller beschädigen kann.

Verwendung des Werkzeugs

⚠ **VORSICHT!** Betreiben Sie das Werkzeug nur unter Last oder in Gegenwart von Schaum- oder Wollpolierpads.

⚠ **WARNUNG!** Lassen Sie keine Kinder in den Arbeitsbereich kommen! Beaufsichtigen Sie Kinder, die sich in der Nähe des Werkzeugs aufhalten.

Ein- und Ausschalten

Wissenswertes zu Ihrem Werkzeug

Wissenswertes zu Ihrem Werkzeug

Niedrige Drehzahl
Hohe Drehzahl
Drehzahlregler
Polierpad
Schleifpad
Polierpaste

Wissenswertes zu Ihrem Werkzeug

Niedrige Drehzahl
Hohe Drehzahl
Drehzahlregler
Polierpad
Schleifpad
Polierpaste