

bodywand™
Date Night
USER GUIDE



LIPSTICK VIBE
With Finger Sling

USB magnetic charging port
Power button

EN

how to use

- **Power On**
Press the Ⓞ button for 3 seconds to turn on the vibrator, and start vibration mode 1.
- **Vibrating Modes**
Press Ⓞ button to continuously to change intensity, total 9 intensities.
- **Power Off**
Press the power button Ⓞ for 3 seconds to turn off the vibrator.
- **Charging**
Flashing LED light : Item is charging
Solid LED light : Item is fully charged, It takes appx 150mins for full charge (depends on the power supply).

Cleaning, Storage & Safety

- Always clean and dry your device thoroughly before and after use. Do not store wet. We recommend that you use a mild cleanser that is suitable for use with silicone items. Use water based lubricant as desired. **Not compatible with silicone lubricant.**
- Avoid leaving your device in direct sunlight and never expose it to extreme heat. Keep away from water, and never immerse it.

ES

Modo de empleo

- **Encender**
Pulse el botón Ⓞ durante 3 segundos para encender el vibrador e iniciar el modo de vibración 1.
- **Modos de vibración**
Pulse el botón Ⓞ repetidamente para cambiar la intensidad, con un total de 9 intensidades.
- **Apagar**
Pulse el botón Ⓞ durante 3 segundos para apagar el vibrador.
- **Carga**
Luz LED intermitente: El dispositivo se está cargando
Luz LED fija: El dispositivo está completamente cargado, se tarda aproximadamente 150 minutos para que cargue completamente. (depende de la fuente de alimentación).

Limpieza, almacenamiento y seguridad

- Siempre limpie y seque bien su dispositivo antes y después de su uso. No lo guarde mojado. Le recomendamos que use un limpiador suave apto para usar con componentes de silicona. Utilice un lubricante a base de agua si lo desea. **No es compatible con lubricantes de silicona.**
- Evite dejar su dispositivo a la luz solar directa y nunca lo exponga al calor extremo. Manténgalo alejado del agua y nunca lo moje.

FR

Instructions d'utilisation

- **Mise sous tension**
Appuyez sur le bouton Ⓞ pendant 3 secondes pour allumer le vibromasseur et démarrer le mode de vibration 1.
- **Modes de vibration**
Appuyez sur le bouton Ⓞ pour changer continuellement l'intensité, total de 9 intensités.
- **Mise hors tension**
Appuyez sur le bouton Ⓞ pendant 3 secondes pour désactiver le vibromasseur.
- **Charge**
Voyant DEL clignotant : l'appareil est en cours de charge
Voyant DEL continu : L'article est complètement chargé. Il faut environ 150 minutes pour effectuer une charge complète. (selon l'alimentation).

Nettoyage, entreposage et sécurité

- Nettoyez et séchez toujours soigneusement votre appareil avant et après utilisation. Ne le rangez pas lorsqu'il est mouillé. Nous vous recommandons d'utiliser un nettoyant doux adapté aux articles en silicone. Utilisez du lubrifiant à base d'eau selon vos besoins. **Non compatible avec les lubrifiants de silicone.**
- Évitez de laisser votre appareil en plein soleil et ne l'exposez jamais à une chaleur extrême. Maintenez-le à l'écart de l'eau et ne l'immergez jamais.

DE

Nutzungsanleitung

- **Einschalten**
Drücken Sie 3 Sekunden lang den Ⓞ-Knopf um den Vibrator einzuschalten und den Vibrationsmodus 1 zu starten.
- **Vibrationsmodi**
Halten Sie den Ⓞ-Knopf gedrückt, um die Intensität zu ändern (insgesamt 9 Intensitäten).
- **Ausschalten**
Drücken Sie 3 Sekunden lang den Ⓞ-Knopf, um den Vibrator auszuschalten.
- **Aufladen**
Blinkendes LED-Licht: Gerät wird geladen
LED-Licht leuchtet durchgehend: Das Gerät ist vollständig aufgeladen. Das vollständige Aufladen dauert etwa 150 Minuten (abhängig von der Stromversorgung).

Reinigung, Lagerung und Sicherheit

- Reinigen und trocknen Sie Ihr Gerät vor und nach dem Gebrauch immer gründlich. Bewahren Sie es nicht nass auf. Wir empfehlen, ein mildes Reinigungsmittel zu verwenden, das für die Verwendung mit Silikonartikeln geeignet ist. Verwenden Sie nach Belieben ein Gleitmittel auf Wasserbasis. Nicht mit Silikon-Gleitmitteln kompatibel.
- Vermeiden Sie es, Ihr Gerät direktem Sonnenlicht auszusetzen und setzen Sie es niemals extremer Hitze aus. Halten Sie es von Wasser fern und tauchen Sie es nicht ein.

WARNING

For adult use only. For external use only. Remove all scarves, neckties, necklaces, and jewelry before using this vibrator.

IMPORTANT

Any individual who may be pregnant, has a pacemaker, suffers from diabetes, phlebitis and/or thrombosis, is at an increase risk of developing blood clots, or who has pins/screws/artificial joints or other medical devices implanted in his/her body should consult with a physician before using a massaging device designed for home use.

**Specification/ Características/
Spécifications/ Technische Daten**

Size Tamaño Taille Größe	133.47 x 20mm	Battery Bateria Batterie Batterie	450mAh
Weight Peso Poids Gewicht	49g	Material Material Matériau Material	Silicone + ABS / Silicone sans danger pour le corps + ABS Silicona segura para el cuerpo + ABS / Silikon +Körpersicheres ABS

CARE AND MAINTENANCE

Clean the vibrator with a soft, damp cloth.
DO NOT clean with an alcohol or chemical-based cleaner.

DISCLAIMER

Bodywand shall not be liable for incidental or consequential damages resulting from the misuse of this product.

Front

STORAGE:

Store at 20 C - 25 C
Store at cool dry place.

SPECIFICATIONS:

- Power - 3.7V/ 450mAh USB 2.0
- Battery Life: Up to 120 mins use depending on speed and massage platform choosen.
- Waterproof: IPX6, splashproof, for cleaning the vibrator only, can not play under water.

Disposal Information

Disposal of old electronic equipment (applicable in the EU and other European countries with separate waste collection systems):



The crossed-out dustbin symbol indicates that these items should not be treated as household waste, but rather brought to the appropriate collection point for recycling electrical and electronic equipment.

XGEN, LLC
Horsham, PA 19044 All Rights Reserved

UK Responsible Person:

ArangaRanga UK LTD, 20-22 Wenlock Road, London, N17 GU, UK.
Phone: +44 2037692960, E-Mail: UKResponsibleperson@arangaranga.com

EU Responsible Person:

ArangaRanga SL, Paseo de la Castellana 194, Madrid, 28046, Spain.
Phone: +34 910054258, E-Mail: EUResponsibleperson@arangaranga.com

Email us at service@thebodywand.com for any unanswered questions.

Back