Run Plus
Quick User Guide

Touchpad   R

L   Power Button

Power On/Off
Press and hold for 2 seconds

Click x1   (Bluetooth mode)
Play & Pause   Answer & Hang up

Pairing
With the headphones powered off,
press and hold for 5 seconds

Click x2   (Bluetooth mode)
Next Track   Ring off

Bluetooth⇄MP3 Mode
Double press and hold for 2 seconds

Click x3
Previous Track

*Click x4 Lock/ Unlock the touchpad
*Please lock touchpad during swimming

Left

Volume Increase
Swipe up

**Using
Phone Voice Assistant**
Double tap on Touchpad
(Bluetooth mode)

Volume Decrease
Swipe down

Play mode shifting
Double tap on Touchpad
(Mp3 mode)
Normal   Shuffle   Single loop

Right