



# Theme Series

## M61 User Manual

Introduction:	
Thank you for choosing Mechanical Rechargeable Keyboard. For the best results, please read the user manual carefully before using this product.	
FN +	: Adjust 19 LED backlit modes
FN +	: Increase brightness
FN +	: Decrease brightness
FN +	: Decrease speed
FN +	: Increase speed
FN +	: Adjust lighting color, 9 levels
FN +	: Adjust lighting dynamic direction, 7 levels
FN +	: WIN lock/unlock
FN +	: I J K L change to up,left,down,right keys press FN+[ I ] again to return to normal
FN + space : Hold for 3 seconds to restore factory settings	

FN + ESC: `
FN + SHIFT + ESC: ~
FN + 1~0: F1~F10
FN + -: F11
FN + =: F12
FN + BACK: Delete

### Package Contents:

- 1 x Mechanical Rechargeable Keyboard
- 1 x USB Nano Receiver
- 1 x Type-C Cable
- 1 x User Manual
- 1 x Keycap Puller

### Features:

- Mechanical 61K keyboard
- 2.4G Wireless + Wired dual modes
- Rechargeable battery:1850mA
- RGB backlit, 19 kinds of lighting modes
- USB Full Speed 2.0 (12Mbps)
- N-key rollover

Installation, Connection and Use:	
1. Wired mode	Toggle the power switch in the OFF position(on/off switch located on bottom of keyboard). Connect the USB charging cable to your computer. Once the computer recognize the keyboard, you're ready to use.
2. 2.4G Wireless mode	Charge the battery. Toggle the power switch in the ON position(on/off switch located on bottom of keyboard). Plug the USB nano receiver into the USB port of your computer. Once the computer recognize the keyboard, you're ready to use.
In 2.4G Wireless mode, If not use for more than 60 seconds, the RGB backlit will turn off automatically and keyboard enter power-saving mode.It is better turn off the keyboard when not use for long time.	

### Build the connection between the USB receiver and keyboard

Toggle the power switch in the ON position, press the FN+ key"P" for 5 seconds, now the key"P" is flashing. Plug the USB nano receiver into the USB port of your computer. Key"P" stop flashing after building connection successfully.

Charge the keyboard	
The battery should be charged for at least 6~8 hours before being used for the first time. When the battery is low, the white light of the ESC key is flashing. Connect the USB Charging cable to your computer or adapter.The battery is charging when the LED light between F2 and F3 is on. The light goes off once the battery is fully charged. (charging time: around 6~8 hours). NOTE: If you want to use the keyboard when charging, you should choose wired mode, the power switch must be toggled in the OFF position.	
Troubleshooting Tips:	
If you experience problems while using the keyboard, here are some helpful troubleshooting tips: Check the power switch is in the ON position Check the battery is charged Check the receiver is properly connected to the USB port Try reducing the distance between the keyboard and the computer Remove any large metal objects located between the keyboard and the computer that could interrupt the signal Product picture are for reference only.	
Pro software download link:	
https://www.xvxchannel.com ★ Please note the macro software is only available for Windows PC at this time. ★ The software can only be used in wire mode adjust the power switch to the OFF position.	



https://www.xvxchannel.com

Instagram.com/xvx\_keyboard Facebook.com/xvxkeyboard



## M61ゲーミング キーボード

### 取扱説明書

製品紹介	
このたびは、XVXゲーミングキーボード「M61」をお買い上げいただき誠にありがとうございます。本製品は、最新の2.4G無線/有線モードキーボードです。 ※本製品をご使用になる前に必ずこの取扱説明書をよくお読みください。	
FN +	: 19個のバックライトモードを調整する
FN +	: バックライトの明るさを明るくなります。
FN +	: バックライトの明るさをと暗くなります
FN +	: LEDの点滅（移動）の速度を速くできます
FN +	: LEDの点滅（移動）の速度を遅くできます
FN +	: バックライトの色を調整する、9色
FN +	: バックライトの動く方向を調整する、7種
FN +	: Windowsキーのロック/アンロック
FN +	: [IJKL]キーは「↑」「↓」「←」「→」の入れ替え、FN+I同時に押すと通常に戻す
FN + space : 3秒長押し、出荷時の状態にする、リセット	

FN + ESC: `
FN + SHIFT + ESC: ~
FN + 1~0: F1~F10
FN + -: F11
FN + =: F12
FN + BACK: Delete

### パッケージ内容

- 1 x ゲーミングキーボード
- 1 x 2.4G ワイヤレスレシーバー
- 1 x Type C ケーブル
- 1 x 取扱説明書
- 1 x キートップ引抜工具

### 特徴

- 61キー、ゲーミングキーボード
- 2.4G ワイヤレス+Type C ケーブル接続
- 消費電流: 1850mA
- RGBバックライト、19個のプリセットバックライトモード
- USB最大スピード 2.0 (12Mbps)
- N-key ロールオーバー

インストール、接続、使用	
1.有線モード	電源スイッチをオフの位置に切り替えます（オン/オフスイッチはキーボードの下部にあります）。USB充電ケーブルをコンピューターに接続します。コンピューターがキーボードを認識すると、準備が整います。
2.2.4Gワイヤレスモード	バッテリーを充電する時、電源スイッチをオンの位置に切り替えます（オン/オフスイッチはキーボードの下部にあります）。使用する準備ができたキーボードをコンピューターが認識したら、USBワイヤレスレシーバーをコンピューターのUSBポートに接続します。
2.4Gワイヤレスモード:	60秒以上使用しないと、RGBバックライトが自動的にオフになり、キーボードが入力されます。 省電力モード: 長期間使用しない時、キーボードの電源を切ることをお勧めします。
USBレシーバーとキーボード間の接続を確立します	
電源スイッチをオンの位置に切り替えます。FN+キー「P」を5秒間押しします。これで、キー「P」が点滅します。USBワイヤレスレシーバーを挿入します。レシーバーはコンピューターのUSBポートに接続します。接続が成功すると、キー「P」バーディングの点滅が停止します	

キーボードを充電する	
バッテリーは、最初に使用する前に少なくとも6~8時間充電する必要があります。 バッテリー残量が少なくなると、ESCキーのLEDライトが点滅します。USB充電ケーブルをコンピューターまたはアダプターに接続します。F2とF3の間のLEDライトが点灯している時、バッテリーは充電中です。バッテリーが完全に充電されると、ライトが消えます。（充電時間約6-8時間） 注: 充電中にキーボードを使用する場合は、有線モードを選択する必要があります、電源スイッチをオフの位置に切り替える必要があります。	
トラブルシューティングのヒント:	
キーボードの使用に問題がある場合は、トラブルシューティングに役立つヒントを次に示します。 電源スイッチがオンの位置にあることを確認してください。 バッテリーが充電されていることを確認してください。 受信機がUSBポートに正しく接続されていることを確認してください。キーボードとコンピューターとの間の距離をできるだけ短くしてください。キーボードとコンピューターとの間の信号を妨げる可能性のある大きな金属物体を取り除きます。 製品の写真は参照用です。	
ソフトウェアダウンロードリンク:	
https://www.xvxchannel.com ★ご注意 現在、ソフトウェアはWindows Pcのみ使用できます *このソフトウェアは、有線モードに電源スイッチがオフの位置に調整されている場合にのみ使用できます。	



当社の製品を受け取ったら、包装内の商品及び付属品をチェックして、すべてを確認してください。

部品が不足、商品が破損している場合、お気軽に弊店のアフターサービスに連絡ください。  
当社の製品は1年品質保証があります、保証期間内に正常な使用状態でご使用の場合に限り品質を保証しております。万一保証期間内で故障がありました場合は、下記保証書の内容を文字で当店のアフターサービス（注文履歴、ins、Face）に連絡してください。

保証書	
品番	M61
シリアルナンバー	
お客様	お名前
	ご住所
販売店	販売店名称:
	郵便番号
保証期間	1年 お買い上げ年月日 年 月 日

※必要事項をご記入の上、大切に保管してください。

https://www.xvxchannel.com

Instagram.com/xvx\_keyboard Facebook.com/xvxkeyboard