



安全警告:

- 请勿将产品及配件靠近火源或任何过热的环境中。
- 请勿将产品及配件接触水及湿气，不要在靠近水的地方使用本设备，也不要将产品浸入任何液体中，避免产品及配件受到水渍或水渍。
- 请勿自行打开或任意拆解、维修电池组件，如果电池更换不当会有爆炸危险，严禁将电池投入水、火中或靠近任何过热的环境中。
- 本产品由外接电源适配器 (5V 1.5A 电源) 充电后使用，充电后可方便的通过拔掉电源适配器插头断开电网电源。
- 当用户暂不使用本产品时，请将产品电源开关旋转至关闭状态关闭电源 (参见产品操作示意图)，避免电池电量的流失。
- 当禁止使用无线设备或设备的使用会引起电子设备的干扰与安全隐患时，请关闭本产品。
- 在易燃易爆区域，请关闭本产品，并遵守相关标示说明，以免引起爆炸或火灾。易燃易爆区域包括但不限于：加油站、易燃或化工制品运输及储存设施、有爆炸危险标志的区域，有“关掉双向无线设备”标志的区域。
- 乘坐飞机时，请遵守航空公司有关规定和条例，在飞机起飞前关闭本产品，以免造成安全隐患。
- 仅适用于非热带气候条件下安全使用，仅适用于海拔2000米以下地区安全使用。
- 若使用电源适配器供电，应购买配套使用获得CCC认证并满足要求的电源适配器。

主要功能特点:

- 匠心设计，双色注塑工艺，支持IPX5级生活防水
- 十度高声扩音电声系统，扩音清晰洪亮
- 配备蓝牙5.0云控，支持网络同步歌材播放
- 大容量3.7V 2500mAh锂离子电池
- 支持TF卡、U盘播放

数据参数:

输出功率	峰值18W	频率响应	80Hz-18KHz
喇叭阻抗	2Ω	工作温度	-10°C-45°C
充电电压	DC 5V 1.5A	使用扩音时间	6-8小时
使用音乐时间	5-7小时	充电时间	3-5小时

主机操作示意图:

1.电源开关/播放暂停: 长按“M”键3秒为开关机，在播放状态下短按“M”键为暂停，再次短按“M”为播放。

2.模式切换:

- 短按“M”键可用于U盘/TF卡/蓝牙/UHF模式之间的切换;
- 在音乐模式下，长按“M”键屏幕显示“ON”为单曲循环播放，再次长按“M”键屏幕显示“RAN”为随机播放，再次长按“M”键屏幕显示“ALL”为全部循环播放。
- 上一曲/音量减: 在音乐模式下，长按“M”为音量减，短按为上一曲。
- 下一曲/音量加: 在音乐模式下，长按“M”为音量加，短按为下一曲。

5.一键录音:

- 连接话筒，在任意模式下插入外接存储器 (U盘或是TF卡)，长按“M”键屏幕时间开始跳动即表示开始录音;在录音模式下，短按“M”键保存并开始播放录音。
- 在音乐模式下，如果外接存储器里有录音文件，短按“M”键进入播放录音状态，默认播放音频为最后一个录制音频为当前录音播放。在此状态可以通过上一曲“M”键或下一曲“M”键来选择录音播放文件。

6.麦克风插口: 7. DC 5V

8.音频输入: 9. TF卡/U盘: 按照主机标识的方向将TF卡/U盘正确插入主机TF卡/U盘槽后，主机将自动播放TF卡/U盘中的音乐文件，同时可通过操作上一曲、下一曲键选择自己喜欢的曲目。

无线蓝牙操作说明:

第一步: 开机配对: “M”键切换到蓝牙模式。(当主机显示“蓝牙已准备好，正在等待配对”，显示屏上显示“bt”时为蓝牙模式;)

第二步: 打开手机，进入手机的“设置”菜单，找到蓝牙功能选项，打开手机蓝牙功能，点“扫描”按钮，待搜索到“M808”点击“M808”连接即可; 同时，主机也会提示配对成功;

第三步: 连接成功后，即可通过主机播放手机教学教材，培训资料，歌曲播放等。

为手机充电:

当手机低电时，请先将主机电源开关关闭，关机状态充电，将随机配带的USB充电线连接主机DC 5V插口，另一端连接5V电源适配器再接电源(220V)插座充电。充电时电量指示图标闪烁，充满后电量图标变长。

注意:

- 在工作时，屏幕电量指示图标不停的闪烁，表示电力不足，请及时充电;本机充电时间约3-5小时充满;
- 第一次使用主机时，电池有小部份电量，但是为了达到最好的效果，建议先充满电再使用。

UHF头戴式无线麦克风配对及使用办法: (仅限无线版)

UHF头戴式无线麦克风开关机:

将开关拨至“ON”状态，指示灯蓝灯长亮表示头戴已开机。
将开关拨至“OFF”状态，指示灯蓝灯熄灭，表示头戴已关机。

UHF头戴式无线麦克风手动配对: (此操作方法运用于话筒无声时手动配对)

第一步: 打开主机切换到UHF模式，长按“M”键3秒，UHF指示灯表示已进入UHF无线配对状态;

第二步: 再打开头戴式无线麦克风，长按“M”键3秒，就可以重新配对无线麦克风，配对成功后UHF字样停止闪烁，可开始试讲话。

注意:

- 当无线麦克风使用过程中长按“M”键配对键为断开UHF无线扩音连接，需要再次使用UHF无线扩音时重新依照以上方法方法进行配对;在UHF无线扩音状态下，短按“M”键为单倍音量加，短按“-”键为单倍音量减。
- 为头戴麦克风充电:** 当无线麦克风蓝色指示灯不停的闪烁时，表示无线麦克风电池低电，请将开关拨至“OFF”状态关闭无线麦克风，再将无线麦克风DC 5V接口连接数据线接口USB接头，另一端数据线USB接头与DC 5V的USB电源接口连接;充电时无线麦克风红色指示灯长亮，充满后红色指示灯熄灭。充电时间约3-5小时充满，充电完成后请及时拔掉电源线断开电网电源。

主机常见问题的自我解决:

- 1. 开关不开, 扩音器没有声音**
 - ①工作指示灯不亮, 电池没电, 充电解决;
 - ②工作指示灯亮扩音无声, 请重新配对; (配对方法, 请参照相对应无线麦克风使用说明)
 - ③操作无反应, 出现死机现象, 可以通过长按“M”键10秒进行复位关机, 再重新开机使用。
- 2. UHF无线麦克风信号点重新配对**
 - ①当近距离使用多台UHF无线扩音设备时, 如出现相互干扰请将主机信号点重新配对。
 - ②当无线麦克风风环、换新或需两对同时使用时, 请将主机信号点重新配对。
- 3. 扩音器有明显啸叫**
 - ①将麦克风对准嘴角方向, 麦克风与主机保持60-70CM距离;
 - ②空间变小时适当调低音量以减少回声造成啸叫。

产品使用注意事项:

- 为了达到随扩音最佳效果, 请将喇叭放置嘴正前方1-2CM处对准喇叭处发声, 若有啸叫, 可适当调小音量或将机器与喇叭的距离稍微拉开, 以防互相干扰;
- 尽量避免频繁触摸麦克风插口, 以免造成插口松动而引起接触不良, 不可将话筒和电源插口;
- 为保证锂电池使用寿命, 建议使用完再充电, 频繁充电将加速电池芯片老化, 长时间不用时应每隔两个月充一次电;
- 因喇叭磁性较强, 不可将机器和银行卡等带磁性的东西放在一起, 以免造成失磁带来不必要的麻烦;
- 本产品所有配件除按本机工作需要设计, 如需更换配件尽量使用本公司原装配件, 以达到最佳工作状态;
- 本产品在和正常使用过程中可能会轻微变形, 这属于正常现象;
- 请使用防静电软布来清洁擦拭本产品, 在清洁本产品时请先关闭电源开关, 并断开所有外部连接。请勿用化学物质擦拭(如: 酒精、苯等化学溶剂或有磨砂性的清洁擦拭剂);
- 请勿摔落、抛掷或者踩踏本产品, 请勿擅自拆解本产品, 否则不能享受本公司的免费维修服务。

100% SHIDU Guaranteed Product Satisfaction.

SHIDU Guarantee:

We promise 1 year warranty. If you have any questions, please feel free to contact us, we will try our best to provide you the best service.

www.shidu.com Email: info@shidu.com

注意:

本手册描述的产品及其附件的某些特征和功能，仅供参考。十度数码科技保留随时修改本手册中任何信息的权利，无需进行任何提前通知且不承担任何责任。

无担保声明:

本手册中的内容，除非适用法律要求，十度数码科技对本手册中的所有内容不提供任何明示或暗示的保证。在法律允许的范围内，十度数码科技在任何情况下，都不对因使用本手册相关内容而产生的任何特殊的、附带的、间接的、继发性的损害进行赔偿，也不对任何利润、数据、商誉或可预期的损失进行赔偿。

进出口管制:

若需将此产品手册中描述的产品出口、再出口、或者进口，您应遵守适用的进出口管制法律法规。

1. Turn on the power switch, but the amplifier has no sound.

A. Turn the volume up on the voice amplifier, and also on the microphone.
B. Please confirm whether the wireless microphone has been paired with the amplifier successfully or not.
C. The voice amplifier has a distinct howling.

2. Talk to the wireless microphone, but the amplifier has no sound.

A. Turn the volume up on the voice amplifier, and also on the microphone.
B. Please confirm whether the wireless microphone has been paired with the amplifier successfully or not.
C. The voice amplifier has a distinct howling.

4. Changing instructions of wireless microphone

When the microphone blue indicator light flashes means low battery. Please turn it off and charging through the USB with DC 5V adapter. The red indicator light will be on all the time when charging, and it will go out after fully charged.

How to use head UHF wireless microphone:

(Only applicable to UHF version)

Recording:

1. Make sure the USB flash drive is inserted, and then plug head UHF wireless microphone into the USB flash disk or TF card. The recording light will be on.

2. Turn on the MFC function of your mobile phone (Bluetooth is waiting for connection).

3. Turn on the Bluetooth function of your mobile phone (Bluetooth is waiting for connection).

4. Press the "M" key for 3 seconds, and when battery symbol stop flash means fully charging. Please remember to unplug after it is fully charged.

5. Recording

Press for previous song, long press for volume down, short press for volume up, long press for volume up.

Bluetooth instruction:

Bluetooth device as follows:

1. Switch on the amplifier and press "M" for 3 seconds. When battery symbol on the screen flashes means low power, please charge through DC cable with DC 5V output adaptor. (charging time: 3-5 hours)
- 2. Turn on the Bluetooth is waiting for connection.
- 3. Turn on the MFC function of your mobile phone (Bluetooth is waiting for connection).
- 4. Press the "M" key for 3 seconds, and when battery symbol stop flash means fully charging. Please remember to unplug after it is fully charged.
- 5. Recording

Press for previous song, long press for volume down, short press for volume up, long press for volume up.

6.03mm Microphone Jack:

Note: It may be unreadable when the file is large or random capacity is 2GB.

It is compatible with most brands, the maximum capacity is 2GB.

8 AUX input: When switch to AUX mode, you can play the audio files via audio cable connect the computer, mobile phone, MP3.

9 TF card/USB flash drive slot: Insert the TF card to be saved automatically into the USB flash disk or TF card.

9.1T Card/USB flash drive slot: Insert the TF card to be saved automatically into the USB flash disk or TF card.

1. Power switch / play & pause:

A. Press the button for 3 seconds to turn on/off. B. In music playing mode, short press to pause, short press it again to play.

2. Mode Key:

1. 1. Short press "M" to select a working mode. Bluetooth, UHF, AUX, UHF mode (Only applicable to UHF version).

2. Loop: When play music on TF card/USB flash drive, long press "M" key for 3 seconds and the screen show "ONE" to switch to single song repeat; long press "M" key for 3 seconds again and the screen show "RAN" to switch to random play; long press "M" key for 3 seconds again and the screen show "ALL" to switch to all repeat. Speaker will be "all repeat" by default after powered on next time.

Notes: Speaker will be "all repeat" by default after powered on next time.

Specifications:

Max output power	18W	Frequency response	80Hz-18KHz
Output impedance	2Ω	Work temperature	-10°C-45°C
Charging voltage	DC 5V 1.5A	Empty time	6-8 hours
Music-playing time	5-7 hours	Charging time	3-5 hours

Features:

1. Two-color reflection molding, IPX5 waterproof.
2. Support Bluetooth 5.0 and recording function.
3. High-capacity 3.7V 2500mAh lithium-ion battery.
4. Supports TF card & USB flash drive play.

Note:

Before turn on the amplifier, ensures carefully before using it. Simply locking the speaker around waist, and mounting the MFC more than 50 cm to avoid howling. And keep the distance between the voice amplifier and you when the basses MFC caps when speaking.

Simply locking the speaker around waist, and mounting the MFC more than 50 cm to avoid howling. And keep the distance between the voice amplifier and you when the basses MFC caps when speaking.