

IMPORTANT
INSTRUCTIONS AND WARRANTY INFORMATION
PLEASE READ.

This Power Steering Pump has plastic spacer installed between the reservoir and pump. See pictures below.

It is critical to replace o’ring on the reservoir and transfer old plastic spacer, for pump to work properly. Failure to transfer old plastic spacer and change this o’ring will lead to leak between housing and reservoir.



Old plastic spacer and new o’ring

IMPORTANTE
INSTRUCCIONES Y INFORMACIÓN DE GARANTÍA
POR FAVOR LEE.

Esta bomba de dirección asistida tiene espaciador de plástico instalado entre el depósito y la bomba. Vea las imágenes a continuación.

Es fundamental reemplazar el o'ring en el depósito y transferir el espaciador de plástico viejo, para que la bomba funcione correctamente. Si no se transfiere el espaciador de plástico viejo y se cambia este o'ring, se producirá una fuga entre la carcasa y el depósito.



Viejo espaciador de plástico y nuevo o'ring