User's Manual

Deepbassx

By Bluephonic

Bluethooth 4.1 HD Earphones

Thank you so much for buying Rambotech earphones with Bluetooth 4.1 APT-X echo elimination technology. Our main goal is to please you with superior sound quality and comfort combined with convenience of hands-free operation. Before using this product, please read this manual.

Function	Operation
Power On	Long press the HOME for 3 seconds
Power Off	Long press the HOME for 3.5 seconds
In pairing mode	Long press the HOME for 6.5 seconds
Answering call	Short press the HOME one time
End call	Short press the HOME one time
Reject	Long press the HOME for 1 second
At the end of the number redial	Double press the HOME onetime
Cancel/End	Short press the HOME Onetime
Transfer Audio	Long press the HOME for 1 second
Mic Mute switch	At the same time press+ -
Pause, Play	Short press the HOME
Vol- Vol+ (BACK/FDW)	Short/ Long press vol- vol+ （BACK/FDW）

SPECIFICATIONS

- Voice Prompts
- Battery Capacity Displayed On Device
- Bluetooth Version:V4.1+EDR,APT-X
- Bluetooth Profiles: Headset, Handsfree, A2DP, AVRCP
- CVC 6.0 Noise Cancellation Technology
- IPX-7 Waterproof
- Li-battery Capacity: 85mAh
- Standby Time: 240 Hours
- Charging Port: Micro USB
- Operating Distance: 10M
- Talk Time: up to 9Hours

HOW TO CHARGE

1- Connect to power using the Micro USB port
2- To better protect battery life, please only use the included cable which is ≤ 5V, 100mAh - 240mAh
3- Allow 1-2 hours to fully charge, after a full charge, the headset will perform best.

VOLUME BUTTON

Volume+ /- (Press the button one time, the volume will change one level)

LED

1. While charging - red light is on
2. When fully charged - blue light is on
3. Low battery -red light flashing twice and voice prompt

4. Pairing mode – blue and red light flashing.

HOW TO CONNECT EARPHONES TO YOUR DEVICE

1- Enable Bluetooth on your device and keep within 3 feet while pairing
2- Press and hold HOME button for approximately 6 seconds until red and blue LEDs flash rapidly
3- Using your Bluetooth device, scan/ search for available Bluetooth devices and select "Deepbassx" from the list of devices shown
4- If prompted, enter password or PIN No: "0000"
5- If prompted by your device to connect, select "Yes"
6- After connecting successfully, the blue LEDs will double flash

HOW TO CONNECT EARPHONES TO MULTIPLE DEVICES

1- Enable Bluetooth on your device and keep within 3 feet while pairing
2- Press and hold HOME button for approximately 6 seconds until red and blue LEDs flash rapidly
3- Using your Bluetooth device, scan/ search for available Bluetooth devices and select "Deepbassx" from the list of devices shown
4- If prompted, enter password or PIN No: "0000"
5- If prompted by your device to connect, select "Yes"
6- After connecting successfully, the blue LEDs will double flash
7- To connect another device, temporarily switch off Bluetooth on device you previously connected.
8- Repeat previous steps and connect the other device.
9- Turn Bluetooth backon for the first device

FOR OPTIMAL SOUND QUALITY. THE DISTANCE BETWEEN YOUR DEVICE AND THE EARPHONES MUST BE LESS THAN 35 FEET, IN AN OPEN SPACE WITH NO BLOCKS

HOW TO RECONNECT THE EARPHONES

1- After connection is lost Xlit500 will try to reconnect automatically
2- If reconnection does not happen automatically, press HOME button once or reconnect through the Bluetooth menu on your device.

RESTORE FACTORY SETTINGS

1- Press and hold the HOME button for about 3 seconds while charging, until the LEDs flash blue 3 times

TROUBLESHOOTING

1. Device can't find the Bluetooth earphones –

- Make sure the XR500 is in pairing mode, and LEDs flash blue and red. Refer to previous section on how to enter pairing mode.
- if XR500 is in pairing mode and flashes blue and red, but is still not found by your device, please restart your device and the headset
- If no connection is made within two minutes after the headset has been in the pairing mode, it will exit pairing mode automatically
- Restore XR500 to factory settings by following instructions in the previous section of the manual

2. Frequent disconnection and noise

- Make sure your earphones are fully charged
- Make sure the distance between your device and the headset is less than 35 feet.
- Make sure nothing is blocking the signal between your device and your Bluetooth earphones
- Restore XR500 to factory settings by following instructions in the previous section of the manual

3. Device is connected to earphones, but music does not sound

- Please go through troubleshooting steps 1 and 2
- Keep in mind some devices do not have a stereo Bluetooth module and Bluetooth function to listen to music. Please connect your Bluetooth earphones to another device
- Restore XR500 to factory settings by following instructions in the previous section of the manual

4. The red LED does not come on while charging

- This can happen when you have not used the earphones for a long time.
- Please allow at least 30 minutes to charge and the problem should be solved.
- -Restore XR500 to factory settings by following instructions in the previous section of the manual

5. Can't connect the earphones to your device

- Restore XR500 to factory settings by following the instructions in the previous section of the manual.
- Go to your device's Bluetooth menu and delete all saved devices from the list by clicking "forget this device".
- Turn your device's Bluetooth off then turn back on, Deepbassx will be deleted.
- Power off device then turn back on.
- Unplug Deepbassx from charging cable then power on.
- Enter the earphone into the pairing mode and follow instructions for connecting.

6. My device is asking for a password

- If prompted please enter 0000 as the password on your device

SAFETY RULES

1- Never disassemble or modify your headset for any reason. Doing this may cause the headset to malfunction or become combustible. The damage to your device can void your manufacturer's warranty.
2- Do not allow your device to get wet, liquids can cause serious damage. Water damage to your device can void your manufacturer's warranty.
3- Avoid exposing your device to very cold or very hot temperatures (below 37F or above 112F). Extreme temperature can cause the deformation of the device and reduce the charging and life of your device.
4- Avoid using your device's light close to the eyes of children or animals.
5- Do not use the device during a thunderstorm. Thunderstorms can cause the device to malfunction and increase the risk of electric shock.

NOTE

Do not charge your headset for much longer than 2-3 hours at a time, because this can lead to reduction in battery capacity

Deepbassx meets IPX-7 waterproof standard

IPX7 Water proof	**Suitable:** *Splashes *Rain or Snow *Showering *Incidental exposure to water of up to 1 meter for up to 30 minutes
	Unsuitable: *Swimming *Diving into water *Snorkeling or Scuba Diving *High-speed watersports

We really appreciate you chose Bluephonic as your trusted

brand of Bluetooth earphones and sincerely hope you enjoy the great sound and comfort Bluephonic provides. We love making our customers happy by providing true value with our products.

If for any reason you are not completely satisfied with your purchase, let us know immediately and we will do everything to make sure you are happy

WARRANTY

1 Year Parts and Labor Warranty

Please visit www.bluephonic.com to register YOUR warranty