YAMAHA®

WS-X1A Reset Procedure

Restarting Unit:

Press and hold the power button for at least 10 seconds to restart the unit. The connection info will not be deleted.

If the unit does not turn on automatically after restarting, press and hold the power button for at least 3 seconds to turn on the unit.

Initializing the Unit:

1: Ensure the unit is in standby.

2: Press the power button while holding down the Clear Voice button.

The Clear Voice light will flash.

3: Press the play/pause button while the Clear Voice light flashes.

The unit will now be initialized.

After initializing, press and hold the power button for at least 3 seconds to turn on the unit.