

HH-200 Cylinder Head Holder Instructions

GOODSON

Tools and Supplies for Engine Builders

156 Galewski Drive • P.O. Box 847 • Winona, MN 55987-0847

Toll-Free 1-800-533-8010 • Local 507-452-1830 • www.goodson.com

HH-200

**Please read instructions
before using.**

Instructions

1. Place the cylinder head on one of the stands at the desired angle.
2. As you lower the other end of the head on the second stand, slide the stand back and forth as needed until the head is centered on the stand. This will align the head on the stands to avoid any uneven rocking.



HH-200

Instrucciones para el Portador de Cabeza de Cilindro

GOODSON

Herramientas y suministros para reconstructores de motores

156 Galewski Drive • P.O. Box 847 • Winona, MN 55987-0847

Toll-Free 1-800-533-8010 • Local 507-452-1830 • www.goodson.com

HH-200

**Porfavor de leer las
instrucciones antes de usar.**

Revisar Junio 2013

Instrucciones

1. Coloque la cabeza del cilindro sobre uno de las bancas en el angulo deseado.
2. Cuando usted baja el otro lado de la cabeza en la banca segundo, resbala la banca para adelante y para atras hasta que la cabeza se acomoda en el centro de la banca. Esto alineara la cabeza en la banca para evitar cualquier desigual cuando mece.

