

JVE-26 Jet Valve Eliminator Instructions

GOODSON

Tools and Supplies for Engine Builders

156 Galewski Drive • P.O. Box 847 • Winona, MN 55987-0847

Toll-Free 1-800-533-8010 • Local 507-452-1830 • www.goodson.com

JVE-26

Please read instructions before using.

Instructions

Remove existing jet valves from head. Install valve eliminator in jet valve hole. Torque to 12ft pounds (144in pounds).

NOTE: Apply a light coat of oil to eliminator threads and "O" ring.

July 2013

JVE-26

Chorro de Válvula

Eliminatoria / Instrucciones

GOODSON

Herramientas y suministros para reconstructores de motores

156 Galewski Drive • P.O. Box 847 • Winona, MN 55987-0847

Toll-Free 1-800-533-8010 • Local 507-452-1830 • www.goodson.com

JVE-26

Por favor de leer las instrucciones antes de usar.

Instrucciones

Retirar los chorros de válvulas que son existente en la cabeza. Instalar la válvula eliminadora en el hoyo de la válvula de chorro. Esfuerzo de torsion hasta 12 pies de libras (144 pulgadas de libras).

NOTA: Aplique una capa ligero de aceite a las roscas eliminadora y el anillo "o".

Julio 2013